

Digi Connect[®] Sensor

User Guide

Revision history-90001491

Revision	Date	Description
К	May 2018	Updated battery percentage information.
L	October 2018	Updated range specifications: Connect Sensor product specifications.
М	April 2019	 Added LED information. Added information about the external power source and battery usage.
N	May 2019	Added gasket lubricant information.
Ρ	December 2019	Removed HART [®] protocol information as it is no longer supported.

Trademarks and copyright

Digi, Digi International, and the Digi logo are trademarks or registered trademarks in the United States and other countries worldwide. All other trademarks mentioned in this document are the property of their respective owners.

© 2019 Digi International Inc. All rights reserved.

Disclaimers

Information in this document is subject to change without notice and does not represent a commitment on the part of Digi International. Digi provides this document "as is," without warranty of any kind, expressed or implied, including, but not limited to, the implied warranties of fitness or merchantability for a particular purpose. Digi may make improvements and/or changes in this manual or in the product(s) and/or the program(s) described in this manual at any time.

Warranty

To view product warranty information, go to the following website: www.digi.com/howtobuy/terms

Send comments

Documentation feedback: To provide feedback on this document, send your comments to techcomm@digi.com.

Customer support

Digi Technical Support: Digi offers multiple technical support plans and service packages to help our customers get the most out of their Digi product. For information on Technical Support plans and pricing, contact us at +1 952.912.3444 or visit us at www.digi.com/support.

Contents

Digi Connect[®] Sensor

Get started

3
ł
5
5
5
7
)
)
)
3
3

Technical specifications

Maximum power and frequency bands	25
Connect Sensor product specifications	25
Cell modem transmit (TX) output power	26

Hardware

Battery inspection	
Battery life	
Battery percentage ranges and replacement	
Battery passivization	
Battery percentage and external power	
CSENSE Continuous Monitoring power source	
Connect Sensor hardware replacement	
•	

Firmware

CSENSE Continuous Monitoring firmware	30
Enable CSENSE Continuous Monitoring	31

Enable continuous monitoring on digital input	31
Enable continuous monitoring on analog input	.32
Configure the buffer time for continuous monitoring	32
8	

Configure pins and protocols

.34
. 35
.36
.37
.38
. 39
.40
. 42
. 42
.44
.44
45
.46
.49
. 49
. 49
.50
50

Configure Connect Sensor device settings

Configure cellular options	51
Configure Remote Manager settings	52
Configure battery life percentage alarms	52
Battery life alarm and alarm notification	53
Create a battery life alarm for Connect Sensor devices	53
Configure the global battery alarm for a device	58
Configure internal temperature settings	60
Configure local interface settings: CLI and Bluetooth	60
Configure device (report) settings	61

View device information

View device information in Remote Manager	
View battery life for a device in Remote Manager	

View device and sensor data streams

Use Remote Manager to view device and sensor data streams	
About data streams	65
View device data streams	
Use the mobile app to view sensor data streams	67

Connect Sensor maintenance

Firmware updates		.69
------------------	--	-----

Update the firmware using Remote Manager	
Update firmware from Connect Sensor	
Update the firmware using the CLI	
Battery replacement	

Remote Manager option definitions for Connect Sensor

Analog Current Loop Input and Voltage Input option definitions	74
Analog Power, Digital Power, and Serial Output option definitions	77
Cellular option definitions	
Device Cloud option definitions	78
Device (report) settings option definitions	79
Digital Input option definitions	
Digital Output option definitions	82
Toggle digital output on alarm	82
Digital Pulse Counter option definitions	
Global Alarm Settings option definitions	85
Internal Temperature option definitions	
Local Interface Settings option definitions	
Modbus Protocol Settings option definitions	87

Data stream definitions

Group definitions for Connect Sensor data streams	90
Connect Sensor device-specific (ts1 and ui) data stream definitions	91
Analog input (ain and cl) data stream definitions	
Analog (avout), digital (dvout1), and serial power output data stream definitions	93
Digital input (din1) data stream definitions	94
Digital output (dout1) data stream definitions	95
Digital pulse counter (pcnt1) data stream definitions	
Temperature sensor (temp1) data stream definitions	
Modbus (modb1) data stream definitions	
Data streams for Modbus protocol	

Use the CLI with Connect Sensor

Open a terminal program and use CLI commands	100
Use the CLI to view status information for the device	102
Verify cellular network coverage using the CLI	
View battery life using the CLI	103

CLI commands

fwupdate	
status	
set	
Analog input CLI commands	
Digital input CLI commands	
Digital output CLI commands	
Digital pulse counter CLI commands	
Analog and digital power output CLI commands	
Cellular CLI commands	
Remote Manager CLI commands	
•	

Internal temperature CLI commands	119
Modbus CLI commands	121

Troubleshooting

Connect Sensor LEDs for troubleshooting	122
Device not responding	122
Check the battery	122
Reset the device	122
Restore factory defaults to the device	123
Device not connected to the cellular network	123
Verify SIM configuration	123
Check cellular antenna	123
Verify cellular network coverage	123
Check battery life	124
Device does not connect to Remote Manager	
Device does not appear in the mobile app	
Verify Bluetooth connectivity	
Reset the device	125

Regulatory information

FCC certifications and regulatory information	126
Declaration of Conformity (DoC)	126
CE mark (Europe)	
Safety notices	
Installation considerations	129
Warnings: Explosion hazards	
RF exposure statement	
UL/cUL conformity	
Special conditions for safe use (ATEX)	
ATEX marking	
-	

Digi Connect® Sensor

Connect Sensor is a low-power cellular sensor gateway for wireless drop-in networking to remotely monitor industrial environments and control systems, such as pipeline flow, air pressure, and light levels. To power Connect Sensor, use either the internal battery or an external power source, such as solar panels, for setups with no power or limited power.

Connect Sensor includes an external input/output (I/O) interface inside a waterproof enclosure for connecting third-party sensors. The sensors gather information (sensor readings) from their environment, and Connect Sensor reports that information to Digi Remote Manager[®] using a low-bandwidth cellular connection. You can sign in to your Remote Manager account to view the reports or use the Digi Connect Wizard app on a mobile device and pair it with a nearby Connect Sensor to view real-time sensor and device data in the field.

Note Make sure there is adequate cellular network coverage where you plan to install the gateway before purchasing cellular service.

This guide shows you how to:

- Set up and maintain Connect Sensor
- Use Remote Manager to configure external sensors and data reports
- View sensor data and Connect Sensor system information

See the *Digi Connect Sensor I/O Wiring Guide* for details about wiring analog or digital I/O sensors and power to Connect Sensor.

Get started

Use the following sections to get started with Connect Sensor.

- 1. Learn about Connect Sensor product components
- 2. Set up a Connect Sensor
- 3. Add a device to Digi Remote Manager
- 4. Configure pins and protocols
- 5. Configure Connect Sensor device settings

Learn about Connect Sensor product components

These sections include a list of Connect Sensor components, and reference information about the Connect Sensor LEDs, ports, and buttons.

Verify product components

Connect Sensor includes the following components:



Component	Description
Battery Connect Sensor uses a lithium metal battery. The battery voltage is almost consistent from initial use to near the end of the battery's useful life. See Battery inspection for lithium battery safety considerations. Note The battery is included for all versions except for the -N versions.	
SIM card The SIM card can be activated or replaced by an activated SIM card from your cellular service provider.	
Note If you have purchased Digi Bundled Services, the SIM card is activated by default.	
Gasket lubricant See Assemble Connect Sensor.	

Optional accessories

The following accessories are available through Digi International Inc. For more information, visit the Digi Connect Sensor product page.

Component	Description
Cellular antenna	
Note This antenna is PN 76000926 and is an indoor- only antenna. Only outdoor-rated antennas should be used outdoors. For more information about antenna options, see the Connect Sensor product page.	
Magnet Used for manually waking the device.	Digi International www.digi.com

Component	:	Description
Magnet more The pack income separated b mount for in	unt accessory pack cludes four screws, and four magnets y plastic discs. See Install the magnet istallation instructions.	
<u>^</u>	CAUTION! The magnets are extremely powerful. Keep magnets separated. If they touch each other they are difficult to separate. Use caution when handling the magnets to avoid injury due to pinching.	

Connect Sensor LEDs

Connect Sensor has four LED indicators to monitor Bluetooth connection, sensor activity, cellular connection, and battery life. If Connect Sensor is powered and all LEDs are off, it is in sleep mode.

Note The LED indicators only light up when you wake the device by manual intervention: pressing the Wake button on the device or using a magnet. When the device wakes up to take and push readings, the LEDs do not light up since no one may be physically present to see the LED start-up sequence. See Wake Connect Sensor for more information about the LED indicators start-up sequence.



Item	LED	Description
1	Bluetooth	 Indicator light for Bluetooth communication: Yellow blinking: Bluetooth is on and Connect Sensor is discoverable. The LED blinks for up to 30 seconds. Yellow solid: A Bluetooth device is attached. Not lit: No Bluetooth devices were found or attached. Note Bluetooth must be enabled on the Connect Sensor for the Bluetooth LED to light up. See Configure local interface settings: CLI and Bluetooth.
2	Sensor reading	 Indicator light for the sensor(s): Green blinking: One or more sensors are reading the environment. Not lit: The LED turns off when readings are complete.

Item	LED	Description
3	Cellular	Indicator light for the cellular network connection:Solid purple: Connect Sensor is waking.
		 Red blinking: Searching for the cellular network.
		Blue:
		Blinking: Connected to the cellular network and
		attempting to communicate with Remote Manager
		Solid light: Successfully sent data to Remote
		Manager. LED turns off after a few seconds.
4	Battery	Indicator light for battery function:
		 Solid purple: Connect Sensor is waking
		The following patterns are based on the Global Alarm > Battery Life setting in Remote Manager:
		 Red blinking: Indicates battery life is less than or equal to
		the Battery Life alarm.
		 Blue blinking: Indicates battery life is greater than the
		Battery Life alarm.

Connect Sensor ports and buttons

The following figure shows the controls for setting up and configuring Connect Sensor.



ltem	Name	Description	
1	Console port	Connects Connect Sensor to a computer using a USB type A to B cable for access to the command line interface (CLI).	
2	Battery port	Connects the battery wire to power Connect Sensor.	
3	Wake button	Wakes Connect Sensor. See Wake Connect Sensor.	
.4	Factory button	Removes all configuration changes and restores Connect Sensor to its original factory default settings when you press and hold it for 3 seconds. If you press this button, but do not hold it down, the device briefly wakes and returns to sleep mode, and no settings are affected.	
5	Reset button	Restarts the device when it is not responding to input (from the CLI or otherwise). Pressing this button does not remove previous configuration changes.	
6	Battery tray	Holds the battery in place.	
7	SIM card tray	Connects the SIM card to Connect Sensor. A SIM card is inserted by default.	

Item	Name	Description
8	Cellular antenna port	Connects an external cellular antenna to Connect Sensor.
9	Input/Output (I/O) interface	Wire analog or digital input and output sensors or power to this interface. For more information, see the <i>Digi</i> <i>Connect Sensor I/O Wiring Guide</i> .
10	Cable glands	Thread sensor cables through these openings into Connect Sensor.

Wake Connect Sensor

If Connect Sensor is powered and all LEDs are off, it is in sleep mode. You can wake the device manually, if needed.

Note The LED indicators only light up when you wake the device by manual intervention: pressing the Wake button inside the device or using a magnet. When the device automatically wakes up as scheduled to take and push readings, the LEDs do not light up since no one may be physically present to see the LED start-up sequence. See Connect Sensor LED start-up sequence.

Manually wake the device

To wake the device, you can either swipe a magnet across the top of the device, or press the Wake button inside the device.

When you wake Connect Sensor, the LED buttons are activated as the device wakes up. The start-up sequence is described below.



Connect Sensor LED start-up sequence

The LED indicators light up in a predetermined sequence when you manually wake the Connect Sensor. For a description of where the LEDs are located on the device, see Connect Sensor LEDs.

- 1. Press the Wake button inside the device or swipe a magnet across the device.
- 2. The cellular and battery LEDs light up purple for one second and then turn off.
- 3. The sensor LED blinks green as readings are taken and then turns off when readings are complete.
- 4. If Bluetooth is enabled, the Bluetooth LED blinks yellow for 30 seconds. If a Bluetooth device is attached, the Bluetooth LED turns solid and remains lit.

Note If Bluetooth is not enabled, the Bluetooth LED does not light up.

- 5. Connect Sensor takes and pushes data readings.
 - a. The Connect Sensor takes a battery life reading. The battery LED blinks either blue or red, depending on the status of the battery life.
 - b. The cellular LED blinks blue until the connection to Remote Manager is complete.
 - c. The Connect Sensor pushes the data. When the data transfer is complete, the cellular LED is solid blue.
 - d. After a few seconds, the cellular LED turns off.

CLI commands and waking Connect Sensor

You can connect a USB cable from a computer to Connect Sensor and use CLI commands to perform actions on the device.

Connect Sensor has a 30-second timeout period between when a CLI command has been entered and the command is processed. When Connect Sensor has finished processing the command, the device goes to sleep, and "zzz..." appears in the terminal program.

If you press the Wake button or use a magnet to wake Connect Sensor during this 30-second timeout period, the LED lights will not be activated, as the device is already awake. Make sure "zzz..." appears in the terminal program before you try to wake the device.

See Open a terminal program and use CLI commands for more details about this process.

Set up a Connect Sensor

Complete all of the tasks in this section in order to set up a Connect Sensor.

- 1. Review safety information
- 2. Activate the SIM card
- 3. Assemble Connect Sensor
- 4. Configure the cellular connection
- 5. Check the cellular connection
- 6. Wire the I/O sensors

Safety information

The following safety information provides guidelines when assembling the Connect Sensor device. For additional safety guidelines, see <u>Safety notices</u>.

CAUTION! The device is sensitive to electrostatic discharge (ESD).



The Connect Sensor device must be maintained only by Digi or a Digi qualified technician. Before assembling the device, note the following:

- To avoid the risk of the battery falling into a protected area, do not assemble the device in the installation area.
- Move the device to a non-hazardous and unclassified area before opening the enclosure and connecting the hardware.
- Always use the designated battery, model number 76000912, from Digi International Inc.
- Allow only a trained technician to replace the lithium thionyl chloride batteries used in Connect Sensor.
- Prior to installation, the battery should be inspected for any signs of damage. If the battery
 appears to be damaged or is dropped during the installation, do not use the battery and
 dispose of it properly. See Battery inspection for more information.
- You may be required to have a licensed electrician install or perform maintenance on this equipment. Always follow applicable local, state, and federal codes and guidelines.

Activate the SIM card

Follow this step if you need to activate your SIM card. You can skip this step if:

- You purchased bundled services, and therefore have a pre-activated SIM card.
- You are using an activated SIM card (standard size) from your cellular service provider.

Activate the SIM card provided by Digi

Connect Sensor has a SIM card inserted in the device by default. To use a cellular connection, you must activate the inserted SIM card.

- 1. Note the Connect Sensor IMEI number. The IMEI number is on the label on the device and on the box the device was shipped in.
- 2. Activate the SIM card.
 - a. Call Digi International Inc. at **952-912-3444** or **877-912-3444**.
 - b. Press 3 for the Technical Support option.
 - c. Select the wireless data plan activation option. You will be asked to provide the Connect Sensor IMEI number.

Activate a SIM card not provided by Digi

You can activate a SIM card from your cellular provider or from a supplier other than Digi.

1. Your SIM card provider will need the following information:

- **Connect Sensor IMEI number**: The IMEI number is on the label on the Connect Sensor device and on the box the device was shipped in.
- **SIM card number**: The SIM number is printed on the SIM card.
- 2. Call your SIM card provider to activate the SIM card.

Assemble Connect Sensor

This section describes how to assemble Connect Sensor. Be sure to complete these steps before wiring sensors to the I/O interface.



CAUTION! This product contains a lithium metal battery. Prior to installation, the battery should be inspected for any signs of damage. If the battery appears to be damaged or is dropped during the installation, do not use the battery and be sure to dispose of it properly. See Battery inspection for more information.

Make sure you have the following equipment available:

- Activated SIM card: See Activate the SIM card
- Battery
- Cellular antenna

Note You must use a passive (non-amplified) antenna with Connect Sensor.

Follow these steps to assemble Connect Sensor:

- 1. Open the Connect Sensor enclosure.
- 2. If desired, replace the existing SIM card with an activated SIM card (standard size) from your cellular service provider.

Note You can skip this step if you are using the existing SIM card inserted in the device.

a. Orient Connect Sensor to match the picture below.



tray.

c. Open the SIM card tray by pulling the tray up from the top or right side of the tray.

b. Unlock the SIM card tray by gently pushing the metal bar toward the bottom of the



CAUTION! Do not pull the SIM card tray up from the left side or use a tool to open the tray. These actions may damage the SIM detect switch, which is beneath the left side of the tray.

- d. Remove and discard the existing SIM card from the SIM card tray.
- e. Insert your own SIM card into the SIM card tray, with the metal contacts face-down and the flat edge inserted into the holder.



- f. Press the SIM card tray onto the board.
- g. Lock the SIM card tray by gently pushing the metal bar toward the top of the SIM card holder.



- 3. Connect the cellular antenna.
- 4. Insert and connect the battery.

- 5. Apply the gasket lubricant on the gasket to properly seal the device.
 - a. Retrieve the gasket lubricant kit that was provided with the product components.
 - b. Open the lubricant pouch and use the swab to apply a thin coating of the lubricant onto the gasket. Make sure to completely cover the black surface of the gasket. There is no harm in applying a thicker coating, as the lubricant cannot harm the device.
- 6. Close the cover on the device. The cover snaps into place.
- 7. Optional: Install the magnet mount to the bottom of Connect Sensor if you have purchased this accessory. See Install the magnet mount.

Note It is recommended that you complete configuration, including verifying cellular and Remote Manager connectivity, before wiring external sensors to Connect Sensor. See the *Digi Remote Manager User Guide* for information about Remote Manager.



Install the magnet mount

You can install a magnet mount on Connect Sensor so that you can securely place the device on a metal object.

Make sure you have the following equipment available:

- Magnet mount accessory pack. See Verify product components for purchasing information.
- Appropriate screw driver.

Note You can skip this step if you did not purchase the magnet mount accessory pack.

- 1. Turn Connect Sensor to access the bottom of the device.
- 2. Remove one magnet from the set of four magnets in the accessory pack.



CAUTION! The magnets are extremely powerful. Keep magnets separated. If they touch each other they are difficult to separate. Use caution when handling the magnets to avoid injury due to pinching.

- 3. Place the magnet on one corner of the device. Be sure to match the hole in the magnet to the hole in the corner.
- 4. Remove one of the screws from the accessory pack.
- 5. Using the screwdriver, screw the magnet onto the device.
- Repeat this process to screw the remaining magnets onto the corners of Connect Sensor. When you have completed this process, a magnet should be screwed onto each corner of the device.



Configure the cellular connection

Note If you purchased Digi Bundled Services, the cellular connection is already configured on your Connect Sensor and you can skip this section.

Connect Sensor is configured with a default APN that you need to change to register Connect Sensor on the cellular network for your cellular service provider. Use the command line interface (CLI) to initially configure the cellular connection.

Before you begin, make sure you have the following required equipment and information:

- Computer running a terminal emulator program
- USB type A to B cable
- APN from your cellular service provider

To register Connect Sensor on a cellular network:

- 1. Open the enclosure and make sure the battery is connected and the SIM card is installed.
- 2. Connect a USB type A to B cable from your computer to the USB type B port.

Note Do not use the mini USB port, which is covered by a red X in the graphic below.

You may need to install device drivers or wait for your computer to automatically install them when connecting Connect Sensor to a computer using a USB cable. Digi recommends drivers available at www.ftdichip.com/Drivers/VCP.htm.



- 3. Open a terminal program on a computer and connect to Connect Sensor using the following configuration:
 - Connection port: Connect to the COM port associated with the USB cable connected to Connect Sensor
 - **Baud rate or bits per second:** 115200
 - Data: 8 bit
 - Parity: None
 - Stop: 1 bit
 - Flow control: None
- 4. Press the Wake button on the device.
- At the command prompt, type set apn=<yourCarrierAPN> where yourCarrierAPN is the string supplied by your cellular service provider.
- 6. Press **Enter**. The terminal program displays the APN configuration setting's current value and the pending value.

- 7. If required, set a user name, password, and PIN for the SIM card. At the command prompt, type the following and press **Enter** after each command:
 - o set usr=<username>
 - Where username is the name of your cellular account.
 - o set pwd=<password>
 - Where *password* is the password for your cellular account.
 - o set pin=<pin>

Where pin is the PIN for your SIM card.

For details about these commands, see CLI commands.

- Type activate at the command prompt and press Enter to immediately make the change. Connect Sensor goes to sleep and immediately wakes up to report the change to Remote Manager. After the change completes, it goes to sleep again.
- 9. (Optional) Verify the new settings:
 - a. Press the **Wake** button.
 - b. At the command prompt type **set commandname** where **commandname** is one of the settings you updated, such as **apn**.

After setting up and configuring Connect Sensor, use the following sections in this guide to configure additional settings and remotely manage Connect Sensor:

- Check the cellular connection
- Configure pins and protocols
- Configure Connect Sensor device settings
- View device and sensor data streams

Check the cellular connection

Make sure the cellular network provides an adequate signal where you install Connect Sensor to maintain a consistent cellular connection.

Note Proper network coverage helps reduce power consumption, leading to improved battery life.

To check the cellular network connection at the install location:

- 1. Wake Connect Sensor:
 - If the enclosure is open, press the Wake button.
 - If the enclosure is closed, swipe the magnet across the magnet icon on the outside of the device.



- 2. The LED indicators light up in a predetermined sequence when you manually wake the device.
- 3. If Connect Sensor does not connect to the cellular network, see Device not connected to the cellular network.

You can now complete I/O interface wiring, see the Digi Connect Sensor I/O Wiring Guide.

Wire the I/O sensors

You can wire the analog and digital input/output sensors or power using the I/O interface. For detailed information, see the *Digi Connect Sensor I/O Wiring Guide*.

Note All external or field wiring must be in accordance with NFPA 70 Article 501.10(B).

After wiring sensors, use the following sections in this guide to configure additional settings and remotely manage Connect Sensor.

- Configure pins and protocols
- View device and sensor data streams
- Configure Connect Sensor device settings

Add a device to Digi Remote Manager

To remotely manage Connect Sensor and get sensor data, you need to create a Remote Manager account and add your Connect Sensor device to your account.

Note To serve our customers most effectively, Digi International Inc. is consolidating its cloud services, Digi Device Cloud and Digi Remote Manager[®], under the Remote Manager name. This phased process does not affect device functionality or the functionality of the web services and other features. However, you will find instances of both Device Cloud and Digi Remote Manager in some documentation, firmware, and user interfaces.

Note If you purchased Digi Bundled Services, the following steps were completed for you. You can skip this section.

To add a device to Remote Manager:

- 1. Sign in to your Remote Manager account:
 - If you need to create an account, go to Remote Manager at remotemanager.digi.com, click Sign up, and complete the form to create your account.
 - If you already have an account, go to Remote Manager at remotemanager.digi.com and sign in with your user name and password.
- 2. Locate the 15-digit device IMEI number on the Connect Sensor label.
- 3. Click Device Management > Devices.
- 4. Click Add Devices. The Add Devices dialog appears.

You cannot use the **Discover** button to discover Connect Sensor devices automatically because the devices are not available on the local network.

- 5. From the Add Devices drop-down menu, select IMEI, and enter the number.
- 6. Click **Add** to add the device.
- 7. Click **OK** to close the **Add Devices** dialog. The device appears in the Device Management list.

Note If the device does not display in the Device Management list, you can wake Connect Sensor to force a connection with Remote Manager and update the data. For instructions, see Update the firmware using the CLI or Update firmware from Connect Sensor.

 Click **Refresh** if the device data does not appear on its own after a short period of time. Device data appears after the first time it communicates with Remote Manager.

Technical specifications

Maximum power and frequency bands

This section contains the maximum power and frequency bands for Connect Sensor.

Maximum power	Associated frequencies	
2 W	Cellular 850 and 900 MHz bands	
1 W	Cellular 1800 and 1900 MHz bands	

Connect Sensor product specifications

The following table provides a summary of general product specifications for Connect Sensor.

Specifications				
Management				
Configuration and management	Remote Manager/Local USB to Serial CLI Protocol			
Protocol	ТСР			
Power				
Battery	7.2V, 14 Ah, Lithium Thionyl Chloride, non-rechargeable, replaceable			
Battery life	2 to 3 years (when following guidelines in Battery life)			
Battery self discharge	up to 1%/year if stored at +30 $^{\circ}$ C			
Battery use	-35°C ≤ Tamb ≤ 60°C ambient temperature range			
External power requirement	8 VDC to 30 VDC at 1A			
Environmental				
Operating temperature	-35°C to +70°C			

Specifications				
Storage temperature	-40°C to +85°C			
Relative humidity	90% (Non-condensing after 90%)			
Ingress	IP66			
rating	Note IP66 is for Class I Division 2 hazardous locations and ordinary locations only. For more information on ATEX installation requirements, see ATEX requirements.			
Physical				
Dimensions (L x W x H)	15.2 cm x 11.4 cm x 7.6 cm (6.0 in x 4.5 in x 3 in)			
Weight	1.25 lbs			
LEDs	Bluetooth [®] , Sensor reading, Cellular, Battery			
Enclosure material	10% fiberglass reinforced polycarbonate			
Enclosure rating	NEMA Type 4, 4X, 6, and 6P UL 94 V-0			

Cell modem transmit (TX) output power

Modem	Band	Power Class
HE910-D	GSM 850 / 900	4 (2W)
	DCS1800 / PCS 1900	1 (1W)
	EDGE, 850/900 MHz	E2 (0.5W)
	EDGE, 1800/1900 MHz	Class E2 (0.4W)
	WCDMA FDD B1, B2, B4, B5, B8	Class 3 (0.25W)
LE910-NA1	LTE All Bands	Class 3 (0.2W)
	WCDMA All Bands	Class 3 (0.25W)
LE910-SV1	LTE All Bands	Class 3 (0.2W)

Hardware

Battery inspection



CAUTION! This product contains a lithium metal battery. Prior to installation, the battery should be inspected for any signs of damage. If the battery appears to be damaged or is dropped during installation, do not use the battery and dispose of it properly.

Please contact Digi Technical Support at 952-912-3444 or Tech.support@digi.com to order a replacement battery.

The MSDS (Material Safety Data Sheet) for the battery can be found at www.digi.com/documentation/ConnectSensor.

Battery life

Connect Sensor uses sleep and wake modes to manage power use. The device wakes only for sensor readings and sending reports to Remote Manager. It is in sleep mode at all other times to maintain low power consumption.

The battery will last 2 to 3 years in these conditions:

- Adequate cellular network coverage where Connect Sensor is installed
- Connect Sensor sends reports to Remote Manager a maximum of two times a day
- Connect Sensor is not powering high-current sensors with long read delays

The temperature at the device's location also affects the battery. Battery power is used more quickly in a cold environment than in a warm environment. A battery in a device located where the temperature is consistently 20° F will not last as long as a battery in a device located where the temperature is consistently 80° F.

Extend battery life by scheduling less frequent sensor readings and reports. Scheduling more frequent sensor readings and reports may shorten the battery life to less than 2 years.

Note When using the Continuous Monitoring feature, it is recommended that you use an external power source rather than relying on the battery within Connect Sensor. See CSENSE Continuous Monitoring power source for more information.

Battery percentage ranges and replacement

When the battery life percentage is above 30%, the battery has enough power to power the device, and the device will function as expected.

When the battery life percentage drops below 30%, the battery power is low and, depending on the conditions in which the device is operating, may cease to power the device. To ensure that readings continue as expected, it is recommended that you change the battery when the battery percentage decreases to 30%. See Battery replacement.

You can view the battery life percentage in Remote Manager. See View battery life for a device in Remote Manager.

Battery passivization

Unused lithium batteries that have been in storage acquire a state of passivization that can cause the battery to report a low battery percentage for a time after initial installation. As the device uses the battery, the passivization is removed and the battery percentage increases to a maximum of 90 - 100% (depending on the temperature). The passivization removal process could take a week or more, if the number of times Connect Sensor wakes to take sensor readings and send reports to Remote Manager is once per day or less.

Note Passivization may never be removed if the device sends reports to Remote Manager too infrequently.

Battery percentage and external power

The device is powered by either external power connected to the device, or by an internal battery that is connected to the device. The device is not powered by both power sources at the same time.

You can view the battery life percentage for a device in Remote Manager. See View battery life for a device in Remote Manager. The battery life percentage depends on whether the device is using the external power source or the battery.

- If the device is using the external power source and the battery is connected to the device, then the battery life is 100%. This will occur whether the battery has any battery life remaining or is dead.
- If the device is using the external power source and the battery is not connected to the device, then the battery life is 0%.
- If the device is not using external power and the device is using the battery, the actual battery life percentage displays, and is a percentage other than 100% or 0%.

CSENSE Continuous Monitoring power source

For some customers, the scheduling paradigm of the standard Connect Sensor offering is inadequate. Digi offers an alternate firmware image that trades alarm reactivity for power consumption. The CSENSE Continuous Monitoring firmware image can be downloaded and installed on a Connect Sensor.

When using the Continuous Monitoring feature, Connect Sensor never sleeps. For best performance and ease of use it is recommended that you use an external power source rather than relying on the battery within Connect Sensor. If the battery is used, the battery life is significantly reduced. The Connect Sensor battery can be used as a short-term battery backup if the external power source fails.

For more information about the Continuous Monitoring feature, see CSENSE Continuous Monitoring firmware.

Connect Sensor hardware replacement

The Connect Sensor hardware can be replaced with Connect Sensor+ hardware. Additional external device monitoring features are available with Connect Sensor+ hardware:

Modbus protocol

Firmware

This section includes information about the Connect Sensor firmware options that are available in addition to the standard firmware. These firmware options provide additional features. Note that these firmware options contain all of the features in the standard Connect Sensor firmware in addition to the features available in the firmware option you select.

If you want to use any of the optional features, you must upgrade from the standard Connect Sensor firmware to the firmware variant that includes those features. The firmware upgrade can happen only when Connect Sensor is awake and connected to Remote Manager. Any firmware upgrades, configuration changes, or commands that have been added to a schedule in Remote Manager are pushed to Connect Sensor at that time. If you need to upgrade the firmware before a scheduled push from Connect Sensor, you can physically wake the Connect Sensor device to force a connection between Connect Sensor and Remote Manager. For information on how to update the firmware, see Firmware updates.

CSENSE Continuous Monitoring firmware

Note It is strongly recommended that an external power source for the Connect Sensor device is used with continuous monitoring.

For some customers, the scheduling paradigm of the standard Connect Sensor offering is inadequate. With continuous monitoring, Connect Sensor can constantly monitor sensors for an alarm by continually sampling sensor data. This enables Connect Sensor to find alarms faster, and to not miss any alarms that may have occurred between scheduled sensor readings.

The Connect Sensor device should be configured to specify a buffer time range for before and after an alarm occurs. When an alarm occurs, Connect Sensor continues to sample data until the time limit of the buffer is reached. When the buffer time limit is reached, the following information is pushed to Remote Manager:

- Sample data in the buffer for the time range specified
- Alarm information
- Information from a scheduled reading stored in the device's memory

In addition to continuous monitoring, scheduled sensor readings still occur, and that data is stored in the Connect Sensor memory.

- If a sensor alarm occurs, the data samples taken during the buffer time range plus any other diagnostic information stored in the device's memory is pushed when the buffer time range is reached.
- If an alarm doesn't occur between scheduled pushes, the information from a scheduled reading stored in the device's memory is pushed to Remote Manager as scheduled.

Continuous monitoring can occur simultaneously for up to five inputs: four analog and 1 digital.

- Analog 4-20mA Current Loop 1 or Analog Voltage Input 1
- Analog 4-20mA Current Loop 2 or Analog Voltage Input 2
- Analog 4-20mA Current Loop 3 or Analog Voltage Input 3
- Analog 4-20mA Current Loop 4 or Analog Voltage Input 4
- Digital Input

When using this feature, Connect Sensor never sleeps. For best performance and ease of use it is recommended that you use an external power source rather than relying on the battery within Connect Sensor. The Connect Sensor battery can be used as a battery backup if the external power source fails.

Enable CSENSE Continuous Monitoring

Follow these steps to enable and configure continuous monitoring.

- 1. Upgrade to the CSENSE Continuous Monitoring firmware. For upgrade information, see Firmware updates.
- 2. Enable the continuous monitoring feature on an Analog 4-20mA Current Loop, Analog Voltage Input, or a Digital Input. For information, see Enable continuous monitoring on analog input or Enable continuous monitoring on digital input.
- 3. Configure the buffer time range for all sensors using continuous monitoring to ensure the desired amount of data is stored when an alarm occurs. For information, see Configure the buffer time for continuous monitoring.

Enable continuous monitoring on digital input

Note The Connect Sensor firmware must be upgraded before continuous monitoring can be enabled on the analog or digital input. For information, see CSENSE Continuous Monitoring firmware.

- 1. Follow the standard process to configure a digital input. For instructions, see Enable and configure a digital input.
- 2. The digital input must be enabled. Verify that the Interface Enable (ena) option is set to On.
- 3. Verify that the Continuous Monitoring Enable (mon) option is set to On.
- 4. Click Save.
- 5. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The Recurring option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

6. Configure the buffer time for the sensor to ensure the desired amount of data is stored when an alarm occurs. For information, see Configure the buffer time for continuous monitoring.

Enable continuous monitoring on analog input

Note The Connect Sensor firmware must be upgraded before continuous monitoring can be enabled on the analog or digital input. For information, see CSENSE Continuous Monitoring firmware.

- 1. Follow the standard process to configure an Analog 4-20mA Current Loop or Analog Voltage Input. For instructions, see Enable and configure analog inputs.
- 2. The analog input must be enabled. Verify that the Interface Enable (ena) option is set to On.
- 3. Verify that the **Continuous Monitoring Enable (mon)** option is set to **On**.
- 4. Click Save.
- 5. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

- c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.
- 6. Configure the buffer time for the sensor to ensure the desired amount of data is stored when an alarm occurs. For information, see Configure the buffer time for continuous monitoring.

Configure the buffer time for continuous monitoring

To ensure the desired amount of data is stored when an alarm occurs, you should configure the buffer time range for the sensor.

- 1. Sign in to Remote Manager.
- 2. Click **Device Management > Devices**.
- 3. Double-click on the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Click Device Settings.
- 6. Configure the buffer time range for before and after the alarm event. The time is measured in seconds.
 - a. In the **Buffer Sensor Data Before Alarm** field, select the number of seconds of sample data that occurred before the alarm that should be saved and pushed.
 - b. In the **Buffer Sensor Data After Alarm** field, select the number of seconds of sample data that occurred after the alarm that should be saved and pushed.
- 7. Apply the configuration changes:

- a. Click Save > Schedule. The Save Device Properties dialog appears.
- b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Configure pins and protocols

Before you begin configuring the analog and digital pins, and the Modbus protocols, make sure you have completed the following steps:

- Configure the cellular connection
- Check the cellular connection
- Wire the I/O sensors
- Add a device to Digi Remote Manager

After completing those steps, you can use Remote Manager with Connect Sensor to remotely configure sensors, schedule sensor readings and reports, review reports (sensor and device data), and manage the device. Connect Sensor automatically detects the device version and provides support for its configuration within the available options in Remote Manager.

You can also configure Connect Sensor to send alarm reports when an alarm condition occurs in an environment. Alarm reports are separate from scheduled reports. Use alarm reports to communicate changes in your environment and the device, including:

- Low and high sensor input values
- Rapid changes in sensor input values
- Battery life

See Configure pins and protocols, Configure battery life percentage alarms, and View device information.

Enable and configure analog inputs

Connect Sensor has four analog inputs, each of which you can configure as either a 4-20 mA current loop or a voltage input. For details about the configuration options, see Analog Current Loop Input and Voltage Input option definitions.

To set analog input options:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the Configuration menu.
- 5. Select the analog input for your sensor:
 - Analog: 4-20mA Current Loop 1-4
 - Analog: Voltage Input 1-4

Note Configure each analog input as either a current loop or a voltage input, not both. For example, if you enable Analog: 4-20mA Current Loop 1, make sure you disable Analog: Voltage Input 1.

- 6. Enable the input by selecting **On** for **Interface Enable**.
- 7. Select **On** for the alarms you want to enable and enter an appropriate value for each threshold that you enabled. For more information, see Alarms.
- 8. Enter a value for **Hysteresis** to prevent multiple alarms when the sensor input value is near a high or low threshold. For more information, see Hysteresis.
- 9. Enter a user-friendly name that describes the sensor in the Sensor Description field.
- 10. Enter the unit of measurement type, such as *inches*, that you are using for your application in the **Custom Scaled Sample Unit** field.
- 11. Enter the sensor manufacturer's values for y1 and y2 in the **Custom Scaled Sample Value** fields. For more information about the Custom Scaled fields, see Custom scaled sensor values.
- 12. Enable the oversampling feature, if desired. For more information about this feature, see Oversampling.
 - a. From the **Oversampling (ovs)** list box, select the option that describes the desired value for the sampled data: **Average**, **Minimum**, or **Maximum**.
 - b. In the **Oversampling Inter-sample Delay** field, specify the time interval between readings. The time is measured in milliseconds.
 - c. In the **Oversampling Number Samples** field, specify the number of data samples that must be taken.
- 13. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The Recurring option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Enable and configure analog power outputs

Note Powering sensors reduces battery life.

Enable and configure the power output options when you use Connect Sensor to power the analog sensors.

Each of the four analog inputs also has four corresponding power outputs to power sensors. The analog power outputs work independently—each one powers only its corresponding analog input. For example:

- Analog: Power Output 1 powers either Analog: 4-20mA Current Loop 1 or Analog: Voltage Input
 1.
- Analog: Power Output 2 powers either Analog: 4-20mA Current Loop 2 or Analog: Voltage Input 2, and so on.

When Connect Sensor powers multiple sensors, it powers only one sensor at a time for each sensor reading. This also allows you to set different voltage ranges for each power output. For example, you can set **Analog: Power Output 1 to 3.3 V** and **Analog: Power Output 2 to 15 V**.

For details about the configuration options, see Analog Power, Digital Power, and Serial Output option definitions.

To set analog power output options in in Remote Manager:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Click **Analog: Power Output** and select the power output that corresponds to your analog input.
- 6. Enable the output by selecting **On** for **Power Output Enable**.
- 7. Select the appropriate voltage **Output Level** for your power output. Refer to the manufacturer specifications for the sensor.
- 8. Enter the appropriate **Read Delay** that your sensor needs to stabilize before reading the sensor input value. Refer to the manufacturer specifications for the sensor.

For example, a sensor may need 7 seconds to power on and stabilize before it can get an accurate reading.

Note A higher read delay keeps the device powered on longer, which reduces battery life.

- 9. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The Recurring option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Enable and configure a digital input

Connect Sensor has one digital I/O pin. You can configure the pin as a digital input, pulse counter, or digital output, but not more than one I/O function simultaneously.

In addition to the standard alarm and user-friendly name settings, the digital input options include rising edge wake, falling edge wake, and a pull-up resistor.

For details about the configuration options, see Digital Input option definitions.
To configure digital input options:

- 1. Sign in to Remote Manager.
- 2. Click **Device Management > Devices** tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Select Digital: Input.
- 6. Select **On** for **Interface Enable** and disable the interface for all other digital I/O settings:
 - Digital: Output > Interface Enable: Off
 - Digital: Pulse Counter > Interface Enable: Off
- 7. Select **On** for the alarms you want to enable.
- 8. Select On for Rising Edge Wake and Falling Edge Wake to enable them.
- 9. Select **On** for **Enable pullup** when your application requires it.
- 10. Enter a user-friendly name for the sensor in the **Sensor Description** field.
- 11. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The Recurring option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Enable and configure a digital pulse counter

Connect Sensor has one digital I/O pin. You can configure the pin as a digital input, pulse counter, or digital output, but not more than one I/O function simultaneously.

When using a digital pulse counter, Connect Sensor continues to count pulses during sleep cycles and reports them to Remote Manager during normal reporting intervals.

For example, if Connect Sensor reports every hour, the sensor counts pulses during each hour Connect Sensor is in sleep mode. At the end of each hour, Connect Sensor wakes and reports the total pulse count for that hour to Remote Manager. The pulse counter resets to zero after each wake cycle and stores the values until the next reporting interval.

For details about the configuration options, see Digital Pulse Counter option definitions.

To set digital pulse counter options:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.

- 5. Click Digital: Pulse Counter.
- 6. Select **On** for **Interface Enable** and disable the interface for all other digital I/O settings:
 - Digital: Input > Interface Enable: Off
 - Digital: Output > Interface Enable: Off
- 7. Select **On** for the alarms you want to enable and enter an appropriate value for each threshold that you enabled.
- 8. Enter a value for **Hysteresis** to prevent multiple alarms when the sensor input value is near a high or low threshold.
- 9. Select **On** for **Enable pullup** when your application requires it.
- 10. Enter a user-friendly name for the sensor in the **Sensor Description** field.
- 11. Enter the unit of measurement type, such as *inches*, that you are using for your application in the **Custom Scaled Sample Unit** field.
- 12. Enter the sensor manufacturer's values for y1 and y2 in the **Custom Scaled Sample Value** fields. For more information about the Custom Scaled fields, see Custom scaled sensor values.
- 13. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Enable and configure a digital output

Connect Sensor has one digital I/O pin. You can configure the pin as a digital input, pulse counter, or digital output, but not more than one I/O function simultaneously. Use Remote Manager to control a digital output level and enable an internal pull-up resistor. For details about the configuration options, see Digital Output option definitions.

To set digital output options:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Select Digital: Output.
- 6. Select **On** for **Interface Enable** and disable the interface for all other digital I/O settings:
 - Digital: Input > Interface Enable: Off
 - Digital: Pulse Counter > Interface Enable: Off
- 7. Select the appropriate **Output Level** for your digital output. Refer to the manufacturer specifications for the sensor.

- 8. Select the appropriate **Toggle Output on** option If you want to toggle the digital output on a selected alarm. For more detailed information, see Toggle digital output on alarm.
- 9. Select **On** for **Enable pullup** when your application requires it.
- 10. Enter a user-friendly name for the sensor in the Sensor Description field.
- 11. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Enable and configure a digital power output

Note Powering sensors reduces battery life.

Configure the digital power output options when you use Connect Sensor to power an external device. For details about the configuration options, see Analog Power, Digital Power, and Serial Output option definitions.

To set digital power output options in Remote Manager:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Select Digital: Power Output.
- 6. Enable the output by selecting **On** for **Power Output Enable**.
- 7. Select the appropriate voltage **Output Level** for your power output. Refer to the manufacturer specifications for the sensor.
- Enter the appropriate **Read Delay** that your sensor needs to stabilize before reading the sensor input value. Refer to the manufacturer specifications for the sensor.
 For example, a sensor may need 7 seconds to power on and stabilize before it can get an accurate reading.

Note A higher read delay keeps the device powered on longer, which reduces battery life.

- 9. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Enable and configure the Modbus protocol

Modbus is an industrial automation protocol used for sending and receiving digital information across a single, external RS-485 serial bus.

Note The Modbus protocol is available only with Connect Sensor+ hardware.

The Modbus protocol allows Connect Sensor to collect remote diagnostic information from a Modbusenabled sensor as well as alert a user remotely if the sensor malfunctions. You can configure Connect Sensor to collect remote diagnostic information from up to four Modbus-enabled sensors.

The Modbus protocol uses the serial pins on the I/O terminal block in Connect Sensor. The configuration settings specified in the **Modbus Protocol Settings** page in Remote Manager must exactly match the Modbus protocol settings on the external sensor device(s). The configuration includes a list of variables, which specify the locations on the Modbus device that the Connect Sensor should read to collect diagnostic information.

You can also choose to enable the Modbus protocol alarm option. This ensures that when an error occurs with the Modbus-enabled sensor, error information is pushed to Remote Manager without waiting for the next scheduled push.

You can review diagnostic information from the Modbus-enabled sensor in the **Data Services** tab in Remote Manager. For more information about reviewing Modbus information in the data stream, see Modbus (modb1) data stream definitions.

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Click Modbus Protocol Settings.
- 6. For the Protocol Enable (ena) field, select the On option.
- 7. Determine whether error information should be pushed immediately. For the **Device Status**
 - Alarm Mask (aem) option:
 - Select the **On** option if error information should be pushed immediately.
 - Select the Off option if error information should be pushed with the next scheduled push.
- 8. The following settings must match the configuration of the external sensor device. Select the appropriate option from the list box.
 - Serial framing mode (mode)
 - Serial baud rate (baud)
 - Serial data bits (dbt)
 - Serial stop bits (sbt)
 - Serial parity (par)

- 9. For each Modbus sensor that you want to monitor, you can specify the station address and then include a list of variable addresses. The items in the list must be separated by a comma without spaces. The list is limited to 63 characters, which allows for 8 to 10 variables in a list. For more information about identifying Modbus stations and locations, see Modbus station addresses and locations.
 - a. In the Station1: Slave Address (saddr1) field, select the station address.
 - b. In the Station 1: Variable list (vars1) field, enter the list of variable addresses.
 - c. Repeat this process for any additional stations. You can specify up to four stations.

Ð	Protocol Enable (ena):	● On ○ Off
?	Device Error Alarm Mask (aem):	● On ◯ Off
	Serial framing mode (mode):	RTU 🔻
	Serial baud rate (baud):	19200 💌
	Serial data bits (dbt):	8 💌
	Serial stop bits (sbt):	1 💌
	Serial parity (par):	even 💌
?	Station 1: Slave Address (saddr1):	1
?	Station 1: Variable List (vars1):	10007,313003
?	Station 2: Slave Address (saddr2):	2
?	Station 2: Variable List (vars2):	17003F
?	Station 3: Slave Address (saddr3):	0
?	Station 3: Variable List (vars3):	
?	Station 4: Slave Address (saddr4):	0
?	Station 4: Variable List (vars4):	

- 10. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

- c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.
- 11. If Connect Sensor is providing power to the Modbus device, you must enable the serial power output. For instructions, see Enable and configure a serial power output.

If the external sensor device has an alternate power source, you can skip this step.

Enable and configure a serial power output

This section describes how to configure serial power. Note that powering sensors reduces battery life; to reduce unnecessary battery consumption, only wake the device when needed.

Note The serial power output option is available only with Connect Sensor+, and is used only with a Modbus device.

If Connect Sensor is providing power to the Modbus device, you must enable the serial power output. To set serial power output options in Remote Manager:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Select Serial: Power Output.
- 6. Enable the output by selecting **On** for **Power Output Enable**.
- 7. Select the appropriate voltage **Output Level** for your power output. Refer to the manufacturer specifications for the sensor.
- 8. Enter the appropriate **Read Delay** that your sensor needs to stabilize before reading the sensor input value. Refer to the manufacturer specifications for the sensor. For example, a sensor may need 7 seconds to power on and stabilize before it can get an accurate reading.

Note A higher read delay keeps the device powered on longer, which reduces battery life.

- 9. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The Recurring option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Modbus station addresses and locations

In Modbus, a station address acts as a unique identifier for the external sensor device. A station address is assigned when the external sensor device is configured and installed. Multiple stations listen to the bus and can respond only to the commands that match their unique station address.

Connect Sensor acts as a master to the slave station addresses. All Modbus devices connected to Connect Sensor must have the exact same serial configuration.

In the Connect Sensor configuration, you can specify a list of variable addresses for each station address. The variable addresses identify the values that should be pulled from each station device. If Connect Sensor is configured to read a variable that is unsupported by a Modbus station, no data sample is stored.

Finding the Modbus address

A Modbus variable address includes a combination of the reading category, the logical address of the information, and the interpretation method. Together these create a variable address that can be added to a variable list in the Connect Sensor configuration.

Step 1: Determine the reading category

The reading category is the single digit prefix of the variable address. Each variable type has a unique prefix.

Modbus variable type	Number of bits	Prefix value
Coil	1	0
Discrete input	1	1
Input register	16	3
Holding register	16	4

Step 2: Determine the logical address

Many Modbus device specifications list variables using a 0-based physical address. Since Modbus uses a 1-based logical address, the logical address is calculated by adding one to the physical address. The logical address must have either four or five digits, padded on the left by zeroes if required.

For each configured station address, you can configure a corresponding variable list. The variable list is limited to 63 characters, which limits the number of variables to between 8 and 10.

A variable address can be either 5 or 6 decimal digits in length.

Five decimal digits:

00001 - 09999	Coils: physical addresses 0 - 9998
10001 - 19999	Discrete inputs: physical addresses 0 - 9998
30001 - 39999	Input registers: physical addresses 0 - 9998
40001 - 49999	Holding registers: physical addresses 0 - 9998

Six decimal digits:

00001 - 065536	Coils: physical addresses 0 - 65535
10001 - 165536	Discrete inputs: physical addresses 0 - 65535
30001 - 365536	Input registers: physical addresses 0 - 65535
40001 - 465536	Holding registers: physical addresses 0 - 65535

Step 3: Determine the interpretation method

Generally, a single-bit value is interpreted as either 0 or 1, and a 16-bit value is interpreted as an integer between 0 and 65535. These are the default interpretations for the four categories, and no extra specification is required.

Some Modbus devices, however, specify that a pair of consecutive 16-bit registers should be combined and the 32-bits be interpreted as an IEEE 754 floating point value instead. To indicate this, the Connect Sensor variable address requires a suffix of either 'f' or 'F':

If the 32-bit value can be represented as DCBA, where D represents the most significant byte of the value, and A represents the least significant byte of the value, two floating point encodings are supported as follows:

f	IEEE 754 floating point value with bytes in the following order: B A D C
F	IEEE 754 floating point value with bytes in the following order: D C B A

Examples

- If the device specification defines a simple holding register at physical address 4002, the prefix is 4, the logical address is 4003, and there is no interpretation suffix. The combined logical address is 44003.
- If the device specification defines a coil at physical address 17, the prefix is 0, the logical address is 0018 (zero padded), and there is no interpretation suffix. The combined logical address is 00018.
- If the device specification defines an input register at physical address 7002 that is 32-bit floating point value with bytes presented in D C B A order, the prefix is 3, the logical address is 7003, and the interpretation suffix is 'F'. The combined logical address is 37003F.

About analog and digital input options

Use Remote Manager to:

- Enable each of the analog and digital inputs and configure their options to get sensor data in Remote Manager. For more information, see Enable and configure analog inputs or Enable and configure a digital input.
- Alarms: Configure alarms for each sensor to alert you when there are sudden changes in your industrial environment. For additional information, see Alarms and Hysteresis.
- Custom Scaling: Use custom scaled sensor values to convert raw data into custom units that are meaningful to your application. For additional information, see Custom scaled sensor values.
- Oversampling: Configure oversampling to increase the precision of a data sample collected at a scheduled reading by reading multiple samples. For additional information, see Oversampling.

Alarms

Use alarms to send reports to Remote Manager when unusual changes occur in sensor values. Alarm reports are sent when a sensor reaches an alarm value during a sensor reading, even if it is between reporting intervals.

Connect Sensor sends alarm reports as follows:

- High alarm: Sends an alarm report when the input value is greater than the high threshold.
- Low alarm: Sends an alarm report when the input value is less than the low threshold.
- Delta high alarm: Sends an alarm report when the input value increases too much between two consecutive readings.
- Delta low alarm: Sends an alarm report when the input value decreases too much between two consecutive readings.
- Rising edge: Sends an alarm report when the device wakes on a digital input change from low voltage to high voltage.
- Falling edge: Sends an alarm report when the device wakes on a digital input change from high voltage to low voltage.

For example, with high alarms enabled and configured, Connect Sensor is configured to read sensor input values every hour and scheduled to send reports twice every day, at 8:00 and 20:00. An input value suddenly reaches its high threshold at 11:00. When Connect Sensor wakes at 11:00 to take a reading, it sends a high alarm report to Remote Manager.

Alarms are available for the following:

- Analog: 4-20mA Current Loop Input
- Analog: Voltage Input
- Digital: Input
- Digital: Pulse Counter

For Connect Sensor+, an alarm is also available for the following:

Modbus protocol: Enable and configure the Modbus protocol

Hysteresis

Sensor values may sometimes fluctuate during an alarm condition, which causes Connect Sensor to send multiple alarm reports.

Hysteresis works with the high and low alarm thresholds to tell the device when to keep an alarm on without sending additional alarm reports, or when to shut off an alarm. Use this to avoid repeated alarms during common sensor input value fluctuations.

For example, a pressure sensor input value increases to the high threshold and the device sends a high alarm report. However, the pressure sensor input value continues to increase and decrease repeatedly between normal and high thresholds during this alarm condition. If you have not set a hysteresis range, the Connect Sensor device sends an alarm report every time the sensor input value reaches the high threshold.

The following are examples of how high and low hysteresis works with a voltage input:

High hysteresis: If your high threshold is 10 volts and your hysteresis value is 2 volts, then your high alarm hysteresis is 8 volts. This means that the alarm turns on when the sensor input value reaches 10 volts and remains on if the sensor input value stays above 8 volts. No additional alarm reports are sent during this alarm condition. The alarm turns off when the sensor input value falls below 8 volts.

• Low hysteresis: If your low alarm threshold is 2 volts and the hysteresis value is 3 volts, then your low alarm hysteresis is 5 volts. This means that the alarm turns on when the sensor input value reaches 2 volts and remains on if the sensor input value stays below 5 volts. No additional alarm reports are sent during this alarm condition. The alarm turns off when the sensor input value rises above 5 volts.

Setting the hysteresis threshold to 0 (zero) causes Connect Sensor to send an alarm report every time the sensor input value exceeds a high or low alarm threshold.

Note Setting the hysteresis threshold to 0 (zero) may cause excessive data usage and reduce battery life.

Custom scaled sensor values

Connect Sensor reads raw sensor values in milliamps (mA), volts, and pulses. Use the Custom Scaled settings in Remote Manager to convert raw values for both analog inputs and the digital pulse counter into meaningful values for your environment, such as when converting 4-20 mA current to liters or pulses to amp hours.

Refer to the sensor's manufacturer specifications for details about conversion rates and calculations.

Analog input examples

In Remote Manager, both the current loop and voltage input settings use the following fields to convert current or volts into meaningful values for your environment.

- Custom Scaled Sample Unit: Unit of measurement that you are converting to, such as liters, watts, miles per hour, degrees, and so on.
- Custom Scaled Sample Value (y1): Point 1 custom value associated as follows:
 - Current loop: 4 mA
 - Voltage: 0 V
- Custom Scaled Sample Value (y2): Point 2 custom value associated as follows:
 - Current loop: 20 mA
 - Voltage: 10 V

Use the manufacturer specifications for your sensor to calculate the y1 and y2 values.

4-20 mA current loop input example

This example demonstrates how to determine y1 and y2 in liters for a 4-20 mA current loop input. This graph is similar to what you find in sensor manufacturer's specifications.

Note When calculating values, there must be a linear relationship between y1 and y2. If the sensor's measurements are not linear, the calculated values will not be accurate.



The following image shows you enter this information in Remote Manager.

Analo	og: 4-20mA Current Loop 1		
	Interface Enable (ena):	● On ◯ Off	
	High Alarm (aem):	🔾 On 💿 Off	
?	High Threshold (alh):	18	mA
	Low Alarm (aem):	🔾 On 💿 Off	
?	Low Threshold (all):	4	mA
	Delta Low Alarm (aem):	🔾 On 💿 Off	
?	Delta Low Threshold (adl):	16	mA
	Delta High Alarm (aem):	🔾 On 💿 Off	
?	Delta High Threshold (adh):	16	mA
?	Hysteresis (ahy):	1	mA
?	Sensor description (dsc):	Water gauge	
?	Custom Scaled Sample Unit (unit):	Liters	
?	Custom Scaled Sample Value (y1):	0	
?	Custom Scaled Sample Value (y2):	10000	

Voltage input example

This example demonstrates how to determine y1 and y2 in candles for a voltage input. This graph is similar to what you find in sensor manufacturer's specifications.

Note When calculating values, there must be a linear relationship between y1 and y2. If the sensor's measurements are not linear, the calculated values will not be accurate.



The following image shows you enter this information in Remote Manager.

Analo	og: Voltage Input 1		
	Interface Enable (ena):	◉ On ◯ Off	
	High Alarm (aem):	🔾 On 💿 Off	
?	High Threshold (alh):	10	volts
	Low Alarm (aem):	🔾 On 💿 Off	
?	Low Threshold (all):	0	volts
	Delta Low Alarm (aem):	🔾 On 💿 Off	
?	Delta Low Threshold (adl):	10	volts
	Delta High Alarm (aem):	🔾 On 💿 Off	
?	Delta High Threshold (adh):	10	volts
?	Hysteresis (ahy):	1	volts
?	Sensor description (dsc):	Light sensor	
?	Custom Scaled Sample Unit (unit):	Candles	
?	Custom Scaled Sample Value (y1):	100	
?	Custom Scaled Sample Value (y2):	34	

Digital pulse counter example

Using pulse counting, Custom Scaling Factor, Custom Scaled Sample Unit, and a time range, the digital pulse counter provides the appropriate measurement for your environment. The following equation shows how pulses are converted:

- Pulses between reporting intervals x Custom scaling factor (in Custom Scaled Sample Unit) = reported measurement
- Pulses between reporting intervals: Number of pulses between reporting intervals, which is based on report settings in Remote Manager (see Configure device (report) settings).
- *Custom scaling factor*: Refer to your sensor's manufacturer specifications for this value.
- Custom scaled sample unit: Unit of measurement for your application.
- *Reported measurement*: Reported value in the unit of measurement for your application.

For example, we want to measure rainfall in inches using a rain gauge with a digital pulse counter. The manufacturer specifications for our sensor state that 1 pulse equals 0.011 inches.

We configure Connect Sensor to send reports to Remote Manager every hour. Connect Sensor reads 100 pulses from 11:00 to 12:00.

100 (pulses) during one hour x 0.011 (inches) = 1.1 inches

The digital pulse counter device reports a rainfall amount of 1.1 inches between 11:00 and 12:00. The following image shows how you would enter this example into the Digital: Pulse Counter settings in Remote Manager.

Digita	al: Pulse Counter	
0	Interface Enable (ena): High Alarm (aem): High Threshold (alh): Low Alarm (aem):	 On Off On Off 500 On Off
?	Low Threshold (all):	0
?	Hysteresis (ahy):	5
(?)	Enable pullup (puen):	● On ○ Off
?	Sensor description (dsc):	Rain gauge
?	Custom Scaled Sample Unit (unit):	Inches
?	Custom Scaling Factor (scl):	0.011

Oversampling

The oversampling feature enables you to increase the precision of a data sample collected at a scheduled reading by reading multiple samples. You can specify the number of samples that should be read and the time interval between each reading. You can also specify how the data samples should be manipulated to create the final data sample that is pushed: an average value of all of the samples, the minimum value, or the maximum.

Oversampling can be enabled on all four Analog 4-20mA Current Loop and on all four Analog Voltage inputs.

For example, oversampling is configured to discover the average value of 10 readings taken 70 milliseconds apart. Whenever Connect Sensor needs a value for that sensor, such as on a scheduled wake, it actually reads the sensor 10 times, 70 milliseconds apart, averages those results, and uses the averaged value as the sensor reading.

Note Reading a large number of data samples over a long interval reduces battery life.

Schedule options

You can schedule a configuration change to occur immediately or at a specified date and time in the future.

Click Save > Schedule to access the Save Device Properties dialog.

Immediate

Apply changes during the next wake cycle.

- 1. Select Immediate.
- 2. Select the **Schedule Offline** check box. Queue upload occurs the next time this device connects to Remote Manager.
- 3. Click Schedule.

One-Time

Apply changes on a specific date and time in the future.

- 1. Select One-Time.
- 2. Choose a date and time from the drop-down menus. The change is applied during the wake cycle after the date and time you specify.
- 3. Select the **Schedule Offline** check box. Queue upload occurs the next time this device connects to Remote Manager.
- 4. Click Schedule.

Recurring

The **Recurring** option does not work with the Connect Sensor device.

Configure Connect Sensor device settings

You can configure Connect Sensor settings in Remote Manager.

- Configure cellular options
- Configure Remote Manager settings
- Configure battery life percentage alarms
- Configure internal temperature settings
- Configure local interface settings: CLI and Bluetooth
- Configure device (report) settings

Note The Connect Sensor battery can operate 2 to 3 years when you follow standard operating conditions. Changes Connect Sensor device settings can affect battery life. For more information on standard operating conditions, see <u>Battery life</u>.

Configure cellular options

You configured necessary cellular settings during the initial Connect Sensor setup. Use these options to review the cellular configuration. Make changes to these settings only when instructed by your cellular service provider and when you have physical access to the device. For details about these options, see Cellular option definitions.



CAUTION! If you make changes to cellular settings that result in a disconnected device, you must use the CLI to reconnect it to the cellular network; see Configure the cellular connection. Using the CLI requires physical access to the device.

To configure cellular options:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Click Cellular Settings.
- 6. Enter an appropriate value for each cellular option.
- 7. Apply the configuration changes:

- a. Click Save > Schedule. The Save Device Properties dialog appears.
- b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Configure Remote Manager settings

Remote Manager settings options for Connect Sensor are configured by default and require updates only when instructed by Digi Technical Support. For details about these options, see <u>Device Cloud</u> option definitions.

To configure Remote Manager options:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Click Device Cloud Settings.
- 6. Enter appropriate values for each option.
- 7. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Configure battery life percentage alarms

Battery percentage is a measurement of the remaining life of a battery used in a Connect Sensor device. This measurement gives you a data point for monitoring the health of the battery and determining whether the battery should be replaced.

The battery percentage is calculated using an algorithm that considers current temperature conditions, cell tower congestion, and how often the device wakes up to take sensor readings and send reports to Remote Manager. See <u>Battery life</u> for more information about these considerations.

The battery percentage fluctuates, which is normal, and shows a trend over time as the battery expends stored power. Locations with large temperature changes will cause corresponding battery percentage fluctuations. For example, the temperature range in a desert environment can range from 0° F in the morning to 100° F in the evening in the same day. In this environment, the battery percentage reading could be 40% in the morning and then 90% in the afternoon.

Note If an external power source is used to power Connect Sensor and a battery is connected to the device, the battery percentage is reported in Remote Manager as 100%.

Battery life alarm and alarm notification

Remote Manager has two battery life alarm methods that you can configure to alert you when the battery life percentage falls below a specified threshold. The Global Alarm setting is configured by default, and works with the battery indicator light on the device. You can also create an additional battery life alarm that sends an email notification.

Global Alarm setting

The battery life percentage threshold for a device is configured in the **Global Alarm Settings** page by default. This feature alerts you when the battery percentage falls below the specified threshold.

The battery indicator light on the device blinks in certain colors and patterns when the device wakes to signify the battery status. When the battery percentage falls below the threshold, a battery alarm data point is added to the data stream.

- Configure the global battery alarm for a device
- View battery information in a data stream
- Connect Sensor LEDs

Create a battery life alarm

You can create an alarm to monitor the battery life percentage for one specified Connect Sensor device, or for all devices that have a battery. When the conditions of the alarm are met, the alarm is fired and the alarm status changes to **Fired** in the alarm list.

If you have set up email notification, you will receive an email when the alarm fires.

- Create a battery life alarm for Connect Sensor devices
- Create an alarm notification

Create a battery life alarm for Connect Sensor devices

Within Remote Manager, you can create an alarm to monitor the battery life percentage in one specific Connect Sensor device, or all devices that have a battery.

Note You cannot monitor a group of devices.

When the conditions of the alarm are met, the alarm is fired and the alarm status changes to **Fired** in the alarm list on the **Alarms** page.

After you have created the alarm, you can set up email notification and receive an email when the alarm fires.

In this example, an alarm is fired when the battery percentage drops below 30%, and automatically resets when the battery percentage is greater than 40%.

- 1. Sign in to Remote Manager.
- 2. Click **Device Management > Alarms**.
- 3. Click Add. The Add Alarm dialog appears.
- 4. From the Alarm Type drop-down, choose the DataPoint condition option.
- 5. From the Severity list box, select the urgency of this alarm.

- 6. In the **Name** field, enter a short, descriptive name for the alarm.
- 7. In the **Description** field, enter a description of what the alarm does.

Add Alarm			8
Alarm Type	DataPoint condition	Severity	Medium •
Name	Battery Life Alarm		
Description	Fires when the battery percentage drops below 30%		

- 8. In the Fire Conditions section, set the conditions that must be met for the alarm to fire.
 - a. From the **Type** list box, select the **Numeric** option.
 - b. From the Condition list box, select the less than or equal to option: <=
 - c. In the Value field, enter the threshold value: 30
 - d. Leave the Timeout value at the default: 10 seconds

larm Type	DataPoint condition		-	Severity	Medium <
lame	Battery Life Alarm				
escription	Fires when the battery percentage dro	ps below 30	36		
Fire Condition Type Condition Value Timeout	Numeric <= 30 10 Seconds	•	Reset Condition Type Condition Value Timeout	on Numeric 30 10 Seconds	v

- In the Reset Conditions section, set the conditions that must be met for the alarm to automatically reset. Specifying reset conditions is optional. If you do not select the Reset Condition option, you will have to manually reset the alarm.
 - a. Select the **Reset Condition** option.
 - b. From the Type list box, select the Numeric option.
 - c. From the Condition list box, select the greater than option: >
 - d. In the Value field, enter the threshold value: 40
 - e. Leave the **Timeout** value at the default: **10 seconds**

Add Alarm				e
Alarm Type Name Description	DataPoint condition Battery Life Alarm Fires when the battery percentage drops below a	30%	Severity 🚺	1edium ▼
Fire Condition Type Condition Value Timeout	Numeric <= 30 10 Seconds V	Reset Condit Type Condition Value Timeout	tion Numeric > 40 10 Seconds	•

10. In the **DataPoint** field, enter the datastream path to which you want to scope.

- To monitor all of the devices that have a battery, enter: */ts1/bat

larm Type	DataPoint condition	•	Severity	Medium 🔻
ame	Battery Life Alarm			
escription	Fires when the battery percentage drops	below 30%		
Fire Conditio	n	✓ Reset Condi	tion	
Туре	Numeric	▼ Туре	Numeric	•
Condition	<=	▼ Condition	>	•
Value	30	Value	40	
Timeout	10	Timeout	10	
	Seconds 🔻		Seconds 🔹	
Scope Reso	urce			
DataPoint/*/	ts1/bat			6

- 11. Click **Create**. The alarm is added to the list of alarms on the **Alarms** page.
- 12. When the alarm is fired, the alarm status is updated to Fired on the Device Management > Alarms page. Remote Manager displays the number of fired alarms in red next to the Alarms tab on the Device Management page.



13. You can also create an alarm notification that sends an email to a list of email addresses when an alarm fires or is reset. See Create an alarm notification.

Create an alarm notification

You can create an alarm notification that sends an email to a specified email address when an alarm fires or is reset.

- 1. Sign in to Remote Manager.
- 2. Click Admin > Account Settings > Notifications.
- 3. Click Add.
- 4. In the Name field, enter a descriptive name for the alarm notification.

- 5. In the **Description** field, enter a description of the alarm notification.
- 6. In the **Send Email to** field, enter the email address you want to receive the notification. More than one email address can be entered. The addresses must be separated by a comma.
- 7. Designate the notification frequency. Both options are enabled by default.
 - Send daily summary reports at: Send a daily summary at the time specified.
 - Send notifications for each alarm event: Send a notification for each alarm event when it occurs.
- 8. Specify whether you want to receive notifications for a set of alarms or for alarms scoped to a group. You can only select one option.
 - Send notification for the following alarms
 - a. Select the Send notification for the following alarms option.
 - b. Begin typing the name of the alarm. Remote Manager automatically searches and displays a list of matching alarms.
 - c. Click the desired alarm in the list. The alarm is added to the field.
 - d. Repeat the process to add additional alarms.
 - Send notification for alarms scoped to the following groups
 - a. Select the **Send notification for alarms scoped to the following groups** option.
 - b. Begin typing the name of the group. Remote Manager automatically searches and displays a list of matching groups.
 - c. Click on a group in the list. The group is added to the field.
 - d. Repeat the process to add additional group.
- 9. Click **Save**. The alarm is now enabled and active.

DIGI	REMOTE MANAC	GER		Dashboa	rd De	evice Management	Data Services	Security	Admin
Account Settings	Services	Subscriptions	Reports	Customers	s E	vent Log			
My Account Notifications Carrier Account Preferences	Add Remove Status Name Default Notification	Enable/Disable c description goes here Battery life is below 30%		Name: Description: Send Email to: Send daily sum Send notification Battery Life Alarm Send notification Save	Battery Life Battery life admin@wo mary report ns for each n for the fol x	e Alarm is below 30% ork.com,manager@work is at 08:00 PM ▼ GM alarm event lowing alarms: is scoped to the following	.com T-05:00 groups:		

Configure the global battery alarm for a device

You can specify the battery life percentage threshold for a device in the **Global Alarm Settings** page. This feature alerts you when the battery percentage falls below the threshold.

- Connect Sensor sends an alarm report to Remote Manager, which you can review in the Data Services screen. See View battery information in a data stream.
- The battery function light for on the device blinks red when the battery life is less than or equal to the battery life percentage. The light blinks blue when battery life is greater than the battery life percentage. See Connect Sensor LEDs.

For details about this option, see Global Alarm Settings option definitions.

Note You can also create a battery life alarm that sends an email notification when the battery life percentage falls beneath a specified threshold. See Create a battery life alarm for Connect Sensor devices.

To configure global alarm options:

- 1. Sign in to Remote Manager.
- 2. Click **Device Management > Devices** tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Click Global Alarm Settings.
- 6. Enter a battery life percentage. The default is 50%.
- 7. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The Recurring option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

View battery information in a data stream

You can view battery life and battery threshold percentages for one specific device or for all devices that have batteries in the **Data Streams** page.

The table below shows the data points for the battery information that you can search for in the **Data Streams** page.

Data point	Description
abt	Reports the battery life threshold setting, which appears as a percentage. This value is configured in the Global Alarm Settings page.

Data point	Description
abt/alm	Reports that an alarm was fired when the battery life remaining percentage fell below the battery life threshold setting. The battery life threshold setting is configured in the Global Alarm Settings page.
bat	Reports the estimated percentage of battery life remaining.

View data stream for all devices

You can view the battery information in the data streams for all devices that have a battery.

- 1. Sign in to Remote Manager.
- 2. Click Data Services > Data Streams.
- 3. In the search field, enter a battery data point:
 - **bat**: Reports the percentage of remaining battery life.
 - **abt**: Reports the battery life threshold percentage setting.
 - abt/alm: Reports that an alarm was fired when the battery life remaining percentage fell below the battery life threshold setting.
- 4. Click the magnifying glass icon. The specified data streams appear.
- 5. Scroll through the data streams and review the entries in the **Current Value** column, which shows the value of the selected data point.
- 6. You can limit the data streams to the stream for one specific device.
 - a. In the search field, enter the Connect Sensor device ID, appended by **/ts1/bat**, **/ts1/abt**, or **/ts1/abt/alm**.
 - b. Click the magnifying glass icon. The specified data streams appear.

View data stream for one device

You can view the battery information in the data streams for one device.

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices.
- 3. Click on a Connect Sensor device.
- 4. Click **Properties** on the toolbar, or double-click the device. The **Home** page for the device appears.
- 5. Click View Device Streams. All of the device streams for the selected device appear.
- 6. In the search field, append the device ID with a battery data point:
 - /ts1/bat: Reports the percentage of remaining battery life.
 - /ts1/abt: Reports the battery life threshold percentage setting.
 - /ts1/abt/alm: Reports that an alarm was fired when the battery life remaining percentage fell below the battery life threshold setting.
- 7. Click the magnifying glass icon. The specified data streams appear.

Configure internal temperature settings

The Connect Sensor internal temperature is included as a report in Remote Manager data streams. Configure internal temperature alarms so that Connect Sensor sends alarm reports for high temperatures, low temperatures, and unusual temperature changes. For details about these options, see Internal Temperature option definitions.

<u>^</u>

CAUTION! If Connect Sensor sends reports less than 15 minutes apart, it may result in an internal temperature that is above the ambient temperature.

To configure global alarm options:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.
- 5. Click Internal Temperature.
- 6. Select On for Interface Enable to turn on this option.
- 7. Enter appropriate values for each option. Threshold and hysteresis values are in Celsius.
- 8. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The Recurring option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Configure local interface settings: CLI and Bluetooth

Enable or disable the CLI or Bluetooth for Connect Sensor through the Local Interface Settings option. For details about these options, see Local Interface Settings option definitions.

Note Digi recommends that you keep the local interface settings enabled.

To configure local interface settings:

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices tab.
- 3. Double-click the Connect Sensor device you want to configure.
- 4. Expand the **Configuration** menu.

- 5. Click Local Interface Settings.
- 6. Enable or disable the command line interface. The CLI is disabled by default.
 - For CLI Enable, select On to enable CLI.
 - For **CLI Enable**, select **Off** to disable CLI.
- 7. Enable Bluetooth. Bluetooth is disabled by default.
 - a. For **Bluetooth Enable**, select **On** to enable Bluetooth.
 - b. In the **Bluetooth Device Name** field, enter a value for the Bluetooth device name.

Note You can disable Bluetooth by selecting **Off** for **Bluetooth Enable**.

- 8. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The **Recurring** option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

Configure device (report) settings

Use the Device Settings options in Remote Manager to configure Connect Sensor reporting. Together, these options control how often Connect Sensor captures data, how often data is reported, and how much data is included when it is sent to Remote Manager.

For details about the configuration options, see Device (report) settings option definitions.



CAUTION! If Connect Sensor sends reports less than 15 minutes apart, it may result in an internal temperature that is above the ambient temperature.

Note Reporting to Remote Manager more than twice a day reduces the battery life.

For example, the following settings cause the device to read the sensor input values every half hour, report that information twice a day, and send only the last four readings:

- Read Sensor Every: 30 minutes
- Report Sensor Data Every: 24 reads
- Send Last: 4 readings

If the sensor value reaches an alarm threshold, that data is sent as an alarm report during the next device wake cycle regardless of device settings.

To configure device options:

- 1. Sign into Remote Manager.
- 2. Click Device Management > Devices.
- 3. Double-click the Connect Sensor you want to configure.

- 4. Click Configuration > Device Settings.
- 5. Enter appropriate values for each option.



Notes:

- Send Location Every and GPS Enable are not supported.
- Reporting to Remote Manager more than twice a day reduces the battery life.
- 6. Apply the configuration changes:
 - a. Click Save > Schedule. The Save Device Properties dialog appears.
 - b. Select a scheduling option. See Schedule options.

Note The Recurring option does not work with the Connect Sensor device.

c. Click **Schedule**. Connect Sensor downloads and applies configuration changes the next time it connects to Remote Manager.

View device information

You can view current information about the device, such as battery percentage, connection history, mobile and cellular connection details, UTC time, and firmware versions.

You can view device information in either Remote Manager or in the CLI.

- View device information in Remote Manager
- View battery life for a device in Remote Manager
- Use the CLI to view status information for the device
- View battery life using the CLI

View device information in Remote Manager

The battery percentage, connection history, mobile and cellular connection details, UTC time, and firmware versions are available in the System Information menu in Remote Manager. This information is available from the last time Connect Sensor reported to Remote Manager.

Note For more information about Remote Manager, visit www.digi.com/products/cloud/digi-remotemanager.

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices.
- 3. Double-click the Connect Sensor device you want to review.
- 4. Click **System Information > UTC Time** to verify the time and date of the last report. The system information was current at that time and date.
- 5. Select a system detail in the System Information node to see additional information.
 - Click System Information > Battery Percentage to view the percentage of battery power remaining. If the remaining percentage is low, you should change the battery. For instructions, see Battery replacement.
 - Click System Information > Mobile Information to view information about the device and the firmware, such as the cellular signal strength.
 - Click System Information > Version to view the version of the firmware installed on the device.

View battery life for a device in Remote Manager

You can view the battery life percentage for a device in Remote Manager.

Note You can also check the battery life percentage using the CLI. See View battery life using the CLI.

- 1. Sign in to Remote Manager.
- 2. Click Device Management > Devices.
- 3. Double-click the Connect Sensor device you want to review.
- Select System Information > Battery Percentage to view the percentage of battery power remaining. If the remaining percentage is low, you should change the battery. For instructions, see Battery replacement.

View device and sensor data streams

You can use either Remote Manager or the Digi Connect Wizard mobile app to view device and sensor data streams.

- Remote Manager: View the most recently reported information and historical details about device or sensor data in a table, graph, or raw data format.
- Digi Connect Wizard Mobile app: View real-time device or sensor data in a table or graph format locally using a Bluetooth-enabled mobile device.

Use Remote Manager to view device and sensor data streams

The Connect Sensor device and sensor data appear as data streams in Remote Manager.

About data streams

Data streams are individual, detailed device or sensor values that Connect Sensor reports to Remote Manager. For Connect Sensor, data streams include time-stamped information such as milliamps (mA), voltage, custom scaled units, internal temperature, alarms, thresholds, hysteresis, and more. Select a specific data stream to see its current value, as well as historical data.

The Connect Sensor data streams have a group and a corresponding short name. The following image and table provide details about the parts of a data stream.



ltem	Name	Description
1	Connect Sensor device ID	Identifies the device.
2	Group	Identifies the device-specific function or sensor for the data stream. For example, <i>ain1</i> corresponds to the sensor for Analog: Voltage Input 1.
3	Short name	Identifies the specific data point. In this example, <i>val</i> is the raw analog voltage input value.

Data streams for custom scaled values

Remote Manager includes two data streams that report input values:

- val: Raw measurement in its original value, such as mA, voltage, or pulses.
- cval: Calculated measurement in its custom value, such as liters, watts, miles per hour, degrees, and so on. This appears in data streams only when you configure Custom Scaled Sample settings for analog inputs or Custom Scaling Factor for a digital pulse counter.

The following images show how these two data streams appear in Remote Manager:

DIGI. REMOTE MANAGER	Dash	board Device M	anagement	Data Services	
Data Streams Data Files					
C Add Delete Properties Preferences					
Stream	Last Updated	Current Value	Current Location	Units	
00010000-0000000-03515790-56398207/cl1/val	03/14/16 10:05:52 AM	2.17555		mA	
00010000-0000000-03515790-56398207/el1/eval	03/14/18 10:05:52 AM	10877.5		Liters	

DIGI. REMOTE MANAGER	Das	hboard Device M	lanagement	Data Services				
Data Streams Data Files								
C Add Delete Properties Preferences								
Stream	Last Updated	Current Value	Current Location	Units				
00010000-0000000-03515790-56398207/pcnt1/val	03/14/16 10:05:52 AM	75		Pulses				
00010000-0000000-03515790-56398207/pont1/cval	03/14/16 10:05:52 AM	0.825		Inches				

Additional information

To learn more about:

- Data stream groups and group-specific short names for Connect Sensor, see Data stream definitions.
- General information for Remote Manager data streams, see the Data Streams section in the Remote Manager User Guide.

View device data streams

To view data for a Connect Sensor device:

- 1. Sign into Remote Manager.
- 2. Access the Data Streams view:
 - Click Device Management, double-click your device, and click View Device Streams.
 - Click Data Services and enter the 15-digit device IMEI in the search field.

The Data Streams view appears showing all reported data for the selected device.

3. Click a data stream to display the details for the stream.

- 4. To view historical information for a data stream, click one of the following options in the bottom half of the window:
 - Click **Charts** to view the data as a graph.
 - Click **Raw Data** to view the data in a table (see the following image).

									_
Data	Streams Data F	iles							
C Ad	d Delete Proper	rties Preferences							
Stream			Last Upda	ted	Current Value	Current Location	Units	Data Type	Desc
00010000-000	00000-03599990-44209062/ui/c	2li	12/15/15 0	3:54:51 PM	1			LONG	
00010000-000	00000-03599990-44209062/ts1	Ival	12/15/15 0	J3:45:28 PM	14.3671875		in	DOUBLE	
00010000-000	00000-03599990-44209062/ts1	J/tum	12/15/15 0	J3:54:51 PM	0			LONG	
00010000-000	00000-03599990-44209062/ls1		12/15/15 0						
00010000-000	00000-03599990-44209062/ts1	/sty	12/15/15 0	3:54:51 PM	1			LONG	
00010000-000	00000-03599990-44209062/ts1	l/sst	12/15/15 0	3:54:51 PM	900		min	LONG	
00010000-000	00000-03599990-44209062/ts1	/sid	12/15/15 0	3:54:51 PM				STRING	
00010000-000	00000-03599990-44209062/ts1	/ser	12/15/15 03:45:28 PM		1			LONG	
00010000-000	00000-03599990-44209062/ts1	/sdpd	12/15/15 03:54:51 PM		0		days	LONG	
00010000-000	00000-03599990-44209062/ts1	/sdp	12/15/15 0	13:54:51 PM	1		min	LONG	
00010000-000	00000-03599990-44209062/ts1	l/sdc	12/15/15 03:54:51 PM		1			LONG	
00010000-000	00000-03599990-44209062/ts1	lscs	12/15/15 03:54:51 PM		1		con	LONG	
		0.1						1010	
00010000-00	000000-03599990-4420906	2/ts1/tmp							
Charts	Time	Updated	 Location 	Quality	Data				
	12/31/69 06:02:51.00 PM	12/15/15 03:54:51.97 PM			24.78027				
Raw Data	12/15/15 03:45:02.00 PM	12/15/15 03:45:28.34 PM		0	24.78027				
	12/15/15 03:30:04.00 PM	12/15/15 03:30:34.72 PM		0	24.78027				
	12/15/15 03:26:56.00 PM	12/15/15 03:27:22.47 PM		0	24.78027				
	12/15/15 03:25:02.00 PM	12/15/15 03:25:28.28 PM		0	24.29151				
	12/31/69 06:05:02.00 PM	12/15/15 03:20:12.29 PM		0	24.29151				
	12/15/15 03:12:15.00 PM	12/15/15 03:12:50.13 PM		0	24.29151				
	12/15/15 03:10:46.00 PM	12/15/15 03:11:10.25 PM		0	24.29151				

Use the mobile app to view sensor data streams

Connect Sensor connects to the Digi Connect Wizard mobile app using Bluetooth Smart (low energy). The Digi Connect Wizard mobile app allows you to view real-time sensor data on a nearby mobile device.

Note When using an Android device, make sure it is running Android 4.4.3 or later.

To install and run the app:

- 1. Download the Digi Connect Wizard app.
- 2. Enable Bluetooth on your device and make sure it is near the Connect Sensor device.
- 3. Open the app.

- 4. Wake Connect Sensor by doing one of the following:
 - Open the enclosure and press the Wake button.
 - Swipe the magnet across the front of the Connect Sensor device.



- 5. Tap Read Sensors > Find Devices to scan for devices.
- 6. Tap your Connect Sensor to list sensors on the device.
- 7. Tap a sensor name to see real-time data. Data points load at 5-second intervals.

Connect Sensor goes into sleep mode when you close the app. If you keep the app open, Connect Sensor remains awake and takes sensor readings. The device goes into sleep mode after 60 minutes. Keeping the app open for long periods of time can reduce battery life.

Connect Sensor maintenance

Use the following information when you need to update or downgrade the firmware or replace the battery.

Firmware updates

You can use either the CLI or Remote Manager to update the Connect Sensor device firmware, reload the current firmware, install optional firmware, or downgrade to a previous version of the firmware.

Update the firmware using Remote Manager

Use Remote Manager to remotely update Connect Sensor firmware. Using this method, the firmware is updated the next time the device connects to Remote Manager.

- 1. Go to www.digi.com/support to download the Connect Sensor firmware file.
- 2. Sign in to Remote Manager.
- 3. Click Device Management > Devices tab.
- Right-click the Connect Sensor device you want to configure and click Firmware > Update Firmware.
- 5. Click the gear button and do the following:
 - a. Select **One-time**.
 - b. Set up the schedule.
 - c. Select Schedule Offline.
 - d. Click outside the Schedule Options pop-up window to return to the Update Firmware window.
- 6. Click **Browse** and find the file.
- 7. Click **Update Firmware**. The firmware is updated the next time the device connects to Remote Manager.
- 8. Refresh your browser to get updated information.
- 9. Verify the firmware version in Remote Manager:
 - a. Click **Device Management** and find your Connect Sensor in the list of devices.
 - b. Verify the firmware version in the Firmware Level column is correct for your device.

Update firmware from Connect Sensor

If you need to update the firmware before a scheduled push from Connect Sensor, you can physically wake Connect Sensor to force a connection between Connect Sensor and Remote Manager.

- 1. Schedule the firmware upgrade for the device in Remote Manager. For instructions, see Update the firmware using Remote Manager.
- 2. When the upload is complete, go to the Connect Sensor device.
- 3. Use a magnet to wake the device. This forces a connection between Connect Sensor and Remote Manager.
- 4. The device wakes up, connect to Remote Manager, and the firmware upload occurs.

Update the firmware using the CLI

If you have physical access to Connect Sensor, you can use the CLI to update the firmware.

- 1. Download the Connect Sensor firmware file.
 - a. Go to the Connect Sensor product support page.
 - b. From the Product Support tab, click Firmware.
 - c. Download and install the firmware file.
- 2. Open the enclosure and make sure the battery is connected and the SIM card is installed.
- 3. Connect a USB type A to B cable from your computer to the USB type B port.

Note Do not use the mini USB port, which is covered by a red X in the graphic below.

4. You may need to install device drivers or wait for your computer to automatically install them when connecting Connect Sensor to a computer using a USB cable. Digi recommends drivers available at www.ftdichip.com/Drivers/VCP.htm.



Open a terminal program on a computer and connect to Connect Sensor using the following configuration:

- Connection port: Connect to the COM port associated with the USB cable connected to Connect Sensor
- Baud rate or bits per second: 115200
- **Data:** 8 bit
- Parity: None
- Stop: 1 bit
- Flow control: None
- 5. Press the Wake button. The command prompt appears in the terminal program window.
- 6. In the terminal program:
 - a. Type **fwupdate** at the command prompt and select the YMODEM protocol to **send** the firmware file to the device. Refer to your terminal program documentation for how to use the YMODEM protocol.
 - b. Press Enter. The device remains awake to load and install the firmware update.
 After the device completes the change, it sends its updated status information to Remote Manager.
- 7. Press the Wake button and type **status** at the command prompt to verify the firmware version.

Battery replacement

Before replacing the battery, review the safety information and make sure you have the necessary tools and equipment. For more information about battery life, see Battery life.

- 1. Open the enclosure.
- 2. Disconnect the battery.
 - a. Press in the tab at the top of the battery wire connector.
 - b. Pull up on the connector.



- 3. Remove the existing battery.
- 4. Place the new battery in the battery holder and connect the wiring to the battery port. Make sure the battery and its wiring are properly placed.
- 5. Press the Wake button and wait for the battery LED to slowly blink blue five times and then remain off.
- 6. Reassemble the device.
Remote Manager option definitions for Connect Sensor

The following tables provide definitions for Remote Manager user interface options and data streams for Connect Sensor devices.

Analog Current Loop Input and Voltage Input option definitions

The following table provides Remote Manager definitions for Connect Sensor Analog: 4-20mA Current Loop and Analog: Voltage Input options. For additional information about using these options, see Enable and configure analog inputs.

Option	Description	Range	Default
Interface Enable	Enables or disables the analog input source.	On/Off	Off
High Alarm	Enables or disables high alarm reports for the analog input source.	On/Off	Off
High Threshold	Specifies the input value that generates a high alarm report when High Alarm is On .	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 20.0 mA Voltage: 10.0 volts
Low Alarm	Enables or disables low alarm reports for the analog input source.	On/Off	Off
Low Threshold	Specifies the input value that generates a low alarm report when Low Alarm is On , in the following units: Current Loop inputs — mA Voltage inputs — volts	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 4.0 mA Voltage: 0.0 volts
Delta Low Alarm	Enables or disables delta low alarm reports for the analog input source.	On/Off	Off
Delta Low Threshold	Specifies the input value that generates a delta low alarm report when Delta Low Alarm is On .	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 16.0 mA Voltage: 10.0 volts
Delta High Alarm	Enables or disables delta high alarm reports for the analog input source.	On/Off	Off
Delta High Threshold	Specifies the input value that generates a delta high alarm report when Delta High Alarm is On .	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 16.0 mA Voltage: 10.0 volts

Digi Connect® Sensor User Guide

Option	Description	Range	Default
Hysteresis	Specifies the input value to keep an alarm on or shut off an alarm during high and low alarm states. 0 — hysteresis is off 1 or more — hysteresis is on and managing alarms	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 1.0 mA Voltage: 1.0 volts
Sensor description	Specifies description of the sensor for this input source.	Text	Empty
Custom Scaled Sample Unit	Specifies the unit of measurement this analog input is using for the custom scaled sensor values.	Text	Empty
Custom Scaled Sample Value (y1)	Specifies the first data point associated with the following raw value: Current Loop inputs — 4 mA Voltage inputs — 0 volts	Number	0
Custom Scaled Sample Value (y2)	Specifies the second data point associated with the following raw value: Current Loop inputs — 20 mA Voltage inputs — 10 volts	Number	0
Oversampling (ovs)	 Enables or disables oversampling. The feature is enabled when you specify how the readings should be manipulated: Average: An average of all of the readings taken. This is the recommended option. Minimum: The minimum value of all of the readings taken. 	Off Average Minimum Maximum	Off
	 Maximum: The maximum value of all of the readings taken. 		
Oversampling inter-sample Delay (ovi)	The time interval at which a sample is taken.	0 - 5000 milliseconds	50

Option	Description	Range	Default
Oversampling Number Samples (ovn)	The number of samples that should be taken.	2 - 100	10

The following table provides Remote Manager definitions for Connect Sensor Analog: Power Output and Digital: Power Output options. For details about setting these options, see:

- Enable and configure analog power outputs
- Enable and configure a digital power output
- Enable and configure a serial power output

Option	Description	Range	Default
Power Output Enable	Enables or disables the power output source.	On/Off	Off
Output Level	Specifies the voltage level output for the analog power source.	 3.3 volts 5 volts 15 volts 24 volts 	3.3 volts
Read Delay	Specifies the time in seconds that the sensor voltage is enabled before Connect Sensor reads its value. This allows the sensor to stabilize to get an accurate reading. Note A higher read delay keeps the device powered on longer, which reduces battery life.	0-120 seconds	0

Digi Connect® Sensor User Guide

Cellular option definitions

The following table provides Remote Manager cellular setting options for Connect Sensor. For additional information about using these options, see Configure cellular options.

Option	Description
APN	Identifies the access point name that connects your device to the correct cellular network.
User Name	Specifies the user name for your cellular network account. Use only when required by your cellular service provider.
Password	Specifies the password for your cellular network account. Use only when required by your cellular service provider.
SIM PIN	Specifies the PIN for your cellular network SIM card. Use only when required by your cellular service provider.

Device Cloud option definitions

The following table provides Remote Manager server name settings for Connect Sensor. For additional information about using these options, see Configure Remote Manager settings.

Option	Description	Value	
Server Name Specifies the URL that connects your device to Remote Manager. This setting is configured by default.		my.devicecloud.com	
	Note Do not make changes to this setting without help from Digi Technical Support.		
SSL Enable	Enables SSL encryption for data sent from Connect Sensor to Remote Manager.	On: Enabled Off: Disabled (default)	
	Note Enabling SSL encryption significantly increases cellular data usage.		

Option	Description	Value
NTP Server Name	Network Time Protocol (NTP) server name that synchronizes Connect Sensor time with Coordinated Universal Time (UTC). This setting is configured by default.	time.devicecloud.com
	Note Do not make changes to this setting without help from Digi Technical Support.	

Device (report) settings option definitions

The following table provides Remote Manager device (report) setting options for Connect Sensor. For details about setting these options, see Configure device (report) settings.

Option	Description	Range	Default
Read Sensor Every	How often Connect Sensor wakes to read the enabled sensors. The time is measured in minutes. Use this option when the device is configured to read sensors more than once a day.	5 minutes to 1440 minutes (24 hours)	720 minutes (12 hours)
Report Sensor Data Every	How often the device wakes and sends sensor data to Remote Manager.	1 to 288 readings	1
Report Sensor Every N Days	How often sensor input values are sent to Remote Manager. The frequency is measured in days. Use this option when configuring Connect Sensor to report less than once per day. Set this option to 0 when Connect Sensor reports more than once per day.	0 to 31 days Note Digi recommends configuring Connect Sensor to report at least once per week.	0 days

Option	Description	Range	Default
First Daily Report At HHMM	 Specifies the time that is used to reset the device's schedule to the beginning of a new day and send the first daily report. The time is noted as the number of minutes after midnight UTC. Examples: 0 minutes = midnight UTC 60 minutes = 1 hour after midnight UTC 360 minutes = 6 hours after midnight UTC 	0 to 1439 (minutes)	60
Send Last	How many sensor values are included in each report to Remote Manager. If set to 0, all buffered data is sent. For example, you have four sensors and set Send Last to 5 . With these settings, Connect Sensor sends up to 20 sensor values in one report, which includes up to five of the most recent sensor values for each of the four sensors. The actual number of sensor values included in a report depends on how often Connect Sensor wakes and sends a report. If you configure your Connect Sensor to send a report at every wake, then each report will have only one sensor value for each sensor.	0 to 65536 readings	
Send Location Every	This option will be available in a future release of Connect Sensor.	N/A	N/A
GPS Enable	This option will be available in a future release of Connect Sensor.	N/A	N/A
Buffer Sensor Data Before Alarm	Defines the number of seconds of sampled data collected before an alarm occurred that should be saved and pushed after an alarm occurs. This field is available only if the CSENSE Continuous Monitoring firmware has been uploaded to the device.	0 to 300	5
Buffer Sensor Data After Alarm	Defines the number of seconds of sampled data collected after an alarm occurred that should be saved and pushed after an alarm occurs. This field is available only if the CSENSE Continuous Monitoring firmware has been uploaded to the device.	0 to 300	10

Remote Manager option definitions for Connect Sensor

Digital Input option definitions

Digital Input option definitions

The following table provides Remote Manager definitions for Connect Sensor Digital: Input options. For details about setting these options, see Enable and configure a digital input.

Option	Description	Range	Default
Interface Enable	Enables or disables the digital input source.	On/Off	Off
High Alarm	Enables or disables high alarm reports for the digital input source. When enabled, sends an alarm report when the pin is high.	On/Off	Off
Low Alarm	Enables or disables low alarm reports for the digital input source. When enabled, sends an alarm report when the pin is low.	On/Off	Off
Delta Low Alarm	Enables or disables delta low alarm reports for the digital input source. When enabled, sends an alarm report for a falling transition.	On/Off	Off
Delta High Alarm	Enables or disables delta high alarm reports for the digital input source. When enabled, sends an alarm report for a rising transition.	On/Off	Off
Rising Edge Wake	Enables or disables the device to monitor a digital input during sleep mode. When enabled, wakes the device when the digital input changes from low voltage to high voltage (rising edge) and reports the value to Remote Manager with the other sensor and device data.	On/Off	Off
Falling Edge Wake	Enables or disables the device to monitor a digital input during sleep mode. When enabled, wakes the device when the digital input changes from high voltage to low voltage (falling edge) and reports the value to Remote Manager with the other sensor and device data.	On/Off	Off
Enable pullup	Enables or disables the internal pull-up resistor to drive a logic level voltage. For example, use this to drive a logic voltage across a mechanical switch to read the value (open or closed) of the mechanical switch.	On/Off	Off
Sensor description	Specifies description of the sensor for this input source.	Text	Empty

Digital Output option definitions

Digital Output option definitions

The following table provides Remote Manager definitions for Connect Sensor Digital: Output options. For details about setting these options, see Enable and configure a digital output.

Option	Description	Range	Default
Interface Enable	Enables or disables the digital output source.	On/Off	Off
Output Level	 Sets the open collector digital output as follows: High output: If the internal pull-up is enabled, the line is pulled up to 3.3 volts. If the internal pull-up is not enabled and there is no external pull-up, the line is high impedance. Low output: The output is shorted to ground. 	Low output/ High output	Low output
Toggle Output on	Controls the level of the DOUT signal when an alarm condition occurs. A default DOUT state can be selected and then configured to toggle when a specified level alarm is detected on the specified analog input. The signal remains in the toggled state until the alarm condition is cleared, including any alarm level hysteresis. For more information, see Toggle digital output on alarm.	High or low alarm on one analog input, either voltage input or current loop	None
Enable pullup	Enables or disables the internal pull-up resistor to drive a logic level voltage.	On/Off	Off
Sensor description	Specifies description of the sensor for this output source.	Text	Empty

Toggle digital output on alarm

You can use the **Toggle Output on** field in the **Digital Output** page to control the level of the DOUT signal when an alarm condition occurs. A default DOUT state can be selected and then configured to toggle when a specified level alarm is detected on the specified analog input. The signal remains in the toggled state until the alarm condition is cleared, including any alarm level hysteresis.

You can toggle the digital output in response to only one level alarm on one analog input (either a voltage input or a current loop).

For example, if the DOUT is ON during normal operation and an alarm occurs, the DOUT toggles to OFF. When the alarm condition is cleared, the DOUT toggles back to ON.

To configure this option:

- An alarm option must be selected from the Toggle Output on field in the Digital Output settings page. Options are available for low or high alarms on an analog input 1, 2, 3, or 4. Only one alarm can be selected. An analog input alarm can be enabled on either a voltage input or a current loop.
- Alarm conditions for the selected alarm type must be configured for the corresponding analog input.

Note Alarms are only evaluated as sensors are read, and the interval between readings can be significant, even with a device using Continuous Monitoring firmware. Note that a reading may be delayed if the device is communicating with the Digi Remote Manager. For this reason, this feature should not be used when safety is critical.

Digital Pulse Counter option definitions

The following table provides Remote Manager definitions for Connect Sensor Digital: Pulse Counter options. For additional information about using these options, see Enable and configure a digital pulse counter.

Option	Description	Range	Defaul
Interface Enable	Enables or disables the digital input source.	On/Off	Off
High Alarm	Enables or disables high alarm reports for the digital pulse counter.	On/Off	Off
High Threshold	Specifies the number of pulses that generates a high alarm report when High Alarm is On .	Number	0
Low Alarm	Enables or disables low alarm reports for the digital pulse counter source.	On/Off	Off
Low Threshold	Specifies the number of pulses that generates a low alarm report when Low Alarm is On .	Number	0
Hysteresis	Specifies when to keep an alarm on or shut off an alarm during high and low alarm states. 0 — hysteresis is off 1 or more — hysteresis is on and managing alarms	Number	0
Enable pullup	Enables or disables the internal pull-up resistor to drive a logic level voltage.	On/Off	Off
Sensor description	Specifies description of the sensor for the pulse counter.	Text	Empty
Custom Scaled Sample Unit	Specifies the unit of measurement the pulse counter uses for the custom scaled sensor values.	Text	Empty
Custom Scaling Factor	Specifies the number used to convert each pulse into the custom scaled sample unit. For example, if one pulse equals 0.011 inches, you would enter 0.011 in this field.	Number	0

Global Alarm Settings option definitions

The following table provides Remote Manager global alarm options for Connect Sensor. For additional information about using these options, see Configure the global battery alarm for a device.

Option	Description	Range	Default
Battery Life	Specifies the battery life percentage that generates a low battery alarm report.	1-100	50

Internal Temperature option definitions

The following table provides Remote Manager internal temperature monitoring options for Connect Sensor. For additional information about using these options, see Configure internal temperature settings.



CAUTION! If Connect Sensor sends reports less than 15 minutes apart, it may result in an internal temperature that is above the ambient temperature.

Option	Description	Range	Default
Interface Enable	Enables or disables the internal temperature sensor.	On/Off	Off
High Alarm	Enables or disables high alarm reports for the internal temperature value.	On/Off	Off
High Threshold	Specifies the internal temperature in degrees Celsius that generates a high alarm report when High Alarm is On .	-100 to 100	50.0
Low Alarm	Enables or disables low alarm reports for the internal temperature value.	On/Off	Off
Low Threshold	Specifies the internal temperature in degrees Celsius that generates a low alarm report when Low Alarm is On .	-100 to 100	0
Hysteresis	Specifies the degrees in Celsius to keep an alarm on or shut off an alarm during high and low alarm states. 0 — Hysteresis is off 1 or more — Hysteresis is on and managing alarms	0 to 100	5.0

Local Interface Settings option definitions

The following table provides Remote Manager CLI and Bluetooth options for Connect Sensor. For additional information about using these options, see Configure local interface settings: CLI and Bluetooth.

Option	Description	Range	Default
CLI Enable	Enables or disables the command line interface (CLI) for local changes to the device.	On/Off	On
Bluetooth Enable	Enables or disables the Bluetooth interface used to communicate with other devices.	On/Off	On
Bluetooth Device Name	Specifies the name of the Connect Sensor device that appears in a list of available Bluetooth devices when pairing with a nearby device.	Text	Empty

Modbus Protocol Settings option definitions

Note The Modbus protocol is available only with Connect Sensor+ hardware.

The following table provides Remote Manager definitions for Connect Sensor Modbus protocol options. For details about setting these options, see Enable and configure the Modbus protocol.

Option	Description	Range	Default
Protocol enable	Enables or disables the Modbus protocol.	On/Off	Off
Device Status Alarm Mask	Determines whether error information should be pushed immediately when an alarm occurs.	On/Off	Off
Serial framing mode	The transmission mode.	RTU ASCII	RTU

Option	Description	Range	Default
Serial baud bits	The baud rate.	600 - 230400 (fixed values within this range)	19200
Serial data bits	The number of data bits that can be sent in a packet.	7 8	8
Serial stop bits	The bit that marks the end of a unit transition.	1 2	1
Serial parity	The check bit for detecting an error in transmission.	none odd even	none
Station 1: Slave Address	A station address configured for the sensor. When the value is set to 0, this station is skipped.	0 - 247	0
Station 1: Variable List	List of variable addresses on the specified station that you want to monitor. The items in the list must be separated by a comma without spaces. The list is limited to 63 characters, which allows for 8 to 10 variables in a list.	63 characters	blank
Station 2: Slave Address	A station address configured for the sensor. When the value is set to 0, this station is skipped.	0 - 247	0
Station 2: Variable List	List of variable addresses on the specified station that you want to monitor. The items in the list must be separated by a comma without spaces. The list is limited to 63 characters, which allows for 8 to 10 variables in a list.	63 characters	blank
Station 3: Slave Address	A station address configured for the sensor. When the value is set to 0, this station is skipped.	0 - 247	0

Option	Description	Range	Default
Station 3: Variable List	List of variable addresses on the specified station that you want to monitor. The items in the list must be separated by a comma without spaces. The list is limited to 63 characters, which allows for 8 to 10 variables in a list.	63 characters	blank
Station 4: Slave Address	A station address configured for the sensor. When the value is set to 0, this station is skipped.	0 - 247	0
Station 4: Variable List	List of variable addresses on the specified station that you want to monitor. The items in the list must be separated by a comma without spaces. The list is limited to 63 characters, which allows for 8 to 10 variables in a list.	63 characters	blank

Data stream definitions

The following sections provide Remote Manager data streams descriptions for Connect Sensor. For additional information about using data streams to analyze Connect Sensor data, see Use Remote Manager to view device and sensor data streams.

Group definitions for Connect Sensor data streams

The following table provides data stream group definitions for Connect Sensor. For additional information about using data streams to analyze Connect Sensor data, see About data streams.

Group	Description	
ain	Data streams for analog voltage input sources 1 - 4, identified as follows: ain1 — Analog: Voltage Input 1 ain2 — Analog: Voltage Input 2 ain3 — Analog: Voltage Input 3 ain4 — Analog: Voltage Input 4	
avout	Data streams for analog power output sources 1 - 4, identified as follows: avout1 — Analog: Power Output 1 avout2 — Analog: Power Output 2 avout3 — Analog: Power Output 3 avout4 — Analog: Power Output 4	
cl	Data streams for analog current loop input sources 1 - 4, identified as follows: cl1 — Analog: 4-20mA Current Loop 1 cl2 — Analog: 4-20mA Current Loop 2 cl3 — Analog: 4-20mA Current Loop 3 cl4 — Analog: 4-20mA Current Loop 4	
din1	Data stream for the Digital: Input source	
dout1	Data stream for the Digital: Output source	
dvout1	Data stream for the Digital: Power Output source	
pcnt1	Data stream for the Digital: Pulse Counter source	
temp1	Data stream for the Internal Temperature sensor	

Group	Description
ts1	Data stream for the following Connect Sensor device-specific settings: Cellular Settings Device Cloud Settings Device Settings Global Alarm Settings System Information
ui	Data stream for Local Interface Settings options

Connect Sensor device-specific (ts1 and ui) data stream definitions

The following table provides data streams definitions for the Connect Sensor device (ts1 and ui). For additional information about data streams, refer to the following:

- Use data streams to analyze Connect Sensor data, see About data streams.
- Data streams group definitions, see Group definitions for Connect Sensor data streams.

Short name	Long name	Description
abt	Alarm battery	Battery Life threshold setting; for example, 75 (percent).
apn	APN	Access point name for the cellular network your device uses.
bat	Battery level	Estimated percentage of battery life remaining.
bte	Bluetooth enable	Bluetooth module enabled or disabled: 0 — Bluetooth off 1 — Bluetooth on
btn	Bluetooth display name	Name of the Connect Sensor device that appears in a list of available Bluetooth devices when pairing with a nearby device. For example, H2O gauge.
cli	CLI enable	Command line interface enabled or disabled for local device changes: $0 - CLI$ off $1 - CLI$ on
dwt	Device wake reason	Reason the device woke up: 2 — Normal reading or report 3 — Alarm reading or report 8 — Wakeup report
fwv	Firmware version	Firmware version on the device; for example, 2.0.1.19.
isn	Cloud server name	Server address that Connect Sensor uses to connect to Remote Manager.
nsn	NTP server name	NTP server address used to remotely synchronize time on the device.

Short name	Long name	Description
rdp	Read period (minutes)	Number of minutes between wake cycles for sensor readings.
rsi	RSSI	Signal strength of the cellular connection.
sdc	Send count	Maximum number of readings sent during one report.
sdp	Send interval	Number of scheduled wake cycles for sensor readings between each report.
sdpd	Read period (days)	Number of days between readings. When using sdpd, the device follows the First Daily Report At HHMM (sst) setting.
ssl	TLS/SSL data encryption	TLS/SSL data encryption for the Connect Sensor connection to Remote Manager: 0 — TLS/SSL data encryption off 1 — TLS/SSL data encryption on
sst	Send start time	Number of minutes after midnight UTC that the new day begins and the first report of the day is sent.

Analog input (ain and cl) data stream definitions

The following table provides data stream definitions for both the voltage analog input (ain) and the current loop analog input (cl) groups for Connect Sensor.

- Use data streams to analyze Connect Sensor data, see About data streams.
- Data streams group definitions, see Group definitions for Connect Sensor data streams.

Short name	Long name	Description
adh	Alarm delta high	Delta High threshold setting. ain (1- 4) — volts cl (1 - 4) — mA
adl	Alarm delta low	Delta Low threshold setting. ain (1- 4) — volts cl (1 - 4) — mA
aem	Alarm enable mask	Alarms that are enabled during the report; the value in the data stream equals the sum of the enabled alarms: 1 — Alarm high enabled (alh) 2 — Alarm low enabled (all) 4 — Alarm delta low enabled (adl) 8 — Alarm delta high enabled (adh) For example, if you have the Alarm high and Alarm low enabled, the aem data stream value is 3. If you have all alarms enabled, the aem data stream value is 15.

Short name	Long name	Description
ahy	Alarm hysteresis	Hysteresis setting. Examples: ain $(1-4) - 1.0$ (volts) cl $(1-4) - 1.0$ (mA)
alh	Alarm high	High Threshold setting. Examples: ain $(1-4) - 8$ (volts) cl $(1-4) - 14$ (mA)
all	Alarm low	Low Threshold setting. Examples: ain $(1-4) - 2$ (volts) cl $(1 - 4) - 6$ (mA)
arm	Alarm reason mask	Alarms that are active during the report; the value in the data stream equals the sum of the active alarms: 1 — Alarm high active (alh) 2 — Alarm low active (all) 4 — Alarm delta low active (adl) 8 — Alarm delta high active (adh) For example, if the Alarm high and Alarm low are active during the report, the arm data stream value is 3.
cval	Custom value	Value calculated from the raw value (val) and custom scaled unit values for y1 and y2 (described in this table).
dsc	Description	Description of the sensor.
ena	Sensor enable	Sensor enabled or disabled: 0 — Sensor off 1 — Sensor on
unit	Custom unit string	Unit for the custom value (cval).
val	Raw value	Measured analog voltage or current loop input.
у1	Custom unit, point 1	Custom value associated with the following raw value: ain $(1 - 4) - 0$ volts cl $(1 - 4) - 4$ mA
у2	Custom unit, point 2	Custom value associated with the following raw value: ain $(1 - 4) - 10$ volts cl $(1 - 4) - 20$ mA

Analog (avout), digital (dvout1), and serial power output data stream definitions

The following table provides data stream definitions for the analog power output (avout 1 - 4), digital power output (dvout1), and serial power output groups for Connect Sensor.

- Use data streams to analyze Connect Sensor data, see About data streams.
- Data streams group definitions, see Group definitions for Connect Sensor data streams.

Short name	Long name	Description
ena	Voltage output status	Voltage output enabled or disabled: 0 — Output off 1 — Output on
out	Voltage output level	Level of voltage output: 0 — 3.3 volts 1 — 5 volts 2 — 15 volts 3 — 24 volts
rdl	Read delay	Time in seconds that the sensor voltage is enabled before Connect Sensor reads its value. This allows the sensor to stabilize to get an accurate reading.

Digital input (din1) data stream definitions

The following table provides data stream definitions for the digital input (din1) group for Connect Sensor.

- Use data streams to analyze Connect Sensor data, see About data streams.
- Data streams group definitions, see Group definitions for Connect Sensor data streams.

Short name	Long name	Description
aem	Alarm enable mask	Alarms that are enabled during the report; the value in the data stream equals the sum of the enabled alarms: 1 — Alarm high enabled (alh) 2 — Alarm low enabled (all) 4 — Alarm delta low enabled (adl) 8 — Alarm delta high enabled (adh) For example, if you have the Alarm high and Alarm low enabled, the aem data stream value is 3. If you have all alarms enabled, the aem data stream value is 15.
arm	Alarm reason mask	Alarms that are active during the report; the value in the data stream equals the sum of the active alarms: 1 — Alarm high active (alh) 2 — Alarm low active (all) 4 — Alarm delta low active (adl) 8 — Alarm delta high active (adh) For example, if the Alarm high and Alarm low are active during the report, the arm data stream value is 3.
dsc	Description	Identifies the user-configured description of the sensor.
ena	Sensor enable	Sensor enabled or disabled: 0 — Sensor off 1 — Sensor on

Short name	Long name	Description
puen	Pull-up enable	Pull-up resistor to 3.3 volts enabled or disabled: 0 — Pull-up disabled 1 — Pull-up enabled
wem	Wake enable mask	Wake enabled when the digital input signal changes; the value in the data stream equals the sum of the enabled values: 1 – Wake on a rising edge of the input 2 – Wake on a falling edge of the input For example, to wake on any edge, the wem data stream value is 3.

Digital output (dout1) data stream definitions

The following table provides data stream definitions for the digital output (dout1) group for Connect Sensor.

- Use data streams to analyze Connect Sensor data, see About data streams.
- Data streams group definitions, see Group definitions for Connect Sensor data streams.

Short name	Long name	Description
dsc	Description	Identifies the user-configured description of the sensor.
ena	Sensor enable	Sensor enabled or disabled: 0 — Sensor off 1 — Sensor on
out	Digital output value	Digital output on or off: 0 — Digital output at low voltage 1 — Digital output at high voltage
puen	Pull-up enable	Pull-up resistor to 3.3 volts enabled or disabled: 0 — Pull-up disabled 1 — Pull-up enabled
tog	Toggle Output on	Toggle digital output on alarm: 0 — Disabled 1 — Analog 1 High Alarm 2 — Analog 1 Low Alarm 3 — Analog 2 High Alarm 4 — Analog 2 Low Alarm 5 — Analog 3 High Alarm 6 — Analog 3 Low Alarm 7 — Analog 4 High Alarm 8 — Analog 4 Low Alarm

Digital pulse counter (pcnt1) data stream definitions

The following table provides data stream definitions for the digital pulse counter (pcnt1) group for Connect Sensor.

For additional information about data streams, refer to the following:

- Use data streams to analyze Connect Sensor data, see About data streams.
- Data streams group definitions, see Group definitions for Connect Sensor data streams.

Short name	Long name	Description
aem	Alarm enable mask	Alarms that are enabled during the report; the value in the data stream equals the sum of the enabled alarms: 1 — Alarm high enabled (alh) 2 — Alarm low enabled (all) For example, if you have the Alarm high and Alarm low enabled, the aem data stream value is 3.
ahy	Alarm hysteresis	Hysteresis setting; for example, 2 (pulses).
alh	Alarm high	High Threshold setting; for example, 4000 (pulses).
all	Alarm low	Low Threshold setting; for example 50 (pulses).
arm	Alarm reason mask	Alarms that are active during the report; the value in the data stream equals the sum of the active alarms: 1 — Alarm high active (alh) 2 — Alarm low active (all) For example, if the Alarm high and Alarm low are active during the report, the arm data stream value is 3.
cval	Custom value	Value calculated from the raw value (val).
dsc	Description	Identifies the user-configured description of the sensor.
ena	Sensor enable	Sensor enabled or disabled: 0 — Sensor off 1 — Sensor on
puen	Pull-up enable	Pull-up resistor to 3.3 volts enabled or disabled: 0 — Pull-up disabled 1 — Pull-up enabled
scl	Custom value scaling factor	Scaling factor used to calculate the custom value (cval) from the raw value (val).
unit	Custom unit string	Identifies the user-configured unit for the custom value (cval).
val	Raw value	Number of pulses since the last reading.

Temperature sensor (temp1) data stream definitions

The following table provides data stream definitions for the temperature sensor (temp1) group for Connect Sensor.



CAUTION! If Connect Sensor sends reports less than 15 minutes apart, it may result in an internal temperature that is above the ambient temperature.

For additional information about data streams, refer to the following:

- Use data streams to analyze Connect Sensor data, see About data streams.
- Data streams group definitions, see Group definitions for Connect Sensor data streams.

Short name	Long name	Description
aem	Alarm enable mask	Alarms that are enabled during the report; the value in the data stream equals the sum of the enabled alarms: 1 — Alarm high enabled (alh) 2 — Alarm low enabled (all) For example, if you have the Alarm high and Alarm low enabled, the aem data stream value is 3.
ahy	Alarm hysteresis	Hysteresis setting; for example, 2.0 (Celsius).
alh	Alarm high	High Threshold setting; for example, 50.0 (Celsius).
all	Alarm low	Low Threshold setting; for example -30.0 (Celsius).
arm	Alarm reason mask	Alarms that are active during the report; the value in the data stream equals the sum of the active alarms: 1 — Alarm high active (alh) 2 — Alarm low active (all) For example, if the Alarm high and Alarm low are active during the report, the arm data stream value is 3.
ena	Sensor enable	Sensor enabled or disabled: 0 — Sensor off 1 — Sensor on
val	Raw value	Measured temperature.

Modbus (modb1) data stream definitions

The following table provides data stream definitions for the Modbus protocol.

Note The Modbus protocol is available only with Connect Sensor+ hardware.

Some data stream information pushed to Remote Manager includes the Modbus device address identified during device detection. For examples, see About data streams.

Short name	Long name	Description
aem	Alarm enable mask	Modbus alarm enabled or disabled: 0 — Modbus alarm disabled 1 — Modbus alarm enabled
baud	Baud rate	The baud rate. Value can be 600 - 230400.
dbt	Data bits	 The number of data bits that can be sent in a packet: 7 8
ena	Modbus protocol enable	Modbus protocol enabled or disabled: 0 — Modbus protocol disabled 1 — Modbus protocol enabled
err	Error response status value	Error values: 1 - Illegal function 2 - Illegal data address 3 - Illegal data value 4 - Device failure 128 - Timeout
mode	Modbus serial transmission mode	Specifies the Modbus serial transmission mode:rtuascii
par	Parity	 The check bit for detecting an error in transmission: none odd even
saddr<1- 4>	Modbus station addresses	The station address number that is configured for the Modbus sensor device.
sbt	Stop bit	 The bit that marks the end of a unit transition. 1 2
val	Variable that returns a value	Coils and discrete inputs will be 0 or 1. Input and holding registers will be 16-bit unsigned integer values, or signed floating point values, depending on configuration.
vars<1-4>	Corresponding Modbus variable list	Comma-separated list of variable addresses.

Data streams for Modbus protocol



ltem	Name	Description
1	Connect Sensor device ID	Identifies the device.
2	Group	Identifies the device-specific function or sensor for the data stream. For example, <i>modb1</i> corresponds to the sensor for a device with Modbus protocol enabled.
3	Modbus station address	Identifies the station address that is being monitored.
4	Modbus variable address	Identifies the variable address that is being monitored at the specified station address.
5	Short name	Identifies the specific data point. In this example, <i>val</i> is the value that is returned.

Use the CLI with Connect Sensor

If you have physical access to Connect Sensor, you can use the CLI (Command Line Interface) to perform firmware updates, configure the device, and verify Connect Sensor status information.

To use CLI commands, you must connect a USB cable from a computer to Connect Sensor, and then open a terminal program in the computer. You can enter CLI commands in the terminal program:

- Use the fwupdate command to update the firmware on the device.
- Use the status command to display device information.
- Use the set command combined with additional commands to configure device and sensor settings.

The sections below explain how to connect to Connect Sensor and perform some standard functions.

- Open a terminal program and use CLI commands
- Update the firmware using the CLI
- Use the CLI to view status information for the device
- Verify cellular network coverage using the CLI
- View battery life using the CLI

Open a terminal program and use CLI commands

You can use CLI commands to perform actions on Connect Sensor. To use CLI commands, you must connect a USB cable from a computer to Connect Sensor, and then open a terminal program in the computer.

- 1. Open the Connect Sensor enclosure and make sure the battery is connected.
- 2. Connect a USB type A to B cable from your computer to the USB type B port.

Note Do not use the mini USB port, which is covered by a red X in the graphic below.

 You may need to install device drivers or wait for your computer to automatically install them when connecting Connect Sensor to a computer using a USB cable. Digi recommends drivers available at www.ftdichip.com/Drivers/VCP.htm.



- 4. Open a terminal program on a computer and connect to Connect Sensor using the following configuration:
 - Connection port: Connect to the COM port associated with the USB cable connected to Connect Sensor
 - Baud rate or bits per second: 115200
 - **Data:** 8 bit
 - Parity: None
 - Stop: 1 bit
 - Flow control: None
- 5. Press the Wake button on Connect Sensor and wait 5-10 seconds after the cellular LED starts blinking.
- 6. Type your CLI command and press Enter.
 - fwupdate: Update the firmware on the device. See Update the firmware using the CLI.
 - status: Display status information. See Use the CLI to view status information for the device.
 - set: Configure device and sensor settings.
- 7. Connect Sensor waits 30 seconds from when you pressed **Enter** to begin processing the command.
- 8. Type in any other CLI commands you want to perform.

9. When Connect Sensor has processed all of the CLI commands you have entered and completed all modem calls, the device goes to sleep. The following line displays in the terminal program when the device is sleeping: zzz...

Note If you press the Wake button or use a magnet to wake Connect Sensor during the 30second timeout period, the LED lights will not be activated, as the device is already awake. Make sure "zzz..." appears in the terminal program before you try to wake the device.

- 10. Close the terminal program.
- 11. Disconnect the USB cable from Connect Sensor and the computer.

Use the CLI to view status information for the device

Use the CLI to view status information for your device.

- 1. Connect to your device using the CLI. See Open a terminal program and use CLI commands for information about connecting your computer to the device and opening a terminal program.
- 2. Press the Wake button and wait 5-10 seconds after the cellular LED starts blinking.
- 3. Type **status** at the command prompt to view additional information about the device.
 - For general information about status information, see status.
 - For additional information about the signal strength status, see Verify cellular network coverage using the CLI.
 - For additional information about battery life status, View battery life using the CLI.

Verify cellular network coverage using the CLI

If you have physical access to Connect Sensor, you can use the CLI to verify the cellular signal strength using the CLI status command.

- 1. On your laptop, go to www.digi.com/support to download the Connect Sensor firmware file.
- 2. Open the enclosure and make sure the battery is connected and the SIM card is installed.
- 3. Connect to your device using the CLI. See Open a terminal program and use CLI commands for information about connecting your computer to the device and opening a terminal program.
- 4. Press the Wake button and wait 5-10 seconds after the cellular LED starts blinking. The command prompt appears in the terminal program window.
- 5. At the command prompt, type **status**.
- Press Enter. The status information appears. Note that cellular network information is available only when the modem has connected to the cellular network. You may have to type status multiple times while the modem connects before the desired status information is available.
- 7. Verify the cellular signal strength in the **Signal strength** option. For more details about all of the options, see status.

View battery life using the CLI

You can check the battery life using the CLI.

Note You can also check battery life using Remote Manager. See View battery life for a device in Remote Manager.

- 1. Connect to your device using the CLI. See Open a terminal program and use CLI commands for information about connecting your computer to the device and opening a terminal program.
- 2. Press the Wake button and wait 5-10 seconds after the cellular LED starts blinking. When the cellular connection is complete, the device calculates the battery life and reports the most recent value. The battery life value is most accurate when the cellular connection has completed.
- 3. Type **status** at the command prompt.

Note If you enter the **status** command before the device has calculated a new battery life value, the old battery life value (if the device has one) displays in Remote Manager.

- 4. Find the **Battery Life** field to see how much battery life remains. See status for information about all of the status information fields.
- 5. If the remaining percentage is low, you should change the battery. For instructions, see Battery replacement.

CLI commands

The following sections provide all of the available CLI commands for configuring Connect Sensor and viewing status information.

twupdate	5
status	5
set	6

fwupdate

Use

Type **fwupdate** at the command prompt to update the device firmware.

Options

Make sure the terminal program is able to transfer YMODEM files.

status

Use

Type **status** at the command prompt to display device information.

The status information represents a snapshot in time, and is updated each time you type the **status** command. The Connect Sensor device modem must be connected to the cellular network to be able to capture and display cellular information for the device. The modem is awake for a short amount of time and then automatically disconnects from the network.

You may have to type the **status** command a few times to makes sure you have a complete set of device status information. This may take between 45 and 60 seconds, depending on how long it takes for the modem to connect. Before and after the modem is connected, only status information about the Connect Sensor hardware displays.

Connect Sensor device options

The following information about the Connect Sensor device hardware always displays.

Option	Description
Device Type	Name and version of the device hardware.
Device ID	ID number for the Connect Sensor device.
Firmware Version	Version of the device's current firmware.
UTC Time	Last reported date and time.
Battery Life	Amount of battery life remaining. See View battery life using the CLI.

Connect Sensor modem and cellular connection options

The following information displays when the modem is connecting or has connected. These fields display depending on the status of the modem connection to the cellular network.

Option	Description
Mobile support software	Version of the mobile software.
Device type	Cellular network type the device connects to.

Option	Description
Manufacturer	Cellular modem manufacturer.
Model	Cellular modem model number.
Modem revision	Modem firmware version.
Serial number	Modem serial number.
Provider	Cellular provider.
Phone number	Phone number registered to the activated SIM card.
SIM IMSI	Unique user identifier for the cellular network.
SIM ICCID	SIM serial number.
SIM PIN status	State of the SIM card.
Signal strength	Strength of the cellular signal. See Verify cellular network coverage using the CLI.
Signal quality	Quality of the cellular signal. This measures signal interference.
Connection state	Cellular connection state.
Connection duration	Amount of time the cellular modem was connected during last wake cycle.
Disconnect reason	Cause of the cellular modem disconnection during last wake cycle.
Connections	Number of cellular connection attempts since power up.
Connection errors	Number of failed connections since power up.
User disconnects	Number of normal disconnections since power up.
Monitoring errors	Number of cellular modem errors since power up.
Device resets	Number of times cellular modem was reset to recover from errors since power up.

set

Use

Type **set** and additional commands at the command prompt to configure device and sensor settings.

Options

See the commands in the following sections.

Analog input CLI commands

Use **set**, the sensor identifier, and the commands in the following table to configure sensor options with the CLI. For example, type **set ain1 ena=on** at the command prompt to enable the analog voltage input 1 interface. Sensor identifiers:

- Analog voltage input 1: ain1
- Analog voltage input 2: ain2
- Analog voltage input 3: ain3
- Analog voltage input 4: ain4
- Analog 4-20 mA current loop 1: cl1
- Analog 4-20 mA current loop 2: cl2
- Analog 4-20 mA current loop 3: cl3
- Analog 4-20 mA current loop 4: cl4

Analog current loop and voltage input CLI commands:

Option	CLI command	Description	Value options	Default
Input interface	ena	Enables or disables the analog input source.	■ on ■ off	off

Option	CLI command	Description	Value options	Default
Alarms	aem	 Enables or disables alarm reports for the analog input sources. When enabled, sends an alarm report in one of the following conditions: High alarm Low alarm Delta high alarm Delta low alarm 	 hi lo dh dl Enable multiple alarms using a comma separated command without spaces (such as set ain1 aem=hi,lo,dh,dl) 	Empty (all alarms disabled)
High threshold	alh	Specifies the input value that generates a high alarm report when the high alarm is enabled.	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 20.0Voltage: 10.0
Low threshold	all	Specifies the input value that generates a low alarm report when the low alarm is enabled.	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 4.0Voltage: 0.0
Delta low threshold	adl	Specifies the input value that generates a delta low alarm report when the delta low alarm is enabled.	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 16.0Voltage: 10.0
Delta high threshold	adh	Specifies the input value that generates a delta high alarm report when the delta high alarm is enabled.	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 16.0Voltage: 10.0

CLI commands
Option	CLI command	Description	Value options	Default
Hysteresis	ahy	 Specifies the input value to keep an alarm on or shut off an alarm during high and low alarm states. 0 — hysteresis is off 1 or more — hysteresis is on and managing alarms 	 Current loop: 4.0 - 22 (mA) Voltage: 0.0 - 10.5 (volts) 	Current loop: 1.0Voltage: 1.0
Sensor description	dsc	Specifies description of the sensor for this input source.	Text	Empty
Custom scaled sample unit	unit	Specifies the unit of measurement this analog input is using for the custom scaled sensor values.	Text	Empty
Custom scaled sample value (y1)	у1	 Specifies the first data point associated with the following raw value: Current Loop inputs - 4 mA Voltage inputs - 0 volts 	Number	0
Custom scaled sample value (y2)	у2	 Specifies the second data point associated with the following raw value: Current Loop inputs - 20 mA Voltage inputs - 10 volts 	Number	0

Use the commands in the following table with the **set** command and **din1** when configuring the digital input options with the CLI. For example, type **set din1 ena=on** to enable the digital input interface.

Option	CLI command	Description	Value options	Default
Input interface	ena	Enables or disables the digital input source.	onoff	off
Alarms	aem	 Enables or disables alarm reports for the digital input source. When enabled, sends an alarm report in one of the following conditions: High alarm Low alarm Delta high alarm Delta low alarm 	 hi lo dh dl Enable multiple alarms using a comma separated command without spaces (such as set ain1 aem=hi,lo,dh,dl) 	Empty (all alarms disabled)

Option	CLI command	Description	Value options	Default
Rising and falling edge wake	wem	 Enables or disables the device to monitor a digital input during sleep mode as follows (they are either all On or all Off when using the CLI for configuration): Rising edge wake alarm: When enabled, wakes the device when the digital input changes from low voltage to high voltage (rising edge) and reports the value to Remote Manager with the other sensor and device data. Falling edge wake alarm: When enabled, wakes the device when the digital input changes from low the device data. Falling edge wake alarm: When enabled, wakes the device when the digital input changes from high voltage to low voltage (falling edge) and reports the value to Remote digital input changes from high voltage to low voltage (falling edge) and reports the value to Remote Manager with the other sensor and device data. 	 rise fall Enable both alarms using a comma separated command without spaces (such as set din1 wem=rise,fall) 	Empty (all edge wake alarms off)
Enable pullup	puen	Enables or disables the internal pull-up resistor to drive a logic level voltage. For example, use this to drive a logic voltage across a mechanical switch to read the value (open or closed) of the mechanical switch.	onoff	off
Sensor description	dsc	Specifies description of the sensor for this input source.	Text	Empty

Digital output CLI commands

Use the commands in the following table with the **set** command and **dout1** when configuring the digital output options with the CLI. For example, type **set dout1 ena=on** to enable the digital output interface.

Option	CLI commands	Description	Value options	Default
Output interface	ena	Enables or disables the digital output source.	■ on ■ off	off
Output level	out	 Sets the open collector digital output as follows: Low output: The output is shorted to ground. High output: If the internal pull-up is enabled, the line is pulled up to 3.3 volts. If the internal pull-up is not enabled and there is no external pull-up, the line is high impedance. 	 low high 	low
Enable pullup	puen	Enables or disables the internal pull-up resistor to drive a logic level voltage.	■ on ■ off	off
Sensor description	dsc	Specifies description of the sensor for this output source.	Text	Empty

Digital pulse counter CLI commands

Use the commands in the following table with the **set** command and **pcnt1** when configuring the digital pulse counter options with the CLI. For example, type **set pcnt1 ena=on** to configure the digital pulse counter interface.

Option	CLI command	Description	Value options	Default
Digital pulse counter interface	ena	Enables or disables the digital input source.	■ on ■ off	off
Alarms	aem	 Enables or disables alarm reports for the digital pulse counter source. When enabled, sends an alarm report in one of the following conditions: High alarm Low alarm 	 hi lo Enable both alarms using a comma separated command without spaces (such as set pcnt1 aem=hi,lo) 	Empty (all alarms disabled)
High threshold	alh	Specifies the high threshold in number of pulses that generates a high alarm report when high alarm is On .	Number	0
Low threshold	all	Specifies the low threshold in number of pulses that generates a low alarm report when low alarm is On .	Number	0
Hysteresis	ahy	 Specifies when to keep an alarm on or shut off an alarm during high and low alarm states. 0 — hysteresis is off 1 or more — hysteresis is on and managing alarms 	Number	0

Option	CLI command	Description	Value options	Default
Enable pullup	puen	Enables or disables the internal pull-up resistor to drive a logic level voltage.	■ on ■ off	off
Sensor description	dsc	Specifies description of the sensor for the pulse counter.	Text	Empty
Custom scaled sample unit	unit	Specifies the unit of measurement the pulse counter uses for the custom scaled sensor values.	Text	Empty
Custom scaling factor	scl	Specifies the number used to convert each pulse into the custom scaled sample unit. For example, if one pulse equals 0.011 inches, you type 0.011 as the value.	Number	0

Analog and digital power output CLI commands

Use the commands in the following table with the **set** command and the sensor power identifier when configuring the sensor options with the CLI. For example, type **set avout1 ena=on** to enable the analog power output 1 interface.

Sensor power identifiers:

- Analog power output 1: avout1
- Analog power output 2: avout2
- Analog power output 3: avout3
- Analog power output 4: avout4
- Digital power output: dvout1

Option	CLI command	Description	Value options	Default
Power output	ena	Enables or disables the power output source.	■ on	off
			■ off	
Output level	out	Specifies the voltage level output for the analog power source.	3 .3	3.3
			5	
			1 5	
			■ 24	
Read delay	rdl	Specifies the time in seconds that the sensor voltage is enabled before Connect Sensor reads its value. This allows the sensor to stabilize to get an accurate reading.	0-120 seconds	0
		Note A higher read delay keeps the device powered on longer, which reduces battery life.		

Cellular CLI commands

Use the following commands with the **set** command when configuring the device with the CLI. All cellular configuration values are supplied by your cellular service provider.

Option	CLI command	Description	Value options
APN	apn	Identifies the access point name that connects your device to the correct cellular network.	 If you purchased Digi Bundled Services, this value is preconfigured for you. If you purchased cellular service through a third party, contact your provider for this value.
User Name	user	Specifies the user name for your cellular network account.	 Use only when required by your cellular service provider. Length: Up to 63 characters Printable characters and spaces only (no quotation marks or backslashes) No value: disabled (no user name required)

Option	CLI command	Description	Value options
Password	pwd	Specifies the password for your cellular network account.	 Use only when required by your cellular service provider. Length: Up to 63 characters Printable characters and spaces only (no quotation marks or backslashes) No value: disabled (no password required)
SIM PIN	pin	Specifies the PIN for your cellular network SIM card.	 Use only when required by your cellular service provider. Length: 4 to 8 numeric characters No value: disabled (no PIN required)

Remote Manager CLI commands

Use the following commands with the **set** command when configuring the device with the CLI. All Remote Manager configuration values are preconfigured. supplied by your cellular service provider. Do not make changes to this setting without help from Digi Technical Support.

Option	CLI command	Description	Values
Server name	isn	Specifies the URL that connects your device to Remote Manager. This setting is configured by default.	my.devicecloud.com
SSL	ssl	Enables SSL encryption for data sent from Connect Sensor to Remote Manager.	onoff (default)
		Note Enabling SSL encryption significantly increases cellular data usage.	
NTP server name	nsn	Network Time Protocol (NTP) server name that synchronizes Connect Sensor time with Coordinated Universal Time (UTC). This setting is configured by default.	time.devicecloud.com

Internal temperature CLI commands

Use the following command with the **set** command when configuring the device with the CLI.



CAUTION! If Connect Sensor sends reports less than 15 minutes apart, it may result in an internal temperature that is above the ambient temperature.

Option	CLI commands	Description	Value options	Default
Internal temperature interface	ena	Enables or disables the internal temperature sensor.	onoff	off
Alarms	aem	 Enables or disables alarm reports for the internal temperature. When enabled, sends an alarm report in one of the following conditions: High alarm Low alarm 	 hi lo Enable multiple alarms using a comma separated command without spaces (such as set ain1 aem=hi,lo) 	Empty (all disabled)
High threshold	alh	Specifies the internal temperature in degrees Celsius that generates a high alarm report when the high alarm is enabled.	-100 to 100	50.0
Low threshold	all	Specifies the internal temperature in degrees Celsius that generates a low alarm report when the low alarm is enabled.	-100 to 100	0

Option	CLI commands	Description	Value options	Default
Hysteresis	ahy	 Specifies the degrees in Celsius to keep an alarm on or shut off an alarm during high and low alarm states. 0 — Hysteresis is off 1 or more — Hysteresis is on and managing alarms 	0 to 100	5.0

Modbus CLI commands

Use the commands in the following table with the **set** command and **modb1** when configuring the digital input options with the CLI. For example, type **set modb1 ena=on** to enable the Modbus protocol for the external sensor device.

Note The Modbus protocol is available only with Connect Sensor+ hardware.

Option	CLI command	Description	Value options	Default
Modbus protocol	ena	Enables or disables the Modbus protocol on a sensor.	■ on ■ off	off
Serial protocol transmission mode	mode	Specifies the Modbus transmission mode.	rtuascii	rtu
Station addresses	saddr<1 - 4>	Specify which station addresses will be queried by Connect Sensor when the sensors are read.	The station address number that is configured for the Modbus sensor device.	0
Variable list	vars<1 - 4>	For each configured station address, you can configure a corresponding variable list. The variable list is limited to 63 characters, which limits the number of variables to between 8 and 10. For more information, see Modbus station addresses and locations.	Comma-separated list of variable addresses.	null

Troubleshooting

This section provides troubleshooting information and resources for a Connect Sensor device. You need physical access to the device to perform the procedures in this section.

Digi International provides the following additional online resources:

- Knowledge Base: www.digi.com/support/kbase
- Support forum: www.digi.com/support/forum
- Support request: www.digi.com/support

Connect Sensor LEDs for troubleshooting

Use the four LEDs on Connect Sensor when troubleshooting the device. These LEDs have specific behaviors that provide information for Bluetooth connection, sensor activity, cellular connection, and battery life. If Connect Sensor is powered and all LEDs are off, it is in sleep mode. See Connect Sensor LEDs for detailed information about the LEDs.

Device not responding

Try the following procedures when your Connect Sensor is not responding, such as when the LEDs do not light up after pressing the Wake button. You need physical access to the device to complete the steps.

Check the battery

The battery may be disconnected or no longer working. Try the following:

- Make sure the battery wires are firmly connected to the Battery port.
- Connect a different battery to the device, if you have an additional battery.

Reset the device

This procedure forces the device to restart and retain its configuration.

- 1. Open the Connect Sensor enclosure.
- Press the Reset button to force a reset when the Connect Sensor device does not respond to any inputs.

Pressing Reset cancels all operations and completes a power cycle, then Connect Sensor enters sleep mode. The device retains the last successful changes you made to its configuration.

3. Wake the device and wait for the proper LED light sequence to indicate it is responding.

Restore factory defaults to the device

This procedure removes all configuration changes and returns the device to its factory default settings. Use this procedure when the device is still not responding after pressing the Reset button.

- 1. With the Connect Sensor enclosure open, press and hold the Factory button for at least 3 seconds until the LEDs flash purple. The device is reset to its factory defaults.
- 2. Reconfigure Connect Sensor to work with your sensors and environment.

Device not connected to the cellular network

The following basic troubleshooting steps resolve most cellular connection issues for a Connect Sensor. You need physical access to the device to complete the steps.

If the basic troubleshooting steps do not resolve the network connection issue, use the CLI to get the status of your device and contact Digi Technical Support.

Verify SIM configuration

- 1. Verify the following for your device:
 - a. Make sure the SIM card is inserted correctly into the SIM tray; see Assemble Connect Sensor.
 - b. Make sure you are using the correct APN and that the PIN, user name, and password are configured, if required; see Configure the cellular connection.
- 2. Contact your cellular service provider to make sure your SIM card is activated and assigned to a contract.

Check cellular antenna

- Make sure the cellular antenna is securely installed on the device and is not damaged.
- Verify that the antenna installed on the device matches the available network. For example, a 3G antenna may not work as expected when installed on an LTE-only device.

Verify cellular network coverage

Work with your cellular service provider to make sure there is adequate network coverage for the device installation area. If possible, do one of the following:

- Move the device to an area with adequate cellular network coverage
- Use a cabled antenna to move the antenna to get a better signal without moving the device
- View device information in Remote Manager
- Verify cellular network coverage using the CLI

Check battery life

Older batteries may not have enough power to connect to the cellular network and you may need to replace the battery. If Connect Sensor has been deployed for some time, check the battery life. This can be done from Remote Manager or by using the CLI.

- View battery life for a device in Remote Manager
- View battery life using the CLI

Device does not connect to Remote Manager

Connect Sensor may be connected to the cellular network but does not show a connection in Remote Manager. In this case, the cellular LED light blinks blue.

Follow this procedure if your Connect Sensor does not connect to Remote Manager.

- 1. Get the correct 15-digit device IMEI number on the Connect Sensor label.
- 2. Sign in to Remote Manager.
- 3. Verify that the 15-digit device IMEI number on the Connect Sensor label is the same as the **Device ID** in Remote Manager.
- 4. Add your device to Remote Manager if the numbers do not match:
 - a. Click Device Management > Devices.
 - b. Click **Add Devices**. The Add Devices dialog appears. You cannot use the Discover button to discover devices automatically because the devices are not available on the local network.
 - c. From the Add Devices drop-down menu, select IMEI, and enter the number.
 - d. Click Add to add the device.
 - e. Click **OK** to close the Add Devices dialog. The device appears in the Device Management list.
 - f. Click **Refresh** if the device data does not appear on its own after a short period of time. Device data appears after the first time it communicates with Remote Manager.

Device does not appear in the mobile app

Try the following if your Connect Sensor does not appear in the mobile app. You need physical access to the device to complete the steps.

Verify Bluetooth connectivity

Note the following:

- Bluetooth is on only when you manually wake Connect Sensor.
- Bluetooth is not on during report or read intervals.

First, verify the following Bluetooth settings.

- 1. Ensure that Bluetooth is enabled on your Connect Sensor:
 - a. Sign in to Remote Manager.
 - b. Click **Device Management > Devices** tab.
 - c. Right-click your Connect Sensor.
 - d. Click Configuration > Local Interface Settings.
 - e. Verify that **Bluetooth Enable** is **On**.
- 2. Verify that your mobile device supports Bluetooth Smart (low energy) and is within range of Connect Sensor.
- 3. Manually wake Connect Sensor.
- 4. Try the mobile app again; see Use the mobile app to view sensor data streams.

Reset the device

If your Connect Sensor still does not appear in the mobile app after verifying Bluetooth settings, try resetting the device.

- 1. Open Connect Sensor enclosure.
- 2. Press and release the **Reset** button.
- 3. Try the mobile app again; see Use the mobile app to view sensor data streams.

Regulatory information

FCC certifications and regulatory information

Radio frequency interface (RFI) (FCC 15.105)

This device has been tested and found to comply with the limits for Class B digital devices pursuant to Part 15 Subpart B, of the FCC rules. These limits are designed to provide reasonable protection against frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to attempt to correct the interference with one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a different circuit from the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Labeling requirements (FCC 15.19)

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

If the FCC ID is not visible when the device is installed inside another device, then the outside of the device into which the module is installed must also display a label referring to the enclosed module FCC ID.

Modifications (FCC 15.21)

Changes or modifications to this equipment not expressly approved by Digi may void the user's authority to operate this equipment.

Declaration of Conformity (DoC)

Digi has issued Declarations of Conformity for the Connect Sensor concerning emissions, EMC, and safety. For more information, see www.digi.com/resources/certifications.

Important note

Digi customers assume full responsibility for learning and meeting the required guidelines for each country in their distribution market. Refer to the radio regulatory agency in the desired countries of operation for more information.

CE mark (Europe)

The Connect Sensor is certified for use in several European countries. For information, visit www.digi.com/resources/certifications.

If the Connect Sensor is incorporated into a product, the manufacturer must ensure compliance of the final product with articles 3.1a and 3.1b of the RE Directive (Radio Equipment Directive). A Declaration of Conformity must be issued for each of these standards and kept on file as described in the RE Directive (Radio Equipment Directive).

Furthermore, the manufacturer must maintain a copy of the Connect Sensor user manual documentation and ensure the final product does not exceed the specified power ratings, antenna specifications, and/or installation requirements as specified in the user manual. If any of these specifications are exceeded in the final product, a submission must be made to a notified body for compliance testing to all required standards.

OEM labeling requirements

The CE marking must be affixed to a visible location on the OEM product.

CE labeling requirements



The CE mark shall consist of the initials "CE" taking the following form:

- If the CE marking is reduced or enlarged, the proportions given in the above graduated drawing must be respected.
- The CE marking must have a height of at least 5mm except where this is not possible on account of the nature of the apparatus.
- The CE marking must be affixed visibly, legibly, and indelibly.

Safety notices

Digi products are designed to the highest standards of safety and international standards compliance for the markets in which they are sold. However, cellular-based products contain radio devices that require specific consideration. Make sure you read and understand all of the safety notices, warnings, and cautions for this product. Digi International assumes no liability for failure to comply with these precautions.

Installation considerations

 Read all instructions before installing and powering the device and keep these instructions in a safe place for future reference. See *Nonincendive Field Wiring Diagram* for additional ATEX wiring safety guidelines.

Note When installing in a C1D2 area, you must use C1D2 listed, IP66 rated conduit and conduit fittings to maintain applicable safety ratings on the Connect Sensor.

USB (P2) (J1) and SIM (P6) connectors are intended for maintenance use within a Division 2 classified area. These connectors can only be used if the power is disconnected or the area is known to be free of ignitable concentrations of flammable gases or vapors.

All external or field wiring must be in accordance with NFPA 70 Article 501.10(B).

- Connect Sensor is intended for fixed installations only.
- Push button switches are not for normal operational or maintenance use in hazardous locations.
- If the device shows any signs of damage or malfunction when connecting the battery, remove the battery connection immediately and contact your supplier for repair or replacement.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Use only the accessories and battery provided by the manufacturer; connecting non-approved accessories and batteries may damage the device.
- Do not attempt to repair the product. Any attempt to service or repair the device by the user will void the product warranty.
- Connect Sensor must be maintained by Digi or a Digi qualified technician only. Always use the designated battery, model number 76000912, from Digi. You must remove the unit from the installation or unclassified hazard location before opening the enclosure due to the risk of batteries falling into a protected area.
- When inserting wires into the terminal block, we recommend tightening torque to 0.2N-m.
- Allowable wire size for terminal blocks is 0.5-1.5mm².

ATEX requirements

- Connect Sensor must be installed in an enclosure that provides a degree of protection not less than IP54, in accordance with EN 60079-15.
- Connect Sensor should be used in an area of not more than pollution degree 2, as defined in EN 60664-1.

Warnings: Explosion hazards

Review the following explosion hazard warnings for the Connect Sensor device.

Note The Connect Sensor device contains internal batteries.



WARNING! Connect Sensor is suitable for use in UL/cUL Class I, Division 2, Groups A, B, C, and D hazardous locations or non-hazardous locations only. Substitution of any component may impair suitability for Class I, Division 2.



WARNING - EXPLOSION HAZARD: BATTERIES MUST ONLY BE CHANGED IN AN AREA FREE OF ignitable CONCENTRATIONS.



WARNING - EXPLOSION HAZARD: DO NOT DISCONNECT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS FREE OF ignitable CONCENTRATIONS.



WARNING! Electrostatic discharge (ESD) can damage equipment and impair electrical circuitry. ESD damage occurs when electronic components are improperly handled and can result in complete or intermittent failures.

Remarque L'unité Connect Sensor contient des batteries internes.



AVERTISSEMENT! L'unité Connect Sensor est adaptée pour utilisation seulement dans des endroits non dangereux ou des endroits dangereux UL/cUL de classe I, division 2, groupes B, C et D. Le remplacement de tout composant risquerait de compromettre la convenance à la classe I, division 2.



AVERTISSEMENT - RISQUE D'EXPLOSION: LES BATTERIES DOIVENT ÊTRE REMPLACÉES DANS UN ENDROIT EXEMPT DE CONCENTRATIONS INFLAMMABLES.



AVERTISSEMENT - RISQUE D'EXPLOSION: NE DÉCONNECTEZ PAS LORSQUE LE CIRCUIT EST SOUS TENSION OU À MOINS QUE LA ZONE SOIT LIBRE DE TOUTE CONCENTRATION INFLAMMABLE.



AVERTISSEMENT! Les décharges électrostatiques peuvent endommager le matériel et nuire aux circuits électriques. Les dommages des décharges électrostatiques surviennent lorsque les composants électroniques sont mal manipulés et peuvent entraîner une défaillance complète ou intermittente.

RF exposure statement

In order to comply with RF exposure limits established in the ANSI C95.1 standards, ensure users maintain a distance from the product of no less than 20 cm (approximately 7.8 inches).

UL/cUL conformity

Conformity to UL / cUL standards in the United States and Canada is in accordance with the following:

Standard	Title	Issue date
UL2054	UL Standard for Safety for Household and Commercial Batteries	October 29, 2004
UN 38.3	Recommendations on the Transport of Dangerous Goods Manual of Tests and Criteria	2009
UL 60950-1	Safety Requirements for Electrical Equipment for Measurement, Control, and Laboratory Use	October 14, 2014

Special conditions for safe use (ATEX)

- Digi complies with the ATEX Directive to ensure a safe working environment when working with equipment in potentially explosive atmospheres.
- Connect Sensor is intended for fixed installation, where the installation is intended to minimize the risk from electrostatic discharge.
- Provision shall be made to prevent the rated voltage being exceeded by the transient disturbances of more than 140% of the peak rated voltage.
- Connect Sensor must be installed in an enclosure that provides a degree of protection not less than IP54, in accordance with EN 60079-15.
- Connect Sensor should be used in an area of not more than pollution degree 2, as defined in EN 60664-1.

Digi complies with the ATEX Directive to ensure a safe working environment when working with equipment in potentially explosive atmospheres. The Connect Sensor device is compliant to the ATEX Directive under Certification DEMKO 16 ATEX 1717X.

Applicability

Connect Sensor has been evaluated according to the following conditions. The ATEX evaluation and the special conditions in this section apply to part numbers 50001907-xx.



WARNING! Connect Sensor is suitable for use in ATEX Zone 2, Group IIC hazardous locations or non-hazardous locations only.



WARNING! The Connect Sensor unit should not be installed in locations with either pressurized or flammable materials. The battery should be replaced in unclassified areas only.

WARNING! Install Connect Sensor in an area that does not have more than pollution degree 2 as defined in EN/ IEC 60664-1.



WARNING! To avoid potentially dangerous electrostatic discharges, control all likely ignition sources, minimize the harmful effects of any accidental fire or explosion by using explosion relief and suppression systems. All zoned areas containing potentially explosive atmospheres should be clearly marked using ATEX Ex hazardous area warning signs.



WARNING! Potential electrostatic charging hazard. To avoid building up an electrostatic charge when cleaning the enclosure of this device, you must use a damp cloth moistened only with water. Do not use flammable cleaning agents.

ATEX marking

The device must include the markings described in the following table.

Mark	Description
Ex	ATEX logo

Mark	Description
(Ex) II 3 G Ex nA IIC T6 Gc	ATEX symbol and classification: • (Ex) — The ATEX symbol. This symbol indicates certification
	 for use in an explosive atmosphere. The symbols that follow it provide the details of that certified use. II — This indicates Group II (Clause 4.2). The equipment is intended for use in places with an explosive gas atmosphere other than mines susceptible to firedamp. 3 — This indicates Equipment category 3. Category 3 comprises products designed to be capable of keeping within its operational parameters, stated by the manufacturer, and based upon a normal level of protection for its intended use, considering areas in which explosive atmospheres caused by mixtures of air and gases, vapors, mists or air/dust mixtures are unlikely to occur and if they do occur, do so infrequently and for a short period of time only. G — This indicates that the Environment is based on International Electrotechnical Commission (IEC) 60079-0, Clause 29.4.
	 Ex — This indicates that the product has been evaluated for use in potentially explosive atmospheres. nA — This indicates that the product provides ignition protection by using components that are non-sparking during normal operations.
	 IIC — The Group symbol where IIC is electrical equipment for places with an explosive gas atmosphere other than mines susceptible to firedamp. T6 — This is the Temp Code, indicating a maximum surface temperature of 85° C.
	 Gc — This indicates the Equipment Protection Level. Gc means equipment for explosive gas atmospheres, having an "enhanced" level of protection, which is not a source of ignition in normal operation and which may have some additional protection to ensure that it remains inactive as an ignition source in the case of regular expected occurrences (for example, failure of a lamp).