

Programmable Power Supply

PSP-603, PSP-405, PSP-2010

USER MANUAL



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Table of Contents

SAFETY INSTRUCTIONS	2
GETTING STARTED	7
Main Features.....	8
Accessories.....	8
PSP Series Lineup.....	9
Front Panel Overview.....	10
Display Overview	12
Rear Panel Overview	14
Set Up	15
OPERATION	17
REMOTE CONTROL	26
Interface Configuration.....	28
Command Set	35
Setting for different command format	52
FAQ.....	56
APPENDIX	57
Fuse Replacement.....	57
Fan	58
Specification	59
Declaration of Conformity.....	61
INDEX	62

S SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow when operating a PSP series power supply and when keeping it in storage. Read the following before any operation to insure your safety and to keep the instrument in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the power supply.



WARNING

Warning: Identifies conditions or practices that could result in injury or loss of life.



CAUTION

Caution: Identifies conditions or practices that could result in damage to the power supply or to other property.



DANGER High Voltage



Attention Refer to the Manual



Protective Conductor Terminal



Earth (ground) Terminal

Safety Guidelines

General Guideline



- Do not place any heavy object on the power supply.
- Avoid severe impact or rough handling that could lead to damaging the power supply.
- Do not discharge static electricity to the power supply.
- Do not block or obstruct the cooling fan vent openings.
- Do not disassemble the power supply unless you are qualified as service personnel.

(Measurement categories) EN 61010-1:2001 specifies the measurement categories and their requirements as follows. The PSP series power supplies fall under category II.

- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.
- Measurement category I is for measurements performed on circuits not directly connected to Mains.

Power Supply



- AC Input voltage: 115V±10%/230V±15%, 50/60Hz.
- Connect the protective grounding conductor of the AC power cord to an earth ground, to avoid electrical shock.

Fuse



- Fuse type: Slow blow T3.15A/250V (230V input), T6.3A/250 (115V input).
- Make sure the correct type of fuse is installed before power up.

- For fire prevention, replace the fuse only with the specified type and rating.
- Disconnect the power cord before fuse replacement.
- Make sure the cause of the fuse blowout is fixed before replacing the fuse.

Cleaning

- Disconnect the power cord before cleaning.
- Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.
- Do not use chemicals or cleaners containing harsh materials such as benzene, toluene, xylene, and acetone.

Operation Environment

- Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)
- Relative Humidity: < 80%
- Altitude: < 2000m
- Temperature: 0°C to 40°C

(Pollution Degree) EN 61010-1:2001 specifies the pollution degrees and their requirements as follows. The PSP power supply falls under degree 2.

Pollution refers to “addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity”.

- Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
- Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.
- Pollution degree 3: Conductive pollution occurs, or dry, non-conductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.

GW INSTEK

SAFETY INSTRUCTIONS

Storage environment

- Location: Indoor
- Relative Humidity: < 80%
- Temperature: -10°C to 70°C

General Precautions



CAUTION

- All electronically conducting materials (cables, leads, terminals) must be sufficiently insulated.
- Connected loads should not be left unsupervised.
- Ensure adequate ventilation for operation.
- High voltages or current can be hazardous, ensure proper safety precautions are used.
- Do not use the power supply in situations where condensation may have occurred, such as where severe temperature/humidity fluctuations have occurred.

Power cord for the United Kingdom

When using the power supply in the United Kingdom, make sure the power cord meets the following safety instructions.


NOTE: This lead/appliance must only be wired by competent persons



WARNING: THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in this lead are coloured in accordance with the following code:

Green/ Yellow:	Earth
Blue:	Neutral
Brown:	Live (Phase)



As the colours of the wires in main leads may not correspond with the coloured marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with either the letter E, the earth symbol  or coloured Green/Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, a cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any exposed wiring from a cable, plug or connection that is engaged in a live socket is extremely hazardous. If a cable or plug is deemed hazardous, turn off the mains power and remove the cable, any fuses and fuse assemblies. All hazardous wiring must be immediately destroyed and replaced in accordance to the above standard.

GETTING STARTED

This chapter describes the main features, front / rear panel appearance, and how to set the power supply connection.



Main Features.....	8
Accessories.....	8
PSP Series Lineup.....	9
Front Panel Overview.....	10
Display Overview.....	12
Rear Panel Overview.....	14
Set Up	15
Power up	15
Single Power Supply Connection.....	15

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Main Features

Performance	• 200 watt output • 0~60V/0~3.5A (PSP-606) • 0~40V/0~5A (PSP-405) • 0~20V/0~10A (PSP-2010) • High resolution and accuracy
Operation	• Current, power and voltage limits. • Current limiter for short circuit and overload protection • Key lock • Percentage offset output • LCD display • Digital scroll wheel • Course and fine control • Temperature and load controlled fan • Optional European terminals
Interface	• Custom RS-232C (Please use GTL-232A cable only)

Accessories

- Power cord x1
- Instruction manual x1
- Test Lead x1


PSP Series Lineup

The PSP Series are single output programmable switching DC power supplies. There are 3 models in the PSP series lineup. For detailed information, please see the specification table on page 58.

Model	Power	Voltage	Current
PSP-603	200W	0~60V	0~3.5A
PSP-405	200W	0~40V	0~5A
PSP-2010	200W	0~20V	0~10A

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


Front Panel Overview




LCD Display Monochrome LCD display.

CE key  Clears the last value entered.

V SET key  Sets the output voltage level.




+ % key  Sets the positive percentage offset value or increases the voltage output by the positive percentage offset.

REM key  Disables remote control. Activates all keys that were disabled during remote control.


NORMAL key  Returns the output voltage to the normal preset level after + % or - % key has been pressed.

GW INSTEK

GETTING STARTED

N key		Sets the scroll wheel to Normal (coarse) mode.
-% key		Sets the negative percentage offset value or decreases the voltage output by the negative percentage offset.
LOCK		Locks the scroll wheel and panel keys.
F key		Sets the scroll to Fine mode.
Scroll Wheel		Adjustments measurement parameters and settings.
POWER Switch		Power: ON:  I OFF: 
V LIMIT		Sets the voltage limit.
ENTER		Confirms settings.
- Output Terminal		Negative terminal output.
P LIMIT		Sets the power limit.
Ground Terminal		Ground terminal.
OUTPUT key		Turns the output ON/OFF.
+ Output Terminal		Positive terminal output.
I LIMIT		Sets the current limit.

Display Overview



Voltage	Displays the voltage output.
Current	Displays the current output.
Adjustment Indicator	Displays the whether a parameter is adjusted higher of lower.
Fine Adjustment Indicator	Indicates when the scroll wheel is in fine mode.
Voltage limit/indicator	Used when adjusting the voltage limit.
Current limit/Indicator	Used when adjusting the current limit.
Power limit Indicator	Used when adjusting the power limit.


GW INSTEK

GETTING STARTED


Over temperature indicator	When the temperature exceeds the internal temperature limit, the Over temperature indicator is displayed.
Panel Lock	Front panel key lock.
Remote	Remote is displayed when in remote control mode.
Power	Displays the power output.

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Rear Panel Overview



Power
Socket/Fuse




The power socket accepts AC mains voltage, 115V or 230V.

Fuse:

T3.15A/250V (230V input),
T6.3A/250V (115V input)

Voltage Selector




Sets the mains input voltage. Left, 230V, right, 115V.

Cooling fan

Temperature or current load controlled fan. See page 58.

RS-232



Custom RS-232C connector for remote control. (Please use GTL-232A cable only)


Set Up

Power up


Panel operation




1. Set the rear panel Voltage selector to the correct position according to the AC mains voltage.



2. Connect the power cord to the socket.




3. Turn On the power switch. The display becomes active in 2~3 seconds.



Single Power Supply Connection

Panel operation

When connecting the power supply to a load, please ensure the safety guidelines below are adhered to.



**Warning**

Ensure the output is off when connecting any cables to the power supply.

Inspect all cables or wires for damage before use. Any exposed wiring from cables can be extremely hazardous. If a cable is deemed hazardous, replace before use.

1. Ensure the power supply's output is turned off before proceeding with any connections.
2. Connect the positive terminal of the power supply to the positive terminal of the load.
3. Connect the negative terminal of the power supply to the load.

OPERATION


The operation chapter describes how to set the limits, output voltage and how to adjust configuration settings.

Voltage Limit Settings.....	18
Current Limit Settings.....	19
Power Limit Settings.....	20
Voltage Output Setting	21
Output.....	22
Percentage Offset Output.....	22
Percentage Offset Settings	23
Scroll Wheel Step Resolution	24
Key Panel Lock	24
Remote Panel Lock	25

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Voltage Limit Settings

The voltage limit settings determine the maximum voltage output for the power supply.

Panel operation	1. Press the V LIMIT key. The U-const icon will flash.	
	2. Use the scroll wheel to adjust the voltage limit in the U-const field.	
	3. Press ENTER to confirm the limit setting.	
		
Range		0~Rating
Step resolution		1 volt
Max Limit	4. Hold the V LIMIT key for 2 seconds to set to the rating voltage and to exit.	
Clear	5. The CE key can be pressed to clear the voltage limit to the previous value when editing. This will also cancel editing the voltage limit and exit.	
Note	Editing the voltage limit will automatically adjust the power limit.	

Current Limit Settings


The current limit settings determine the maximum current output for the power supply.

- Panel operation

1. Press the I LIMIT key. The I-const icon will flash.

I LIMIT
2. Use the scroll wheel to adjust the current limit in the I-const field.
3. Press ENTER to confirm the limit setting.

ENTER



Range	0~Rating	
Step resolution	Fine	10mA
	Coarse	100mA

- Max Limit

4. Hold the I LIMIT key for 2 seconds to set to the rating current and to exit.

I LIMIT
- Clear

5. The CE key can be pressed to clear the current limit to the previous value when editing. This will also cancel editing the current limit and exit.


CE

Note

Editing the current limit will automatically adjust the power limit.

Power Limit Settings

The power limit settings determine the maximum power output for the power supply.

Panel operation	1. Press the P LIMIT key. The P-const icon will flash.	
	2. Use the scroll wheel to adjust the current limit in the P-const field.	
	3. Press ENTER to confirm the limit setting.	
		
Range		0~Rating
Step resolution		1 watt
Max Limit	4. Hold the P LIMIT key for 2 seconds to set to the rating power and to exit.	
Clear	5. The CE key can be pressed to clear the power limit to the previous value when editing. This will also cancel editing the power limit and exit.	
Note	Editing the power limit will automatically adjust the current limit.	


GW INSTEK

OPERATION

Voltage Output Setting

The voltage output can be changed at any time when the panel is not locked. The voltage output is limited by the voltage limit value (U-const). The voltage output can be edited regardless of whether the output is on or off.

- Panel operation
1. Use the scroll wheel to adjust the Voltage output.



Range	0~voltage limit (U-const)	
Step resolution	Fine	10 mV
	Coarse	1V

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


Output

The output can be turned on or off via the OUTPUT key. The power supply's output is off by default. The voltage output level can be changed regardless of whether the output is on or off.

Panel operation

1. Press the OUTPUT key to turn the output on or off. The output status is displayed in the lower left hand side.

OUTPUT



Percentage Offset Output

The power supply output can be increased or decreased by a percentage offset.

Panel operation

1. Turn the output on.

Percentage Output

2. Press the + % key or the - % key to increase or decrease the voltage output by a set percentage offset. (see page 23)

+%

or

-%

Normal Output


3. To cancel the percentage offset output, press the NORMAL key to revert the output to normal.

NORMAL

Percentage Offset Settings


The power supply output can be increased or decreased by a set percentage. For example, if the voltage output is 10V, and the +% value is 110, then the voltage will increased to 110%, making the final voltage 11V.

Panel operation 1. Ensure the Output is off. Page 22

2. Press the + % key or the - % key. 

3. Use the scroll wheel to adjust the % setting. 

4. Press Enter to confirm the setting and exit. 



Range (-%) 50~100
(+) 100~150

Step resolution 1 %


Exit 5. Press CE to cancel and exit. 

Scroll Wheel Step Resolution

The Step resolution of the scroll wheel can be adjusted by fine or coarse steps. Fine and Normal (Coarse) mode is applicable to limit and voltage output settings.

Fine Mode

1. Press the F key to select fine mode.
2. Fine will be displayed in the panel when in fine mode.



Normal Mode

3. Press the N key to select Normal (coarse) mode.
4. The fine icon will disappear when in coarse mode.



Key Panel Lock

The panel keys and selector wheel can be locked to prevent the settings being changed. When the panel is locked only the power key and lock key can be used.

Panel Operation


1. Press the LOCK key.



GW INSTEK

OPERATION

- When the panel is locked, locked will be displayed at the bottom of the display.



Unlock

- Press the LOCK key for two seconds.

LOCK

- The locked icon will disappear.

Remote Panel Lock


When the PSP power supply is used via remote control, the panel keys will be locked. Remote will be displayed when remote control is active. The REM key can be used to unlock the panel and return the power supply to local control.

Panel Operation

- Press the REM key.

REM

- Remote will no longer be visible on the display panel.



REMOTE CONTROL

This chapter describes how to configure the power supply and PC for RS-232C remote control (Please use GTL-232A cable only).

Interface Configuration	28
Configure RS-232C interface.....	28
RS-232C Setup	29
Command Syntax.....	33
Command Set	35
L.....	35
V	37
A.....	38
W	38
U	39
I.....	39
P.....	40
F.....	41
SV+	42
SV-	42
SU+.....	42
SU-.....	43
SI+	43
SI-	43
SP+	44
SP-	44
SUM	44
SIM.....	45
SPM	45
KF	45
KN	46
KO	46
KOE	46
KOD.....	46
EEP	47
B	47
D.....	48

GW INSTEK

REMOTE CONTROL

Q.....	48
SB+	49
SB-	49
SD+	49
SD-	49
SV	50
SU	50
SI.....	50
SP.....	51
Setting for different command format	52


원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Interface Configuration


Configure RS-232C interface

RS-232C configuration	Connector	DB-9, Male
	Baud rate	2400
	Parity	None
	Data bit	8
	Stop bit	1
	Data flow control	none

Connect the GTL-232A cable (custom RS-232C) to the rear panel port: DB-9 male connector.




Pin assignment



- 2: RxD (Receive data)
- 3: TxD (Transmit data)
- 4: +12V
- 5: GND
- 1, 6, 7, 8, 9: No connection

PC connection

Use the GTL-232A cable (custom RS-232C) only. The internal connection of GTL-232A is in the below diagram.





Note

Because DTR is controlled by software, it needs to be set beforehand. Otherwise, it may cause that 12V can't be output to PSP and no readback response.

RS-232C Setup

Background

For remote control connection, the PSP power supply series uses a custom RS-232C connection with a propriety pin out configuration. Please use the GTL-232A only. See the pin out configuration on page 28.

Operation

1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:



Start>All Programs>National Instruments>Measurement & Automation



2. From the Configuration panel access;

My System>Devices and Interfaces>Network Devices


3. Right click ASRL2: INSTR"COM2"




Note

The port number depends on which port you connected to PSP Power Supply.

Functionality
Check

4. Click the *Open Visa Test Panel*.5. Click on the *Configuration* icon.6. Select the *Serial Settings* tab.

7. Set the Baud rate to 2400.

8. Click *Apply Changes*.

9. Click on the *Configuration* icon.

10. Select the *Flow Control Settings*.

11. Click *Apply Changes*.



12. Click on the *Configuration* icon.


13. Select the *I/O Settings* tab.

14. Mark the *Enable Termination Character* checkbox. Make sure the termination character is a line feed (\n, value: xA).

15. Click *Apply Changes*.



16. Click the *Input/Output* icon.
17. Enter “L\r” in the *Select or Enter Command* drop box.
18. Click on *Query*.
19. The information about xxx will be displayed in the buffer as below.



GW INSTEK

REMOTE CONTROL

Command Syntax

Command types The power supply has 25 remote commands. Commands and queries can be written in either ASCII or hexadecimal. All ASCII commands are case sensitive. All parameters are format sensitive.

Command format	SV 10.00<CR>	1: command header
	1 2 3 4	2: space
	W<CR>	3: parameter
	1 4	4: message terminator

Return format	P100<CR><LF> or	1: command header
	<CR><CR><LF>	2: parameter
	1 2 3	3: message terminator

Parameters	Type	Example	Description
	xx	10	2 character ASCII number, no decimal places.
	xx.x	10.5	4 character ASCII number including the decimal point. One decimal place only.
	xx.xx	10.50	5 character ASCII number including the decimal point. 2 decimal places only.

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Hexadecimal Commands can be written in ASCII or Hexadecimal. Below are examples of ASCII and hexadecimal commands.

ASCII W<CR>

Hex 57 0D

Message terminators Each command must have a carriage return and line feed character as a message terminator.

All return messages are terminated with a carriage return and line feed terminator.

<CR><LF> Carriage return/line feed



Depend on firmware version, there will be different ending characters for the response code. It may appear on the display either <CR><LF> 0x0D 0x0A or <CR><CR><LF> 0x0D 0x0D 0x0A Refer to the section of "Setting for different command format" page for further information.

GW INSTEK

REMOTE CONTROL

Command Set

L	Query	
Description	The L query returns all the status values of the power supply.	
Query Syntax	L<CR>	ASCII
	4C 0D	HEX
Return Parameter	Vvv.vvAa.aaaWwww.wUuuli.iiPpppFf1f2f3f4f5f6<CR><LF>	
	Character	Description
	V	Voltage unit
	vv.vv	Voltage value (5 characters, 2 decimal places)
	A	Current Unit
	a.aaa	Current value (5 characters, 3 decimal places)
	W	Power unit
	www.w	Power value (5 characters, 1 decimal place)
	U	Voltage limit unit
	uu	Voltage limit value (2 characters, no decimal)
	I	Current limit unit
	i.ii	Current limit value (4 characters, 2 decimal places)
	P	Power limit unit
	ppp	Power limit value (3 characters, no decimal)
	F	Status Byte character

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

GW INSTEK

PSP Series User Manual

	f1f2f3f4f5f6	f1:Relay Status: 0: on, 1: off
		f2:Temperature Status 0:normal, 1:overtemp
		f3: Step mode: 0:coarse, 1:fine
		f4: Scroll wheel status: 0:locked, 1:unlocked
		f5: Remote Status: 0:normal, 1:remote
		f6: Lock Status: 0:unlocked, 1:locked
Example	L<CR> V20.00A2.500W050.0U40I5. 00P200F10I100<CR><LF>	Returns the status values of the power supply in order. 20.00V output voltage, 2.500A output current, 50W output load, 40V voltage limit, 5.00A current limit, 200W power limit, Relay off, temperature normal, fine step mode, scroll wheel unlocked, remote status normal, panel unlocked.

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

GW INSTEK

REMOTE CONTROL

V	Query	
Description	The V query returns the voltage output of the power supply.	
Query Syntax	V<CR>	ASCII
	56 0D	HEX
Return Parameter	Vvv.vv<CR><LF>	
	Character	Description
	V	Voltage unit
	vv.vv	Voltage value (5 characters, 2 decimal places)
Example	V<CR>	Returns the voltage output.
	V20.00<CR><LF>	20.00V

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

A		Query
Description	The A query returns the current output of the power supply.	
Query Syntax	A<CR>	ASCII
	41 0D	HEX
Return Parameter	Aa.aaa<CR><LF>	
	Character	Description
	A	Current unit
	a.aaa	current value (5 characters, 3 decimal places)
Example	A<CR>	Returns the current output.
	A1.000<CR><LF>	1.000A

W		Query
Description	The W query returns the load output of the power supply.	
Query Syntax	W<CR>	ASCII
	57 0D	HEX
Return Parameter	Wwww.w<CR><LF>	
	Character	Description
	W	Power unit
	www.w	power value (5 characters, 1 decimal place)
Example	W<CR>	Returns the load output.
	W050.0<CR><LF>	50W

GW INSTEK

REMOTE CONTROL

U		Query
Description	The U query returns the current voltage limit.	
Query Syntax	U<CR>	ASCII
	55 0D	HEX
Return Parameter	Uuu<CR><LF>	
	Character	Description
	U	Voltage limit unit
	uu	Voltage limit value (2 characters, no decimal)
Example	U<CR>	Returns the current voltage limit.
	U10<CR><LF>	10V

I		Query
Description	The I query returns the current current limit.	
Query Syntax	I<CR>	ASCII
	49 0D	HEX
Return Parameter	Ii.ii<CR><LF>	
	Character	Description
	I	current limit unit
	i.ii	Current limit value (5 characters, 2 decimal places)
Example	I<CR>	Returns the current current limit.
	I1.500<CR><LF>	1.5A

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

GW INSTEK

PSP Series User Manual

P	Query	
Description	The P query returns the current power load limit.	
Query Syntax	P<CR>	ASCII
	50 0D	HEX
Return Parameter	Pppp<CR><LF>	
	Character	Description
	P	Power load limit unit
	ppp	Power limit value (3 characters, no decimal)
Example	P<CR>	Returns the current load limit.
	P050<CR><LF>	50W

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

GW INSTEK

REMOTE CONTROL

F	Query	
Description	The F query returns the status of the power supply.	
Query Syntax	F<CR>	ASCII
	46 0D	HEX
Return Parameter	F f1f2f3f4f5f6<CR><LF>	
	F	Status Byte character
	f1f2f3f4f5f6	f1:Relay Status: 0: off, 1: on
		f2:Temperature Status 0:normal, 1:overtemp
		f3: Step mode: 0: normal, 1: fine
		f4: Scroll wheel status: 0:locked, 1:unlocked
		f5: Remote Status: 0:normal, 1:remote
		f6: Lock Status: 0:unlocked, 1:locked
Example	F<CR>	Returns the status of the power supply.
	F101100<CR><LF>	Relay on, temperature normal, fine step mode, scroll wheel unlocked, remote status normal, panel unlocked.

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

GW INSTEK

PSP Series User Manual

SV+		Command
Description	The SV+ command increases the voltage output by 1V (coarse mode) or 1mV(fine mode). 20.00V→21.00V (coarse mode) 20.00V→20.01V (fine mode)	
Syntax	SV+<CR>	ASCII
	53 56 2B 0D	HEX
Example	SV+<CR>	Increases the voltage output by one unit.

SV-		Command
Description	The SV- command decreases the voltage output by 1V (coarse mode) or 1mV(fine mode). 20.00V→19.00V (coarse mode) 20.00V→19.99V (fine mode)	
Syntax	SV-<CR>	ASCII
	53 56 2D 0D	HEX
Example	SV-<CR>	Decreases the voltage output by one unit.

SU+		Command
Description	The SU+ command increases the voltage limit by 1V.	
Syntax	SU+<CR>	ASCII
	53 55 2B 0D	HEX
Example	SU+<CR>	Increases the voltage limit by one unit.

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

GW INSTEK

REMOTE CONTROL

SU-		Command
Description	The SU- command decreases the voltage limit by 1V.	
Syntax	SU-<CR>	ASCII
	53 55 2D 0D	HEX
Example	SU-<CR>	Decreases the voltage limit by one unit.

SI+		Command
Description	The SI+ command increases the current limit by 10mA (coarse mode) or 1mA(fine mode). 3.01A→3.11A (coarse mode) 3.01A→3.02A (fine mode)	
Syntax	SI+<CR>	ASCII
	53 49 2B 0D	HEX
Example	SI+<CR>	Increases the current limit by one unit.

SI-		Command
Description	The SI- command decreases the current limit by 10mA (coarse mode) or 1mA(fine mode). 3.01A→2.91A (coarse mode) 3.01A→3.00A (fine mode)	
Syntax	SI-<CR>	ASCII
	53 49 2D 0D	HEX
Example	SI-<CR>	Decreases the current limit by one unit.

SP+		Command
Description	The SP+ command increases the load limit by 1W.	
Syntax	SP+<CR>	ASCII
	53 50 2B 0D	HEX
Example	SP+<CR>	Increases the load limit by one unit.

SP-		Command
Description	The SP- command decreases the load limit by 1W.	
Syntax	SP-<CR>	ASCII
	53 50 2D 0D	HEX
Example	SP-<CR>	Decreases the load limit by one unit.

SUM		Command
Description	The SUM command sets the voltage limit to the maximum rating.	
Syntax	SUM<CR>	ASCII
	53 55 4D 0D	HEX
Example	SUM<CR>	The voltage limit is set to the maximum rating.

GW INSTEK

REMOTE CONTROL

SIM		Command
Description	The SIM command sets the current limit to the maximum rating.	
Syntax	SIM<CR>	ASCII
	53 49 4D 0D	HEX
Example	SIM<CR>	The current limit is set to the maximum rating.
SPM		Command
Description	The SPM command sets the load limit to the maximum rating.	
Syntax	SPM<CR>	ASCII
	53 50 4D 0D	HEX
Example	SPM<CR>	The load limit is set to the maximum rating.
KF		Command
Description	The KF command sets the step resolution to fine mode.	
Syntax	KF<CR>	ASCII
	4B 46 0D	HEX
Example	KF<CR>	The scroll wheel step resolution is set to fine.

KN		Command
Description	The KN command sets the step resolution to normal (coarse) mode.	
Syntax	KN<CR>	ASCII
	4B 4E 0D	HEX
Example	KN<CR>	The scroll wheel step resolution is set to normal (coarse).

KO		Command
Description	The KO command toggles the output On or Off.	
Syntax	KO<CR>	ASCII
	4B 4F 0D	HEX
Example	KO<CR>	Output is toggled On→Off or Off→On

KOE		Command
Description	The KOE command turns the output On.	
Syntax	KOE<CR>	ASCII
	4B 4F 45 0D	HEX
Example	KOE<CR>	Output is turned on.

KOD		Command
Description	The KOD command turns the output Off.	
Syntax	KOD<CR>	ASCII
	4B 4F 44 0D	HEX
Example	KOD<CR>	Output is turned off.

GW INSTEK

REMOTE CONTROL

EEP		Command
Description	The EEP command saves the settings to internal memory. The settings will recalled upon the next startup.	
Syntax	EEP<CR>	ASCII
	45 45 50 0D	HEX
Example	EEP<CR>	Save settings to memory.
B		Query
Description	The B query returns the +% value.	
Query Syntax	B<CR>	ASCII
	42 0D	HEX
Return Parameter	Bbbb<CR><LF>	
	Character	Description
	B	+% unit
	Bbb	+% value 100~150 (3 characters, no decimal)
Example	B<CR>	Returns the +%unit and value
	B150<CR><LF>	150 %

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

D		Query
Description	The D query returns the -% value.	
Query Syntax	D<CR>	ASCII
	44 0D	HEX
Return Parameter	Bbbb<CR><LF>	
	Character	Description
	D	-% unit
	Dddd	-% value 50~100 (3 characters, no decimal)
Example	D<CR>	Returns the -%unit and value
	D050<CR><LF>	50 %

Q		Query
Description	The Q query returns the status of -% and +% offsets.	
Query Syntax	Q<CR>	ASCII
	51 0D	HEX
Return Parameter	Qq1q2q3q4q5q6<CR><LF>	
	Q	Percentage Offset Character
	q1q2q3q4q5q6	q1 :-% status: 0: off, 1: on
		q2 : +% status 0:off, 1:on
		q3-q6 : Not used

GW INSTEK

REMOTE CONTROL

SB+	Command	
Description	The SB+ command increases the +% offset by 1%.	
Syntax	SB+<CR>	ASCII
	53 42 2B 0D	HEX
Example	SB+<CR>	Increase the +% offset by 1 percent.

SB-	Command	
Description	The SB- command decreases the +% offset by 1%.	
Syntax	SB-<CR>	ASCII
	53 42 2D 0D	HEX
Example	SB-<CR>	Decrease the +% offset by 1 percent.

SD+	Command	
Description	The SD+ command increases the -% offset by 1%.	
Syntax	SD+<CR>	ASCII
	53 44 2B 0D	HEX
Example	SD+<CR>	Increase the -% offset by 1 percent.

SD-	Command	
Description	The SD- command decreases the -% offset by 1%.	
Syntax	SD-<CR>	ASCII
	53 44 2D 0D	HEX
Example	SD-<CR>	Decrease the -% offset by 1 percent.

SV		Command
Description	The SV command sets the voltage output level.	
Syntax	SV <parameter> <CR>	ASCII
	53 56 <parameter> 0D	HEX
Parameter	<parameter>	Description
	xx.xx	Voltage value(5 characters, 2 decimal places)
Example	SV 10.50<CR>	Sets the voltage output to 10.5V.

SU		Command
Description	The SU command sets the voltage output limit.	
Syntax	SU <parameter> <CR>	ASCII
	53 55<parameter> 0D	HEX
Parameter	<parameter>	Description
	xx	Voltage value(2 characters, no decimal)
Example	SU 11<CR>	Sets the voltage limit to 11V.

SI		Command
Description	The SI command sets the current limit. The power limit will be automatically altered to suit.	
Syntax	SI <parameter> <CR>	ASCII
	53 49<parameter> 0D	HEX
Parameter	<parameter>	Description
	x.xx	Current limit value(4 characters, two decimal places)
Example	SI 1.10<CR>	Sets the current limit to 1.10A.

GW INSTEK

REMOTE CONTROL

SP	Command	
Description	The SP command sets the power limit. When the power limit is changed the current limit will be automatically altered to suit.	
Syntax	SP <parameter> <CR>	ASCII
	53 50<parameter> 0D	HEX
Parameter	<parameter>	Description
	xxx	Power limit value(3 characters, no decimal)
Example	SP 100<CR>	Sets the power limit to 100W.


원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Setting for different command format

Background

UART setting can be used to deter if command format to be modified for the PSP with firmware V1.66 or above.

Before setting, please make sure that the connection between a computer and the PSP is normal by entering "L" from terminal (2400/ N8/ 1 or 9600/ N/ 8/1) and get the response message as shown in the diagram below.



Note

Please complete the settings within 15 seconds after power is on because setting can't be changed after 15 seconds.

The setting procedure only needs to be executed once. Afterward, the device will be kept in the same setting mode when the device is turned on every time.


GW INSTEK

REMOTE CONTROL

Operation


1. Set PSP1 with setting A (see note below), then Enter "URPSP1".

The PSP's response is shown in the diagram below and has beep sound.



2. Set PSP2 without A(see note below), then Enter "URPSP2".


The PSP's response is shown in the diagram below and has beep sound.



Note

The difference between firmware V1.55 and the current firmware version for shipping PSP (V1.66).

When the letter "A" appears on the PSP's display as shown in the diagram below, it means that it is setting with A and the terminator for response message is 0x0D 0x0D 0x0A. Otherwise, it is 0x0D 0x0A.



When setting is with A, the terminator for responded message on the display is

0x0D 0x0D 0x0A as shown in the diagram below.

Communication			
ASCII	HEX	Decimal	Binary
09:56:18.587 [TX]	-	56 0D	
09:56:18.603 [RX]	-	56 31 32 2E 30 30 0D 0D 0A	
09:56:27.012 [TX]	-	56 0D	
09:56:27.028 [RX]	-	56 30 35 2E 30 30 0D 0D 0A	
09:56:30.395 [TX]	-	41 0D	
09:56:30.410 [RX]	-	41 30 2E 30 30 30 0D 0D 0A	
09:56:31.495 [TX]	-	57 0D	
09:56:31.509 [RX]	-	57 30 30 30 2E 30 0D 0D 0A	
09:56:33.425 [TX]	-	49 0D	
09:56:33.441 [RX]	-	49 33 2E 35 30 0D 0D 0A	
09:57:06.929 [TX]	-	49 0D	
09:57:06.946 [RX]	-	49 30 2E 37 30 0D 0D 0A	

When setting is without A, the terminator for responded message on the display is 0x0D 0x0A as shown in the diagram below.

Communication			
ASCII	HEX	Decimal	Binary
09:59:54.214 [TX]	-	56 0D	
09:59:54.229 [RX]	-	56 31 32 2E 30 30 0D 0A	
09:59:58.715 [TX]	-	56 0D	
09:59:58.730 [RX]	-	56 35 2E 3C 30 0D 0A	
10:00:01.394 [TX]	-	41 0D	
10:00:01.408 [RX]	-	41 30 2E 3C 30 30 0D 0A	
10:00:01.995 [TX]	-	57 0D	
10:00:02.008 [RX]	-	57 30 2E 3C 0D 0A	
10:00:03.051 [TX]	-	55 0D	
10:00:03.068 [RX]	-	55 36 30 0D 0A	
10:00:03.652 [TX]	-	49 0D	
10:00:03.667 [RX]	-	49 33 2E 3E 30 0D 0A	

On the other hand, you can judge if setting is with A by the readback voltage value.

When you see the readback voltage value insert an "0" digit before first digit if for voltage value less than 10, it means that setting is with A.

For example, if readback voltage value is 5V as the diagram shown below, it means that setting is with A.

GW INSTEK

REMOTE CONTROL

ASCII	HEX	Decimal	Binary
09:55:18.587 [TX]	-	V	
09:55:18.603 [RX]	-	V12.00	
09:55:27.012 [TX]	-	V	
09:55:27.028 [RX]	-	V05.00	
09:55:30.395 [TX]	-	A	
09:55:30.410 [RX]	-	A0.000	
09:55:31.495 [TX]	-	W	
09:55:31.509 [RX]	-	W000 0	

Otherwise, it is setting without A as the diagram shown below.

Communication			
ASCII	HEX	Decimal	Binary
09:59:54.214 [TX]	-	V	
09:59:54.229 [RX]	-	V12.00	
09:59:58.715 [TX]	-	V	
09:59:58.730 [RX]	-	V5.00	
10:00:01.394 [TX]	-	A	
10:00:01.408 [RX]	-	A0.000	
10:00:01.995 [TX]	-	W	
10:00:02.008 [RX]	-	W0.0	

FAQ

Q1. No Display.

A1.

- Ensure the power supply is turned on.
- Ensure the mains cable is properly inserted and power is on.
Check the fuse assembly.

Q2. The front panel keys are inactive.

A2.


- The panel lock or remote control is activated. See page 24, 25.

For more information, contact your local dealer or GWInstek at www.gwinstek.com.tw / marketing@goodwill.com.tw.


APPENDIX

Fuse Replacement

- Step 3. Take off the power cord and remove the fuse socket using a minus driver.



4. Replace the fuse in the holder.



Rating T3.15A/250V

Fan

Cooling fan

The PSP has a temperature or load controlled fan. The fan will be activated when the temperature or current exceeds a set level (model specific).

Model	PSP-405	PSP-603	PSP-2010
Fan On	45 °C±5 °C	45 °C±5 °C	45 °C±5 °C
	2.10A±50mA	1.40±50mA	2.10±50mA
Fan Off	40 °C±5 °C	40 °C±5 °C	40 °C±5 °C
	1.80A±50mA	1.20A±50mA	1.80A±50mA

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Specification

Model	PSP-603	PSP-405	PSP-2010
Operating voltage	115/230 VAC ±15%		
Power frequency	50/60 Hz		
Power consumption	approx. 420VA max.		
Power output	200W max.		
Output voltage	0~60VDC 20mV resolution	0~40VDC 10mV resolution	0~20VDC 10mV resolution
Program Accuracy	±0.05%±4 digits	±0.05%±3 digits	±0.05%±3 digits
Output Current	0~3.5A 10mA resolution	0~5A 10mA resolution	0~10A 10mA resolution
Program Accuracy	±0.1%±5 digits	±0.1%±5 digits	±0.3%±10 digits
Voltage Load Regulation	≤ 10 mV		
Current Load Regulation	≤ 5 mA		
Voltage Line Regulation.	≤ 0.05%		
Current Line Regulation	≤ 0.05%		
Ripple Voltage	≤ 20 mV rms		
Ripple Current	≤ 10 mArms		
Readback Resolution(Meter)	20mV 2mA	10mV 2mA	10mV 5mA
Response Time	Rise Time	≤150ms(≤95% rating load)	
	Full Time	≤150ms(≥10% rating load)	
Recovery Time	30ms(50% Load Change, Minimum load 0.5A)		
Readback Accuracy (Meter)			
Voltage	±0.05%±4 digits	±0.05%±3 digits	±0.05%±3 digits

GW INSTEK

PSP Series User Manual

Current	±0.1%±5 digits	±0.1%±5 digits	±0.3%±10 digits
Digital Display	Multi-line LCD with background lighting		
AC fuse	Slow-blow T6.3A/250V for 115V, T3.15A/250V for 230V		
Weight	Approx. 4 kg		
Dimensions	Approx. 225×100×305 mm		
(W × H × D)	(excluding stand and power cable)		

원문: GW Instek PSP Series PSP User Manual · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Declaration of Conformity

We

GOOD WILL INSTRUMENT CO., LTD.

Declare that the below mentioned product

Model Number: PSP-405, PSP-603, PSP-2010

satisfies all technical relations application to the product within the scope of council:

Directive: 2014/30/EU, 2014/35/EU, 2011/65/EU, 2012/19/EU

The above product is in conformity with the following standards or other normative documents:

◎ EMC	
EN 61326-1: EN 61326-2-1:	Electrical equipment for measurement, control and laboratory use -- EMC requirements (2013)
Conducted & Radiated Emission EN 55011: 2009+A1:2010 Class A	Electrical Fast Transients EN 61000-4-4: 2012
Current Harmonics EN 61000-3-2: 2014	Surge Immunity EN 61000-4-5: 2014
Voltage Fluctuations EN 61000-3-3:2013	Conducted Susceptibility EN 61000-4-6: 2014
Electrostatic Discharge EN 61000-4-2: 2009	Power Frequency Magnetic Field EN 61000-4-8: 2010
Radiated Immunity EN 61000-4-3: 2006+A2: 2010	Voltage Dip/ Interruption EN 61000-4-11: 2004
◎ Safety	
Low Voltage Equipment Directive 2014/35/EU	
Safety Requirements	EN 61010-1: 2010

GOOD WILL INSTRUMENT CO., LTD.

No. 7-1, Jhongsing Road, Tucheng Dist., New Taipei City 236, Taiwan

Tel: +886-2-2268-0389

Fax: +866-2-2268-0639

Web: www.gwinstek.com

Email: marketing@goodwill.com.tw

GOOD WILL INSTRUMENT (SUZHOU) CO., LTD.

No. 521, Zhujiang Road, Snd, Suzhou Jiangsu 215011, China

Tel: +86-512-6661-7177

Fax: +86-512-6661-7277

Web: www.instek.com.cn

Email: marketing@instek.com.cn

GOOD WILL INSTRUMENT EURO B.V.

De Run 5427A, 5504DG Veldhoven, The Netherlands

Tel: +31(0)40-2557790

Fax: +31(0)40-2541194

Email: sales@gw-instek.eu

I NDEX

Caution symbol	2, 29	Operation	17
Cleaning the instrument	4	Output	22
Coarse mode	24	panel keys	
Command		faq	56
format	33	Percentage offset output	22
parameter	33	Percentage offset settings	23
syntax	33	Power limit settings	20
terminators	34	Power supply	
Current limit settings	19	safety instruction	3
Display overview	12	Power up sequence	15
EN61010		PSP series lineup	9
measurement category	3	Rear panel overview	14
pollution degree	4	remote control	26
Fine mode	24	Remote Panel Lock	25
front panel overview	10	RS-232C configuration	28
fuse		Safety guidelines	3
replacing	57	service contact point	56
Fuse		Single power supply	
safety instruction	3	connection	15
General precautions	5	Step resolution	24
ground symbol	2	Storage environment	5
Key panel lock	24	UK power cord	6
Main features	8	Voltage limit settings	18
No display		Voltage output settings	21
faq	56	Warning symbol	2
Normal mode	24		
Operating environment	4		