DIGI

Connect EZ 4 WS

User Guide

Firmware version 25.5

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Revision history—80002607

Revision	Date	Description
B	November 2025	Updated the color of the power LED • Front panel and LEDs • Step 2: Connect the power cord and turn the device on
A	August 2025	Initial release

Trademarks and copyright

Digi, Digi International, and the Digi logo are trademarks or registered trademarks in the United States and other countries worldwide. All other trademarks mentioned in this document are the property of their respective owners.

© 2025 Digi International Inc. All rights reserved.

Disclaimers

Information in this document is subject to change without notice and does not represent a commitment on the part of Digi International. Digi provides this document "as is," without warranty of any kind, expressed or implied, including, but not limited to, the implied warranties of fitness or merchantability for a particular purpose. Digi may make improvements and/or changes in this manual or in the product(s) and/or the program(s) described in this manual at any time.

Warranty

To view product warranty information, go to the following website:

www.digi.com/howtobuy/terms

Customer support

Gather support information: Before contacting Digi technical support for help, gather the following information:

- Product name and model
- Product serial number (s)
- Firmware version
- Operating system/browser (if applicable)
- Logs (from time of reported issue)
- Trace (if possible)
- Description of issue
- Steps to reproduce

Contact Digi technical support: Digi offers multiple technical support plans and service packages. Contact us at +1 952.912.3444 or visit us at www.digi.com/support.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Feedback

To provide feedback on this document, email your comments to

[redacted]

Include the document title and part number (Digi Connect EZ 4 WS User Guide, [redacted]) in the subject line of your email.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Contents

Digi Connect EZ 4 WS User Guide

Essential performance 10
Target audience 10
Applicable hardware 10
DAL OS Vulnerability Patch Policy 10

Get started with Connect EZ 4 WS

Before you begin: Register your Connect EZ 4 WS 13
Step 1: Gather the product components 13
Step 2: Connect the power cord and turn the device on 13
Step 3: Connect the device to a site network or your computer 20
Connect the device to your computer or your site's network with an Ethernet cable 20
Connect to the device to your site's network with Wi-Fi 21
Step 4: Connect to the web UI and update the Connect EZ 4 WS firmware 21
Step 5: Configure serial ports 22
Step 6: Connect to Digi Remote Manager 22

Hardware reference for the Connect EZ 4 WS

Front panel and LEDs 25
Back panel 27
Top panel 27
Bottom panel 27
Connect EZ 4 WS hardware components 28
Connect EZ 4 WS LED functions and descriptions 29
Connect equipment to the Connect EZ serial port 30
Connect equipment to a serial port 30
Serial connector pinout 31
Power the device on and off 32
Power on the device using a power cord 32
Power on the device using a PoE-enabled Ethernet port 33
Power off the device 33
Power on LED sequence 34
Power options for the Connect EZ 4 WS 35
Power and cabling requirements 35
Power loss and Connect EZ 4 WS configuration 35
Mount the Connect EZ 4 WS 35
Use the RESET button to reset your device to the factory defaults 36
Change the password on the Connect EZ 37

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Discover the device's IP address 37
Discover the IP address using the Digi Navigator 38
Discover the IP address from the console port 38
Manually configure the PC and assign an IP address to the device 39
Connect to the local Web UI on the Connect EZ 40
Installation requirements 41
Cleaning and inspection 41
Safety and regulatory standards 42
Recycling and disposal 42
Environmental information 42
Symbol Definitions 43

Firmware configuration

Review Connect EZ 4 WS default settings 47
Local Web UI 47
Digi Remote Manager 47
Default interface configuration 47
Other default configuration settings 47
Change the factory-assigned administrator password for a device to a unique password 48
Change the default SSID and pre-shared key for the preconfigured Wi-Fi access point 48
Configuration methods 50
Using Digi Remote Manager 50
Access Digi Remote Manager 50
Using the local web interface 51
Review the dashboard 52
Log out of the web interface 52
Review the dashboard 53
Use the local REST API to configure the Connect EZ 4 WS device 54
Use the GET method to return device configuration information 54
Use the POST method to modify device configuration parameters and list arrays 57
Use the DELETE method to remove items from a list array 57
Access the terminal screen from the web UI 58
Using the command line 60
Access the command line interface 60
Log in to the command line interface 60
Exit the command line interface 61

Interfaces

Define a static IP address 63
IP address and netmask 63
Local Area Networks (LANs) 64
About Local Area Networks (LANs) 65
Configure a Local Area Network (LAN) 65
Configure the ETH1 port as a LAN or in a bridge 73
Change the default LAN subnet 80
Example: Configure two LANs 81
Example: Configure two LANs 86
Show LAN status and statistics 88
Delete a LAN 89
DHCP servers 89
Default services listening on LAN1 port 91
Virtual LANs (VLANs) 92

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Create a trunked VLAN route 121
Create a VLAN using switchport mode 123
Bridging 126
Configure a bridge 127
Configure a TCP connection timeout 130

Serial port

Default serial port configuration 132
Serial mode options 134
View serial port information 137
Default serial port configuration 139
Baud rate options 140
Configure Login mode for a serial port 141
Configure Remote Access mode for a serial port 146
Additional advanced settings for Remote Access mode 147
Configure Application mode for a serial port 148
Configure ITY dial-in mode for a serial port 151
Configure UDP serial mode for a serial port 155
Configure Modem emulator mode for a serial port 161
Configure Modbus mode for a serial port 164
Configure RealPort mode using the Digi Navigator 166
Installation and configuration process 166
Digi Navigator features 169
Install the Digi Navigator 170
Configure RealPort on a Digi device from the Digi Navigator 171
Install and configure RealPort on your computer 173
Digi Navigator device discovery process 175
Services used to discover a device when connected to a network 176
Digi Navigator application features 177
Copy a serial port configuration 179
Advanced RealPort configuration without using the Digi Navigator 182
Windows Operating System 183
Linux Operating System 191
Download the RealPort driver 193
Configure RealPort on your computer 195
Configure the serial port for RealPort mode 196
Configure the RealPort service 200
Disconnect a user from a serial port 203
Show serial port status and statistics 204
Serial Status page 206
Review the serial port message log 208
Search for a port 211

Wi-Fi

Wi-Fi configuration 216
Default access point SSID and password 216
Default Wi-Fi configuration 218
Configure the Wi-Fi radio's channel 221
Configure the Wi-Fi radio to support DFS channels in client mode 223
Required configuration items 223
Configure the Wi-Fi radio's band and protocol 226
Configure the Wi-Fi radio's transmit power 228

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure an open Wi-Fi access point 339
Configure a Wi-Fi access point with personal security 340
Configure a Wi-Fi access point with enterprise security 341
Isolate Wi-Fi clients 342
Isolate clients connected to the same access point 342
Isolate clients connected to different access points 343
Configure a Wi-Fi client and add client networks 343
Show Wi-Fi access point status and statistics 344
Show Wi-Fi client status and statistics 345

Routing

IP routing 346
Configure a static route 346
Delete a static route 347
Configure a routing policy 347
Routing services 348
Configure routing services 348
Show the routing table 349
Virtual Router Redundancy Protocol (VRRP) 349
Configure VRRP 350
Show VRRP status and statistics 350

Virtual Private Networks (VPN)

IPsec 351
IPsec data protection 352
IPsec mode 352
Internet Key Exchange (IKE) settings 352
Authentication 353
Configure an IPsec tunnel 353
Configure IPsec failover 354
Show IPsec status and statistics 355
Debug an IPsec configuration 355
Configure a Simple Certificate Enrollment Protocol client 356
Example: SCEP client configuration with Fortinet SCEP server 357
Show SCEP client status and information 358
OpenVPN 358
Configure an OpenVPN server 359
Configure an OpenVPN Authentication Group and User 359
Configure an OpenVPN client by using an .ovpn file 360
Configure an OpenVPN client without using an .ovpn file 360
Show OpenVPN server status and statistics 361
Show OpenVPN client status and statistics 361
Generic Routing Encapsulation (GRE) 362
Configuring a GRE tunnel 362
Show GRE tunnels 363
Example: GRE tunnel over an IPSec tunnel 363
Dynamic Multipoint VPN (DMVPN) 364
Configure a DMVPN spoke 365
L2TP 366
Configure a PPP-over-L2TP tunnel 367
L2TP with IPsec 367
Show L2TP tunnel status 368

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

L2TPv3 Ethernet 413
Configure an L2TPv3 tunnel 413
Show L2TPv3 tunnel status 417
MACsec 418
Configure a MACsec tunnel 418
WireGuard VPN 421
Configure the WireGuard VPN 421

Services

Allow remote access for web administration and SSH 431
Configure the web administration service 434
Configure SSH access 440
Use SSH with key authentication 450
Generating SSH key pairs 450
Configure telnet access 453
Configure DNS 456
Show DNS server 457
Simple Network Management Protocol (SNMP) 458
SNMP Security 459
Configure Simple Network Management Protocol (SNMP) 460
Download MIBs 470
Location information 472
Enable modem GNSS support 473
Configure the device to use a user-defined static location 475
Configure the device to accept location messages from external sources 477
Forward location information to a remote host 480
Configure geofencing 482
Show location information 486
Modbus gateway 487
Configure the Modbus gateway 488
Modbus hardening 494
Show Modbus gateway status and statistics 497
System time synchronization 500
Configure the system time synchronization 500
Manually set the system date and time 504
Network Time Protocol 505
Configure the device as an NTP server 505
Show status and statistics of the NTP server 509
Configure a multicast route 511
Ethernet network bonding 514
Enable service discovery (mDNS) 518
Use the iPerf service 521
Example performance test using iPerf3 526
Configure the ping responder service 528
Example performance test using iPerf3 529

Applications

Develop Python applications 532
Set up the Connect EZ 4 WS for Python development 533
Create and test a Python application 535
Python modules 537
Set up the Connect EZ 4 WS to automatically run your applications 539

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure scripts to run automatically
Show script information
Stop a script that is currently running
Start an interactive Python session
Run a Python application at the shell prompt
Configure scripts to run manually
Task one: Upload the application
Task two: Configure the application to run automatically
Start a manual script
Python versions and corresponding DAL OS firmware versions

User authentication

Connect EZ 4 WS user authentication
User authentication methods
Add a new authentication method
Delete an authentication method
Rearrange the position of authentication methods
Authentication groups
Change the access rights for a predefined group
Add an authentication group
Delete an authentication group
Local users
Change a local user's password
Configure a local user
Delete a local user
Terminal Access Controller Access-Control System Plus (TACACS+)
TACACS+ user configuration
TACACS+ server failover and fallback to local authentication
Configure your Connect EZ 4 WS device to use a TACACS+ server
Remote Authentication Dial-In User Service (RADIUS)
RADIUS user configuration
RADIUS server failover and fallback to local configuration
Configure your Connect EZ 4 WS device to use a RADIUS server
LDAP
LDAP user configuration
LDAP server failover and fallback to local configuration
Configure your Connect EZ 4 WS device to use an LDAP server
Configure serial authentication
Disable shell access
Set the idle timeout for Connect EZ 4 WS users
Example user configuration
Example 1: Administrator user with local authentication
Example 2: RADIUS, TACACS+, and local authentication for one user

Firewall

Firewall configuration
Create a custom firewall zone
Configure the firewall zone for a network interface
Delete a custom firewall zone
Port forwarding rules
Configure port forwarding
Delete a port forwarding rule

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Packet filtering
Configure packet filtering
Enable or disable a packet filtering rule
Delete a packet filtering rule
Configure custom firewall rules
Configure captive portals
Delete captive portals
Web filtering
Configure web filtering with Cisco Umbrella
Configure web filtering with manual DNS servers
Verify your web filtering configuration
Show web filter service information

Containers

Use Digi Remote Manager to deploy and run containers
Use an automation to start the container
Upload a new LXC container
Configure a container
Starting and stopping the container
Starting the container
Stopping the container
View the status of containers
Show status of all containers
Show status of a specific container
Schedule a script to run in the container
Create a custom container
Create the custom container file
Test the custom container file

System administration

Review device status
Configure system information
Update the system firmware
Manage firmware updates using Digi Remote Manager
Python and DAL OS firmware updates
Certificate management for firmware images
Downgrading
Dual boot behavior
External storage
Configure external storage on a network server
Configure log location
Reboot your Connect EZ 4 WS device
Reboot your device immediately
Schedule reboots of your device
Device reset
Things to know
Compare device reset modes
Configure device reset behavior
Configure your device to use custom default settings after a device reset
Trigger a Config Reset using the RESET button
Trigger a Config Reset in the device Web UI
Trigger a Config Reset using the CLI

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Trigger a factory reset using the RESET button 258
Locate the device by using the Find Me feature 260
Enable FIPS mode 261
Configuration files 263
Save configuration changes 263
Save configuration to a file 264
Restore the device configuration 265
Schedule system maintenance tasks 268
Disable device encryption 272
Re-enable cryptography after it has been disabled 273
Configure the speed of your Ethernet ports 276
Watchdog service 277
Configure the Watchdog service 277
View Watchdog metrics 280

Monitoring

Configure the monitoring of a device's internet connection 282
Intelliflow 285
Enable Intelliflow 286
Configure service types 288
Configure domain name groups 290
Use Intelliflow to display average CPU and RAM usage 292
Use Intelliflow to display top data usage information 294
Use Intelliflow to display data usage by host over time 296
Configure NetFlow Probe 297

Central management

Digi Remote Manager support 301
Certificate-based enhanced security 302
Configure your device for Digi Remote Manager support 303
Collect device health data and set the sample interval 310
Event log upload to Digi Remote Manager 313
Reach Digi Remote Manager on a private network 314
Reverse method 315
Proxy server method 316
VPN tunnel method 316
Log in to Digi Remote Manager 316
Use Digi Remote Manager to view and manage your device 317
Add a device to Remote Manager 317
Add a device to Remote Manager using information from the label 317
Add a device to Remote Manager using your Remote Manager login credentials 318
Configure multiple Connect EZ 4 WS devices by using Digi Remote Manager configurations 319
View Digi Remote Manager connection status 320
Learn more 321

File system

The Connect EZ 4 WS local file system 322
Display directory contents 323
Create a directory 324
Display file contents 325

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Copy a file or directory
Move or rename a file or directory
Delete a file or directory
Upload and download files
Upload and download files by using the WebUI
Upload and download files by using the Secure Copy command
Upload and download files using FTP

Diagnostics

Perform a speedtest
Generate a support report
Support report overview
View system and event logs
View System Logs
View Event Logs
Configure syslog servers
Configure options for the event and system logs
Configure an email notification for a system event
Configure an SNMP trap for a system event
Analyze network traffic
Configure packet capture for the network analyzer
Example filters for capturing data traffic
Capture packets from the command line
Stop capturing packets
Show captured traffic data
Save captured data traffic to a file
Download captured data to your PC
Clear captured data
Use the ping command to troubleshoot network connections
Ping to check internet connection
Stop ping commands
Use the traceroute command to diagnose IP routing problems

Command line interface

Access the command line interface
Log in to the command line interface
Exit the command line interface
Execute a command from the web interface
Display help for commands and parameters
The help command
The question mark (?) command
Display help for individual commands
Use the Tab key or the space bar to display abbreviated help
Auto-complete commands and parameters
Available commands
Use the scp command
Display status and statistics using the show command
show config
show system
show network
Device configuration using the command line interface
Execute configuration commands at the root Admin CLI prompt

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Display help for the config command from the root Admin CLI prompt
Configuration mode
Enable configuration mode
Enter configuration commands in configuration mode
Save changes and exit configuration mode
Exit configuration mode without saving changes
Configuration actions
Display command line help in configuration mode
Move within the configuration schema
Manage elements in lists
Enter strings in configuration commands
Example: Create a new user by using the command line
Command line reference
air calibrate
air calibration-reset
analyzer clear
analyzer save
analyzer start
analyzer stop
cat
clear dhcp-lease ip-address
clear dhcp-lease mac
cp
device state
grep
help
ls
mkdir
monitoring metrics upload
monitoring
monitoring metrics upload
more
mv
ping
poweroff
pyroshell
reboot
rm
scp
config directory: show command
show air
show analyzer
show arp
show bluetooth-scanner log
show bluetooth-scanner registry
show bluetooth-scanner static-candidate
show bluetooth-scanner static-confirmed
show cloud
show config
show containers
show dhcp-lease
show dio
show dns
show eth
show event

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

show hotspot 208
show ipsec 208
show l2p lac 208
show l2p tos 209
show l2path 209
show localtcp 209
show log 209
show manufacture 210
show modbus-gateway 210
show nemo 210
show network 210
show ntp 210
show openvpn client 210
show openvpn server 210
show route 210
show soap-client 210
show scripts 210
show serial 210
show system 210
show version 210
show vrrp 210
show web-filter 210
show wifi ap 210
show wifi client 211
show wifi-scanner 211
show wifi-scanner blocklist 211
show wifi-scanner candidates 211
show wifi-scanner log 212
iperf 212
ssh 212
system backup 213
system cloud register 213
system custom-default-config current 213
system custom-default-config file 214
system custom-default-config remove 214
system disable-cryptography 214
system duplicate-firmware 214
system factory-erase 215
system firmware update 215
system power ignition off delay 215
system reboot 215
system script start 215
system script stop 216
system serial clear 216
system serial copy 216
system serial ipport 217
system serial restart 217
system serial save 217
system serial show 217
system storage format 218
system storage mount 218
system storage show 218
system storage unmount 218
system support-report 219
system time set 219

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

system time sync 21
system time local 21
ssl 21
telnet 22
traceroute 22
vlydi 22

Safety Information

Warnings, cautions, and notes 23
Important safety information 23
Smoke 23
Avoid contact with electrical current 23
Installation and configuration 23
Connecting to IT networks 24
Security 24
Magnetic fields 24
Equipment connections 24

Safety warnings

English 25
Bulgarian—Български 25
Croatian—Hrvatski 25
French—Français 26
Greek—Ελληνικά 27
Hungarian—Magyar 27
Italian—Italiano 28
Latvian—Latviešu 28
Lithuanian—Lietuvių 29
Polish—Polski 29
Portuguese—Português 30
Slovak—Slovák 30
Slovenian—Slovenski 30
Spanish—Español 31

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Digi Connect EZ 4 WS User Guide

This guide provides reference and usage information for the Connect EZ 4 WS.

The Connect EZ 4 WS, an electronic data transmitting device, is intended to provide electronic transfer of device data without controlling or altering the function or parameters of any device to which it is connected. As part of a network system, the Connect EZ 4 WS is intended to receive and transmit data to and from devices to which it is connected. It does not incorporate a therapeutic or diagnostic function.

The Connect EZ 4 WS is intended for use as an ITE device for data transmission only.



Any use of this product beyond the scope of the above description is at the customer's sole risk and responsibility.

Essential performance

The essential performance of the Connect EZ 4 WS is to not compromise the data coming from the attached device (excluding issues which might cause delayed delivery of data or data not being delivered), and to not compromise the operation of the connected device.

The expected service life of the Connect EZ 4 WS is 7 years.

Target audience

This guide is intended for those who are responsible for setting up and configuring Digi devices, and who are trained to operate the equipment connected to the Connect EZ 4 WS to ensure that the product is safe and fully functional.

Applicable hardware

This user guide contains information for the Connect EZ 4 WS model. Hardware features are shown in the table below:

Name	SKU	Serial ports	Ethernet ports	Wi-Fi	PoE
Connect EZ 4 Medical	EZ04-WS00	4	2	X	X

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

DAL OS Vulnerability Patch Policy

Digi has created a vulnerability patch policy to document the guidelines and procedures we plan to take to identify, assess, and remediate security vulnerabilities in our DAL OS firmware integrated into Enterprise (EX), Industrial (IX) and Transportation routers (TX), device and serial servers (Connect EZ), console servers and USB-connected devices. Specifically, this policy outlines how quickly and effectively patches need to be applied to mitigate risks from potential threats. The policy protects against cyberattacks but also ensures that our firmware is in compliance with regulatory standards.

The DAL Vulnerability Patch Policy is documented on the digi.com website, and covers the following topics:

- Objective
- Scope
- Audience
- Introduction
- Reporting Potential Vulnerabilities
- Assessing Potential Vulnerabilities
- Information and Resolution Timelines
- Resolution of Potential Vulnerabilities
- Receiving Information on Potential Vulnerabilities

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Get started with Connect EZ 4 WS

This section explains what comes with each Connect EZ model, how to install the necessary software, and how to connect the hardware.

Before you begin: Register your Connect EZ 4 WS 19
Step 1: Gather the product components 19
Step 2: Connect the power cord and turn the device on 20
Step 3: Connect the device to a site network or your computer 21
Step 4: Connect to the web UI and update the Connect EZ 4 WS firmware 22
Step 5: Configure serial ports 23
Step 6: Connect to Digi Remote Manager 23

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Before you begin: Register your Connect EZ 4 WS

Welcome to the Digi family! Register your new Connect EZ 4 WS today and start enjoying a suite of exclusive benefits, including centralized management and 24/7 technical support. Click here to register now!

NEXT STEP: Let's get started! Proceed to the first step: Step 1: Gather the product components

Step 1: Gather the product components

Gather the product components needed to assemble and power the device.

1. From the box, get the Connect EZ 4 WS.
2. Gather the required components needed to complete the hardware assembly. These must be purchased separately.
   - **Power cord:** You will need a C7 power cord that connects to the Connect EZ 4 WS and can be plugged into a mains power supply.

     Note The power supply is built into the Connect EZ 4 WS.
   - **Ethernet cord:** You will need a CAT 6 Ethernet cable to connect the Connect EZ 4 WS to your site network or computer.

NEXT STEP: If you are performing the initial device set-up, proceed to the next step after verifying the components: Step 2: Connect the power cord and turn the device on.

Step 2: Connect the power cord and turn the device on

The Connect EZ 4 WS has an internal power supply, but you also need to connect a power cord to the device and plug it into a mains power supply.

Note You can also power the device using an Ethernet cable connected your computer and the 2.5GbE Ethernet port on the device.

1. Orient the device so the back of the device is facing you.



2. Connect the "figure-eight" connector on the power cord to the device.



"figure-eight" connector

3. Plug the other end of the power cord to a mains power supply.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Turn on the power switch. As the device powers up, multiple LEDs may blink, including the Power LED.



Power switch

5. When complete, the Power LED is solid blue when the device is on and receiving power.



Power LED

NEXT STEP If you are performing the initial device set-up, proceed to the next step: Step 3: Connect the device to a site network or your computer.

Step 3: Connect the device to a site network or your computer

Connecting to your Connect EZ 4 WS from your computer or site's network enables you to log into the device's web UI and configure it.

You can connect to your device using any of the following methods.

- **Ethernet**. Use an Ethernet cable to connect your device to either your computer or your site's network.

  If you connect the device to your site's network, your computer must be connected to the same network for you to be able to log in to the web UI for the Connect EZ 4 WS.
- **Wi-Fi**. Enable Wi-Fi on the device and then connect to your device remotely.

Connect the device to your computer or your site network with an Ethernet cable

You can use an Ethernet cable to connect your Connect EZ to your computer or your site network.

1. Connect one end of an Ethernet cable to your computer or your site network.
2. Orient the device so the front of the Connect EZ 4 WS is facing you.
3. Connect the other end of the Ethernet cable to the 1 Ethernet port on the Connect EZ.



1 Ethernet port

If you have connected the Ethernet cable to your site network, a DHCP request will be sent to the local Ethernet network by default.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note If you do not have a DHCP server on your network, you can connect locally over 192.168.210.1. See Using the local web interface.

WARNING! Do not connect the Ethernet cable into a serial port. Damage may occur to the serial pins, causing malfunction of the device.

Connect to the device to your site's network with Wi-Fi

You can connect to your device using Wi-Fi. Wi-Fi is disabled by default and must be enabled to allow a Wi-Fi connection.

1. Make sure your device is powered on.
2. Connect your device to either your computer or your site's network with an Ethernet cable.
3. On your computer, open a browser window and enter the IP address for the device. The log in page for the device's web UI displays.
4. Log into the device using the default user name and password.
   - **Default user name**: admin
   - **Default password**: The unique password printed on the label packaged with your device.
5. On the web UI dashboard, click **System**. Under **Configuration**, click **Device Configuration**. The **Configuration** window displays.
6. Click **Network** > **Wifi**.
7. Click **Enable** to enable Wi-Fi.
8. Click **Apply** to save the configuration and apply the change.

Next Step: If you are performing the initial device set-up, proceed to the next step: Step 4: Connect to the web UI and update the Connect EZ 4 WS firmware.

Step 4: Connect to the web UI and update the Connect EZ 4 WS firmware

You should update the firmware on the Connect EZ 4 WS device to ensure that you have the latest features.

1. Make sure that an Ethernet cable is connected to the Connect EZ 4 WS's **ETH 1** port and to your computer or your site's network.
2. Open a browser and enter the IP address for the device.
3. Log into the device using the default user name and password. The default user name is **admin** and the default password is the unique password printed on the label packaged with your device.
4. After logging in, the local web admin dashboard is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. On the main menu, click **System**. Under **Administration**, click **Firmware Update**.



6. Click **Download from server**.



7. For **Version**, select the version of the device firmware to which you want to update your device.
8. Click **Update firmware**.

Note For more detailed information about this process, see Update the system firmware.

Next Step: If you are performing the initial device set-up, proceed to the next step: Step 5: Configure serial ports.

Step 5: Configure serial ports

Connect EZ 4 WS device has four serial ports that can each be configured to allow access to different features, depending on the serial port mode selection. By default, each serial port is configured for Remote Access serial port mode, which provides socket level access to ports.

- **Serial port modes**: For configuration information about the serial port modes, see Serial port.
- **Default serial port configuration**: Review the default serial port configuration for your device.

Next Step: If you are performing the initial device set-up, proceed to the next step: Step 6: Connect to Digi Remote Manager.

Step 6: Connect to Digi Remote Manager

You can connect your device to Digi Remote Manager to ensure that you receive automatic notification of firmware updates and security notices. From Remote Manager, you can also easily update firmware, and ensure consistent configuration across a large group of devices.

To start Digi Remote Manager:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. If you have not already done so, click here to sign up for a Digi Remote Manager account.
2. Check your email for Digi Remote Manager login instructions.
3. Go to remotemanager.digi.com.
4. Log into your Digi Remote Manager account.

For more information about configuring Remote Manager and managing devices, see Central management.

Next Step: If you are performing the initial device set-up, you have now completed all of the required steps.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


Hardware reference for the Connect EZ 4 WS

This section contains the following topics:

Front panel and LEDs 23
Back panel 24
Top panel 25
Bottom panel 27
Connect EZ 4 WS hardware components 28
Connect EZ 4 WS LED functions and descriptions 29
Connect equipment to the Connect EZ serial port 30
Power the device on and off 31
Power options for the Connect EZ 4 WS 32
Power and cabling requirements 33
Power loss and Connect EZ 4 WS configuration 34
Mount the Connect EZ 4 WS 35
Use the RESET button to reset your device to the factory defaults 36
Change the password on the Connect EZ 37
Discover the device's IP address 37
Installation requirements 38
Cleaning and inspection 39
Safety and regulatory standards 40
Recycling and disposal 42
Environmental information 43
Symbol Definitions 43

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Front panel and LEDs




Item	Name	Description
1	Console	Use the USB console port to connect the device to your computer with a USB-C cable. You can then use a terminal emulator to connect to the device when a network is not available. This is useful to find the IP address for the device. For more information, see Discover the IP address from the console port.
2	Serial ports 1-4 1 2 3 4	Use the serial port s to connect to devices and equipment to the Connect EZ 4 WS. See Connect equipment to the Connect EZ serial port. The serial port LED shows the status of the connection. • **Green**: The LED is solid green when a device is connected to the port. • **Yellow**: The LED is linked directly to the serial transmit pin. During serial transmit, the specific LED blink pattern is very dependent on the bit rate and amount of traffic. At higher baud rates the flicker rate may be difficult to detect. For more information about the LEDs, see Connect EZ 4 WS LED functions and descriptions.
3	1 Ethernet port	Use the 1 Ethernet port to connect the device to your local network, using an Ethernet cable. For connection instructions, see The 1 Ethernet port LED shows the status of the connection. • **Yellow** (left): There is activity on the port. • **Green** (right): The port is in use. For more information about the LEDs, see Connect EZ 4 WS LED functions and descriptions.
4	2/PoE Ethernet port	Use the 2/PoE Ethernet port to connect to a second Ethernet cable to the device. This is useful for redundancy, if you have more than one network, or you can use it as a remote power point. The 2/PoE LED shows the status of the connection. • **Yellow** (left): There is activity on the port.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Item	Name	Description
		• **Green** (right): The port is in use. **Power over Ethernet (PoE)** Use the 2/PoE Ethernet port as a remote power point by connecting a 802.3af PoE PSE (power source) to the port. The 2/PoE Ethernet port is enabled for PoE by default. No additional configuration is required to enable PoE on the device. Note The Connect EZ 4 WS will not draw more than 15 W from the PoE supply. This device meets the IEEE 802.3af PoE standard. For more information about the LEDs, see Connect EZ 4 WS LED functions and descriptions.
5	**Wi-Fi LED**	Shows the status of the Wi-Fi connection. • **Solid green**: Client is connected. (No access point.) • **Flashing green**: Client is searching for connection. (No Access Point.) • **Solid amber**: Client is unconfigured. Access point is up. • **Solid blue**: Client is connected. Access point is up. • **Flashing amber/green**: Client is searching. Access point is up. • **Solid red**: An error has occurred. • **Off**: Both the access point and Wi-Fi client are unconfigured. For more information about the LEDs, see Connect EZ 4 WS LED functions and descriptions.
6	**Find Me LED**	The **Find Me** LED is used to help locate a device. You can enable the Find Me feature from the device's web UI. • **Flashing green**: The **Find Me** feature is on, which helps you to physically find the device among a group of devices. • **Off**: The **Find Me** feature is disabled. For more information about the LEDs, see Connect EZ 4 WS LED functions and descriptions.
7	**Power LED**	Shows whether the device is powered. • **Solid blue**: The device is on and receiving power. • **Flashing**: As the device powers up, multiple LEDs may blink, including the **Power** LED. • **Off**: The device is not receiving power. For more information about the LEDs, see Connect EZ 4 WS LED functions and descriptions.
8	**Reset button**	Use this button to reset the device to factory defaults. You need to use a pinhole tool to press the button.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Back panel



1	Power switch Press the power switch to turn the power to the device off and on. For details, see Power the device on and off.
2	Power cord connector Connect a 12 power supply to the device and a mains power supply. For details, see Step 2: Connect the power cord and turn the device on.

Top panel

The top panel of the Connect EZ 4 WS contains the identifiers for the serial ports and the Ethernet ports.

You can write on the top of the device with a dry erase marker, to help identify the devices that are connected to each serial port. As needed, you can wipe off the dry erase marker writing.




Bottom panel

The Connect EZ 4 WS features a VESA 75 mounting pattern located on the bottom of the device enclosure. If needed, you can mount the device on a wall or behind a panel using a 75 x 75 mm VESA adapter.

A pair of four screws is included with the Connect EZ 4 WS. The screws are intended to be used to attach the VESA adapter to the device.

For details, see Mount the Connect EZ 4 WS.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



VESA mounting pattern

Connect EZ 4 WS hardware components

Verify that you have the following included equipment.

Included equipment for Connect EZ 4 WS

Component	Description
Connect EZ 4 WS	Connect EZ 4 WS device  For detailed information about the panels, see: • Front panel and LEDs • Back panel • Top panel • Bottom panel
Set of 4 screws	A set of four screws is included, and can be used to mount a 75 x 75 mm VESA adapter on the bottom of the device. For details, see Mount the Connect EZ 4 WS.
Loose label	A loose label sticker that includes information about the device is included in the box. You should retain this label sticker with your hardware records. Note This label includes the unique default password for the device. This unique password will be needed if the device is factory reset and you want to access the web UI on the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


Required additional equipment

Equipment	Description
Power cord	A CF power cord that connects to the Connect EZ 4 WS that can be plugged into a mains power supply. One end of the power cord has a "figure eight" shaped connector that connects to the device. The other end has a standard two-prong plug that connects to US outlets. Note The power supply is built into the Connect EZ 4 WS.
Ethernet cable	CAT 6 Ethernet cable. Connect to a site network using an Ethernet cable. For details, see Digi 3: Connect the device to a site network or your computer.

Optional equipment

Equipment	Description
USB-C cable	A USB-C cable can be used to connect the device to the USB console port on your computer. This feature can be used to find the IP address for the device. For more information, see Discover the IP address from the console port.

Connect EZ 4 WS LED functions and descriptions

	Description	Color and light pattern	Description
	Wi-Fi LED	Solid green	The device is connected to an access point.
		Flashing green	The device is attempting to connect to an access point.
		Solid amber	The device is scanning for a network.
		Off	Wi-Fi is disabled.
	Ethernet LED	Solid green	There is a connection to the device, but there is no traffic on the line.
		Flashing green	There is traffic on the connection.
		Off	There is no connection.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

	Power LED	Solid blue	The device is on and receiving power.
		Off	The device is off and not receiving power.
IOIOI	Serial LED	Green or yellow	The serial port LED shows the status of the connection. • **Green**: The LED is solid green when a device is connected to the port. • **Yellow**: The LED is linked directly to the serial transmit pin. During serial transmit, the specific LED blink pattern is very dependent on the bit rate and amount of traffic. At higher baud rates the flicker rate may be difficult to detect.
		Off	TCP connection is not in use.
	Find Me LED	Flashing green	Find Me LED is on, which allows finding the device among a group of devices.
		Off	Find Me LED is turned off.

Connect equipment to the Connect EZ serial port

After your device is connected and powered up, you can connect equipment to the serial ports on the device. The serial ports on the Connect EZ provide console access to the connected equipment through a connected Ethernet LAN.

The serial ports are enabled by default. You can configure each serial port to allow the type of connection needed by the equipment connected to the port. The equipment connected to the serial port may be accessed using RealPort, Digi Remote Manager, the local web user interface, TCP, telnet, or SSH connections. TCP, telnet and SSH connections to serial ports are disabled by default and must be enabled by a device-specific configuration.

Serial port pinout information

For pinout information, see Serial connector pinout.

Serial cable requirements

You must use a cable with an RJ45 (10 pin) connector to connect to a serial port on the Connect EZ. Consult the user guide for the equipment you are connecting to the Connect EZ to determine the required connector type, cable type, and pinout positions.

Connect equipment to a serial port

You can connect equipment to a serial port on the Connect EZ 4 WS and access the equipment using a terminal emulator program, such as Tera Term or PuTTy. The serial port on the Connect EZ 4

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

WS must be configured to the serial port mode required to complete a connection to the equipment connected to the port.

Before you begin

- Configure the serial port to the serial port mode required by the equipment connected to that port.
- Make sure you have a terminal emulator installed on your computer.
- Make sure you have a serial cable.

To connect equipment to a serial port on the Connect EZ 4 WS:

1. Connect one end of a serial cable to a serial port on the Connect EZ 4 WS.



2. Connect the other end of the serial cable to your equipment.
3. Verify the connection between the Connect EZ 4 WS and the equipment:
   a. Open your terminal emulator.
   b. Press **Enter**.
   c. When the connection has been made, the serial port LED is solid green.

Serial connector pinout

The Connect EZ has an RJ45 (10 pin) serial connector. The table below contains the pinout information.

ATpin

If you enable **ATpin** in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 6-wire cables. **ATpin** has no impact on 422 or 485 mode.

Data+/Data- pins (in RS 485 half duplex mode)

For RS 485 cables in half duplex mode, you only need to connect one each of the Data+ and Data- pins.

10-pin	8-pin	RS232 signals (DTE)	RS422 full duplex	RS485 half duplex
1		RI	TxD-	Data-
2	1	DSR (DCD*) *When ATpin is enabled	RxD-	Data-
3	2	RTS	RTS+	N/A
4	3	GND	GND	GND
5	4	TxD	TxD+	Data+
6	5	RxD	RxD+	Data+

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

[illegible]	[illegible]	[illegible]	[illegible]	[illegible]
7	8	SG	SG	SG
8	7	CTS	CTS-	N/A
9	6	DTR	RTS-	N/A
10		DCD (DSR*) *When ADpin is enabled.	CTS-	N/A

Power the device on and off

You can power the device with a power cord and/or with an Ethernet cable connected to the PoE-enabled Ethernet port (2/PoE) on the device. You can use both mains power and PoE at the same time. No additional configuration is required to enable PoE on the device.

For more detailed information, see Power options for the Connect EZ 4 WS.

Power on the device using a power cord

The Connect EZ 4 WS has an internal power supply, but you also need a C7 power cord to connect the device to a mains power supply.

Note For more information about the power supply, see Connect EZ 4 WS hardware compatibility.

1. Orient the device so the back of the device is facing you.



2. Connect the "figure-eight" connector on the power cord to the device.



"figure-eight" connector

3. Plug the other end of the power cord to a mains power supply.
4. Turn on the power switch. As the device powers up, multiple LEDs may blink, including the Power LED.



Power switch

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. When complete, the **Power** LED is solid blue when the device is on and receiving power.



Power on the device using a PoE-enabled Ethernet port

You can power the Connect EZ 4 WS with an Ethernet cable connected to the **2/PoE** Ethernet port on the device.

WARNING! Do not connect the Ethernet cable into a serial port. Damage may occur to the serial pins, causing malfunction of the device.

1. Connect one end of an Ethernet cable to your computer.
2. Orient the device so the front of the Connect EZ 4 WS is facing you.
3. Connect the other end of the Ethernet cable to the **2/PoE** Ethernet port on the Connect EZ 4 WS.



2/PoE Ethernet port

4. Orient the device so the back of the device is facing you.
5. Turn on the power switch on the back of the device.



Power switch

6. Look at the **Power** LED on the front of the device. The **Power** LED is noted by the power icon, and is solid blue when the device is on and receiving power.



Power LED

Power off the device

You can use the power switch to power off the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

WARNING! To disconnect the Connect EZ 4 WS from power, you must remove both the mains power cord and the Ethernet cable.

1. Orient the device so the back of the device is facing you.
2. Turn off the power switch on the back of the device.



Power switch

3. The **Power** LED on the front of the device is no longer illuminated.



Power LED

4. Disconnect the power source(s) from the Connect EZ 4 WS.
   - **Power cord**: Disconnect the power cord from the mains power connector on the back of the Connect EZ 4 WS.



"figure-eight" connector

   - **Ethernet Port**: Disconnect the Ethernet cable from the Ethernet port on the front of the Connect EZ 4 WS.



1/Port Ethernet port

Power on LED sequence

The power on LED sequence occurs when the device is connected to a power source and you have pressed the power switch on the back of the device to turn it on.

The LEDs illuminate as booting occurs, then shut off as the unit finishes booting. The **Find Me** LED blinks amber initially, signifying that the device is attempting to complete the start-up boot process. After the boot process is complete, the **Find Me** LED shuts off, and you can now configure the device through a web user interface (UI).

Wi-Fi is disabled by default, so first-time configuration of the Connect EZ 4 WS terminal server must be done via an Ethernet connection. You can make subsequent configurations or modifications to the device through the web UI. This can either be done via Ethernet or Wi-Fi, once Wi-Fi capabilities have been enabled.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Power options for the Connect EZ 4 WS

The Connect EZ 4 WS is powered via Power-over-Ethernet (PoE) or an AC mains power cord. If both PoE and a power cord are plugged into the device, it will access power via the AC power supply. In this case, a minimum current is drawn from the PoE supply to maintain the power signature of the Connect EZ 4 WS. The PoE in the Connect EZ 4 WS is responsible for keeping the power signature continuous.

During power transitions from AC/DC to PoE and vice versa, the device may or may not go through a reset; therefore, seamless power transition is not guaranteed in either direction. After you have connected the power supply and powered the device on, the **Power** LED will be solid blue. In case of system failure, the Connect EZ 4 WS is designed to maintain its settings through the use of its internal non-volatile storage.

WARNING! If loss of power would create an unacceptable risk, Connect EZ 4 WS must be connected to appropriate power source.

Power and cabling requirements

Use an appropriate power cable meeting national standards to connect to a standard outlet. The appropriate requirements are listed per region:

EU/International

- VDE Mark, conforming to IEC 60083, IEC 60227, or IEC 60320, with C7 to the appropriate national mains connector, 2 x 0.75 mm2.

USA/Canada

- UR Mark, conforming to UL 62, UL 817, or CSA-C22.2, with C7 to the appropriate national mains connector.
- If PoE (Power over Ethernet) is used, the device shall use a CAT5 or higher cable that has been inspected and approved by Facility IT and which provides connectivity on all pins.

WARNING! If PoE is used as a back up power source, periodic maintenance, functional review and or replacement is necessary.

Power loss and Connect EZ 4 WS configuration

The Connect EZ 4 WS retains its configuration if power is lost and then power is restored when the device is plugged into a mains power supply, or if the device is commanded to restart automatically or interactively.

Mount the Connect EZ 4 WS

The Connect EZ 4 WS features a VESA 75 mounting pattern located on the back of the enclosure. This gives you the option to fix mount the device on a wall or cart/stand using a 75 x 75 mm VESA adapter.

A set of four screws is included with the Connect EZ 4 WS. The screws are intended to be used to attach the VESA adapter to the device. Maximum torque for the VESA screws should not exceed 2.5 N.m (22 in-lbf).

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The VESA adapter and tools needed for installation are not included. Commercially available VESA mounts and mounting tools may be used by personnel familiar with their use.

Before you begin

You will need the following:

- The set of four screws that is included with the Connect EZ 4 WS
- An appropriate screwdriver
- Your VESA adapter and the tools needed for installation

To mount the Connect EZ 4 WS:

1. Orient the device so that you can access the bottom of the device.



VESA mounting pattern

2. Place the VESA adapter on the device.
3. Use the set of four screws that is included with the Connect EZ 4 WS to attach the adapter to the device.

Use the RESET button to reset your device to the factory defaults

You can reset the Connect EZ to the factory default settings. Resetting the device to factory defaults performs the following actions:

- Clears all configuration settings
- Deletes all user files
- Regenerates SSH keys
- Clears event and system log files
- Creates a new event in the event log, indicating a factory reset

Note While the settings are reset, the device's firmware version remains the same.

1. Make sure that the Connect EZ has been powered on for at least 30 seconds.
2. Locate the RESET button on the front of the device.
3. Using a pinhole tool, press and hold the RESET button. The RESET button has the following modes:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **Configuration reset**:
  - Press and release the **Reset** button for 10 seconds.
  - The device reboots automatically and resets to factory defaults. This does not remove any automatically generated certificates and keys.
- **Full device reset**:
  - After the device reboots from the first button press, immediately press and release the **Reset** button for 10 seconds again.
  - The device reboots again and resets to factory defaults, as well as also removing generated certificates and keys.

Change the password on the Connect EZ

The unique, factory-assigned password for the default **admin** user account is printed on the bottom label of the device and on the loose label included in the package. For ease of use, you may want to change the password from the default.

If you erase the device configuration or reset the device to factory defaults, the password for the **admin** user will revert to the original, factory-assigned default password.

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the menu, click **System** > **Device Configuration**. The **Configuration** window appears.
3. Click **Authentication** > **Users** > **Admin**.
4. For **Password**, enter the new password. The password must be at least eight characters long and must contain at least one uppercase letter, one lowercase letter, one number, and one special character.



5. Click **Apply** to save the configuration and apply the change.

For more detailed information about this process, see Change the factory-assigned administrator password for a device to a unique password.

Discover the device's IP address

The IP address is used to log in to the Web UI for the device. You can discover the IP address for your Connect EZ 4 WS using any of the following methods.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Discover the IP address using the Digi Navigator

You can use the Digi Navigator to quickly discover the IP address for the Connect EZ 4 WS.

1. To ensure that your computer and device are connected to each other and your local network, make the following connections:
   - Connect the device to your computer with an Ethernet cable.
   - Connect the device to your local network with an Ethernet cable.
   - Connect your computer to your local network with an Ethernet cable.
2. Download and install the **Digi Navigator**.
3. Launch the **Digi Navigator**.
4. The tool discovers the Connect EZ 4 WS devices that are powered on and connected to your network. When the process is complete, a list of the devices appears.
   - **Connected to a network**: By default, the HTTPS service is enabled and used to find an IP address for the Connect EZ 4 WS. Other services can be enabled if needed from the **Filters** section. See Services used to discover a device when connected to a network.
   - **Connected directly to a device or on a network with no DHCP server**: In either of these situations, a setup IP address is assigned to the device. You can specify the filters used to assign an IP address. See Use the autodiscovery protocol to discover a device and Assign a generic IP address to the device.
5. Expand a device to display the IP address.

Discover the IP address from the console port

You can connect a USB-C cable to the device's console port and your computer and use a terminal emulator to determine the device's IP address.

Prerequisites

- A power cord must be connected to the device and the device turned on.
- Access to a terminal emulation application.
- A USB-C cable.

To use the console port to discover the device's IP address:

1. Connect one end of a USB-C cable to your computer.
2. Orient the device so the front of the Connect EZ 4 WS is facing you.
3. Connect the other end of the USB-C cable to the **Console** port on the Connect EZ 4 WS.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Use the terminal emulator to discover the device's IP address.
   a. Access the terminal emulation application.
   b. Log in to the Connect EZ 4 WS.
      - **User name**: admin
      - **Password**: The unique password printed on the device label.
   c. Type **e** to enter the Admin CLI.
   d. Type **show network** to show all devices currently connected to the network.
   e. Scroll down until you discover the Connect EZ.
   f. Write down the IP address shown for the device.

Manually configure the PC and assign an IP address to the device

You can manually assign an IP address to the device.

Prerequisites

- An Ethernet cable must be connected to the device and your network.
- A power supply must be connected to the device and the device powered on.
- Determine the IP address that you want to assign to the device.

To configure your laptop and assign an IP address:

1. On your PC, navigate to the Ethernet network settings dialog.
2. Click the **Internet Protocol Version 4 (TCP/IPv4)** parameter.



3. Click **Properties**. The **Internet Protocol Version 4 (TCP/IPv4) Properties** dialog appears.
4. Select **Use the following IP address**.

   Note **IMPORTANT**: Make note of the current IP address entries for **IP address**, **Subnet mask**, and **Default gateway**. You will need this information to complete the final step of the process.

5. Configure with the following details:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **IP address** for PC: 192.168.210.2
- **Subnet**: 255.255.255.0
- **Gateway**: 192.168.210.1



8. Click **OK**.
7. Open a browser window.
8. Enter the default gateway IP address: 192.168.210.1
9. Log into the device using the default user name and password. The default user name is **admin** and the default password is the unique password printed on the label packaged with your device. For more detailed instructions, see Connect to the local Web UI on the Connect EZ.
10. Update the IP address for the device.
11. On your PC, revert the IP address information to the original entries.
    a. Return to the **Internet Protocol Version 4 (TCP/IPv4) Properties** dialog.
    b. Enter the original IP address entries for **IP address**, **Subnet mask**, and **Default gateway**.
    c. Click **OK**.

Connect to the local Web UI on the Connect EZ

Once you are connected to the local Web UI, you can configure your device.

1. Make sure that an Ethernet cable is connected to the Connect EZ 4 WS's **ETH 1** port and to a laptop or PC.
2. Open a browser and enter the IP address for the device. The web UI log in screen displays.
3. Log into the device using the default user name and password. The default user name is **admin** and the default password is the unique password printed on the label packaged with your device.
4. After logging in, the local web admin dashboard is displayed.

The dashboard shows the current status of the device. For more information about the dashboard, see Using the local web interface.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Installation requirements

- Make sure the Connect EZ 4 WS installation is performed by IT personnel with at least one year of experience operating network equipment within the intended environment.
- Any additional required configuration or troubleshooting for the Connect EZ 4 WS is performed remotely with the third party software and equipment and follows specific procedures provided by the System Integrator.
- Personnel connecting and configuring devices to the Connect EZ 4 WS should have knowledge of how these devices work and the proper procedures for configuring their serial ports, as defined in the documentation provided with the equipment.
- The personnel responsible for configuring and verifying proper communication between an attached device and the data acquisition system that is monitoring it's data should have knowledge of the correct configuration methods and procedures, as defined in the materials provided with the data acquisition system.
- The System Integrator is responsible to ensure compliance with any country-specific regulations that pertain when installing or implementing a solution that uses this product.

CAUTION Do not modify the Connect EZ 4 WS terminal server or cables, or mount it in any way other than instructed in this guide. Any modification to the hardware can prevent proper functioning and cause damage to the connected device.

WARNING When deploying the Connect EZ 4 WS in an environment subject to IEC 60601-1, refer to the requirements applicable to medical equipment systems in the standard.

Cleaning and inspection

CAUTION Before cleaning or moving the device, turn off the power and disconnect the device from the mains power connector and the Ethernet cable.

WARNING Clean and inspect the device periodically.

- Periodically inspect power cable and replace power cable in case it shows wear.
- Clean device regularly.
- Do not sterilize the device server. (To clean: gently wipe the case with a mild detergent or 70% isopropyl alcohol.)
- Disconnect the mains power cord and the Ethernet cable from the Connect EZ 4 WS before cleaning the Connect EZ 4 WS or inspecting the power cord or other cables for wear.

CAUTION Verify correct operation before each use and periodically thereafter.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Do not use the device server to activate, deactivate, control, or adjust any medical device.
- Do not use data from the device server for diagnosis without validating the integrity of the entire information collection system.



WARNING! This device contains no user serviceable parts. No modification of this equipment is allowed. The manufacturer cannot take responsibility for any damage caused by opening the device.

Safety and regulatory standards

Category	Standard
EMC/EMI	FCC 47 CFR Part 15 part B ICES-003
Radio	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-17 V3.2.4
	EN 55032 CLASS A
	EN 61000-3-2
	EN 61000-3-3
	EN 55035

Note The safety and regulatory information in this section is provided for information purposes only, and is believed to be accurate at the time of publication of this manual. Please refer to the Declaration of Conformity for current safety and regulatory information. The above categories reference the common names of standards and do not necessarily reflect intended uses. The Connect EZ 4 WS does not change or manipulate transmitted data or its display in any way. It does not incorporate a therapeutic or diagnostic function, and is not intended to be used with active patient monitoring. The Connect EZ 4 WS is intended for use as an ITE device for data transmission only.

Recycling and disposal

Symbol	Description
	Improper disposal of IT equipment can have a negative impact on health and the environment. Dispose of equipment and accessories at an appropriate facility to enable recovery and recycling.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Symbol	Description
	Recycle packaging and guides according to your local recycling regulations.

Environmental information

Item	Environment	Description
	Operating temperature	0° C to +40° C (32° F to 104° F)
	Storage temperature	-20° C to 60° C (-4° F to 140° F)
	Relative humidity	10% to 90% (non-condensing)
	Operating atmospheric pressure	800 hPa to 1060 hPa
	Storage atmospheric pressure	500 hPa to 1060 hPa

Symbol Definitions

Symbol	Description
	Atmospheric pressure limitation
	Humidity limitation
	Temperature limitation

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Symbol	Description
DIM	Device carton shipping dimensions
ETH	Ethernet MAC address
GW	Gross weight
NW	Net weight
REF	Catalog number
SN	Serial number
WLAN	Wi-Fi MAC address
CE	Mark of conformity
	Operating instructions
	Date of manufacture
	Manufacturer

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Symbol	Description
	Ethernet port and status LED
IOIOI	Serial port(s) and status LED(s)
	Power status LED
	Wi-Fi connection status LED
	Find ME LED
	AI sensing current
	Caution
	Warning
	Package recycling information
	WEEE: Device was put on the market after 13 August 2005. Conforms to the Directive 2002/96/EC on waste electrical and electronic equipment (WEEE) of the European Parliament.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firmware configuration

This chapter contains the following topics:

Review Connect EZ 4 WS default settings 47
Change the factory-assigned administrator password for a device to a unique password 48
Change the default SSID and pre-shared key for the preconfigured Wi-Fi access point 49
Configuration methods 51
Using Digi Remote Manager 52
Access Digi Remote Manager 52
Using the local web interface 52
Review the dashboard 53
Use the local REST API to configure the Connect EZ 4 WS device 54
Access the terminal screen from the web UI 58
Using the command line 60

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Review Connect EZ 4 WS default settings

You can review the default settings for your Connect EZ 4 WS device by using the local WebUI or Digi Remote Manager.

Local WebUI

1. Log into the Connect EZ 4 WS WebUI as a user with Admin access.
2. On the menu, click **System** > **Device Configuration**.

Digi Remote Manager

1. If you have not already done so, connect to your Digi Remote Manager account.
2. Click **Device Management** to display a list of your devices.
3. Locate and select your device as described in Use Digi Remote Manager to view and manage your device.
4. Click **Configure**.

The following tables list important factory default settings for the Connect EZ 4 WS.

Default interface configuration

Interface type	Pre-configured interfaces	Device	Default configuration
Ethernet Network	• ETH1	• Ethernet: ETH1	• Firewall zone: Edge • DHCP client enabled
	• ETH2	• Ethernet: ETH2	• Firewall zone: Edge • DHCP client enabled
	• Loopback	• Ethernet: Loopback	• Firewall zone: Loopback • IP address: 127.0.0.1/8
	• Setup IP	• Ethernet: ETH1	• Firewall zone: Setup • IP address: 192.168.210.1/24
	• Setup Link-local IP	• Ethernet: ETH1	• Firewall zone: Setup • IP address: 169.254.100.100/16

Other default configuration settings

Feature	Configuration
Central	• Digi Remote Manager enabled as the central management service.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firmware configuration — Change the factory-assigned administrator password for a device to a unique password

Feature	Configuration
management	
Security policies	• Packet filtering allows all outbound traffic. • SSH and web administration ▪ Enabled for local administration ▪ Firewall zones: Set up
Monitoring	• Device health metrics uploaded to Digi Remote Manager at 60 minute interval. • SNMP: Disabled

Change the factory-assigned administrator password for a device to a unique password

Tip: Triggering a **Config reset** reverts the unique **admin** password you may have configured back to the factory-assigned default **admin** password. If you are trying to log in to the device locally after the **Config reset** is complete, you will have to use the factory-assigned default **admin** password, which is located on the product label sticker on the bottom of the device or the extra product label sticker. For more information about triggering a device reset, see Device reset.

To change the factory-assigned administrator password for a device to a different one:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:


   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Authentication** > **Users** > **admin**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Enter a new password for the admin user. The password must be at least eight characters long and must contain at least one uppercase letter, one lowercase letter, one number, and one special character.



5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Set a new password for the admin user. The password must be at least eight characters long and must contain at least one uppercase letter, one lowercase letter, one number, and one special character.

```
(config)> auth user admin password new-password
(config)>
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Change the default SSID and pre-shared key for the preconfigured Wi-Fi access point

By default, the SSID and pre-shared key for the preconfigured Wi-Fi access point are:

- Enabled
- SSID: Digi-Connect EZ 4 WS-*serial_number*

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firmware configuration Change the default SSID and pre-shared key for the preconfigured Wi-Fi access point:

- Encryption: WPA2 Personal (PSK)
- Pre-shared key: The unique password printed on the bottom label of the device

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Wi-Fi** > **Digi AP**.



4. Enter a new **SSID** and **Pre-shared key**.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Set a new SSID for the **digi_ap** access point:

```
(config)> network wifi ap digi_ap ssid new_ssid
(config)>
```

4. Set a new pre-shared key:

```
(config)> network wifi ap digi_ap encryption key_psk2 new_key
(config)>
```

5. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configuration methods

There are two primary methods for configuring your Connect EZ 4 WS device:

- Web interface.
The web interface can be accessed in two ways:
  - Central management using the Digi Remote Manager, a cloud-based device management and data enablement platform that allows you to connect any device to any application, anywhere. With the Remote Manager, you can configure your Connect EZ 4 WS device and use the configuration as a basis for a Remote Manager configuration which can be applied to other similar devices. See Central management for more information about using the Remote Manager to manage and configure your Connect EZ 4 WS device.
  - The local web interface. See Using the local web interface for more information about using the local web interface to manage and configure your Connect EZ 4 WS device.

  Note Changes made to the device's configuration by using the local web interface will not be automatically reflected in Digi Remote Manager. You must manually refresh Remote Manager for the changes to be displayed.

  Web-based instructions in this guide are applicable to both the Remote Manager and the local web interface.
- Command line.
A robust command line allows you to perform all configuration and management tasks from within a command shell. Both the Remote Manager and the local web interface also have the

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

option to open a terminal emulator for executing commands on your Connect EZ 4 WS device. See Using the command line for more information about using the command line to manage and configure your Connect EZ 4 WS device.

In this guide, task topics show how to perform tasks:

Web

Shows how to perform a task by using the local web interface.

Command line

Shows how to perform a task by using the command line interface.

Using Digi Remote Manager

By default, your Connect EZ 4 WS device is configured to use Digi Remote Manager as its central management server. Devices must be registered with Remote Manager using one of the following options:

- As part of the getting started process. See the Quick Start Guide for information.
- If you have not registered the device already, you can do so using the Device ID, MAC address, IMEI, or your Remote Manager login credentials. See Add a device to Remote Manager.

For information about configuring central management for your Connect EZ 4 WS device, see Central management.

Access Digi Remote Manager

To access Digi Remote Manager:

1. If you have not already done so, go to https://myaccount.digi.com/ to sign up for a Digi Remote Manager account.
2. Check your email for Digi Remote Manager login instructions.
3. Go to remotemanager.digi.com.
4. Enter your user name and password. The Digi Remote Manager Dashboard appears.

Using the local web interface

To connect to the Connect EZ 4 WS local Web UI:

1. Use an Ethernet cable to connect the Connect EZ 4 WS's **ETH** port to a laptop or PC.
2. Open a browser and go to **192.168.2.1**.
3. Log into the device using a configured user name and password.

   The default user name is **admin** and the default password is the unique password printed on the label packaged with your device.

Review the dashboard

After logging in, the local web admin dashboard is displayed.

The dashboard shows the current state of the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Dashboard area	Description
Network activity	• Summarizes network statistics: the total number of bytes sent and received over all configured bridges and Ethernet devices. • Displays the status of the network interfaces configured on the device.
Digi Remote Manager	Displays the device connection status for Digi Remote Manager, the amount of time the connection has been up, and the Digi Remote Manager device ID. See Using Digi Remote Manager. The links in this section enable you to do the following: • **Launch Digi Remote Manager**: Click **Go to Digi Remote Manager** to open the Digi Remote Manager login page. • **Add a device to Remote Manager**: Click **Register device on new account** to add a device to Remote Manager using your Remote Manager login credentials.
Device	Displays the Connect EZ 4 WS device's status, statistics, and identifying information.
Serial Ports	Displays information about the serial ports on the Connect EZ 4 WS. Each serial port is identified by port name or number, followed by the serial port mode configured for the port. The icons next to the port name or number shows the serial port status. • **Empty circle**: Port is not connected. • **Green circle**: Active connection on the port. • **Red X**: No signal, which is an error state where the port is not available. • **Down arrow**: One of the control signals is not active. This icon may display for for ports configured in **Remote Access** serial port mode and that have a signal monitor enabled (CTS or DCD) in the **Monitoring Settings** section. You can click the icons at the top of the section to access other pages. • **Blue "i"**: Click to access the Serial Status page. • **Blue wrench**: Click to access the Serial Configuration page.
Services	Displays an option for the Watchdog service if it has been enabled.

Log out of the web interface

- On the main menu, click your user name. Click **Log out**.



Review the dashboard

After logging in, the local web admin dashboard is displayed.

The dashboard shows the current state of the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Dashboard area	Description
Network activity	• Summarizes network statistics: the total number of bytes sent and received over all configured bridges and Ethernet devices. • Displays the status of the network interfaces configured on the device.
Digi Remote Manager	Displays the device connection status for Digi Remote Manager, the amount of time the connection has been up, and the Digi Remote Manager device ID. See Using Digi Remote Manager. The links in this section enable you to do the following: • **Launch Digi Remote Manager**: Click **Go to Digi Remote Manager** to open the Digi Remote Manager login page. • **Add a device to Remote Manager**: Click **Register device in new account** to add a device to Remote Manager using your Remote Manager login credentials.
Device	Displays the Connect EZ 4 WS device's status, statistics, and identifying information.
Serial Ports	Displays information about the serial ports on the Connect EZ 4 WS. Each serial port is identified by port name or number, followed by the serial port mode configured for the port. The icons next to the port name or number shows the serial port status: • **Empty circle**: Port is not connected. • **Green circle**: Active connection on the port. • **Red X**: No signal, which is an error state where the port is not available. • **Down arrow**: One of the control signals is not active. This icon may display for for ports configured in **Remote Access** serial port mode and that have a signal monitor enabled (CTS or DCD) in the **Monitoring Settings** section. You can click the icons at the top of the section to access other pages: • **Blue "i"**: Click to access the Serial Status page. • **Blue wrench**: Click to access the Serial Configuration page.
Services	Displays an option for the Watchdog service if it has been enabled.

Use the local REST API to configure the Connect EZ 4 WS device

Your Connect EZ 4 WS device includes a REST API that can be used to return information about the device's configuration and to make modifications to the configuration. You can view the REST API specification from your web browser by opening the URL:

http://ip-address/cgi-bin/config.cgi

For example:

http://192.168.210.1/cgi-bin/config.cgi

Use the GET method to return device configuration information

To return device configuration, issue the GET method. For example, using curl:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firmware configuration Use the local REST API to configure the Connect EZ 4 WS device

```
$ curl -k -u admin https://ip-address/cgi-bin/config.cgi/value/path -H GET
```

where is:

- ip-address is the IP address of the Connect EZ 4 WS device.
- path is the path location in the configuration for the information being returned.

To determine allowed values for path from the Admin CLI:

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights. Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type ?(question mark):

```
(config)> ?
auth                    Authentication
cloud                   Central management
firewall                Firewall
monitoring              Monitoring
network                 Network
serial                  Serial
service                 Services
system                  System
vpn                     VPN

(config)>
```

The allowed values for path are listed in the first (left) column.

4. To determine further allowed path location values by using the ?(question mark) with the path name:

```
(config> service ?

Services

  Additional Configuration

-------------------------

dns                     DNS
iperf                   IPerf
location                Location
sdns                    Service Discovery (mDNS)
modbus_gateway          Modbus Gateway
multicast               Multicast
ntp                     NTP
ping                    Ping responder
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firmware configuration Use the local REST API to configure the Connect EZ 4 WS device

```
snmp                    SNMP
ssh                     SSH
telnet                  Telnet
web_admin               Web administration

(config)> service
```

For example, to use **curl** to return the ssh configuration:

```
$ curl -k -u admin https://192.168.210.1/cgi-bin/config.cgi/value/service/ssh -
$ GET
Enter host password for user 'admin':
{
"ok": true,
        "result": {
                "type": "object",
                "path": "service.ssh"
                "collapsed": {
"acl.zone.0": "internal"
,
"acl.zone.1": "edge"
,
"acl.zone.2": "ipsec"
,
"acl.zone.3": "setup"
,
"enable": "true"
,
"key": ""
,
"mdns.enable": "true"
,
"mdns.name": ""
,
"mdns.type": "_ssh._tcp."
,
"port": "22"
,
"protocol.0": "tcp"
                }
        }
}
$
```

You can also use the **Ctrl** method to return the configuration parameters associated with an item:

```
curl -k -u admin https://192.168.210.1/cgi-bin/config.cgi/keys/service/ssh -b
GET
Enter host password for user 'admin':
{ "ok": true, "results": [ "acl", "custom", "enable", "key", "mdns", "port",
"protocol" ] }
$
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use the POST method to modify device configuration parameters and list arrays

Use the POST method to modify device configuration parameters

To modify configuration parameters, use the **POST** method with the **path** and **value** parameters.

```
$ curl -k -u admin "https://ip-address/cgi-
bin/config.cgi?value1path=path&value=new_value" -X POST
```

where:

- **path** is the path to the configuration parameter, in dot notation (for example, **wlan.service.enable**).
- **new_value** is the new value for the parameter.

For example, to disable the ssh service using **curl**:

```
$ curl -k -u admin "https://192.168.210.1/cgi-
bin/config.cgi?value1path=service.ssh.enable&value=false" -X POST
Enter host password for user 'admin':
{ "ok": true }
$
```

Use the POST method to add items to a list array

To add items to a list array, use the **POST** method with the **path** and **append** parameters. For example, to add the external firewall zone to the ssh service:

```
$ curl -k -u admin "https://192.168.210.1/cgi-
bin/config.cgi?value1path=service.ssh.acl.zone&append=true&value=external" -X
POST
Enter host password for user 'admin':
{ "ok": true, "result": "service.ssh.acl.zone.4" }
$
```

Use the DELETE method to remove items from a list array

To remove items from a list array, use the **DELETE** method. For example, using **curl**:

```
$ curl -k -u admin "https://192.168.210.1/cgi-bin/config.cgi?value1path=path
```

where **path** is the path to the list item, including the list number, in dot notation (for example, **service.ssh.acl.zone.4**).

For example, to remove the external firewall zone to the ssh service:

1. Use the **GET** method to determine the SSH service's list number for the external zone:

```
$ curl -k -u admin "https://192.168.210.1/cgi-
bin/config.cgi?value1path=service/ssh/acl/zone -X GET
{
        "ok": true,
        "result": {
                "type": "array",
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
                "path": "service.ssh.acl.zone"
                "collapsed": [
"0": "internal"
,
"1": "edge"
,
"2": "ipsec"
,
"3": "setup"
,
"4": "external"
                ]
        }
}
$
```

2. Use the **DELETE** method to remove the external zone (list item 4).

```
$ curl -k -u admin https://192.168.210.1/cgi-
bin/config.cgi/value/path=service.ssh.acl.zone.4 -X DELETE
Enter host password for user 'admin':
{ "ok": true }
$
```

Access the terminal screen from the web UI

A user can log into a terminal screen and use CLI commands to access features.

Note You can also access the terminal screen from a port listed in the Serial Status page.

1. Log in to the web UI.
2. Click **System** > **Terminal**. The **Terminal** screen displays.
3. When prompted, enter your user name and password.
4. Enter the number of the port that you want to access.
5. Information about the port you are connected to displays, as well as commands.

```
Connecting to port1:
Settings: 9600, 8, 1, none, none
Type '~.' to disconnect from port
Type '~?' to list commands
```

6. Enter **~?** to display additional commands.

Command	Description
~.	Disconnect from the port.
~b	Send a BREAK sequence.
~c	Clear the history buffer.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

[illegible]	[illegible]
~b	Send a BREAK sequence.
~b?	Display a list of commands.

7. Enter ~b to disconnect from the port.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Using the command line

The Digi Connect EZ 4 WS device provides a command-line interface that you can use to configure the device, display status and statistics, update firmware, and manage device files.

See Command line interface for detailed instructions on using the command line interface and see Command line reference for information on available commands.

Access the command line interface

You can access the Connect EZ 4 WS command line interface using an SSH connection, a telnet connection, or a serial connection. You can use an open-source terminal software, such as PuTTY or TeraTerm, to access the device through one of these mechanisms.

You can also access the command line interface in the WebUI by using the **Terminal**, or the Digi Remote Manager by using the **Console**.

To access the command line, your device must be configured to allow access, and you must log in as a user who has been configured for the appropriate access.

For further information about configuring access to these services, see:

- Serial: Serial port
- WebUI: Configure the web administration service
- SSH: Configure SSH access
- Telnet: Configure telnet access

Log in to the command line interface

Command line

1. Connect to the Connect EZ 4 WS device by using a serial connection, SSH or telnet, or the **Terminal** in the WebUI or the **Console** in the Digi Remote Manager. See Access the command line interface for more information.
   - For serial connections, the default configuration is:
     - 9600 baud rate
     - 8 data bits
     - no parity
     - 1 stop bit
     - no flow control
   - For SSH and telnet connections, the default IP address of the device is 192.168.2.1 on the **ETH1** port.
2. At the login prompt, enter the username and password of a user with Admin access.

   ```
   login: admin
   Password: **********
   ```

   The default username is **admin**. The default unique password for your device is printed on the device label.
3. Depending on the device configuration, you may be presented with another menu. For example:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library
TS-TL-DGI-010

```
Access selection menu:

        a: Admin CLI
        q: Quit

Select access or quit [admin] :
```

Type **a** or **admin** to access the Connect EZ 4 WS command line.

You will now be connected to the Admin CLI.

```
Connecting now...
 Press Tab to autocomplete commands
 Press '?' for a list of commands and details
 Type 'help' for details on navigating the CLI
 Type 'exit' to disconnect from the Admin CLI

>
```

See Command line interface for detailed instructions on using the command line interface.

Exit the command line interface

Command line

1. At the command prompt, type **exit**.

```
> exit
```

2. Depending on the device configuration, you may be presented with another menu, for example:

```
Access selection menu:

        a: Admin CLI
        q: Quit

Select access or quit [admin] :
```

Type **q** or **quit** to exit.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Interfaces

Connect EZ devices have a LAN physical communications interface.

This chapter contains the following topics:

Define a static IP address
Local Area Network (LAN)
Virtual LANs (VLANs)
Bridging
Configure a TCP connection timeout

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Define a static IP address

You can configure a static IP address for the Connect EZ.

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the menu, click **System**. Under **Configuration**, click **Device Configuration**. The **Configuration** window is displayed.



3. Click **Network** > **Interfaces**.
4. Click the desired Ethernet section, and keep the default settings.
   - **Enable**: Selected
   - **Interface type**: Ethernet
   - **Zone**: Edge
   - **Device**: The option matches the selected Ethernet: Device: ETH1, Device: ETH2, or Device ETH.
5. Configure IPv4 settings.
   a. Click to expand **IPv4** settings.
   b. Enable IPv4 support, if it is not enabled. This is enabled by default.
   c. For **Type**, select **Static IP address**.
   d. For **Address**, type the IP address and subnet of the LAN interface. Use the format **IPv4_address/netmask**, for example, 192.168.2.1/24. For more information about the netmask, see IP address and netmask.
   e. For **Default gateway**, type the default gateway associated with this network interface.
6. (Optional) Add DNS servers to use with this static IP address.
   a. Expand the **DNS Servers** section.
   b. Click the plus sign icon next to **Add DNS server**.
   c. In the **DNS server** field, enter the IP address of the DNS server.
   d. Repeat this process if you want to add another DNS server.
7. Click **Apply** to save the configuration and apply the change.

IP address and netmask

The netmask is the length of the subnet mask in bits. For example, for a class C address with a subnet mask of 255.255.255.0, the length in bits would be 24.

NETMASK	255	255	255	255
Netmask length	8	16	24	32

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Area Networks (LANs)

The Connect EZ 4 WS device is preconfigured with the following Local Area Networks (LANs).
You can modify configuration settings for **ETH0**, and you can create new LANs.
This section contains the following topics:

About Local Area Networks (LANs) 65
Configure a Local Area Network (LAN) 66
Configure the ETH1 port as a LAN or in a bridge 71
Change the default LAN subnet 80
Example: Configure two LANs 81
Example: Configure two LANs 88
Show LAN status and statistics 98
Delete a LAN 101
DHCP servers 102
Default services listening on LAN ports 110

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

About Local Area Networks (LANs)

A Local Area Network (LAN) connects network devices together, such as Ethernet or Wi-Fi, in a logical Layer-2 network.

The following diagram shows a LAN connected to the **ETH2** Ethernet device and the **Digi AP** access point. Once the LAN is configured and enabled, the devices connected to the network interfaces can communicate with each other, as demonstrated by the **ping** commands.

Configure a Local Area Network (LAN)

Configuring a Local Area Network (LAN) involves configuring the following items:

Required configuration items

- A name for the interface.

  Note If the interface name is more than eight characters, the name will be truncated in the underlying network interface to the first six characters followed by three digits, incrementing from 000. This affects any custom scripts or firewall rules that may be trying to adjust the interface or routing table entries.

- The interface type, either **Ethernet**, **IP Passthrough**, or **PPP**.
- The firewall zone: **Internal**.
- The network device or bridge that is used by the LAN.
- The IPv4 address and subnet mask for the LAN. While it is not strictly necessary for a LAN to have an IP address, if you want to send traffic from other networks to the LAN, you must configure an IP address.

Additional configuration items

- Additional IPv4 configuration:
  - The metric for IPv4 routes associated with the LAN.
  - The relative weight for IPv4 routes associated with the LAN.
  - The IPv4 management priority of the LAN. The active interface with the highest management priority will have its address reported as the preferred contact address for central management and direct device access.
  - The IPv4 Maximum Transmission Unit (MTU) of the LAN.
  - Whether to assign a static IPv4 address to the LAN.
  - When to use DNS: always, never, or only when this interface is the primary default route.
- IPv6 configuration:
  - The metric for IPv6 routes associated with the LAN.
  - The relative weight for IPv6 routes associated with the LAN.
  - The IPv6 management priority of the LAN. The active interface with the highest management priority will have its address reported as the preferred contact address for central management and direct device access.
  - The IPv6 Maximum Transmission Unit (MTU) of the LAN.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Whether to assign a static IPv6 address to the LAN.
- When to use DNS: always, never, or only when this interface is the primary default route.
- The IPv6 prefix length and ID.

- MAC address override and advertise.

To create a new LAN or edit an existing LAN:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network > Interfaces**.
4. Create the LAN or select an existing LAN:
   - To create a new LAN, for **Add interface**, type a name for the LAN and click **+**.

   - To edit an existing LAN, click to expand the LAN.

The Interface configuration window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

New LANs are enabled by default. To disable, toggle off **Enable**.

5. For **Interface type**, leave at the default setting of **Ethernet**.
6. For **Zone**, select the appropriate firewall zone. See Firewall configuration for further information.
7. For **Device**, select an Ethernet device, a Wi-Fi access point, or a bridge. See Bridging for more information about bridging.
8. (Optional) Click to expand **802.1x** to configure 802.1x port based network access control. The Connect EZ 4 WS can function as an 802.1x authenticator, it does not function as an 802.1x supplicant.
   a. Click to expand **Authentication**.
   b. Click **Enable server** to enable the 802.1x authenticator on the Connect EZ 4 WS device.
   c. Set the **Reauth** period.
9. Configure IPv4 settings.
   a. Click to expand **IPv4**.
      IPv4 support is enabled by default.
   b. For **Type**, select **Static IP address**.
   c. For **Address**, type the IP address and subnet of the LAN interface. Use the format *IPv4_address/netmask*; for example, 192.168.2.1/24.
   d. Optional IPv4 configuration items:
      i. Set the **Metric**.
      ii. For **Weight**, type the relative weight for default routes associated with this interface. For multiple active interfaces with the same metric, **Weight** is used to load balance traffic to the interfaces.
      iii. Set the **Management priority**. This determines which interface will have priority for central management activity. The interface with the highest number will be used.
      iv. Set the **MTU**.
   e. Enable the DHCP server:
      i. Click to expand **DHCP server**.
      ii. Click **Enable**.
   f. Enable **Force link** to keep the network interface active even when the device link is down.
10. (Optional) Configure IPv6 settings:
    a. Click to expand **IPv6**.
    b. **Enable** IPv6 support.
    c. For **Type**, select **IPv6 prefix delegation**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

d. For **Prefix length**, type the minimum length of the prefix to assign to this LAN. If the minimum length is not available, then a longer prefix will be used.

e. For **Prefix ID**, type the identifier used to extend the prefix to the assigned length. Leave blank to use a random identifier.

f. Set the **Metric**.

g. For **Weight**, type the relative weight for default routes associated with this interface. For multiple active interfaces with the same metric, **Weight** is used to load balance traffic to the interfaces.

h. Set the **Management priority**. This determines which interface will have priority for central management activity. The interface with the highest number will be used.

i. Set the **MTU**.

j. (Optional) To assign a static address to a network interface, click to expand **Static addresses**.

i. Click the slider to enable.

ii. For **Address**, type the name of the static address you want to use (for example, `lnxcaguma1ac1154`).

11. (Optional) Click to expand **MAC address denylist**.

Incoming packets will be dropped from any devices whose MAC addresses is included in the **MAC address denylist**.

a. Click to expand **MAC address denylist**.

b. For **Add MAC address**, click **+**.

c. Type the **MAC address**.

12. (Optional) Click to expand **MAC address allowlist**.

If allowlist entries are specified, incoming packets will only be accepted from the listed MAC addresses.

a. Click to expand **MAC address allowlist**.

b. For **Add MAC address**, click **+**.

c. Type the **MAC address**.

13. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Create a new LAN or edit an existing one:
   - To create a new LAN named my_lan:

```
(config)> add network interface my_lan
(config network interface my_lan)>
```

   - To edit an existing LAN named my_lan, change to the my_lan node in the configuration schema:

```
(config)> network interface my_lan
(config network interface my_lan)>
```

4. Set the appropriate firewall zone:

```
(config network interface my_lan)> zone zone
(config network interface my_lan)>
```

   See Firewall configuration for further information.

5. Select an Ethernet device, a Wi-Fi device, or a bridge. See Bridging for more information about bridging:
   a. Enter **device ?** to view available devices and the proper syntax:

```
(config network interface my_lan)> device ?

Current value:

(config network interface my_lan)> device
```

   b. Set the device for the LAN:

```
(config network interface my_lan)> device device
(config network interface my_lan)>
```

6. Configure IPv4 settings:
   - IPv4 support is enabled by default. To disable:

```
(config network interface my_lan)> ipv4 enable false
(config network interface my_lan)>
```

   - The LAN is configured by default to use a static IP address for its IPv4 configuration. To configure the LAN to be a DHCP client, rather than using a static IP address:

```
(config network interface my_lan)> ipv4 type dhcp
(config network interface my_lan)>
```

     These instructions assume that the LAN will use a static IP address for its IPv4 configuration.
   a. Set the IPv4 address and subnet of the LAN interface. Use the format IPV4_address/netmask, for example, 192.168.2.1/24.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network interface my_lan)> ipv4 address ip_address/netmask
(config network interface my_lan)>
```

b. Optional IPv4 configuration items:

i. Set the IP metric:

```
(config network interface my_lan)> ipv4 metric num
(config network interface my_lan)>
```

ii. Set the relative weight for default routes associated with this interface. For multiple active interfaces with the same metric, the weight is used to load balance traffic to the interfaces.

```
(config network interface my_lan)> ipv4 weight num
(config network interface my_lan)>
```

iii. Set the management priority. This determines which interface will have priority for central management activity. The interface with the highest number will be used.

```
(config network interface my_lan)> ipv4 mgmt num
(config network interface my_lan)>
```

iv. Set the MTU:

```
(config network interface my_lan)> ipv4 mtu num
(config network interface my_lan)>
```

f. (Optional) Configure IPv6 settings:

a. Enable IPv6 support:

```
(config network interface my_lan)> ipv6 enable true
(config network interface my_lan)>
```

b. Set the IPv6 type to DHCP:

```
(config network interface my_lan)> ipv6 type dhcpv6
(config network interface my_lan)>
```

c. Generally, the default settings for IPv6 support are sufficient. You can view the default IPv6 settings by using the question mark ('?').

```
(config network interface my_lan)> ipv6 ?

IPv6

Parameters                Current Value
-------------------------------------------------------------------------------
enable                    true                Enable
metric                    0                   Metric
mgmt                      0                   Management priority
mtu                       1500                MTU
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
prefix_id                 1                    Prefix ID
prefix_length             48                   Prefix length
type                      prefix_delegation    Type
weight                    10                   Weight

Additional Configuration
------------------------------------------------------------------------------

connection_monitor        Active recovery
dhcpv6_server             DHCPv6 server

(config network interface my_lan)>
```

View default settings for the IPv6 DHCP server:

```
(config network interface my_lan)> ipv6 dhcpv6_server ?

DHCPv6 server: The DHCPv6 server settings for this network interface.

 Parameters               Current Value
 ------------------------------------------------------------------------------

 enable                   true            Enable

(config network interface my_lan)>
```

e. Modify any of the remaining default settings as appropriate. For example, to change the minimum length of the prefix:

```
(config network interface my_lan)> ipv6 prefix_length 64
(config network interface my_lan)>
```

If the minimum length is not available, then a longer prefix will be used.

e. (Optional) To assign a static address to a network interface:

```
>config
(config)> network interface my_lan ipv6 static ?

Static address: IPv6 static address.

Parameters          Current value
------------------------------------------------------------------------------
address                                          Address
enable                   false                   Enable

(config)> network interface my_lan ipv6 static address ?

Address: The IPv6 address to use.
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Format: IPv6_address/prefix_length

Current value:

(config)>
```

8. (Optional) To configure 802.1x port-based network access control:

   Note: The Connect EZ 4 WS can function as an 802.1x authenticator; it does not function as an 802.1x supplicant.

   a. Enable the 802.1x authenticator on the Connect EZ 4 WS device:

   ```
   (config network interface my_lan)> 802_1x authentication enable true
   (config network interface my_lan)>
   ```

   b. Set the frequency period for reauthentication:

   ```
   (config network interface my_lan)> 802_1x authentication reauth_period
   value
   (config network interface my_lan)>
   ```

   where value is an integer between 0 and 86400. The default is 3600.

9. (Optional) Configure the MAC address deny list.

   Incoming packets will be dropped from any devices whose MAC addresses is included in the MAC address deny list.

   a. Add a MAC address to the deny list:

   ```
   (config network interface my_lan)> add mac_denylist end mac_address
   (config network interface my_lan)>
   ```

   where mac_address is a hyphen-separated MAC address, for example, 00-40-9d-2b-81-b6.

   b. Repeat for each additional MAC address.

10. (Optional) Configure the MAC address allowlist.

    If allowlist entries are specified, incoming packets will only be accepted from the listed MAC addresses.

    a. Add a MAC address to the allowlist:

    ```
    (config network interface my_lan)> add mac_allowlist end mac_address
    (config network interface my_lan)>
    ```

    where mac_address is a hyphen-separated MAC address, for example, 00-40-9d-2b-81-b6.

    b. Repeat for each additional MAC address.

11. Save the configuration and apply the changes.

    ```
    (config network interface my_lan)> save
    Configuration saved.
    >
    ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

12. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the ETH1 port as a LAN or in a bridge

By default, the ETH1 Ethernet port on your Connect EZ 4 WS is configured to function as a LAN port, which means that it:

- Uses the Edge firewall zone.
- Receives its IPv4 address from an upstream DHCP server.

Alternatively, you can configure the ETH1 port to function as a LAN port, or you can create a bridge that includes the ETH1 and ETH2 ports and/or Wi-Fi access points.

Configure the ETH1 Ethernet port as a LAN

This procedure reconfigures the ETH1 port to serve as port for a LAN, which will result in the device having two separate LANs: the default **ETH2** LAN, and the LAN created in this procedure. To utilize both LANs, you will need to have a device connected to the ETH1 port, and a separate device connected to the ETH2 port, and these devices will be on separate LANs.

If instead, you want the ETH1 port to be bridged with the ETH2 port, see Create a bridge that includes the ETH1 port.

To configure the ETH1 Ethernet port as a LAN:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces** > **ETH1**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. For **Zone**, select **Edge**.
5. Configure IPv4 settings:
   a. Click to expand **IPv4**.
   b. For **Type**, select **Static IP address**.
   c. For **Address**, type the IPv4 address and netmask, using the format *IPv4_address/netmask*, for example, 192.168.3.1/24.



   d. Enable the DHCP server only if a DHCP server is needed for your use case:
      i. Click to expand **DHCP server**.
      ii. Click to toggle on **Enable**.
6. (Optional) Configure IPv6 settings:
   a. Click to expand **IPv6**.
   b. For **Type**, select **IPv6 prefix delegation**.
7. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Set the **zone** to **internal**:

```
(config)> network interface eth1 zone internal
(config)>
```

4. Configure IPv4 settings:
   a. Set the **type** to **static**:

```
(config)> network interface eth1 ipv4 type static
(config)>
```

   b. Set the address IPv4 address and netmask, using the format *IPv4_address/netmask*, for example:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> network interface eth1 ipv4 address 192.168.3.1/24
(config)>
```

c. Enable the DHCP server:

```
(config)> network interface eth1 ipv4 dhcp_server enable true
(config)>
```

5. (Optional) Configure IPv6:
   a. Set the **type** to **prefix_delegation**:

```
(config)> network interface eth1 ipv6 type prefix_delegation
(config)>
```

6. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Create a bridge that includes the ETH1 port

This procedure will bridge the ETH1 port with the ETH2 port, which will configure the two Ethernet ports to function as a hub.
To bridge the Connect EZ 4 WS device's ETH1 Ethernet port with the ETH2 port or Wi-Fi access points:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.




The **Configuration** window is displayed.

3. Create the bridge and add devices.
   a. Click **Network** > **Bridges**.
   b. For **Add Bridge**, type a name for the bridge and click **+**.




   c. Click to expand **Devices**.
   d. Click **Add Device +**.



   e. For **Device**, select **Device: ath1**.
   f. Click **Add Device +** again and select the **Device: ath2** or access point to add to the bridge.
   g. Repeat for additional access points.
4. Create a LAN interface for the bridge.
   a. Click **Network** > **Interfaces**.
   b. For **Add Interface**, type a name for the interface and click **+**.




   c. For **Zone**, select **Internal**.
   d. For **Device**, select the new bridge.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

e. Click to expand **IPv4**.

f. For **Address**, type the IPv4 address and netmask, using the format *IPv4_address/netmask*. For example, 192.168.3.1/24.



g. Enable the DHCP server:

i. Click to expand **DHCP server**.

ii. Click to toggle on **Enable**.

5. Disable the ETH1 interface:

a. Click **Network** > **Interfaces** > **ETH1**.

b. Click to toggle off **Enable**.

6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Create the bridge and add devices:

a. Create the bridge:

```
(config)> add network bridge bridge_name
(config network bridge bridge_name)>
```

   where *bridge_name* is the name of the new bridge. For example, to create a bridge named LAN1 bridge:

```
(config)> add network bridge LAN1_bridge
(config network bridge LAN1_bridge)>
```

b. Add the **eth1** device:

```
(config network bridge LAN1_bridge)> add device end
/network/device/eth1
(config network bridge LAN1_bridge)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Add the **eth2** device:

```
(config network bridge LAN_bridge)> add device end
/network/device/eth0
(config network bridge LAN_bridge)>
```

d. Add the **eth2** device or access points.

i. Use the tab key (or ?) to determine available devices:

```
(config network bridge LAN_bridge)> add device end [TAB]
(config network bridge LAN_bridge)> add device end /network/[TAB]
/network/device/eth1                /network/device/eth1
/network/device/loopback            /network/bridge/lan1

/network/wlan/wan_bonding           /network/wifi/ap/digi_ap
>
```

ii. Add the device.

```
(config network bridge LAN_bridge)> add device end device-path-
end-value
(config network bridge LAN_bridge)>
```

iii. Repeat for additional access points.

Note If you are adding a port or access point that is already part of the default LAN1 bridge, you should either disable the default bridge, or remove the port or access point:

- To disable the bridge:

```
(config network bridge LAN_bridge)> ... lan1 enable false
(config network bridge LAN_bridge)>
```

- To remove a port or access point from the bridge:

i. Use the show keyword to display the devices:

```
(config network bridge LAN_bridge)> show ... lan1 device
0 /network/device/eth1
1 /network/wifi/ap/digi_ap
(config network bridge LAN_bridge)>
```

ii. Use the device's index number to delete the device. For example, to delete **eth1**, use the 0 index number:

```
(config network bridge LAN_bridge)> del .. lan1 device 0
(config network bridge LAN_bridge)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Create a LAN interface for the bridge.
   a. Type .. to return to the root of the configuration:

```
(config network bridge LAN_bridge)> ..
(config)>
```

   b. Create the bridge:

```
(config)> add network interface interface_name
(config network interface interface_name)>
```

   where **interface_name** is the name of the new interface. For example, to create a interface named LAN_bridge_interface:

```
(config)> add network interface LAN_bridge_interface
(config network interface LAN_bridge_interface)>
```

   c. Set the **zone** to **internal**.

```
(config network interface LAN_bridge_interface)> zone internal
(config network interface LAN_bridge_interface)>
```

   d. Set the **device** to the new bridge:

```
(config network interface LAN_bridge_interface)> device
/network/bridge/LAN_bridge
(config network interface LAN_bridge_interface)>
```

   e. Set the IPv4 address and netmask for the interface, using the format *IPv4_address/netmask*. For example, 192.168.3.1/24.

```
(config network interface LAN_bridge_interface)> ipv4 address
192.168.3.1/24
(config network interface LAN_bridge_interface)>
```

   f. Enable the DHCP server:

```
(config network interface LAN_bridge_interface)> ipv4 dhcp_server
enable true
(config network interface LAN_bridge_interface)>
```

5. Disable the eth1 interface:

```
(config)> network interface eth1 enable false
(config)>
```

6. Save the configuration and apply the change.

```
(config network interface LAN_bridge_interface)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Change the default LAN subnet

You can change the Connect EZ 4 WS default LAN subnet—192.168.2.1/24—to any range of private IPs. The local DHCP server range will also change to the range of the LAN subnet.

To change the LAN subnet:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces** > **LAN** > **IPv4**.
4. For **Address**, change the IP address to an alternate private IP. You must also specify the subnet mask. It must have the syntax of *IPv4_address/ net-mask*.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. At the config prompt, set the IP address to an alternate private IP:

```
(config)> network interface lan1 ipv4 address IPv4_address/network
(config)>
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Example: Configure two LANs

The default configuration of the Connect EZ 4 WS consists of one LAN (named **ETH1**) and one LAN (**ETH2**). For Connect EZ 4 WS Wi-Fi enabled devices, the default configuration of the **ETH2** uses a bridge that consists of two devices, the **ETH2** Ethernet device and the Digi AP Wi-Fi access point.

In this example, we will:

1. Create a new Wi-Fi access point.
2. Create a new bridge that consists of the new access point and the **ETH1** device.
3. Create two new LANs:
   - **LAN1** will be configured to use the new bridge.
   - **LAN2** will be configured to use the **ETH2** device.

Task one: Create a new access point

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in User Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.




The **Configuration** window is displayed.

3. Click **Network** > **Wi-fi** > **Access points**.
4. For **Add Wi-fi access point**, type **Example_AP** for the name of the new access point and click **+**.



The Wi-Fi access point configuration window is displayed.

5. For **SSID**, type **Example_SSID**.
6. Type a **Pre-shared key** that clients will use to access the AP.



7. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Create a new access point:

```
(config)> add network wifi ap Example_AP
(config network wifi ap Example_AP)>
```

New access points are enabled by default.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Set the SSID for the Wi-Fi access point. Up to 32 characters are allowed.

```
(config network wifi ap Example_AP)> ssid Example_SSID
(config network wifi ap Example_AP)>
```

SSID broadcasting is enabled by default for new access points.

5. Set the security for the access point to WPA2.

```
(config network wifi ap Example_AP)> encryption type wpa2
(config network wifi ap Example_AP)>
```

6. Set the password that clients will use when connecting to the access point:

```
(config network wifi ap Example_AP)> encryption key_psk2 password
(config network wifi ap Example_AP)>
```

7. Save the configuration and apply the changes.

```
(config network wireless ap Example_AP)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Task two: Create a new bridge

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.




The **Configuration** window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click **Network** > **Bridges**.
4. For **Add Bridge**, type **Example_bridge** and click **+**.

The new bridge configuration window is displayed.

5. Click to expand **Devices**.
6. For **Add Device**, click **+**.
7. For Device, select **Ethernet: ETH1**.
8. Click **+** again to add another device.
9. For Device, select **Wi-Fi access point: Example_AP**.



10. (Optional) Enable Spanning Tree Protocol (STP).

    STP is used when using multiple LANs on the same device, to prevent bridge loops and other routing conflicts.

    a. Click **STP**.
    b. Click **Enable**.
    c. For **Forwarding delay**, enter the number of seconds that the device will spend in each of the listening and learning states before the bridge begins forwarding data. The default is **2** seconds.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
>config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Create a new bridge:

```
(config)> add network bridge Example_bridge
(config network bridge Example_bridge)>
```

New access points are enabled by default.

4. Use the Tab key (twice) to determine available devices:

```
(config network bridge Example_bridge)> add device eth1 [TAB][TAB]
/network/device/eth1                    /network/device/eth2
/network/device/loopback                /network/bridge/lan
/network/wifi/ap/ctgt_ap                /network/wifi/ap/Example_AP
(config network bridge Example_bridge)> add device eth1 /network/
```

5. Add the **eth1** Ethernet device:

```
(config network bridge Example_bridge)> add device eth1
/network/device/eth1
(config network bridge Example_bridge)>
```

6. Add the **Example_AP** Wi-Fi access point:

```
(config network bridge Example_bridge)> add device eth1
/network/wireless/ap/Example_AP
(config network bridge Example_bridge)>
```

7. (Optional) Enable Spanning Tree Protocol (STP).
   STP is used when using multiple LANs on the same device, to prevent bridge loops and other routing conflicts.
   a. Enable STP:

```
(config network bridge Example_bridge)> stp enable true
```

   b. Set the number of seconds that the device will spend in each of the listening and learning states before the bridge begins forwarding data:

```
(config network bridge Example_bridge)> stp forward_delay 4sec
(config)>
```

   The default is 2 seconds.

8. Save the configuration and apply the change:

```
(config network bridge Example_bridge)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Task three: Create the LANs

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Create LAN1:


   a. Click **Network** > **Interfaces**.

   b. For **Add Interface**, type **LAN1** and click **+**.

   c. For **Zone**, select **Internal**.

   d. For **Device**:

   - If you are configuring a Wi-Fi enabled Connect EZ 4 WS, select **Bridge: Example bridge**.
   - If you are configuring a non-Wi-Fi Connect EZ 4 WS, select **Ethernet: ETH1**.

   e. Click to expand **IPv4**.

   f. For **Address**, type 192.168.3.1/24.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

g. Click to expand **DHCP server**.

h. Click **Enable**.

4. Create LAN2:

a. Click **Network** > **Interfaces**.

b. For **Add Interface**, type **LAN2** and click **+**.

c. For **Zone**, select **Internal**.

d. For **Device**, select **Ethernet: br1**.

e. Click to expand **IPv4**.

f. For **Address**, type **192.168.4.1/24**.

g. Click to expand **DHCP server**.

h. Click **Enable**.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Create the LAN1 interface:

a. Add the interface:

```
(config)> add network interface LAN1
(config network interface LAN1)>
```

b. Configure the LAN1 interface:

i. Enter **device ?** to view available devices and the proper syntax:

```
(config network interface LAN1)> device ?

Device: The network device used by this network interface.
Format:
  /network/device/eth1
  /network/device/eth2
  /network/bridge/LAN
  /network/bridge/[example_bridge]
  /network/wireless/ap/digi_ap
  /network/wireless/ap/[example_AP]
Current value:

(config network interface LAN1)> device
```

ii. Set the device for the LAN1 interface:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- If you are configuring a Wi-Fi enabled Connect EZ 4 WS, set the device to **/network/bridge/bsample_bridge**.

```
(config network interface LAN1)> device
 /network/bridge/bsample_bridge
(config network interface LAN1)>
```

- If you are configuring a non-Wi-Fi Connect EZ 4 WS, set the device to **/network/device/eth1**.

```
(config network interface LAN1)> device /network/device/eth1
(config network interface LAN1)>
```

c. Configure the firewall zone for the LAN1 interface to **internal**.

```
(config network interface LAN1)> zone internal
(config network interface LAN1)>
```

d. Configure the IPv4 address for the LAN1 interface.

```
(config network interface LAN1)> ipv4 address 192.168.1.1/24
(config network interface LAN1)>
```

e. Enable the DHCP server for the LAN1 interface.

```
(config network interface LAN1)> ipv4 dhcp_server enable true
(config network interface LAN1)>
```

4. Create the LAN2 interface.

a. Add the interface.

```
(config)> add network interface LAN2
(config network interface LAN2)>
```

b. Configure the LAN2 interface.

i. Enter **device ?** to view available devices and the proper syntax.

```
(config network interface LAN2)> device ?

Device: The network device used by this network interface.
Format:
   /network/device/eth1
   /network/device/eth2
   /network/bridge/LAN
   /network/bridge/[sample_bridge
   /network/wireless/ap/digi_ap
   /network/wireless/ap/[sample_AP
Current value:

(config network interface LAN1)> device
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

ii. Set the device for the LAN2 interface:

```
(config network interface LAN2)> device /network/device/eth2
(config network interface LAN2)>
```

c. Configure the firewall zone for the LAN2 interface to **internal**:

```
(config network interface LAN2)> zone internal
(config network interface LAN2)>
```

d. Configure the IPv4 address for the LAN2 interface:

```
(config network interface LAN2)> ipv4 address 192.168.4.1/24
(config network interface LAN2)>
```

e. Enable the DHCP server for the LAN2 interface:

```
(config network interface LAN2)> ipv4 dhcp_server enable true
(config network interface LAN2)>
```

5. Save the configuration and apply the changes.

```
(config network interface LAN2)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Task four: Verify the new configuration

The final step in this example is to verify the new configuration.

1. Verify that LAN1 is operating correctly:
   a. Connect a device to LAN1 through the **ETH1** Ethernet port, or by connecting to the Example_AP Wi-Fi1 access point.
   b. Verify that the device has been provided an IP address from the LAN1 DHCP server in the "192.168.3." subnet.
2. Verify that LAN2 is operating correctly:
   a. Connect a device to LAN2 through the **ETH2** Ethernet port.
   b. Verify that the device has been provided an IP address from the LAN2 DHCP server in the "192.168.4." subnet.

Example: Configure two LANs

The default configuration of the Connect EZ 4 WS consists of one LAN (ETH2), which is configured to use the LAN1 bridge. Its Setup IP address is 192.168.2.1, and it has its DHCP server enabled. The default configuration of the LAN1 bridge consists of the following devices:

- ETH2
- ETH3

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- ETH1
- WWAN2 cellular modem
- WWAN2 cellular modem

In this example, we will create a second bridge, called LAN2. We will then create a second LAN, LAN2, and configure LAN2 to use the new bridge.

Note To avoid potential problems with access to the device while performing these procedures, you should use an Ethernet connection connected to LAN1 through the ETH2 Ethernet port, or, if using the command line, use the serial port.

Task one: Configure bridges

In this task, we will create a new bridge and configure the LAN1 and LAN2 bridges to use the following devices:

- LAN1 bridge:
  - ETH2
  - WWAN2 cellular modem
- LAN2 bridge:
  - ETH3
  - Digi AP (WiFi2)

In task two, we will assign the new LAN2 bridge to a LAN.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Configuration > Network > Bridges > LAN1 > Devices**.
4. Delete the **ETH3**, **ETH4**, and **Digi AP [IN-H2]** devices from the bridge.
   a. Click the menu icon (...) next to the **ETH3** device and select **Delete**.

   b. Repeat for the **ETH4** and **Digi AP [IN-H2]** devices.
5. Create a new bridge.
   a. For **Add Bridge**, type **LAN2** and click **+**.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Add the **Ethernet** and **Digi AP (W6-H2)** devices to the bridge:

i. Click to expand **Devices**.

ii. For **Add Device**, click **+**.

iii. For **Device**, select **Ethernet: ETH3**.



iv. For **Add device**, click **+** again and select **Wifi access point: Digi AP (W6-H2)**.

6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Display a list of devices currently configured for the LAN1 bridge:

```
(config)> show network bridge lan1 device
0 /network/device/eth2
1 /network/device/eth3
2 /network/device/eth4
3 /network/wireless/ap/digi_ap1
4 /network/wireless/ap/digi_ap2
(config)>
```

4. Remove devices from the LAN1 bridge that will be used by other interfaces in this configuration.

   a. The Digi AP (W6-H2) access point (/network/wireless/ap/digi_ap2) from the bridge, using its index number, **4**, as determined above with the show command:

```
(config)> del network bridge lan1 device 4
(config)>
```

   b. Remove the ETH4 device (/network/device/eth4) from the bridge, using its index number, **2**, as determined above with the show command:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> del network bridge lan1 device 2
(config)>
```

c. Remove the ETH0 device (/network/device/eth0) from the bridge, using its index number, 1, as determined above with the show command.

```
(config)> del network bridge lan1 device 1
(config)>
```

d. Use the show command again to verify that the LAN1 bridge now has only two devices, ETH2 and Digi AP (WI-FI).

```
(config)> show network bridge lan1 device
0 /network/device/eth2
1 /network/wireless/ap/dtgt_ap1
(config)>
```

5. Create a new bridge, named LAN2.

```
(config)> add network bridge LAN2
(config network bridge LAN2)>
```

6. Add devices to the bridge:

a. View available devices and the proper syntax by using the add device command with the **TAB** autocomplete feature.

```
(config network bridge LAN2)> add device end <TAB>
(config network bridge LAN2)> add device end /network/<TAB>
/network/device/eth1              /network/device/eth2
/network/device/eth3
/network/device/eth4              /network/device/loopback
/network/bridge/LAN2
/network/bridge/lan1              /network/wireless/ap/dtgt_ap1
/network/wireless/ap/dtgt_ap2
(config network bridge LAN2)>
```

b. Add the ETH0 device to the bridge.

```
(config network bridge LAN2)> add device end /network/device/eth0
(config network bridge LAN2)>
```

c. Use Digi AP (WI-FI2) access point to the bridge.

```
(config network bridge LAN2)> add device end
/network/wireless/ap/dtgt_ap1
(config network bridge LAN2)>
```

d. Use the show command again to verify that the LAN2 bridge now has two devices, ETH0 and Digi AP (WI-FI2).

```
(config network bridge LAN2)> show network bridge lan2 device
0 /network/device/eth0
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Interface: Local Area Network (LAN)

```
2 /network/wireless/ap/intf_ap2
(config network bridge LAN2)>
```

7. Save the configuration and apply the changes.

```
(config network bridge LAN2)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Task two: Create a new LAN

In this task, we will create a new LAN, named LAN2, to use the LAN2 bridge created in task one.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces**.
4. For **Add Interface:** type **LAN2** and click **+**.


5. Configure the **LAN2** LAN:
   a. For **Zone**, select **Internal**.
   b. For **Device**, select **Bridge: LAN2**.
   c. Click to expand **IPv4**.
   d. For **Address**, type 192.168.3.1/24.
   e. Click to expand **DHCP server**.
   f. Click **Enable**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Interfaces Local Area Networks (LANs)




8. Enable the access points and set the SSIDs:
   a. Configure **Digi AP (Wi-Fi 1)**:
      i. Click **Network** > **Wi-Fi** > **Access points** > **Digi AP (Wi-Fi 1)**.
      ii. Click **Enable**.
      iii. For **SSID**, type **Example1**.
      iv. For **Pre-shared key**, enter a password that clients will use to connect to this access point.



   b. Configure **Digi AP (Wi-Fi 2)**:
      i. Click **Network** > **Wi-Fi** > **Access points** > **Digi AP (Wi-Fi 2)**.
      ii. Click **Enable**.
      iii. For **SSID**, type **Example2**.
      iv. For **Pre-shared key**, enter a password that clients will use to connect to this access point.

Digi Connect EZ 4 WS User Guide 88

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



7. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a new network interface named LAN2:

```
(config)> add network interface LAN2
(config network interface LAN2)>
```

4. Configure the device for the LAN2 interface:

   a. Enter **device ?** to view available devices and the proper syntax.

```
(config network interface LAN2)> device ?

Device: The network device used by this network interface.
Format:
  /network/device/eth1
  /network/device/eth2
  /network/device/eth3
  /network/device/ethe
  /network/device/loopback
  /network/bridge/LAN2
  /network/bridge/lan1
  /network/wireless/ap/dtgt_ap1
  /network/wireless/ap/dtgt_ap2
Current value:

(config network interface LAN2)> device
```

   b. Set the device for the LAN2 interface to the LAN2 bridge created in task one:

```
(config network interface LAN2)> device /network/bridge/LAN2
(config network interface LAN2)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Configure the firewall zone for the LAN2 interface to **internal**:

```
(config network interface LAN2)> zone internal
(config network interface LAN2)>
```

6. Configure the IPv4 address for the LAN2 interface:

```
(config network interface LAN2)> ipv4 address 192.168.3.1/24
(config network interface LAN2)>
```

7. Enable the DHCP server for the LAN2 interface:

```
(config network interface LAN2)> ipv4 dhcp_server enable true
(config network interface LAN2)>
```

8. Enable the access points and set the SSIDs:
   a. Move to the root of the configuration schema by typing three periods (...):

```
(config network interface LAN2)> ...
(config)>
```

   b. Enable the Digi AP (Wi-Fi1) access point:

```
(config)> network wifi ap dtgi_ap1 enable true
(config)>
```

   c. Set the SSID for the Digi AP (Wi-Fi1) access point:

```
(config)> network wifi ap dtgi_ap1 ssid Example1
(config)>
```

   d. Set the password for the Digi AP (Wi-Fi1) access point:

```
(config)> network wifi ap dtgi_ap1 encryption key_psk1 password1
(config)>
```

   e. Enable the Digi AP (Wi-Fi2) access point:

```
(config)> network wifi ap dtgi_ap2 enable true
(config)>
```

   f. Set the SSID for the Digi AP (Wi-Fi2) access point:

```
(config)> network wifi ap dtgi_ap2 ssid Example2
(config)>
```

   g. Set the password for the Digi AP (Wi-Fi2) access point:

```
(config)> network wifi ap dtgi_ap2 encryption key_psk2 password2
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

ii. Save the configuration and apply the changes.

```
(config network bridge LAN1)> save
Configuration saved.
>
```

iii. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Task three: Verify the new configuration

The final step in this example is to verify the new configuration.

1. Connect an Ethernet cable from an Internet-connected modem to WAN1 through the WAN/ETH1 Ethernet port.
2. Verify that LAN1 is operating correctly:
   a. Connect a device to LAN1 through the ETH2 Ethernet port, or by connecting to the Digi AP (Wi-Fi1) access point.
   b. Verify that the device has been provided an IP address from the LAN1 DHCP server in the 192.168.2.* subnet.
3. Verify that LAN2 is operating correctly:
   a. Connect a device to LAN2 through the ETH3 Ethernet port, or by connecting to the Digi AP (Wi-Fi2) access point.
   b. Verify that the device has been provided an IP address from the LAN2 DHCP server in the 192.168.3.* subnet.

Show LAN status and statistics

Web

Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.

1. From the menu, click **Status**.
2. Under **Networking**, click **Interfaces**.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Enter the show network command at the Admin CLI prompt:

```
> show network

Interface        Proto  Status     Address
---------------  -----  ---------  ------------------------------------
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
setup1p          IPv4   up        192.168.210.1/24
setup1p6localip  IPv6   up          169.254.188.188/16
eth2             IPv4   up          192.168.3.1/24
eth2             IPv6   up          fd60:2704::1/48
loopback         IPv4   up          127.0.0.1/8
```

3. Additional information can be displayed by using the show network verbose command.

```
> show network verbose

Interface          Proto  Status   Type     Zone       Device     Metric :
weight
-----------------  -----  -------  -------  ---------  ---------  -------  -
------
setup1p          IPv4   up       static   setup      eth2       10       10
setup1p6localip  IPv6   up         static   setup      eth2       0        10
eth2             IPv4   up         static   internal   eth2       5        10
eth2             IPv6   up         static   internal   eth2       5        10
loopback         IPv4   up         static   loopback   loopback   0        10
```

4. Enter **show network interface name** at the Admin CLI prompt to display additional information about a specific LAN. For example, to display information about ETH2, enter **show network interface eth2**.

```
> show network interface eth2

lan1 Interface Status
---------------------

Device                : eth2
Zone                  : internal

IPv4 Status           : up
IPv4 Type             : static
IPv4 Address(es)      : 192.168.3.1/24
IPv4 Gateway          :
IPv4 MTU              : 2560
IPv4 Metric           : 5
IPv4 Weight           : 10
IPv4 DNS Server(s)    :

IPv6 Status           : up
IPv6 Type             : prefix
IPv6 Address(es)      : fd60:2704::1/48
IPv6 Gateway          :
IPv6 MTU              : 2560
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
IPv6 Metric          : 5
IPv6 Weight          : 10
IPv6 DNS Server[0]   :
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete a LAN

Follow this procedure to delete any LANs that have been added to the system. You cannot delete the preconfigured LAN, **LAN1**.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces**.
4. Click the menu icon (...) next to the name of the LAN to be deleted and select **Delete**.

5. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Use the **del** command to delete the LAN. For example, to delete a LAN named my_lan:

```
(config)> del network interface my_lan
```

4. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

DHCP servers

You can enable DHCP on your Connect EZ 4 WS device to assign IP addresses to clients, using either:

- The DHCP server for the device's local network, which assigns IP addresses to clients on the device's local network. Addresses are assigned from a specified pool of IP addresses. For a local network, the device uses the DHCP server that has the IP address pool in the same IP subnet as the local network.

  When a host receives an IP configuration, the configuration is valid for a particular amount of time, known as the lease time. After this lease time expires, the configuration must be renewed. The host renews the lease time automatically.

- A DHCP relay server, which forwards DHCP requests from clients to a DHCP server that is running on a separate device.

Configure a DHCP server

Note These instructions assume you are configuring the device to use its local DHCP server. For instructions about configuring the device to use a DHCP relay server, see Configure DHCP relay.

Required configuration items

- Enable the DHCP server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Additional configuration items

- The lease address pool: the range of IP addresses leased by the DHCP server to clients.
- Lease time: the length, in minutes, of the leases issued by the DHCP server.
- The Maximum Transmission Units (MTU).
- The domain name suffix appended to host names.
- The IP gateway address given to clients.
- The IP addresses of the preferred and alternate Domain Name Server (DNS), NTP servers, and WINS servers that are given to clients.
- The TFTP server name.
- The filepath and name of the bootfile on the TFTP server.
- Custom DHCP options. See Configure DHCP options for information about custom DHCP options.
- Static leases. See Map static IP addresses to hosts for information about static leases.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces**.
4. Click to expand an existing LAN, or create a new LAN. See Configure a Local Area Network (LAN).
5. Click to expand **IPv4** > **DHCP server**.
6. **Enable** the DHCP server.
7. (Optional) For **Lease time**, type the amount of time that a DHCP lease is valid.
   Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number**(w|d|h|m|s).

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

For example, to set **Lease time** to ten minutes, enter **10m** or **600s**.

The default is 12 hours.

- By default, DHCP leases are persistent across reboots. You can disable persistent leases:
  a. Click **Network** > **Advanced**.
  b. Click to toggle off **DHCP persistent leases**.

8. (Optional) For **Lease range start** and **Lease range end**, type the lowest and highest IP address that the DHCP server will assign to a client. This value represents the low order byte of the address (the final triplet in an IPv4 address, for example, 192.168.2.xxx). The remainder of the IP address will be based on the LAN's static IP address as defined in the **Address** field.

   Allowed values are between 1 and 254, and the default is 100 for **Lease range start** and 250 for **Lease range end**.

   - Sequential DHCP address allocation

     By default, DHCP addresses are assigned pseudo-randomly, using a hash of the client's MAC address to determine the IP address that gets assigned. You can configure the device to use sequential IP addresses instead.

     a. Click **Network** > **Advanced**.
     b. Click to enable **Sequential DHCP address allocation**.

     Because sequential mode does not use a hash based on the client's MAC address, when DHCP leases expires, the client is not likely to get the same IP address assigned to it. Therefore, sequential DHCP address allocation generally should not be used.

9. Optional DHCP server settings:
   a. Click to expand **Advanced settings**.
   b. For **Gateway**, select either:
      - **None**: No gateway is broadcast by the DHCP server. Client destinations must be reachable without a gateway.
      - **Automatic**: Broadcasts the Connect EZ 4 WS device's gateway.
      - **Custom**: Allows you to identify the IP address of a **Custom gateway** to be broadcast.

     The default is **Automatic**.
   c. For **MTU**:
      - **None**: An MTU of length 0 is broadcast. This is not recommended.
      - **Automatic**: No MTU is broadcast, and clients will determine their own MTU.
      - **Custom**: Allows you to identify a **Custom MTU** to be broadcast.

     The default is **Automatic**.
   d. For **Domain name suffix**, type the domain name that should be appended to host names.
   e. For **Primary** and **Secondary DNS**, **Primary** and **Secondary NTP server**, and **Primary** and **Secondary WINS server**, select either:
      - **None**: No server is broadcast.
      - **Automatic**: Broadcasts the Connect EZ 4 WS device's server.
      - **Custom**: Allows you to identify the IP address of the server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Enable **DDDD** dynamic allocation to automatically assign an IP address to a device on the server.

   CAUTION! The IP address assigned to the device is leased forever and becomes permanently unavailable for other hosts to use.

2. For **Bootfile name**, type the relative path and file name of the bootfile on the TFTP server.
3. For **TFTP server** name, type the IP address or host name of the TFTP server.
4. Enable.

10. See Configure DHCP options for information about **Custom DHCP options**.
11. See Map static IP addresses to hosts for information about **Static leases**.
12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable the DHCP server for an existing LAN. For example, to enable the DHCP server for a LAN named **my_lan**:

```
(config)> network interface my_lan ipv4 dhcp_server enable true
(config)>
```

   See Configure a Local Area Network (LAN) for information about creating a LAN.

4. (Optional) Set the amount of time that a DHCP lease is valid:

```
(config)> network interface my_lan ipv4 dhcp_server lease_time value
(config)>
```

   where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number[w|d|h|m|s]**.

   For example, to set **network interface my_lan ipv4 dhcp_server lease_time** to ten minutes, enter either **10m** or **600s**:

```
(config)> network interface my_lan ipv4 dhcp_server lease_time 10m
(config)>
```

   - By default, DHCP leases are persistent across reboots. You can disable persistent leases:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

```
(config)> network advanced dhcp_persistent_lease false
(config)>
```

5. (Optional) Set the lowest IP address that the DHCP server will assign to a client. This value represents the low order byte of the address (the final triplet in an IPv4 address, for example, 192.168.2.xxx). The remainder of the IP address will be based on the LAN's static IP address as defined in the **address** parameter.

```
(config)> network interface eg_lan ipv4 dhcp_server lease_start num
(config)>
```

Allowed values are between **1** and **254**, and the default is **100**.

6. (Optional) Set the highest IP address that the DHCP server will assign to a client.

```
(config)> network interface eg_lan ipv4 dhcp_server lease_end num
(config)>
```

Allowed values are between **1** and **254**, and the default is **250**.

7. Sequential DHCP address allocation

By default, DHCP addresses are assigned pseudo-randomly, using a hash of the client's MAC address to determine the IP address that gets assigned. You can configure the device to use sequential IP addresses instead:

```
(config)> network advanced sequential_dhcp_allocation true
(config)>
```

Because sequential mode does not use a hash based on the client's MAC address, when DHCP leases expires, the client is not likely to get the same IP address assigned to it. Therefore, sequential DHCP address allocation generally should not be used.

8. Optional DHCP server settings

a. Click to expand **Advanced settings**.

b. Determine how the DHCP server should broadcast the gateway server:

```
(config)> network interface eg_lan ipv4 dhcp_server advanced gateway
value
(config)>
```

where **value** is one of:

- **none**: No gateway is broadcast by the DHCP server. Client destinations must be reachable without a gateway.
- **auto**: Broadcasts the Connect EZ 4 WS device's gateway.
- **custom**: Allows you to identify the IP address of a custom gateway to be broadcast.

```
(config)> network interface eg_lan ipv4 dhcp_server advanced
gateway_custom ip_address
(config)>
```

The default is **auto**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Determine how the DHCP server should broadcast the the MTU:

```
(config)> network interface eq_lan ipv4 dhcp_server advanced mtu value
(config)>
```

where **value** is one of:

- **none**: An MTU of length 0 is broadcast. This is not recommended.
- **auto**: No MTU is broadcast and clients will determine their own MTU.
- **custom**: Allows you to identify a custom MTU to be broadcast:

```
(config)> network interface eq_lan ipv4 dhcp_server advanced
mtu_custom mtu
(config)>
```

The default is **auto**.

d. Set the domain name that should be appended to host names:

```
(config)> network interface eq_lan ipv4 dhcp_server advanced domain_
suffix name
(config)>
```

e. Set the IP address or host name of the primary and secondary DNS, the primary and secondary NTP server, and the primary and secondary WINS servers:

```
(config)> network interface eq_lan ipv4 dhcp_server advanced primary_
dns value
(config)> network interface eq_lan ipv4 dhcp_server advanced
secondary_dns value
(config)> network interface eq_lan ipv4 dhcp_server advanced primary_
ntp value
(config)> network interface eq_lan ipv4 dhcp_server advanced
secondary_ntp value
(config)> network interface eq_lan ipv4 dhcp_server advanced primary_
wins value
(config)> network interface eq_lan ipv4 dhcp_server advanced
secondary_wins value
(config)>
```

where **value** is one of:

- **none**: No server is broadcast.
- **auto**: Broadcasts the Connect EZ 4 WS device's server.
- **custom**: Allows you to identify the IP address of the server. For example:

```
(config)> network interface eq_lan ipv4 dhcp_server advanced
primary_dns_custom ip_address
(config)>
```

The default is **auto**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Set the IP address or host name of the DHCP server.

```
(config)> network interface my_lan ipv4 dhcp_server advanced dhcp_
server ip_address
(config)>
```

2. Set the relative path and file name of the bootfile on the DHCP server.

```
(config)> network interface my_lan ipv4 dhcp_server advanced bootfile
 filename
(config)>
```

3. Enable **BOOTP dynamic allocation** to automatically assign an IP address to a device on this server.

CAUTION! The IP address assigned to the device is leased forever and becomes permanently unavailable for other hosts to use.

```
(config)> network interface my_lan ipv4 dhcp_server advanced bootp_
dynamic true
(config)>
```

II. See Configure DHCP options for information about custom DHCP options.

III. See Map static IP addresses to hosts for information about static leases.

11. Save the configuration and apply the changes.

```
(config network interface my_lan ipv4 dhcp_server advanced static_lease
s)> save
Configuration saved.
>
```

12. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Map static IP addresses to hosts

You can configure the DHCP server to assign static IP addresses to specific hosts.

Required configuration items

- IP address that will be mapped to the device.
- MAC address of the device.

Additional configuration items

- A label for this instance of the static lease.

To map static IP addresses:

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces**.
4. Click to expand an existing LAN, or create a new LAN. See Configure a Local Area Network (LAN).
5. Click to expand **IPv4** > **DHCP server** > **Advanced settings** > **Static leases**.
6. For **Add Static lease**, click **+**.
7. Type the **MAC address** of the device associated with this static lease.
8. Type the **IP address** for the static lease.

   Note The IP address here should be outside of the DHCP server's configured lease range. See Configure a DHCP server for further information about the lease range.

9. (Optional) For **Hostname**, type a label for the static lease. This does not have to be the device's actual hostname.
10. Repeat for each additional DHCP static lease.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Add a static lease to the DHCP server configuration for an existing LAN. For example, to add static lease to a LAN named my_lan:

```
(config)> add network interface my_lan ipv4 dhcp_server advanced static_
lease end
(config network interface my_lan ipv4 dhcp_server advanced static_lease
0)>
```

See Configure a Local Area Network (LAN) for information about creating a LAN.

4. Set the MAC address of the device associated with this static lease, using the colon-separated format.

```
(config network interface my_lan ipv4 dhcp_server advanced static_lease
0)> mac 00:40:9d:13:3b:3d
(config network interface my_lan ipv4 dhcp_server advanced static_lease
0)>
```

5. Set the IP address for the static lease.

```
(config network interface my_lan ipv4 dhcp_server advanced static_lease
0)> ip 10.81.81.10
(network interface my_lan ipv4 dhcp_server advanced static_lease 0)>
```

Note The IP address here should be outside of the DHCP server's configured lease range. See Configure a DHCP server for further information about the lease range.

6. (Optional) Set a label for this static lease.

```
(config network interface my_lan ipv4 dhcp_server advanced static_lease
0)> name label
(config network interface my_lan ipv4 dhcp_server advanced static_lease
0)>
```

7. Save the configuration and apply the change.

```
(config network interface my_lan ipv4 dhcp_server advanced static_lease
0)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show current static IP mapping

To view your current static IP mapping:

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.

1. On the main menu, click **Status**.
2. Under **Networking**, click **DHCP Leases**.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Show the static lease configuration. For example, to show the static leases for a lan named **my_lan**:

```
(config)> show network interface my_lan ipv4 dhcp_server advanced static_
lease
0
    ip 192.168.2.10
    mac 8F:C3:4C:34:6E:8A
    no name
1
    ip 192.168.2.11
    mac E2:C1:1F:02:C2:6E
    no name
(config)>
```

4. Type **cancel** to exit configuration mode.

```
(config)> cancel
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete static IP mapping entries

To delete a static IP entry:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Network** > **Interfaces**.
4. Click to expand an existing LAN.
5. Click to expand **IPv4** > **DHCP server** > **Advanced settings** > **Static leases**.
6. Click the menu icon (...) next to the name of the static lease to be deleted and select **Delete**.

7. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Show the static lease configuration. For example, to show the static lease list is lan named **my_lan**:

```
(config)> show network interface my_lan type4 dhcp_server advanced static_
lease
0
    ip 192.168.1.10
    mac BF:C3:46:34:8C:D9
    no name
1
    ip 192.168.1.11
    mac F3:C1:1F:G3:C1:8C
    no name
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Use the **del index_number** command to delete a static lease. For example, to delete the static lease for the device listed in the above output with a mac address of 0F:D3:46:24:BC:D9 (index number 0):

```
(config)> del network interface lan1 ipv4 dhcp_server advanced static_
lease 0
(config)>
```

5. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure DHCP options

You can configure DHCP servers running on your Connect EZ device to send certain specified DHCP options to DHCP clients. You can also set the user class, which enables you to specify which specific DHCP clients will receive the option. You can also force the command to be sent to the clients.

DHCP options can be set on a per-LAN basis, or can be set for all LANs. A total of 32 DHCP options can be configured.

Required configuration items

- DHCP option number
- Value for the DHCP option

Additional configuration items

- The data type of the value.
- Force the option to be sent to the DHCP clients.
- A label for the custom option.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces**.
4. Click to expand an existing LAN, or create a new LAN. See Configure a Local Area Network (LAN).
5. Click to expand **IPv4** > **DHCP server** > **Advanced settings** > **Custom DHCP option**.
6. For **Add Custom option**, click **+**.

   Custom options are enabled by default. To disable, toggle off **Enable**.
7. For **Option number**, type the DHCP option number.
8. For **Value**, type the value of the DHCP option.
9. (Optional) For **Label**, type a label for the custom option.
10. (Optional) If **Forced send** is enabled, the DHCP option will always be sent to the client, even if the client does not ask for it.
11. (Optional) For **Data type**, select the data type that the option uses. If the incorrect data type is selected, the device will send the value as a string.
12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a custom DHCP option to the DHCP server configuration for an existing LAN. For example, to add static leases to a LAN named **my_lan**:

```
(config)> add network interface my_lan ipv4 dhcp_server advanced custom_
option end
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)>
```

See Configure a Local Area Network (LAN) for information about creating a LAN.

4. Custom options are enabled by default. To disable:

```
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)> enable false
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)>
```

5. Set the option number for the DHCP option:

```
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)> option 210
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)>
```

6. Set the value for the DHCP option:

```
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)> value_str value
(network interface my_lan ipv4 dhcp_server advanced custom_option 0)>
```

7. (Optional) Set a label for this custom option:

```
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)> name label
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)>
```

8. (Optional) To force the DHCP option to always be sent to the client, even if the client does not ask for it:

```
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)> force true
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)>
```

9. (Optional) Set the data type that the option uses.
If the incorrect data type is selected, the device will send the value as a string.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)> datatype value
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)>
```

where value is one of:

- 1byte
- 2byte
- 4byte
- hex
- ipv4
- str

The default is **str**.

iii. Save the configuration and apply the change.

```
(config network interface my_lan ipv4 dhcp_server advanced custom_option
0)> save
Configuration saved.
>
```

iv. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure DHCP relay

DHCP relay allows a router to forward DHCP requests from one LAN to a separate DHCP server, typically connected to a different LAN.

For the Connect EZ 4 WS device, DHCP relay is configured by providing the IP address of a DHCP relay server, rather than an IP address range. If both the DHCP relay server and an IP address range are specified, DHCP relay is used, and the specified IP address range is ignored.

Multiple DHCP relay servers can be provided for each LAN. If multiple relay servers are provided, DHCP requests are forwarded to all servers without waiting for a response. Clients will typically use the IP address from the first DHCP response received.

Configuring DHCP relay involves the following items:

Required configuration items

- Disable the DHCP server, if it is enabled.
- IP address of the primary DHCP relay server, to define the relay server that will respond to DHCP requests.

Additional configuration items

- IP address of additional DHCP relay servers.

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces**.
4. Click to expand an existing LAN, or create a new LAN. See Configure a Local Area Network (LAN).
5. Disable the DHCP server, if it is enabled:
   a. Click to expand **IPv4** > **DHCP server**.
   b. Click **Enable** to toggle off the DHCP server.
6. Click to expand **DHCP relay**.
7. For **Add DHCP Server:**, click **+**.
8. For **DHCP server address**, type the IP address of the relay server.
9. Repeat for each additional DHCP relay server.
10. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

   ```
   > config
   (config)>
   ```

3. Add a DHCP relay server to an existing LAN. For example, to add a server to a LAN named **my_lan**:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> add network interface my_lan ipv4 dhcp_relay end
(config network interface lan1 my_lan dhcp_relay 0)>
```

See [Configure a Local Area Network (LAN)] for information about creating a LAN.

4. Set the IP address of the DHCP relay server:

```
(config network interface my_lan ipv4 dhcp_relay 0)> address 10.10.10.10
(config network interface my_lan ipv4 dhcp_relay 0)>
```

5. (Optional) Add additional DHCP relay servers:

   a. Move back one step in the configuration schema by typing two periods (..):

   ```
   (config network interface my_lan ipv4 dhcp_relay 0)> ..
   (config network interface my_lan ipv4 dhcp_relay)>
   ```

   b. Add the next server:

   ```
   (config network interface lan1 ipv4 dhcp_relay)> add end
   (config network interface lan1 ipv4 dhcp_relay 1)>
   ```

   c. Set the IP address of the DHCP relay server:

   ```
   (config network interface my_lan ipv4 dhcp_relay 1)> address
   10.10.10.11
   (config network interface my_lan ipv4 dhcp_relay 1)>
   ```

   d. Repeat for each additional relay server.

6. Disable the DHCP server, if it is enabled:

```
(config network interface my_lan ipv4 dhcp_relay 1)> .. .. dhcp_server
enable false
(config network interface my_lan ipv4 dhcp_relay 1)>
```

7. Save the configuration and apply the change:

```
(config network interface lan1 ipv4 dhcp_relay 1)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show DHCP server status and settings

View DHCP status to monitor which devices have been given IP configuration by the Connect EZ device and to diagnose DHCP issues.

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **Status**.
2. Under **Networking**, click **DHCP Leases**.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Enter the show dhcp-lease command at the Admin CLI prompt:

```
> show dhcp-lease

IP Address      Hostname          Expires
--------------  ----------------  -------
192.168.2.194   RTN-ENG-2SGR1
192.168.2.195   RTN-ENG-2SGR2

>
```

3. Additional information can be returned by using the show dhcp-lease verbose command.

```
> show dhcp-lease verbose

 IP Address      Hostname        Expires                    Type      Active
MAC Address
 --------------  --------        -------------------------  --------  ------
----------------
 192.168.2.194   RTN-ENG-2SGR1 May 10 08:25:11 UTC 2021  Dynamic   Yes
ba:ba:1a:13:8c:71
 192.168.2.195   RTN-ENG-2SGR2 May 20 11:33:13 UTC 2021  Dynamic   Yes
68:eb:18:f9:bc:18

>
```

4. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Default services listening on LAN ports

The following table lists the default services listening on the specified ports on the Connect EZ 4 WS LAN interfaces.

Description	Protocol*	Port number
DNS server	UDP	53
DHCP server	UDP	67 and 68

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Description	Default*	Port number
SSH server	ED*	22
Web UI	ED*	443 (also listens on port 80, then redirects to port 443

Virtual LANs (VLANs)

Virtual LANs (VLANs) allow splitting a single physical LAN into separate Virtual LANs. Each device on a VLAN can only access other devices on the same VLAN and each device is unaware of any other VLAN, which isolates network traffic from one another, even though they run over the same physical network.

Your Connect EZ 4 WS device supports two VLAN modes:

- Trunking: Supports multiple VLANs per Ethernet port, which enables you to extend your VLANs across multiple switches through your entire network.
- Switchport: Each Ethernet port can have one or more VLAN IDs associated to it. Any untagged VLAN packets that come into a network interface are automatically tagged with the primary VLAN ID for that switchport. This allows devices on the network that aren't configured with a VLAN to act as if they are directly connected to the VLAN.

This section contains the following topics:

Create a trunked VLAN mode 121
Create a VLAN using switchport mode 123

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Create a trunked VLAN route

Required configuration items

- Devices to be assigned to the VLAN.
- The VLAN ID. The 'ID' header uses the VLAN ID to identify the destination VLAN for the packet.

To create a VLAN:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Virtual LAN**.
4. Type a name for the VLAN and click **+**.
5. Select the **Device**.
6. Type or select a unique numeric **ID** for the VLAN ID.
7. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Add the VLAN:

```
[config]> add network vlan name
[config]>
```

4. Set the device to be used by the VLAN:
   a. View a list of available devices:

```
(config network vlan vlan1)> device ?

Device: The Ethernet device to use for this virtual LAN
Format:
  /network/device/eth1
  /network/device/eth2
  /network/device/loopback
  /network/vlan/vlan1
  /network/bridge/lan
  /network/wireless/ap/digi_ap
Current value:

(config network vlan vlan1)>
```

   b. Add the device:

```
(config network vlan vlan1)> device /network/device/
(config network vlan vlan1)>
```

5. Set the VLAN ID:

```
(config network vlan vlan1)> id value
```

   where *value* is an integer between 1 and 4095.
6. Save the configuration and apply the change:

```
(config network vlan vlan1)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Create a VLAN using switchport mode

Required configuration items

- Devices to be assigned to the VLAN.
- The VLAN ID. The 802.1Q header uses the VLAN ID to identify the destination VLAN for the packet.

To create a VLAN using switchport mode:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Bridges**.
4. For **Add Bridge**, type a name for the bridge and click **+**.
5. Bridges are enabled by default. To disable, toggle off **Enable**.
6. For **Bridge type**, select **Switchport**.
7. (Optional) Enable Spanning Tree Protocol (STP).

   STP is used when using multiple LANs on the same device, to prevent bridge loops and other routing conflicts.

   a. Click **STP**.

   b. Click **Enable**.

   c. For **Forwarding delay**, enter the number of seconds that the device will spend in each of the listening and learning states before the bridge begins forwarding data. The default is 2 seconds.
8. For **Port**, type a name for the VLAN port and click **+**. Generally, numbers are used for VLAN ports.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

ii. Select the **Device** that the port uses.

iii. Configure Vlan IDs:

a. Click to expand **Vlan IDs**.

b. Click **+** for **Add Vlan ID**.

c. Type or select a unique numeric **Vlan ID**.

d. Click **+** for **Add Vlan ID** again to add additional VLAN IDs.

iv. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add the VLAN:

```
(config)> add network vlan name
(config)>
```

4. Set the device to be used by the VLAN:

   a. View a list of available devices:

```
(config network vlan vlan1)> device ?

Device: The Ethernet device to use for this virtual LAN
Format:
  /network/device/eth1
  /network/device/eth2
  /network/device/loopback
  /network/vlan/vlan1
  /network/bridge/lan
  /network/wireless/apinterface_ac
Current value:

(config network vlan vlan1)>
```

   b. Add the device:

```
(config network vlan vlan1)> device /network/device/
(config network vlan vlan1)>
```

5. Set the VLAN ID:

```
(config network vlan vlan1)> id value
```

   where **value** is an integer between 1 and **4095**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Interface: Virtual LAN ID (VLAN ID)

8. Save the configuration and apply the changes.

```
(config network vlan vlan)# save
Configuration saved.
#
```

9. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Bridging

Bridging is a mechanism to create a single network consisting of multiple devices, such as Ethernet devices and wireless access points. You can also use bridging to create a Virtual LAN switchport bridge. See [illegible] for more information about switchport bridging for VLANs.

This section contains the following topics:

Configure a bridge ..... [illegible]

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure a bridge

Required configuration items

- A name for the bridge.
  Bridges are enabled by default.
- Devices to be included in the bridge.

Additional configuration items

- Enable Spanning Tree Protocol (STP).

To create a bridge:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:
   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:
   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Bridges**.
4. For **Add bridge**, type a name for the bridge and click **+**.
5. Bridges are enabled by default. To disable, toggle off **Enable**.
6. For **Bridge type**, select **Standard**.
   See Create a VLAN using switchport mode for information about switchport bridging.
7. (Optional) Enable Spanning Tree Protocol (STP).
   STP is used when using multiple LANs on the same device, to prevent bridge loops and other routing conflicts.
   a. Click **STP**.
   b. Click **Enable**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. For **Forwarding delay**, enter the number of seconds that the device will spend in each of the listening and learning states before the bridge begins forwarding data. The default is 2 seconds.

8. (Optional) Enable Rapid Spanning Tree Protocol (RSTP) for faster response to topology changes on the network.
   a. Click **RSTP** to enable.
   b. For **Hello time**, enter the number of seconds between bridge protocol units (BPDUs) sent on a port. The default is 2 seconds.
   c. For **Max Age**, enter the maximum number of seconds before a bridge port saves its BPDU configuration. The default is 20 seconds.
   d. For **Priority**, enter the system priority. The default priority number is 8.
   e. (Optional) For **Custom mstpd options**, enter the extra configuration options to pass to mstpd daemon.

9. Add devices to the bridge.
   a. Click to expand **Devices**.
   b. For **Add device**, click +.
   c. Select the **Device**.
   d. Repeat to add additional devices.

Note The MAC address of the bridge is taken from the first available device in the list.

10. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Create the bridge.

```
(config)> add network bridge my_bridge
(config network bridge my_bridge)>
```

4. Bridges are enabled by default.
   - To disable:

```
(config network bridge my_bridge)> enable false
(config network bridge my_bridge)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To enable if it has been disabled:

```
(config network bridge my_bridge)> enable true
(config network bridge my_bridge)>
```

5. Set the bridge **mode** to **standard**:

```
(config network bridge my_bridge)> mode standard
(config network bridge my_bridge)>
```

6. Add devices to the bridge:
   a. Determine available devices:

```
(config network bridge my_bridge)> .. .. interface lan device ?


Default value: /network/lan
Current value: /network/lan

(config network bridge my_bridge)>
```

   b. Add the appropriate devices. For example, to add the **Digi AP** Wi-Fi access point:

```
(config network bridge my_bridge)> add device end
/network/wireless/ap/digi_ap
(config)>
```

Note The MAC address of the bridge is taken from the first available device in the list.

7. (Optional) Enable Spanning Tree Protocol (STP).

   STP is used when using multiple LANs on the same device, to prevent bridge loops and other routing conflicts.
   a. Enable STP:

```
(config network bridge my_bridge)> stp enable true
```

   b. Set the number of seconds that the device will spend in each of the listening and learning states before the bridge begins forwarding data:

```
(config network bridge my_bridge)> stp forward_delay num
(config)>
```

   The default is 2 seconds.

8. (Optional) Enable Rapid Spanning Tree Protocol (RSTP) for faster responses to topology changes on the network.

```
(config network bridge my_bridge)> rstp enable true
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

ii. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

iii. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure a TCP connection timeout

You can configure the number of times an unacknowledged TCP data packet will be retransmitted before the connection is considered lost.

This feature is useful as it allows a backup system to control the serial port if the primary system goes offline, or for the primary system to be able to recover regardless of whether there has been a network disruption.

A low number of retries will end a "stale" connection more quickly than a larger number. The default is 15 retries.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Set the TCP retry attempts value:

   a. Click **Network** > **Advanced**.

   b. For **TCP retries2**, enter the number of times an unacknowledged TCP data packet will be transmitted before the connection is considered lost.

   Minimum: 0

   Maximum: 255

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Interfaces Configure a TCP connection timeout

Default: 15

4. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port

Connect EZ 4 WS devices have multiple serial ports that provide access to different features, depending on the serial port mode selection.

Default serial port configuration

You can review the default serial port configuration for your device.

Serial mode options

You can choose a serial mode option for each serial port, depending on the feature that you want to use.

- Login: Allows the port to be used to log into the CLI.
- Remote Access: Provides socket level access to ports.
- Application: Provides access to the serial device from Python applications.
- PPP dial-in: Allows the device to answer Point-to-Point Protocol (PPP) connections over serial ports.
- RealPort: Exposes a serial port on a remote device as a standard COM/TTY port on a client computer. RealPort is configured using the **Digi Navigator**. For more information about configuring RealPort, see Configure RealPort mode using the Digi Navigator.
- UDP serial: Provides access to the serial port using UDP.
- Modem emulation: Allows the device to act as a dial-up modem emulator for handling incoming AT dial-ins.
- Modbus: Allows the device to function as a Modbus protocol gateway.

View serial port information

- Show serial port status and statistics
- Review the serial port message log

Default serial port configuration

The Connect EZ 4 WS default serial port configuration is:

- **Enabled**: enabled
- **Serial mode**: Remote access

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **Label**: None
- **Baud rate**: 9600
- **Data bits**: 8
- **Parity**: None
- **Stop bits**: 1
- **Flow control**: None
- **Escape sequence**: None
- **History size**: 0
- **Exclusive access**: disabled
- **Idle timeout**: 0 m

Baud rate options

The baud rate options are: 50, 75, 110, 134, 150, 200, 300, 600, 1200, 1800, 2400, 4800, 9600, 14400, 19200, 28800, 38400, 57600, 115200, 230400

- **Default baud rate**: 9600
- **Minimum baud rate**: 50
- **Maximum baud rate**: 230400

Configure Login mode for a serial port

Login mode allows the user to log into the device through the serial port.

To change the configuration to match the serial configuration of the device to which you want to connect:

Web

1. Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.
2. On the menu, click **System**. Under **Configuration**, click **Serial Configuration**.



The **Serial Configuration** page is displayed.



Note You can also configure the serial port by using **Device Configuration** > **Serial**. Changes made by using either **Device Configuration** or **Serial Configuration** will be reflected in both.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click the name of the port that you want to configure.



The serial port is enabled by default. To disable, toggle off **Enable**.

4. For **Mode**, select **Login**.
5. Enable **ATpm** to use the ATpm feature. **ATpm** is disabled by default. If you enable **ATpm** in RS-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **ATpm** has no impact on 422 or 485 mode. For more information, see Serial connection pinout.
6. (Optional) For **Label**, enter a label that will be used when referring to this port.
7. For **Signaling**, select the electrical signaling interface type used on this serial port.
   - RS-232
     - Enable **RTS Toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control.
     - For **RTS Pre-delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.
     - For **RTS Post-delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.
   - RS-422
     - Enable **Termination** if you want to enable electrical termination on this serial port.
   - RS-485
     - Enable **Termination** if you want to enable electrical termination on this serial port.
     - Enable **Full Duplex** if you want to enable full duplex communication on this serial port.

   The default is RS-232.
8. Expand **Serial Settings**.

   The settings in the following fields must match the information for the power controller. Refer to your power controller manual for the correct settings.

   a. **Baud rate**. For **Baud rate**, select the baud rate used by the device to which you want to connect. The default is **9600**.
      - Max baud rate: **230400**
      - Minimum: **50**

      For a complete list, see Baud rate options.

   b. **Data bits**. For **Data bits**, select the number of data bits used by the device to which you want to connect. The default is **8**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. **Parity**: For **Parity**, select the type of parity used by the device to which you want to connect. The default is **None**.

d. **Stop bits**: For **Stop bits**, select the number of stop bits used by the device to which you want to connect. The default is 1.

e. **Flow control**: For **Flow control**, select the type of flow control used by the device to which you want to connect. The default is **None**.

8. Expand **Logging Settings** to configure logging for this serial port.

a. To enable logging, click to toggle on **Enable**.

b. In the **Log file name** field, enter a descriptive name for the log file.

c. For **Log file size**, type the size of the log file. When the log file reaches the size limit, the current file is saved and a new file is created. The default is 65535 bytes.

d. From the **Type of data to log** list box, specify the type of data that should be saved.

- **Received**
- **Transmitted**
- **Both**
- **Both with arrows**. This is the default.

e. If you want to log the time at which data was received or transmitted, click the **Timestamps** toggle to **Enable**.

f. If you want to log the data as hexadecimal values, click the **Hexadecimal** toggle to **Enable**.

> Note You can review the message log in the **Serial Port Log** page. See Review the serial port message log.

10. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. The serial port is enabled by default. To disable:

```
(config)> serial port1 enable false
(config)>
```

4. Set the mode:

```
(config)> serial port1 mode login
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.

```
(config)> serial port1 altpin true
(config)>
```

6. Set the signaling interface type used on this serial port.
   - **rs-232**
     - Enable **rts toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control.

       ```
       (config)> serial port1 rts_toggle true
       (config)>
       ```

     - For **rts pre delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.

       ```
       (config)> serial port1 rts_pre_delay value
       (config)>
       ```

     - For **rts post delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.

       ```
       (config)> serial port1 rts_post_delay value
       (config)>
       ```

   - **rs-422**
     - Enable **termination** if you want to enable electrical termination on this serial port.
   - **rs-485**
     - Enable **termination** if you want to enable electrical termination on this serial port.

       ```
       (config)> serial port1 termination true
       (config)>
       ```

     - Enable **full duplex** if you want to enable full duplex communication on this serial port.

       ```
       (config)> serial port1 full_duplex true
       (config)>
       ```

   The default is **rs-232**.
7. (Optional) Set a label that will be used when referring to this port.

```
(config)>path-parameLabel label
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Set the baud rate used by the device to which you want to connect.

```
(config)> serial port1 baudrate rate
(config)>
```

where **rate** is the desired baud rate:

- Default baud rate: **9600**
- Max baud rate: **230400**
- Minimum baud rate: **50**

For a complete list, see Baud rate options.

9. Set the number of data bits used by the device to which you want to connect.

```
(config)> serial port1 databits bits
(config)>
```

10. Set the type of parity used by the device to which you want to connect.

```
(config)> serial port1 parity parity
(config)>
```

Allowed values are:

- **even**
- **odd**
- **none**

The default is **none**.

11. Set the stop bits used by the device to which you want to connect.

```
(config)> serial port1 stopbits bits
(config)>
```

12. Set the type of flow control used by the device to which you want to connect.

```
(config)> serial port1 flow value
(config)>
```

where *value* is one of:

- **none**
- **rts/cts**
- **xon/xoff**

13. Configure serial port logging:

a. Enable serial port logging:

```
(config)>serial ports logging enable true
(config)>
```

b. Set the file name:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)>serial ports logging filename string
(config)>
```

c. Set the maximum allowed log size for the serial port log when starting the log:

```
(config)>serial ports logging size value
(config)>
```

where value is the size of the log file in bytes. The default is 65536.

d. Specify the data type:

```
(config)>serial ports logging type value
(config)>
```

where value is one of:

- received
- transmitted
- both
- errors. This is the default.

e. Log the time at which data was received or transmitted:

```
(config)>serial ports logging hex true
(config)>
```

f. Log data as hexadecimal values:

```
(config)>serial ports logging timestamp true
(config)>
```

14. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

15. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure Remote Access mode for a serial port

Remote Access mode allows for remote access to another device that is connected to the serial port. Real Port exposes a serial port on a remote device as a standard COM/TTY port on a client computer. To change the configuration to match the serial configuration of the device to which you want to connect:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.

3. On the menu, click **System**. Under **Configuration**, click **Serial Configuration**.


   

   The **Serial Configuration** page is displayed.

   Note You can also configure the serial port by using **Device Configuration** > **Serial**. Changes made by using either **Device Configuration** or **Serial Configuration** will be reflected in both.

4. Click the name of the port that you want to configure.

   The serial port is enabled by default. To disable, toggle off **Enable**.

5. For **Serial mode**, select **Remote access (TCP)**. This is the default.

6. Enable **ATpm** to use the ATpm feature. **ATpm** is disabled by default. If you enable **ATpm** in RS-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

cables. **Align** has no impact on 422 or 485 modes. For more information, see Serial connector pinout.

7. (Optional) For **Label**, enter a label that will be used when referring to this port.
8. For **Signaling**, select the electrical signaling interface type used on this serial port:
   - **RS-232**
     - Enable **RTS Toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control.
     - For **RTS Pre-delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.
     - For **RTS Post-delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.
   - **RS-422**
     - Enable **Termination** if you want to enable electrical termination on this serial port.
   - **RS-485**
     - Enable **Termination** if you want to enable electrical termination on this serial port.
     - Enable **Full Duplex** if you want to enable full duplex communication on this serial port.

   The default is **RS-232**.
9. Expand **Serial Settings**.

   The entries in the following fields must match the information for the power controller. Refer to your power controller manual for the correct entries.
   a. **Baud rate**: For **Baud rate**, select the baud rate used by the device to which you want to connect. The default is **9600**.
      - Max baud rate: **230400**
      - Minimum: **50**

      For a complete list, see Baud rate options.
   b. **Data bits**: For **Data bits**, select the number of data bits used by the device to which you want to connect. The default is **8**.
   c. **Parity**: For **Parity**, select the type of parity used by the device to which you want to connect. The default is **None**.
   d. **Stop bits**: For **Stop bits**, select the number of stop bits used by the device to which you want to connect. The default is **1**.
   e. **Flow control**: For **Flow control**, select the type of flow control used by the device to which you want to connect. The default is **None**.
10. Click to expand **Data Framing**.
    a. Click **Enable** to enable the data framing feature.
    b. For **Maximum Frame Count**, enter the maximum size of the packet. The default is **1024**.
    c. For **Idle Time**, enter the length of time the device should wait before sending the packet.
    d. For **End Pattern**, enter the end pattern. The packet is sent when this pattern is received from the serial port.
    e. Click **Stop End Pattern** if you want to remove the end pattern from the packet before it is sent.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

11. Expand **Service Settings**.

All service settings are disabled by default. Click available options to toggle them to enabled, and set the IP port as appropriate.



Note If the Telnet service is enabled for the serial port, note that the **Telnet Login** option, when enabled, prompts the user to enter Telnet login credentials when accessing the serial port via Telnet. The **Telnet Login** option is enabled by default. To disable this option, navigate to **System** > **Device Configuration** > **Authentication** > **Serial** and disable **Telnet Login**.

For each type of service, you can also configure the access control.

To do this, you need to go to **Device Configuration**:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

b. Access the configuration for the appropriate type of service:

i. Click to expand **Serial**.

ii. Click to expand the appropriate serial port.

iii. Click to expand the appropriate type of service.

iv. Click to expand **Access Control List**.

For example, to set the Access Control List for the SSH connection for serial port 1, click to expand **Serial** > **Port 1** > **SSH connection** > **Access Control List**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure Remote Access mode for a serial port



- To limit access to specified IPv4 addresses and networks:
  i. Click **IPv4 Addresses**.
  ii. For **Add Address**, click **+**.
  iii. For **Address**, enter the IPv4 address or network that can access the device's service type. Allowed values are:
    - A single IP address or host name.
    - A network designation in CIDR notation, for example, 192.168.1.0/24.
    - **any**: No limit to IPv4 addresses that can access the service type.
  iv. Click **+** again to list additional IP addresses or networks.
- To limit access to specified IPv6 addresses and networks:
  i. Click **IPv6 Addresses**.
  ii. For **Add Address**, click **+**.
  iii. For **Address**, enter the IPv6 address or network that can access the device's service type. Allowed values are:
    - A single IP address or host name.
    - A network designation in CIDR notation, for example, 2001:db8::/48.
    - **any**: No limit to IPv6 addresses that can access the service type.
  iv. Click **+** again to list additional IP addresses or networks.
- To limit access to hosts connected through a specified interface on the device:
  i. Click **Interfaces**.
  ii. For **Add Interface**, click **+**.
  iii. For **Interface**, select the appropriate interface from the dropdown.
  iv. Click **+** again to allow access through additional interfaces.

Digi Connect EZ 4 WS User Guide 142

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


- To limit access based on firewall zones:
  i. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and Other.
  ii. For **Add Zone**, click **+**.
  iii. For **Zone**, select the appropriate firewall zone from the dropdown.
  See Firewall configuration for information about firewall zones.
  iv. Click **+** again to allow access through additional firewall zones.

12. Expand **Autoconnect Settings**. The autoconnect feature is used to initiate a connection to a remote server to directly access the serial port.
   a. Click **Enable** to enable the autoconnect feature.
   b. For **Connection Trigger**, select the option that describes the type of event that should trigger the connection.
   If you select the **Data received matches a string** option, additional fields display:
      a. In the **Data Match String** field, enter the received data string that should trigger the connection. The syntax is: **backslash escaped string**.
      b. The **Flush String** option determines whether the match string data sent from the remote server is discarded.
         - **Enable**: Discard the match string data. This is the default.
         - **Disable**: Do not discard the match string data.
   c. For **Outbound Connection Type**, select the option that describes the method used to initiate the connection.

   Note Additional autoconnect configuration options are available when you select the **SSH connection** option. These options can be configured in the CLI and in the web UI Configuration page.

   d. For **Destination**, enter the host name or IP address of the remote server. When using SSH, this should be prefixed with the user name and followed by **@**, for example, **admin@192.168.1.1**.
   e. For **IP port**, enter the TCP port of the remote server (1-65535).
   f. Click **Enable TCP keep-alive** to enable TCP keepalive on the connection.
   g. Click **Enable TCP nodelay** to enable TCP nodelay on the connection.
   h. For **Socket ID string**, type text to be transmitted to the remote server when the socket connects.

13. Expand **Session Settings**.



   a. Enable **Exclusive access** to limit access to the serial port to a single active session. This option is disabled by default. When it is disabled, multiple users can connect using Telnet, TCP, and SSH.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. For **Escape sequence**, type the characters used to start an escape sequence. If no characters are defined, the escape sequence is disabled. The default is `~b`.

c. For **History size**, type or select the number of bytes of output from the serial port that are written to buffer. These bytes are redisplayed when a user connects to the serial port. The default is **4000** bytes.

d. For **Idle timeout**, type the amount of time to wait before disconnecting due to user inactivity.

14. Expand **Monitor Settings**.

a. Enable **CTS** to monitor CTS (Clear to Send) changes on this port.

b. Enable **DCD** to monitor DCD (Data Carrier Detect) changes on this port.

15. Expand **Logging Settings** to configure logging for this serial port.

a. To enable logging, click to toggle on **Enable**.

b. In the **Log file name** field, enter a descriptive name for the log file.

c. For **Log file size**, type the size of the log file. When the log file reaches the size limit, the current file is saved and a new file is created. The default is 65535 bytes.

d. From the **Type of data to log** list box, specify the type of data that should be saved:

- **Received**
- **Transmitted**
- **Both**
- **Both with arrows**. This is the default.

e. If you want to log the time at which data was received or transmitted, click the **Timestamps** toggle to **Enable**.

f. If you want to log the data as hexadecimal values, click the **Hexadecimal** toggle to **Enable**.

> Note You can review the message log in the **Serial Port Log** page. See Review the serial port message log.

16. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Serial ports is enabled by default. To disable:

```
(config)> serial port_number enable false
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line examples in this section will use port 1 for the serial port. However, any port number can be used.

4. Set the mode:

```
(config)> serial port1 mode remoteaccess
(config)>
```

5. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in RS-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 8-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see [Serial connector pinout](#).

```
(config)> serial port1 altpin true
(config)>
```

6. Set the signaling interface type used on this serial port:
   - **rs-232**
     - Enable **rts toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control:

       ```
       (config)> serial port1 rts_toggle true
       (config)>
       ```

     - For **rts pre_delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**:

       ```
       (config)> serial port1 rts_pre_delay value
       (config)>
       ```

     - For **rts post_delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.

       ```
       (config)> serial port1 rts_post_delay value
       (config)>
       ```

   - **rs-422**
     - Enable **termination** if you want to enable electrical termination on this serial port.
   - **rs-485**
     - Enable **termination** if you want to enable electrical termination on this serial port.

       ```
       (config)> serial port1 termination true
       (config)>
       ```

     - Enable **full_duplex** if you want to enable full duplex communication on this serial port.

       ```
       (config)> serial port1 full_duplex true
       (config)>
       ```

The default is **rs-232**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

7. (Optional) Set a label that will be used when referring to this port.

```
(config)>serial port1 label label
(config)>
```

8. Set the baud rate used by the device to which you want to connect.

```
(config)> serial port1 baudrate rate
(config)>
```

where **rate** is the desired baud rate.

- Default baud rate: **9600**
- Max baud rate: **230400**
- Minimum baud rate: **50**

For a complete list, see Baud rate options.

9. Set the number of data bits used by the device to which you want to connect.

```
(config)> serial port1 databits bits
(config)>
```

10. Set the type of parity used by the device to which you want to connect.

```
(config)> serial port1 parity parity
(config)>
```

Allowed values are:

- **even**
- **odd**
- **none**

The default is **none**.

11. Set the stop bits used by the device to which you want to connect.

```
(config)> serial port1 stopbits bits
(config)>
```

12. Set the type of flow control used by the device to which you want to connect.

```
(config)> serial port1 flow value
(config)>
```

where value is one of:

- **none**
- **rts/cts**
- **xon/xoff**

13. Configure the session settings.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Set the characters used to start an escape sequence:

```
(config)>serial ports escape string
(config)
```

If no characters are defined, the escape sequence is disabled. The default is **+b**.

b. Limit access to the serial port to a single active session:

```
(config)>serial ports exclusive true
(config)
```

c. Set the number of bytes of output from the serial port that are written to buffer. These bytes are redisplayed when a user connects to the serial port.

```
(config)>serial ports history bytes
(config)
```

The default is **4000** bytes.

d. Set the amount of time to wait before disconnecting due to user inactivity:

```
(config)>serial ports idle_timeout value
(config)
```

where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number(w|d|h|m|s)**.

For example, to set **idle timeout** to ten minutes, enter either **10m** or **600s**.

```
(config)>serial ports idle_timeout 10m
(config)
```

The default is **15m**.

14. Configure monitor settings.

a. (Optional) Enable monitoring of CTS (Clear to Send) changes on this port:

```
(config)>serial ports monitor cts true
(config)
```

b. (Optional) Enable monitoring of DCD (Data Carrier Detect) changes on this port:

```
(config)>serial ports monitor dcd true
(config)
```

15. (Optional) Configure autoconnect.

a. Enable autoconnect:

```
(config)>serial ports autoconnect enable true
(config)>
```

b. Set the option that will trigger the connection:

```
(config)>serial ports autoconnect trigger value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is one of:

- always
- data
- dout
- destination
- dsr
- match

If **match** is selected:

i. Set the string that, when received, will trigger the connection:

```
(config)>serial port1 autoconnect match_string string
(config)>
```

ii. **flush_string** is enabled by default, which will discard the matched string from data sent to the server. To disable:

```
(config)>serial port1 autoconnect flush_string false
(config)>
```

The default is **always**.

c. Set the option that initiates the connection:

```
(config)>serial port1 autoconnect conn_type value
(config)>
```

where value is one of:

- ssh
- tcp
- telnet
- tls
- tls auth

The default is **tls**.

d. Set the host name or IP address of the destination server:

```
(config)>serial port1 autoconnect destination hostname/IP_address
(config)>
```

When using SSH, this should be prefixed with the user name and followed by @ for example:

```
(config)>serial port1 autoconnect destination admin@192.168.1.1
(config)>
```

e. Set the TCP port of the destination server:

```
(config)>serial port1 autoconnect port tnr
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where *int* is any integer between 1 and 65535.

f. To enable TCP keepalive:

```
(config)>serial ports autoconnect keepalive true
(config)>
```

g. To enable TCP modelay:

```
(config)>serial ports autoconnect nodelay true
(config)>
```

h. Set the text to be transmitted to the remote server when the socket connects:

```
(config)>serial ports autoattn string
(config)>
```

i. Set the additional autoconnect options. These are available if you have set the **serial ports autoconnect conn_type** option to **ssh**.:

i. Set the variable that determines from where the user name used for the connection should be read.

```
(config)>serial ports autoconnect username_source value
(config)>
```

Where *value* is one of the following:

- **config**: Define the user name. When you choose this option, you must also configure the static user name:

```
(config)>serial ports autoconnect username string
(config)>
```

where *string* is the static user name.

- **prompt**: The user is prompted to enter their user name when the trigger connection condition is met. This is the default.

ii. Set the variable that determines whether you want to run in a mode more suitable for an interactive user session.

```
(config)>serial ports autoconnect interactive true|false
(config)>
```

Set this to **true** to run the allocated pseudo-terminal in canonical mode, enable escape sequences, and output notifications from the ssh process. This is the default.

iii. Set the value of the [SHH environment variable that is sent to the remote server. The default is **vt100**.

```
(config)>serial ports autoconnect terminal string
(config)>
```

h. (Optional) Configure data framing:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Enable data framing:

```
(config)>serial ports framing enable true
(config)
```

b. Set the maximum size of the packet:

```
(config)>serial ports framing max_count int
(config)
```

The default is 1024.

c. Set the length of time the device should wait before sending the packet:

```
(config)>serial ports framing idle_time value
(config)
```

where value is in milliseconds (ms) or seconds (s). The maximum value is 60s.

d. Set the end pattern. The packet is sent when this pattern is received from the serial port:

```
(config)>serial ports framing end_pattern backslash-escaped-string
(config)
```

e. Set the strip end pattern if you want to remove the end pattern from the packet before it is sent:

```
(config)>serial ports framing strip_pattern true
(config)
```

f. (Optional) Configure service settings:

a. Configure SSH settings:

i. Enable SSH:

```
(config)>serial ports service ssh enable true
(config)>
```

ii. Set the port to be used for ssh communications:

```
(config)>serial ports service ssh port int
(config)>
```

where int is any integer between 1 and 65535. The default is 3001.

iii. Enable TCP keep-alive messages:

```
(config)>serial ports service ssh keepalive true
(config)>
```

iv. Enable TCP nodelay messages:

```
(config)>serial ports service ssh nodelay true
(config)>
```

v. (Optional) Configure access control:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to specified IPv4 addresses and networks:

```
[config]> add serial port1 service ssh acl address end value
[config]>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- any: No limit to IPv4 addresses that can access the service type.

Repeat this step to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:

```
[config]> add serial port1 service ssh acl address6 end value
[config]>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- any: No limit to IPv6 addresses that can access the service type.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
[config]> add serial port1 service ssh acl interface end
value
[config]>
```

Where value is an interface defined on your device.

Display a list of available interfaces:

Use ... **network interface** ? to display interface information:

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
[config]> add serial port1 service ssh acl zone end value
[config]>
```

Where value is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type ... **firewall zone** ? at the config prompt:

```
[config]> ... firewall zone ?

Zones: A list of groups of network interfaces that
can be referred to by packet
filtering rules and access control lists…
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Additional Configuration
-------------------------------------------------------------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

vi. (Optional) Enable Multicast DNS (mDNS):

```
(config)>serial port1 service ssh mdns enable true
(config)>
```

b. Configure TCP settings:

i. Enable TCP:

```
(config)>serial port1 service tcp enable true
(config)>
```

ii. Set the port to be used for ssh communications:

```
(config)>serial port1 service tcp port int
(config)>
```

where *int* is any integer between 1 and 65535. The default is 4001.

iii. Enable TCP keep-alive messages:

```
(config)>serial port1 service tcp keepalive true
(config)>
```

iv. Set the option that initiates the connection:

```
(config)>serial port1 service tcp conn_type value
(config)>
```

where *value* is one of:

- tcp
- tls
- tls auth

The default is tls.

v. Enable TCP nodelay messages:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
[config]>serial ports service tcp nodelay true
[config]>
```

vi. (Optional) Configure access control:

- To limit access to specified IPv4 addresses and networks:

```
[config]> add serial ports service tcp acl address end value
[config]>
```

Where **value** can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- **any**: No limit to IPv4 addresses that can access the service type.

Repeat this step to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:

```
[config]> add serial ports service tcp acl address6 end value
[config]>
```

Where **value** can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IPv6 addresses that can access the service type.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
[config]> add serial ports service tcp acl interface end
value
[config]>
```

Where **value** is an interface defined on your device.

Display a list of available interfaces:

Use **... network interface ?** to display interface information:

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
[config]> add serial ports service tcp acl zone end value
[config]>
```

Where **value** is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Type ... firewall zone ?at the config prompt:

```
[config]> ... firewall zone ?
Zones: A list of groups of network interfaces that
can be referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------
  ------------------------------

    any
    dynamic_routes
    edge
    external
    internal
    ipsec
    loopback
    setup

[config]>
```

Repeat this step to include additional firewall zones.

vii. (Optional) Enable Multicast DNS (mDNS)

```
[config]>serial port1 service tcp mdns enable true
[config]>
```

c. Configure telnet settings:

i. Enable telnet:

```
[config]>serial port1 service telnet enable true
[config]>
```

ii. Set the port to be used for telnet communications:

```
[config]>serial port1 service telnet port tcp
[config]>
```

where *int* is any integer between 1 and 65535. The default is 3001.

iii. Enable TCP keep-alive messages:

```
[config]>serial port1 service telnet keepalive true
[config]>
```

iv. Enable TCP nodelay messages:

```
[config]>serial port1 service telnet nodelay true
[config]>
```

v. (Optional) Configure access control:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to specified IPv4 addresses and networks:

```
(config)> add serial port1 service telnet acl address end
value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- any: No limit to IPv4 addresses that can access the service-type.

Repeat this step to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:

```
(config)> add serial port1 service telnet acl address6 end
value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- any: No limit to IPv6 addresses that can access the service-type.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add serial port1 service telnet acl interface end
value
(config)>
```

Where value is an interface defined on your device.

Display a list of available interfaces:

Use ... **network interface** ? to display interface information.

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add serial port1 service telnet acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type ... **firewall zone** ? at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure Remote Access mode for a serial port

```
can be referred to by packet
filtering rules and access control lists.

Additional Configuration
------------------------------------------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

vi. (Optional) Enable Multicast DNS (mDNS)

```
(config)>serial ports service telnet mdns enable true
(config)>
```

18. Configure serial port logging:

a. Enable serial port logging:

```
(config)>serial ports logging enable true
(config)>
```

b. Set the file name:

```
(config)>serial ports logging filename string
(config)>
```

c. Set the maximum allowed log size for the serial port log when disabling the log:

```
(config)>serial ports logging size value
(config)>
```

where value is the size of the log file in bytes. The default is 65536.

d. Specify the data type:

```
(config)>serial ports logging type value
(config)>
```

where value is one of:

- received
- transmitted
- both
- errors. This is the default.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

e. Log the time at which data was received or transmitted:

```
(config)>serial ports logging hex true
(config)>
```

f. Log data as hexadecimal values:

```
(config)>serial ports logging timestamp true
(config)>
```

10. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

20. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Additional autoconnect settings for Remote Access mode

Additional autoconnect configuration options are available when you have configured a serial port for **Remote Access** mode and selected the **SSH connection** option for the **Outbound connection type**. You can configure these in the CLI and in the web UI.

For information about the complete **Remote Access** mode configuration, see Configure Remote Access mode for a serial port.

Note These options described in this topic are not available in the Serial Configuration page of the web UI. They are only available in the **Configuration** page, as described below.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your device.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



   The **Configuration** window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library
TS-TL-DGI-010
we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 157 / 927

3. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

4. At the command line, type **config** to enter configuration mode:

   ```
   > config
   (config)>
   ```

5. On the menu, click **System**. Under **Configuration**, click **Device Configuration**. The **Configuration** page displays.
6. Click **Serial** to expand the section.
7. Make sure **Enable** has been selected, and **Remote Access (TCP)** has been selected for **Serial mode**.
8. Click **Autoconnect** to expand the section.
   a. From the **Outbound connection type** list box, select **SSH connection**. Additional autoconnect configuration settings display at the bottom of the section.
   b. From the **Username Source** list box, select an option to determine from where the user name used for the connection should be read. Options are:
      - **Static configuration**: Select this option if you want to define the user name. When you choose this option, the **Username** field displays. Enter the static user name in this field.
      - **Prompt for user name**: When this option is selected, the user is prompted to enter their user name when the Connection Trigger condition is met. This is the default.
   c. The **Interactive Mode** option to determine whether you want to run in a mode more suitable for an interactive user session.
      - **Enable**: Enable this option to run the allocated pseudo-terminal in canonical mode, enable escape sequences, and output notifications from the ssh process. This is the default.
      - **Disable**: Disable this option to turn off the **Interactive Mode** option.
   d. In the **Advertised Terminal Type** field, enter the value of the TERM environment variable that is sent to the remote server. The default is **vt100**.
9. Click **Apply** to save the configuration and apply the change.

Configure Application mode for a serial port

Application mode provides access to the serial device from Python applications.

To change the configuration to match the serial configuration of the device to which you want to connect:

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure Application mode for a serial port

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the menu, click **System**. Under **Configuration**, click **Serial Configuration**.




The **Serial Configuration** page is displayed.



Note You can also configure the serial port by using **Device Configuration > Serial**. Changes made by using either **Device Configuration** or **Serial Configuration** will be reflected in both.

3. Click the name of the port that you want to configure.



The serial port is enabled by default. To disable, toggle off **Enable**.

4. For **Mode**, select **Application**. The default is **Remote Access**.
5. Enable **ATpin** to use the ATpin feature. **ATpin** is disabled by default. If you enable **ATpin** in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **ATpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.
6. (Optional) For **Label**, enter a label that will be used when referring to this port.
7. For **Signaling**, select the electrical signaling interface type used on this serial port.
   - RS-232
     - Enable **RTS toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control.
     - For **RTS Pre-delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.
     - For **RTS Post-delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.
   - RS-422
     - Enable **Termination** if you want to enable electrical termination on this serial port.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- RS-485
  - Enable **Termination** if you want to enable electrical termination on this serial port.
  - Enable **Full Duplex** if you want to enable full duplex communication on this serial port.

The default is **RS-232**.

8. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. The serial port is enabled by default. To disable:

```
(config)> serial port1 enable false
(config)>
```

4. Set the mode:

```
(config)> serial port1 mode application
(config)>
```

5. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.

```
(config)> serial port1 altpin true
(config)>
```

6. Set the signaling interface type used on this serial port:
   - **rs232**
     - Enable **rts toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control:

```
(config)> serial port1 rts_toggle true
(config)>
```

     - For **rts pre delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.

```
(config)> serial port1 "rts_pre_delay value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- For **rts post delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.

```
(config)> serial ports rts_post_delay value
(config)>
```

- **rs-422**
  - Enable **termination** if you want to enable electrical termination on this serial port.
- **rs-485**
  - Enable **termination** if you want to enable electrical termination on this serial port.

```
(config)> serial ports termination true
(config)>
```

  - Enable **full duplex** if you want to enable full duplex communication on this serial port.

```
(config)> serial ports full_duplex true
(config)>
```

The default is **rs-232**.

7. (Optional) Set a label that will be used when referring to this port.

```
(config)>path-parameters label
(config)>
```

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure PPP dial-in mode for a serial port

PPP dial-in allows the device to answer Point-to-Point Protocol (PPP) connections over serial ports. To change the configuration to match the serial configuration of the device to which you want to connect:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure RFC dial-in mode for a serial port

b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click to expand the name of the port that you want to configure, for example, **Port 1**.
The serial port is enabled by default. To disable, toggle off **Enable**.
4. For **Mode**, select **RFC-Dial-in**. The default is **Remote Access**.



5. (Optional) For **Label**, enter a label that will be used when referring to this port.
6. For **Baud rate**, select the baud rate used by the device to which you want to connect. The default is **9600**.
   - Max baud rate: **230400**
   - Minimum: **50**

   For a complete list, see Baud rate options.
7. For **Flow control**, select the type of flow control used by the device to which you want to connect. The default is **None**.
8. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 5-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.
9. For **Idle timeout**, type the amount of time that the active session can be idle before the session is disconnected.

   Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

   For example, to set **Idle timeout** to ten minutes, enter **10m** or **600s**.
10. Click to expand **RFC dial-in**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

11. For **Local IP address**, type the IP address assigned to this interface.
12. For **Remote IP address**, type the IP address assigned to the remote peer.
13. For **Metric**, set the priority of routes associated with this interface. If there are multiple active routes that match a destination, then the route with the lowest metric will be used.
14. For **Default route**, toggle to control whether a default route gets added for the PPP interface. This feature is disabled by default.
15. For **Zone**, select the firewall zone for this interface. This can be used by packet filtering rules and access control lists to restrict network traffic on this interface.
16. For **Authentication method**, select the method used to authenticate the remote peer. Allowed values are:
    - **None**: No authentication is required.
    - **Automatic**: Attempt to authenticate using CHAP first, and then PAP.
    - **CHAP**: Use Challenge Handshake Authentication Protocol (CHAP) to authenticate.
    - **PAP**: Use Password Authentication Protocol (PAP) to authenticate.

    If Automatic, CHAP, or PAP are selected, type the **Username** and **Password** used to authenticate the remote peer.
17. (Optional) Configure the serial port to use a custom PPP configuration file.
    a. Click to expand **Custom PPP configuration**.
    b. Click **Enable** to enable the use of a custom PPP configuration file.
    c. Click **Override** to override the default PPP configuration and only use the custom configuration file.

    If **Override** is not enabled, the custom PPP configuration file is used in addition to the default configuration.
    d. For **Configuration file**, paste or type the configuration data in the format of a pppd options file. Because the options are passed directly to the pppd command line, they should all be entered on a single line. For example:

    ```
    debug lcp-echo-interval 10 lcp-echo-failure 2
    ```
18. (Optional) Configure a script that will be run to prepare the link before PPP negotiations are started.
    a. Click to expand **Connect script**.
    b. Click **Enable** to enable the use of a connection script.
    c. For **Connect script filename**, type the name of the script. Scripts are located in the /etc/config/serial directory. An example script, windows_dun.sh is provided.

    Example windows_dun.sh file:

    ```
    #!/bin/sh

    # Example connect script for connecting from a PC using a Windows
    dial-up
    # networking connection with built-in standard 33600 bps modem driver
    and phone
    # number 123.
    ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
# The shell's 'read' builtin breaks on newline, so translate incoming
carriage-
# return to newline, and outgoing newline to carriage-return-newline.
stty icrnl onlcr opost

# Read input from the serial port, one line at a time.
while read -r line; do
    case "$line" in
        ATDT123)
            echo "CONNECT" # instruct the peer to start PPP
            exit 0 # start up the local PPP session
            ;;
        AT*)
            echo "OK" # passively accept any other AT command
            ;;
    esac
done
```

10. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. The serial port is enabled by default. To disable:

```
(config)> serial port1 enable false
(config)>
```

4. Set the mode:

```
(config)> serial port1 mode ppp_static
(config)>
```

5. (Optional) Set a label that will be used when referring to this port.

```
(config)> serial port1 label label
(config)>
```

6. Set the baud rate used by the device to which you want to connect.

```
(config)> serial port1 baudrate rate
(config)>
```

where **rate** is the desired baud rate.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure PPP dial-in mode for a serial port

- Default baud rate: 9600
- Max baud rate: 230400
- Minimum baud rate: 50

For a complete list, see Baud rate options.

7. Set the type of flow control used by the device to which you want to connect:

```
(config)> serial port1 flow value
(config)>
```

where value is one of:

- none
- rts/cts
- xon/xoff

8. Set the amount of time that the active session can be idle before the session is disconnected:

```
(config)> serial port1 idle_timeout value
(config)>
```

where value is any number of weeks, days, hours, minutes, or seconds, and takes the format number(w|d|h|m|s).

For example, to set idle timeout to ten minutes, enter either 10m or 600s:

```
(config)> serial port1 idle_timeout 600s
(config)>
```

9. Enable Altpin to use the Altpin feature. Altpin is disabled by default. If you enable Altpin in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. Altpin has no impact on 422 or 485 mode. For more information, see Serial connector pinout.

```
(config)> serial port1 altpin true
(config)>
```

10. Set the local IP address assigned to this interface:

```
(config)> serial port1 ppp_dialin local_address IPv4_address
(config)>
```

11. Set the IP address assigned to the remote peer:

```
(config)> serial port1 ppp_dialin remote_address IPv4_address
(config)>
```

12. The default route is added for the PPP interface is disabled by default. To enable:

```
(config)> serial port1 ppp_dialin default_route true
config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

13. Set the authentication method used to authenticate the remote peer:

```
(config)> serial port1 ppp_dialin auth value
(config)>
```

where value is one of:

- **none**: No authentication is required.
- **auto**: Attempt to authenticate using CHAP first, and then PAP.
- **chap**: Use Challenge Handshake Authentication Protocol (CHAP) to authenticate.
- **pap**: Use Password Authentication Protocol (PAP) to authenticate.

The default is **none**.

If auto, chap, or pap are set, set the username and password used to authenticate the remote peer:

```
(config)> serial port1 ppp_dialin username username
(config)> serial port1 ppp_dialin password password
(config)>
```

14. Set the priority of routes associated with this interface. If there are multiple active routes that match a destination, then the route with the lowest metric will be used.

```
(config)> serial port1 ppp_dialin metric 100
(config)>
```

The default is **10**.

15. Set the firewall zone for this interface. This can be used by packet filtering rules and access control lists to restrict network traffic on this interface.
    a. Use the **?** to determine available zones.

```
(config)> serial port1 ppp_dialin zone ?

Zone: The firewall zone assigned to this interface. This can be used
by packet
filtering rules and access control lists to restrict network traffic
on this
interface.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup
Default value: internal
Current value: internal

(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Set the zone:

```
(config)> serial ports ppp_dialin zone zone
(config)>
```

iii. (Optional) Configure the serial port to use a custom PPP configuration file:

a. Enable the use of a custom PPP configuration file:

```
(config)> serial ports ppp_dialin custom enable true
(config)>
```

b. Enable **override** to override the default PPP configuration and only use the custom configuration file:

```
(config)> serial ports ppp_dialin custom override true
(config)>
```

If **override** is not enabled, the custom PPP configuration file is used in addition to the default configuration.

c. Paste or type the configuration data in the format of a pppd options file:

```
(config)> serial ports ppp_dialin custom config_file data
(config)>
```

where **data** are one or more pppd command line options. Because the options are passed directly to the pppd command line, they should all be entered on a single line. For example:

```
(config)> serial ports ppp_dialin custom config_file "debug lcp-echo-
interval 10 lcp-echo-failure 2"
(config)>
```

iv. (Optional) Configure a script that will be run to prepare the link before PPP negotiations are started.

a. Enable the use of a connection script:

```
(config)> serial ports ppp_dialin connect enable true
(config)>
```

b. Set the name of the script:

```
(config)> serial ports ppp_dialin connect script filename
(config)>
```

Scripts are located in the /etc/config/serial directory. An example script, windows.dun.sh is provided.

Example windows.dun.sh file:

```
#!/bin/sh

# Example connect script for connecting from a PC using a Windows
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
etal-up
# networking connection with built-in standard 19200 bps modem driver
and phone
# number 123.

# The shell's 'read' builtin breaks on newline, so translate incoming
carriage-
# return to newline, and outgoing newline to carriage-return-newline.
stty icrnl onlcr opost

# Read input from the serial port, one line at a time.
while read -r line; do
    case "$line" in
        ATDT123)
            echo "CONNECT" # instruct the peer to start PPP
            exit 0 # start up the local PPP session
            ;;
        AT*)
            echo "OK" # passively accept any other AT command
            ;;
    esac
done
```

18. Save the configuration and apply the changes.

```
[config]> save
Configuration saved.
>
```

19. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure UDP serial mode for a serial port

The **UDP** serial mode option in the serial port configuration provides access to the serial port using UDP.

To change the configuration to match the serial configuration of the device to which you want to connect:

Web

1. Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.
2. On the menu, click **System**. Under **Configuration**, click **Serial Configuration**.



The **Serial Configuration** page is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure UDP serial mode for a serial port



Note You can also configure the serial port by using **Device Configuration** > **Serial**. Changes made by using either **Device Configuration** or **Serial Configuration** will be reflected in both.

3. Click to expand the port that you want to configure for UDP serial mode.



The serial port is enabled by default. To disable, toggle off **Enable**.

4. For **Mode**, select **UDP serial**.

   The default is **Remote Access**.

5. (Optional) For **Label**, enter a label that will be used when referring to this port.

6. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** on EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 8-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.


7. For **Signaling**, select the electrical signaling interface type used on this serial port.

   - RS-232
     - Enable **RTS Toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control.
     - For **RTS Pre-delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.
     - For **RTS Post-delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.
   - RS-422
     - Enable **Termination** if you want to enable electrical termination on this serial port.
   - RS-485
     - Enable **Termination** if you want to enable electrical termination on this serial port.
     - Enable **Full Duplex** if you want to enable full duplex communication on this serial port.

   The default is RS-232.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


8. Expand **Serial Settings**.



a. For **Baud rate**, select the baud rate used by the device to which you want to connect.
   - Default baud rate: 9600
   - Max baud rate: 230400
   - Minimum: 50

   For a complete list, see baud rate options.
b. For **Data bits**, select the number of data bits used by the device to which you want to connect.
c. For **Parity**, select the type of parity used by the device to which you want to connect.
d. For **Stop bits**, select the number of stop bits used by the device to which you want to connect.
e. For **Flow control**, select the type of flow control used by the device to which you want to connect.

9. Expand **Data Framing Settings**.



a. Click to expand **Data Framing**.
   i. Click **Enable** to enable the data framing feature.
   ii. For **Maximum Frame Count**, enter the maximum size of the packet. The default is 1024.
   iii. For **Idle time**, enter the length of time the device should wait before sending the packet.
   iv. For **End Pattern**, enter the end pattern. The packet is sent when this pattern is received from the serial port.
   v. Click **Strip End Pattern** if you want to remove the end pattern from the packet before it is sent.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iii. Expand **UDP Serial Settings**.



a. For **Local port**, enter the UDP port. The default is 4001 or serial port 1, 4002 for serial port 2, etc.

b. (Optional) For **Socket String ID**, enter a string that should be added at the beginning of each packet.

c. For **Destinations**, you can configure the remote sites to which you want to send data. If you do not specify any destinations, the Connect EZ 4 WS sends new data from the last IP address and port from which data was received. To add a destination:

i. Click **Add Destination**. A destination row is added.

ii. (Optional) For **Description**, enter a description of the destination.

iii. For **Hostname**, enter the host name or IP address of the remote site to which data should be sent.

iv. For **Port**, enter the port number of the remote site to which data should be sent.

You can also configure access control for the serial port.

To do this, you need to go to **Device Configuration**:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

b. Access the configuration for the appropriate type of service:

i. Click to expand **Serial**.


ii. Click to expand the appropriate serial port.

iii. Click to expand **UDP serial**.

iv. Click to expand **Access Control List**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure UDP serial mode for a serial port



- To limit access to specified IPv4 addresses and networks:
  i. Click **IPv4 Addresses**.
  ii. For **Add Address**, click **+**.
  iii. For **Address**, enter the IPv4 address or network that can access the device's service type. Allowed values are:
    - A single IP address or host name.
    - A network designation in CIDR notation, for example, 192.168.1.0/24.
    - **any**: No limit to IPv4 addresses that can access the service type.
  iv. Click **+** again to list additional IP addresses or networks.
- To limit access to specified IPv6 addresses and networks:
  i. Click **IPv6 Addresses**.
  ii. For **Add Address**, click **+**.
  iii. For **Address**, enter the IPv6 address or network that can access the device's service type. Allowed values are:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IP/VE addresses that can access the service-type.

iv. Click **+** again to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the device:
  i. Click **Interfaces**.
  ii. For **Add Interface**, click **+**.
  iii. For **Interface**, select the appropriate interface from the dropdown.
  iv. Click **+** again to allow access through additional interfaces.
- To limit access based on firewall zones:
  i. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
  ii. For **Add Zone**, click **+**.
  iii. For **Zone**, select the appropriate firewall zone from the dropdown.
  See Firewall configuration for information about firewall zones.
  iv. Click **+** again to allow access through additional firewall zones.

11. Expand **Logging Settings** to configure logging for this serial port.
    a. To enable logging, click to toggle on **Enable**.
    b. In the **Log file name** field, enter a descriptive name for the log file.
    c. For **Log file size**, type the size of the log file. When the log file reaches the size limit, the current file is saved and a new file is created. The default is 65536 bytes.
    d. From the **Type of data to log** list box, specify the type of data that should be saved.
       - **Received**
       - **Transmitted**
       - **Both**
       - **Both with arrows**. This is the default.
    e. If you want to log the time at which data was received or transmitted, click the **Timestamps** toggle to **Enable**.
    f. If you want to log the data as hexadecimal values, click the **Hexadecimal** toggle to **Enable**.

Note You can review the message log in the **Serial Port Log** page. See Review the serial port message log.

12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device's configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. The serial port is enabled by default. To disable:

```
[config]> serial port1 enable false
[config]>
```

4. Set the mode:

```
[config]> serial port1 mode udp
[config]>
```

5. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in RS-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **Altpin** has no impact on 422 or 485 modes. For more information, see Serial connector pinout.

```
[config]> serial port1 altpin true
[config]>
```

6. Set the signaling interface type used on this serial port:
   - **rs-232**
     - Enable **rts toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control.

       ```
       [config]> serial port1 rts_toggle true
       [config]>
       ```

     - For **rts pre delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.

       ```
       [config]> serial port1 rts_pre_delay value
       [config]>
       ```

     - For **rts post delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.

       ```
       [config]> serial port1 rts_post_delay value
       [config]>
       ```

   - **rs-422**
     - Enable **termination** if you want to enable electrical termination on this serial port.
   - **rs-485**
     - Enable **termination** if you want to enable electrical termination on this serial port.

       ```
       [config]> serial port1 termination true
       [config]>
       ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Enable **full duplex** if you want to enable full duplex communication on this serial port.

```
(config)> serial port1 full_duplex true
(config)>
```

The default is **rs232**.

7. (Optional) Set a label that will be used when referring to this port.

```
(config)>serial port1 label label
(config)>
```

8. Set the baud rate used by the device to which you want to connect.

```
(config)>serial port1 label baudrate rate
(config)>
```

Where **rate** is the desired baud rate.

- Default baud rate: **9600**
- Max baud rate: **230400**
- Minimum baud rate: **50**

For a complete list, see Baud rate options.

9. Set the number of data bits used by the device to which you want to connect.

```
(config)>serial port1 label databits bits
(config)>
```

10. Set the type of parity used by the device to which you want to connect.

```
(config)>serial port1 label parity parity
(config)>
```

Allowed values are:

- **even**
- **odd**
- **none**

The default is **none**.

11. Set the stop bits used by the device to which you want to connect.

```
(config)>serial port1 label stopbits bits
(config)>
```

12. Set the type of flow control used by the device to which you want to connect.

```
(config)>serial port1 label flow type
(config)
```

Allowed values are:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- none
- rts/cts
- xon/xoff

The default is **none**.

13. (Optional) Configure data framing:

a. Enable data framing:

```
(config)>serial ports framing enable true
(config)
```

b. Set the maximum size of the packet:

```
(config)>serial ports framing max_count int
(config)
```

The default is **1024**.

c. Set the length of time the device should wait before sending the packet:

```
(config)>serial ports framing idle_time value
(config)
```

where *value* is in milliseconds (ms) or seconds (s). The maximum value is **60s**.

d. Set the end pattern. The packet is sent when this pattern is received from the serial port:

```
(config)>serial ports framing end_pattern backslash-escaped-string
(config)
```

e. Set the strip end pattern if you want to remove the end pattern from the packet before it is sent:

```
(config)>serial ports framing strip_pattern true
(config)
```

14. Set the UDP port:

```
(config)> serial port1 udp port port
(config)>
```

The default is **4001**.

15. (Optional) Enter a string that should be added at the beginning of each packet:

```
(config)> serial port1 udp packetid backslash-escaped-string
(config)>
```

16. Configure the remote sites to which you want to send data. If you do not specify any destinations, the Connect EZ 4 WS send new data to the last hostname and port from which data was received. To add a destination:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

i. Add a destination:

```
(config)> add serial port1 udp destination end
(config serial port1 udp destination 0)>
```

ii. (Optional) Enter a description of the destination:

```
(config serial port1 udp destination 0)> description string
(config serial port1 udp destination 0)>
```

iii. Set the host name or IP address of the remote site to which data should be sent:

```
(config serial port1 udp destination 0)>hostname hostname-or-IP-
address
(config serial port1 udp destination 0)>
```

iv. Set the port number of the remote site to which data should be sent:

```
(config serial port1 udp destination 0)> port port
(config serial port1 udp destination 0)>
```

f. (Optional) Configure access control:

a. Return to the root configuration prompt by typing ..:

```
(config serial port1 udp destination 0)> ..
(config)>
```

b. Set the Access Control List:

- To limit access to specified IPv4 addresses and networks:

```
(config)> add serial port1 udp acl address end value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- **any**: No limit to IPv4 addresses that can access the service-type.

Repeat this step to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:

```
(config)> add serial port1 udp acl address6 end value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IPv6 addresses that can access the service-type.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure UDP serial mode for a serial port

```
(config)> add serial port1 udp acl interface eth value
(config)>
```

Where value is an interface defined on your device.

Display a list of available interfaces.

Use ... network interface ? to display interface information.

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add serial port1 udp acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the any keyword.

Display a list of available firewall zones.

Type ... firewall zone ? at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that
can be referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------
  ------------------------------

    any
    dynamic_routes
    edge
    external
    hotel-wifi
    ipsec
    loopback
    setup

(config)>
```

Repeat this step to include additional firewall zones.

- To limit access to specified IPv4 addresses and networks:

```
(config)> add serial port1 udp acl address end value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- any: No limit to IPv4 addresses that can access the service type.

Repeat this step to list additional IP addresses or networks.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to specified IPV6 addresses and networks:

```
(config)> add serial port1 udp acl address end value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IPV6 addresses that can access the service-type.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add serial port1 udp acl interface end value
(config)>
```

Where value is an interface defined on your device.

Display a list of available interfaces.

Use **... network interface ?** to display interface information.

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add serial port1 udp acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type **... firewall zone ?** at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------

------------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

------------------------------------------------------------
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)>
```

Repeat this step to include additional firewall zones.

18. Configure serial port logging:

    a. Enable serial port logging:

    ```
    (config)>serial ports logging enable true
    (config)>
    ```

    b. Set the file name:

    ```
    (config)>serial ports logging filename string
    (config)>
    ```

    c. Set the maximum allowed log size for the serial port log when starting the log:

    ```
    (config)>serial ports logging size value
    (config)>
    ```

    where value is the size of the log file in bytes. The default is 65535.

    d. Specify the data type:

    ```
    (config)>serial ports logging type value
    (config)>
    ```

    where value is one of:

    - received
    - transmitted
    - both
    - arrows. This is the default.

    e. Log the time at which data was received or transmitted:

    ```
    (config)>serial ports logging hex true
    (config)>
    ```

    f. Log data as hexadecimal values:

    ```
    (config)>serial ports logging timestamp true
    (config)>
    ```

19. Save the configuration and apply the changes.

    ```
    (config)> save
    Configuration saved.
    >
    ```

20. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an Access selection menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure Modem emulator mode for a serial port

Modem emulator mode allows the device to act as a dial-up modem emulator for handling incoming AT dial-ins.

To change the configuration to match the serial configuration of the device to which you want to connect:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click to expand the name of the port that you want to configure, for example, **Port 1**.

   The serial port is enabled by default. To disable, toggle off **Enable**.
4. For **Mode**, select **Modem emulator**. The default is **Remote Access**.
5. (Optional) For **Label**, enter a label that will be used when referring to this port.
6. For **Baud rate**, select the baud rate used by the device to which you want to connect. The default is **9600**.
   - Max baud rate: **230400**
   - Minimum baud rate: **50**

   For a complete list, see Baud rate options.
7. For **Data bits**, select the number of data bits used by the device to which you want to connect. The default is **8**.
8. For **Parity**, select the type of parity used by the device to which you want to connect. The default is **None**.
9. For **Stop bits**, select the number of stop bits used by the device to which you want to connect. The default is **1**.
10. For **Flow control**, select the type of flow control used by the device to which you want to connect. The default is **None**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

11. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in RS-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 5-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.
12. For **Idle timeout**, type the amount of time that the active session can be idle before the session is disconnected.

    Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*(w|d|h|m|s).

    For example, to set **Idle timeout** to ten minutes, enter **10m** or **600s**.
13. For **Escape character**, type the character to use in the escape sequence. Enter this character three times, followed by the escape delay and then an AT command to switch from data mode to command mode. The default is the plus sign (**+**).
14. For **Escape delay**, type the delay between the escape sequence and an AT command to switch from data mode to command mode. The default is **1s**.
15. For **Auto-answer rings**, type the number of rings to wait before auto-answering. Enter **0** (zero) to disable auto-answering.
16. **Command echo** is enabled by default. Commands sent to the port are echoed back to the user. Select to disable this feature.
17. For **Result codes**, select the type of result code that are displayed as responses to commands. Options are:
    - **None**: No result codes are displayed.
    - **Numeric**: Numeric result codes are displayed.
    - **Verbose**: Result codes are displayed in English, for example: OK, ERROR, CONNECT. This is the default.
18. (Optional) Click to expand **Phonebook** and create dial strings that can be used to connect to remote servers.
    a. Click **+** to add a phone book entry.
    b. For **Label**, type a descriptive name for the phone book entry.
    c. (Required) For **Dialstring**, type the string to dial to connect to the remote server.
    d. (Required) For **Connection destination**, type the host name or IP address of the remote server.
    e. (Required) For **Connection port**, type the TCP port of the remote server. Minimum is 1 and maximum is 65535.
19. Expand **TCP connection** to configure TCP connection for this serial port.
    a. To enable a TCP connection, click to toggle on **Enable**.
    b. For **Port**, type the TCP port for this service. The default is **4001**.
    c. Expand **Access control list** to create a list of IP addresses, interfaces, and firewall zones from which this service may be accessed.
        - To limit access to specified IPv4 addresses and networks:
            i. Click **IPv4 Addresses**.
            ii. For **Add Address**, click **+**.
            iii. For **Address**, enter the IPv4 address or network that can access the device's service type. Allowed values are:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- **any**: No limit to IPv4 addresses that can access the service-type.

iv. Click **+** again to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:
  i. Click **IPv6 Addresses**.
  ii. For **Add Address**, click **+**.
  iii. For **Address**, enter the IPv6 address or network that can access the device's service-type. Allowed values are:
    - A single IP address or host name.
    - A network designation in CIDR notation, for example, 2001:db8::/48.
    - **any**: No limit to IPv6 addresses that can access the service-type.
  iv. Click **+** again to list additional IP addresses or networks.
- To limit access to hosts connected through a specified interface on the device:
  i. Click **Interfaces**.
  ii. For **Add Interface**, click **+**.
  iii. For **Interface**, select the appropriate interface from the dropdown.
  iv. Click **+** again to allow access through additional interfaces.
- To limit access based on firewall zones:
  i. Click **Zones**. By default, there are three firewall zones already configured: internal, edge, and IPsec.
  ii. For **Add Zone**, click **+**.
  iii. For **Zone**, select the appropriate firewall zone from the dropdown. See Firewall configuration for information about firewall zones.
  iv. Click **+** again to allow access through additional firewall zones.

e. Toggle on **Enable mDNS** to enable Multicast DNS (mDNS) reporting for this service. This feature is disabled by default.

21. Expand **Logging Settings** to configure logging for this serial port.
   a. To enable logging, click to toggle on **Enable**.
   b. In the **Log file name** field, enter a descriptive name for the log file.
   c. For **Log file size**, type the size of the log file. When the log file reaches the size limit, the current file is saved and a new file is created. The default is 65536 bytes.
   d. From the **Type of data to log** list box, specify the type of data that should be saved.
      - **Received**
      - **Transmitted**
      - **Both**
      - **Both with arrows**: This is the default.
   e. If you want to log the time at which data was received or transmitted, click the **Timestamps** toggle to **Enable**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. If you want to log the data as hexadecimal values, click the **Hexadecimal** toggle to **Enable**.

Note You can review the message log in the **Serial Port Log** page. See Review the serial port message log.

21. Click **Apply** to save the configuration and apply the change.

Configure Modbus mode for a serial port

Modbus mode allows you to use the serial port for Modbus. See Modbus gateway.

To change the configuration to match the serial configuration of the device to which you want to connect:

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the menu, click **System**. Under **Configuration**, click **Serial Configuration**.



The **Serial Configuration** page is displayed.



Note You can also configure the serial port by using **Device Configuration** > **Serial**. Changes made by using either **Device Configuration** or **Serial Configuration** will be reflected in both.

3. Click the name of the port that you want to configure.



The serial port is enabled by default. To disable, toggle off **Enable**.

4. For **Mode**, select **Modbus**.
5. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** on EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.
6. (Optional) For **Label**, enter a label that will be used when referring to this port.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

7. For **Signaling**, select the electrical signaling interface type used on this serial port:
   - RS-232
     - Enable **RTS toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control.
     - For **RTS pre-delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.
     - For **RTS post-delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.
   - RS-422
     - Enable **Termination** if you want to enable electrical termination on this serial port.
   - RS-485
     - Enable **Termination** if you want to enable electrical termination on this serial port.
     - Enable **Full Duplex** if you want to enable full duplex communication on this serial port.

   The default is RS-232.
8. Expand **Serial Settings**.

   The entries in the following fields must match the information for the power controller. Refer to your power controller manual for the correct entries.
   a. **Baud rate**: For **Baud rate**, select the baud rate used by the device to which you want to connect. The default is **9600**.
      - Max baud rate: **230400**
      - Minimum: **50**

      For a complete list, see Baud rate options.
   b. **Data bits**: For **Data bits**, select the number of data bits used by the device to which you want to connect. The default is **8**.
   c. **Parity**: For **Parity**, select the type of parity used by the device to which you want to connect. The default is **None**.
   d. **Stop bits**: For **Stop bits**, select the number of stop bits used by the device to which you want to connect. The default is **1**.
   e. **Flow control**: For **Flow control**, select the type of flow control used by the device to which you want to connect. The default is **None**.
9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. The serial port is enabled by default. To disable:

```
(config)> serial port1 enable false
(config)>
```

4. Set the mode:

```
(config)> serial port1 mode modbus
(config)>
```

5. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.

```
(config)> serial port1 altpin true
(config)>
```

6. Set the signaling interface type used on this serial port:
   - **rs-232**
     - Enable **rts toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control.

       ```
       (config)> serial port1 rts_toggle true
       (config)>
       ```

     - For **rts pre_delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.

       ```
       (config)> serial port1 rts_pre_delay value
       (config)>
       ```

     - For **rts post_delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.

       ```
       (config)> serial port1 rts_post_delay value
       (config)>
       ```

   - **rs-422**
     - Enable **termination** if you want to enable electrical termination on this serial port.
   - **rs-485**
     - Enable **termination** if you want to enable electrical termination on this serial port.

       ```
       (config)> serial port1 termination true
       (config)>
       ```

     - Enable **full_duplex** if you want to enable full duplex communication on this serial port.

       ```
       (config)> serial port1 full_duplex true
       (config)>
       ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The default is rs-232.

7. (Optional) Set a label that will be used when referring to this port.

```
(config)>path-parameter label
(config)>
```

8. Set the baud rate used by the device to which you want to connect.

```
(config)> serial port1 baudrate rate
(config)>
```

where **rate** is the desired baud rate.

- Default baud rate: 9600
- Max baud rate: 230400
- Minimum baud rate: 50

For a complete list, see Baud rate options.

9. Set the number of data bits used by the device to which you want to connect.

```
(config)> serial port1 databits bits
(config)>
```

10. Set the type of parity used by the device to which you want to connect.

```
(config)> serial port1 parity parity
(config)>
```

Allowed values are:

- **even**
- **odd**
- **none**

The default is **none**.

11. Set the stop bits used by the device to which you want to connect.

```
(config)> serial port1 stopbits bits
(config)>
```

12. Set the type of flow control used by the device to which you want to connect.

```
(config)> serial port1 flow value
(config)>
```

where *value* is one of:

- **none**
- **rts/cts**
- **xon/xoff**

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

13. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

14. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure RealPort mode using the Digi Navigator

You can use RealPort mode to enable communication between a device and your computer. RealPort exposes a serial port on a remote device as a standard COM/TTY port on a client computer. You can install the **Digi Navigator**, which helps you to easily configure your devices and computer to use Realport.

Each time the **Digi Navigator** is launched on your computer, any Digi devices that are on the network and support device discovery are discovered by the **Navigator**.

For each of the devices that have been discovered, you can set serial ports on the device to RealPort mode as needed, and then also enable the RealPort service. The COM ports on your laptop are also configured. These processes ensure that RealPort is configured on the device and on your computer.

Note You can also configure your device and computer to use RealPort serial port mode without using the **Digi Navigator**. See Advanced RealPort configuration without using the Digi Navigator.

Digi Navigator Installation

The **Digi Navigator** can only be installed on a computer with a Windows OS. If you are using Linux, you can manually install and configure RealPort without **Digi Navigator**. For the Linux installation process, refer to the Get started: Install RealPort for LINUX in the **RealPort Installation User's Guide**.

Installation and configuration process

These steps explain how to install and configure the **Digi Navigator**.

Step 1: Install the Digi Navigator

Step 2: Configure RealPort on a Digi device from the Digi Navigator

Step 3: Install and configure RealPort on your computer

Note If you have Digi Navigator 1.0 already installed, Digi recommends that you uninstall it, as both versions of the Digi Navigator are not needed. See Uninstall Digi Navigator 1.0.

Digi Navigator features

- Digi Navigator application features
- Filter devices for display in the Digi Navigator
  - Filter the device list by service options
  - Filter the device list for auto-discovered devices
  - Filter the device list by RealPort configuration status

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Specify the IP addresses to discover a Digi device
- Set an IP address for a device
- Access a device's web UI from the Digi Navigator
- Manage the list of devices configured for RealPort
  - Refresh the RealPort device list
  - Review the COM ports configured for RealPort
  - Uninstall the RealPort device configuration from your computer
- Reconfigure RealPort on a device
- Generate a device setup script
- Review Digi Navigator version information
- Uninstall Digi Navigator 5.0

Install the Digi Navigator

This section explains how to download and install the **Digi Navigator** application.

Note Microsoft Visual C++ is required for RealPort and is installed by default during the Digi Navigator install process.

1. Navigate to the Digi Navigator support page.

   Note The **Digi Navigator** application can also be downloaded from your device's product support page.

2. Scroll down to the **Product Resources** tab, and in the **Drivers & Patches** section, click **Digi Navigator**.
3. From the list box, select the appropriate Microsoft Windows option from the list of driver options.
4. Click the **download** link to download the **Digi Navigator** application.
5. When the download is complete, click on the downloaded .exe file. The **Digi Navigator Setup** wizard displays.
6. In the **License Agreement** page, review the agreement and select the **I accept the agreement** option.



7. Click **Next**. The **Select Destination Location** page displays.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- You can leave the installation location as the default, or click **Browse** to select a different location.



8. Click **Next**. The **Select Additional Tasks** page displays.
   - If you want to create a shortcut for the Digi Navigator, select the **Create a desktop shortcut** option.



9. Click **Next**. The **Ready to Install** page displays.



10. Click **Install** to start the installation. When complete, the **Completing the Digi Navigator Setup Wizard** page displays.
    The **Launch Digi Navigator** option is selected by default. Deselect this option if you don't want the **Digi Navigator** to automatically launch each time you boot your computer.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



11. Click **Finish** to complete the installation process. If the **Launch Digi Navigator** option was selected, the Digi Navigator launches.

Next Step: Configure RealPort on a device. See Configure RealPort on a Digi device from the Digi Navigator.

Configure RealPort on a Digi device from the Digi Navigator

You can configure the Connect EZ 4 WS to communicate with your computer using RealPort. In this step, you can select which serial ports on the device should be set to RealPort mode, and the RealPort service is enabled for the device.


Configuring RealPort on your device is the final step in a two-step process. To ensure communication between the device and your laptop, you must also configure your computer for RealPort after the final step is completed.

Note You can also manually configure the device for RealPort by logging into the device's web UI. See Advanced RealPort configuration without using the Digi Navigator.

1. Make sure the Connect EZ 4 WS is powered and connected to your local network or computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. A list of the devices discovered by the **Digi Navigator** displays. For information about how devices are discovered and how to add a device to the list, see Digi Navigator device discovery process.
4. Find the device that you want to configure and expand it to display the IP addresses for the device.
5. Use one of the following methods to begin configuring RealPort on the device:
   - **Configuration pane:** Click on the IP address to display options in the Configuration pane. Click **Configure Device for RealPort**. The **Enter Device Credentials** page displays.
   - **Shortcut menu:** Right-click on an IP address to display the shortcut menu, and click **Configure Device For RealPort**. The **Enter Device Credentials** page displays.
6. In the **Enter Device Credentials** page, enter the device's default user name and password in the **Username** and **Password** fields. The default user name is **admin** and the default password is the unique password printed on the label packaged with your device. If the defaults do not work, they may have been changed. Verify with your system administrator.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

7. Click **OK**.
8. When RealPort configuration is complete, the **Success** message displays.



9. Click **OK** to close the message.
10. (Optional) If desired, you can verify the RealPort configuration. See Configure the serial port for RealPort mode and Configure the RealPort service.

Next Step: Install and configure RealPort on your computer. See Install and configure RealPort on your computer.

Install and configure RealPort on your computer

You can configure your computer to communicate with the Connect EZ 4 WS using RealPort. In this step, RealPort is installed on your computer and communication with the device is configured.

Configuring RealPort on your device is the second step in a two-step process. To ensure communication between the device and your laptop, you must also have configured your device for RealPort. See Configure RealPort on a Digi device from the Digi Navigator.

Note You can also manually install and configure RealPort on your computer. See Advanced RealPort configuration without using the Digi Navigator.

1. Make sure the Connect EZ 4 WS is powered and connected your local network or computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. A list of the devices discovered by the **Digi Navigator** displays. For information about how devices are discovered and how to add a device to the list, see Digi Navigator device discovery process.
4. Find the device that you want to access and expand it to display the IP addresses for the device.
5. Use one of the following methods to begin configuring RealPort on your computer:
   - **Configuration pane**: Click on the IP address to display options in the Configuration pane. Click **Configure this PC for RealPort**. The **Select RealPort features** dialog displays.
   - **Shortcut menu**: Right-click on an IP address to display the shortcut menu, and click **Configure this PC for RealPort**. The **Select RealPort features** dialog displays.
6. Configure features in the **Select RealPort features** dialog.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Enable **Encryption** to enable encryption of data. This is enabled by default.

b. Enable **Authentication** to configure the authentication method the RealPort server uses to authenticate clients. The **Authentication Configuration** dialog displays.

- From the **Method** list box, select the **Shared Secret - SHA256** option.
- For **Shared Secret**, enter the authentication password to ensure secure communication. Leave this field blank to disable authentication.



c. Click **OK**.

7. The **Select Ports** dialog displays. By default, all of the ports on the device are selected to be configured for RealPort. De-select the ports that you don't want to configure for RealPort.
8. Click **OK**. The **COM Selection** dialog displays.
9. From the **Select starting COM** list box, select the first COM port that should be configured for RealPort. The first available COM port is selected by default. The number of COM ports configured matches the number of serial ports on the device.
10. Click **OK**. A series of progress messages displays.
11. When the configuration is complete, a message displays.



12. Click **OK** to close the message.
13. (Optional) After RealPort configuration on your laptop is complete, you can open the Windows **Properties** dialog for your computer.
    a. Launch the **Digi Navigator** if it is not currently open. A list of devices that have RealPort enabled and configured displays in the **Installed RealPort Devices** section at the bottom of the screen.
    b. Double-click on a device name. The Windows **Properties** dialog for your computer displays, and display the COM ports on your computer that are configured for RealPort. For more information, see Remove the COM ports configured for RealPort.

Digi Navigator device discovery process

When the **Digi Navigator** is installed or launched, it discovers Digi devices that are on your local network and that also support device discovery. A list of the discovered Digi devices are displayed by default in the **Digi Navigator**.

If a Digi device is not on the same network as your computer or the device is undiscoverable, the device is not displayed in the **Digi Navigator**. You can add the device using that device's IP address, and after it has been added, it also displays in the **Digi Navigator**.

The sections below describe different scenarios for discovering devices.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Device supports Digi Navigator discovery

When the **Digi Navigator** is launched, all discoverable devices are displayed on the application screen. These include devices that are on the same network as your computer and the network has a DHCP server, or devices that have a static IP address.

The **Digi Navigator** uses the HTTPS service by default to discover devices to your network. Other services can be used. See [list of services used to discover a device when connected to a network].

Device cannot be discovered by Digi Navigator

If a device is not on the same network as your computer or the device is undiscoverable, you can manually add the device using that device's IP address. See [Specify the IP address to discover a Digi device].

Device supports Digi Navigator discovery, but a DHCP server is not on the network

If the device is directly connected to a computer or connected to a network with no DHCP server, there are two options available to connect to the device:

- 192.168.210.1: A set up address that is available in the OS. See [Assign a generic IP address to the device].
- 169.254.100.100: An auto-IP address available in the OS. See [Use the autodiscovery protocol to discover a device].

Note If you use either of these IP addresses to connect to the device for initial config, you should then set a unique IP address for the device that is appropriate for the network on which it will be deployed.

Services used to discover a device when connected to a network

To discover the IP address for a Digi device connected to your network, the **Digi Navigator** uses the HTTPS service by default. Other services can be used, if needed.

You can limit the service options that display in the configuration pane in the **Digi Navigator**.

1. Make sure **Digi Navigator** is [installed] and the Connect EZ 4 WS is powered and connected to your local network or computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. Click **Others > Services** from the toolbar to display the service options: **HTTPS**, **HTTP**, and **SSH**. To ensure that you can communicate with your device, at least one option should be selected.
4. Click on service option to select it or deselect it. A check mark displays next to a selected option.

   The selected options are included in the configuration pane. You can click on a service option in the configuration pane to use that service to login to the device.

Use the autodiscovery protocol to discover a device

If a Digi device is directly connected to a computer or connected to a network with no DHCP server, you can assign an IP address to the Digi device so that the device is automatically discovered.

1. Make sure **Digi Navigator** is [installed] and the Connect EZ 4 WS is powered and connected to your local network or computer with an Ethernet cable.
2. Launch the **Digi Navigator**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. From the toolbar, click **Filters** > **IP Addresses** > 169.254.100.100 option.
4. Log into the device and set a unique IP address for the device that is appropriate for the network on which it will be deployed. See Define a static IP address.

Assign a generic IP address to the device

If the Connect EZ device is directly connected to a computer or connected to a network with no DHCP server, you can assign a generic IP address to the device. Using this IP address requires you to set this IP address on your computer as well as on the device.

Step 1: Assign a generic IP address to the device

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. From the toolbar, click **Filters** > **IP Addresses** > 192.168.210.1.

Step 2: Assign the IP address to your computer

You must also manually assign this IP address to your computer to ensure a connection. Both your computer and device must be connected to a private network that does not have a DHCP server.

1. Use an Ethernet cable to connect the device and your computer. Both your computer and device must be connected to your private network.
2. On your PC, navigate to the Ethernet network settings dialog.
3. Click the **Internet Protocol Version 4 (TCP/IPv4)** parameter.



4. Click **Properties**. The **Internet Protocol Version 4 (TCP/IPv4) Properties** dialog appears.
5. Select **Use the following IP address**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note **IMPORTANT**: Make a note of the current IP address entries for **IP address**, **Subnet mask**, and **Default gateway**. You will need this information to complete the final step of the process.

8. Configure with the following details:
   - **IP address** for PC: 192.168.210.2
   - **Subnet**: 255.255.255.0
   - **Gateway**: 192.168.210.1



7. Click **OK**.
8. Open a browser window.
9. Enter the default gateway IP address to access the device: **192.168.210.1**. The device's login screen displays.
10. Log into the device using the default user name and password. The default user name is **admin** and the default password is printed on the bottom label of the device and on the loose label included in the package. If the default is not work, they may have been changed. Confirm this information with your system administrator.
11. Update the IP address for the device.
12. On your PC, revert the IP address information to the original entries.
    a. Return to the **Internet Protocol Version 4 (TCP/IPv4) Properties** dialog.
    b. Enter the original IP address entries for **IP address**, **Subnet mask**, and **Default gateway**.
    c. Click **OK**.

Specify the IP address to discover a Digi device

You can manually add a device to the known device list, using the device's IP address. This feature is useful if a device is not on the same network as your computer or the device is undiscoverable.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Before you begin

To add a device, you will need:

- The device's IP address.
- The user name and password for the device.


To add a device to the known devices list:

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. Click **Configure** > **Known Devices**.
4. Click **Add**. The **New Device** dialog displays.
   a. In the **Name** field, enter a descriptive name for the device.
   b. Click **Add**.
   c. In the **IP Addresses** field, enter the IP address of the device.
   If you want to enter more than one IP address for this device, click **Add** and enter another IP address.
   d. Click the buttons for the services that you want to use to communicate with the device. The default port number for each service can be changed. After a service has been selected, you can click the button for the service to de-select it.
   To ensure that you can communicate with your device, at least one option should be selected.
      - **HTTPS**. The HTTPS service is selected by default. The default port number is **443**.
      - **HTTP**. The default port number is **80**.
      - **SSH**. The default port number is **22**.
      - **RealPort**. Click **RealPort** to enable the RealPort service for the device. The default port number is **1027**.
5. Click **OK**. You are returned to the **Known Devices** dialog.
6. Click the **X** in the upper right corner to close the dialog.
7. The device you just added displays in the device list.

Digi Navigator application features

All features of the **Digi Navigator** are available from the main application screen.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



Toolbar

The toolbar menus are used to configure Digi Navigator.

Menu Item	Subpanel Item	Description
Configure	Known Devices	If a Digi device is not on the same network as your computer or the device is undiscoverable, you can manually add the device using that device's IP address. ▪ Specify the IP address to discover a Digi device
	Refresh Installed RealPort Device List	Use the **Refresh Installed RealPort Device List** feature to update the list of the Digi devices that have RealPort enabled and configured. The list displays in the RealPort Device List pane in the Digi Navigator. ▪ Refresh the RealPort device list
	Generate Device Setup Script	Use the **Generate Device Setup Script** feature to generate a script of the RealPort configuration of the local PC. The script can be saved and used as a backup. The script is generated as a .cmd file. ▪ Generate a device setup script
Filters	Services	You can limit the service options that display in the Configuration pane in the **Digi Navigator**. You can click on a service option in the

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Menu item	Sub-menu item	Description
		Configuration pane to use that service to log in to the device. • Filter the device list by service option
	IP Addresses	These specific IP addresses can be used to discover a Digi device that is directly connected to a computer or connected to a network with no DHCP server. • 192.168.210.1: A set up IP address that is available in the OS. See Assign a generic IP address to the device. • 169.254.100.100: An auto-IP address available in the OS. See Use the autodiscovery protocol to discover a device.
	Devices > Supported Services > RealPort	You can use the RealPort option to filter which devices are included in the device list, depending on the RealPort configuration status. • Filter the device list by RealPort configuration status
	Devices > Discovered Devices	You can use the Discovered Devices option to filter which devices are included in the device list, depending on whether the device was auto-discovered. • Filter the device list for auto-discovered devices
Help	About	Review the Digi Navigator version information. • Review Digi Navigator version information

Device pane

A list of the discovered devices and those added to the known device list display in the Device pane. Expand each device to display the IP addresses associated with each device.

Filter the device list

You can apply filters to limit which devices display in the pane.

- Filter the device list by service option
- Filter the device list for auto-discovered devices
- Filter the device list by RealPort configuration status

Display configuration options for a device in the Configuration page

Expand a device and click on an IP address for the device to display related configurations options in the Configuration pane.

Shortcut menu

You can right-click on the IP address for a device to display the shortcut menu options. The options are an easy way to use the features from the toolbar.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Item	Description
Add to Known Devices	If a Digi device is not on the same network as your computer or the device is undiscoverable, you can manually add the device using that device's IP address. • Specify the IP address to discover a Digi device
HTTPS	You can use the HTTPS menu option to access the device's web UI using the HTTPS service. • Access a device's web UI from the Digi Navigator
HTTP	You can choose the HTTP menu option to access the device's web UI using the HTTP service. • Access a device's web UI from the Digi Navigator
SSH	You can use the SSH menu option to access the device's web UI using the SSH service. • Access a device's web UI from the Digi Navigator
Set IP Address	You can reconfigure the IP address of a device to a DHCP address or a specified static address. • Set an IP address for a device
Configure Device for RealPort	You can use the Configure Device for RealPort menu option to configure RealPort on the device. • Configure RealPort on a Digi device from the Digi Navigator • Reconfigure RealPort on a device
Configure this PC for RealPort	Use the Configure this PC for RealPort menu option to configure RealPort on your computer so that it can communicate with the device. • Install and configure RealPort on your computer

Configuration pane

You can use the buttons in the Configuration pane to connect to a device's web UI, and configure RealPort on your device and on your computer.

Item	Description
HTTPS	You can click HTTPS to access the device's web UI using the HTTPS service. • Access a device's web UI from the Digi Navigator
HTTP	You can click HTTP to access the device's web UI using the HTTP service. • Access a device's web UI from the Digi Navigator
SSH	You can click SSH to access the device's web UI using the SSH service. • Access a device's web UI from the Digi Navigator

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Item	Description
Set IP Address	You can reconfigure the IP address of a device to a DHCP address or a specified static address. • Set an IP address for a device
Configure Device for RealPort	Click **Configure Device for RealPort** to configure RealPort on the device. • Configure RealPort on a Digi device from the Digi Navigator • Reconfigure RealPort on a device
Configure this PC for RealPort	Click **Configure this PC for RealPort** to configure RealPort on your computer so that it can communicate with the device. • Install and configure RealPort on your computer

RealPort device list pane

The RealPort device list displays all of the devices in Digi Navigator that are configured for RealPort.

Item	Description
Open Device Manager	Click a name in the RealPort device list to open the Windows **Properties** dialog on your computer to access the configured COM ports. The number of COM ports configured for RealPort matches the number of serial ports on the device. • Review the COM ports configured for RealPort
Uninstall Device	You can uninstall RealPort from the device and uninstall the RealPort configuration for this device from your computer if needed, using the **Uninstall Device** short cut menu option. • Uninstall the RealPort device configuration from your computer

Filter the device list displayed in the Digi Navigator

You can apply filters to limit which devices display in the device list.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Filter the device list by service option

You can filter the device list that displays in the Device page by service. This also determines which service buttons display in the Configuration pane.

The Digi Navigator uses the HTTPS service by default to discover the IP addresses for the Digi devices connected to your network. Other services can be used, if needed.

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. Click **Filters** > **Services** from the toolbar to display the service options: **HTTPS**, **HTTP**, and **SSH**. To ensure that you can communicate with your device, at least one option should be selected.
4. Click on service option to select it or deselect it. A check mark displays next to a selected option.

   The selected options are included in the configuration pane. You can click on a service option in the configuration pane to use that service to log in to the device.

Filter the device list for auto-discovered devices

You can use the **Discovered Devices** option to filter which devices are included in the device list, depending on whether the device was auto-discovered or is a device that was manually added to the known device list.

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. From the toolbar, click **Filters** > **Devices**. Use the **Discovered Devices** menu option to filter the devices.
   - **Selected**: Both known and discovered devices are listed.
   - **Not selected**: Only known devices are listed.

Filter the device list by RealPort configuration status

You can use the **RealPort** option to filter which devices are included in the device list, depending on the RealPort configuration status.

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. From the toolbar, click **Filters** > **Devices** > **Supported Services**. Use the **RealPort** menu option to filter the devices.
   - **Selected**: Only discovered devices that are configured for the RealPort service display. Known devices are included if the device is configured for RealPort.
   - **Not selected**: All discovered devices on your network and all known devices display, regardless of RealPort service configuration status.

Specify the IP address to discover a Digi device

You can manually add a device to the known device list, using the device's IP address. This feature is useful if a device is not on the same network as your computer or the device is undiscoverable.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Before you begin

To add a device, you will need:

- The device's IP address.
- The user name and password for the device.

To add a device to the known devices list:

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. Click **Configure** > **Known Devices**.
4. Click **Add**. The **New Device** dialog displays.
   a. In the **Name** field, enter a descriptive name for the device.
   b. Click **Add**.
   c. In the **IP Addresses** field, enter the IP address of the device.
   If you want to enter more than one IP address for this device, click **Add** and enter another IP address.
   d. Click the buttons for the services that you want to use to communicate with the device. The default port number for each service can be changed. After a service has been selected, you can click the button for the service to deselect it.
   To ensure that you can communicate with your device, at least one option should be selected.
      - **HTTPS**. The HTTPS service is selected by default. The default port number is **443**.
      - **HTTP**. The default port number is **80**.
      - **SSH**. The default port number is **22**.
      - **RealPort**. Click **RealPort** to enable the RealPort service for the device. The default port number is **1027**.
5. Click **OK**. You are returned to the **Known Devices** dialog.
6. Click the **X** in the upper right corner to close the dialog.
7. The device you just added displays in the device list.

Set an IP address for a device

You can reconfigure the IP address of a device to a DHCP address or a specified static address.

Note This feature can be used with only discovered devices. It is not available for known devices.

1. Make sure the Connect EZ 4 WS is powered and connected your local network or computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. A list of the devices discovered by the **Digi Navigator** displays. For information about how devices are discovered and how to add a device to the list, see Digi Navigator device discovery process.
4. Find the device that you want to configure and expand it to display the IP addresses for the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Use one of the following methods to begin reconfiguring the IP address:
   - **Configuration pane**: Click on the IP address to display options in the Configuration pane. Click **Set IP Address**. The **IP Address Configuration** dialog displays.
   - **Shortcut menu**: Right-click on an IP address to display the shortcut menu, and click **Set IP Address**. The **IP Address Configuration** dialog displays.
6. In the **IP Address Configuration** dialog, enter the required information:
   - **Type**: From the **Type** list box, select an option, **DHCP** or **Static IP address**.
   - **Address**: Enter the IP address.
   - **Default gateway**: Enter the default gateway that should be used.
7. Click **OK**.

Manage the list of devices configured for RealPort

After you have enabled and configured RealPort on at least one Digi device, a list of configured devices displays at the bottom of the **Digi Navigator**. You can refresh the list and easily access the COM port configuration on your computer.



- **Refresh**: From the toolbar, choose **Configure > Refresh Installed RealPort Device List** to update the list of Connect EZ 4 WS devices that have RealPort enabled and configured.
- **Device Manager**: Double-click on a device name in the list to open the Windows **Properties** dialog on your computer to access the configured COM ports. The number of COM ports configured for RealPort matches the number of serial ports on the device.
- **Uninstall the RealPort configuration on your computer**: You can use the **Uninstall Device** option to remove the RealPort device configuration on your computer for a selected device. This ensures that your computer is not able to connect to the selected device.

Refresh the RealPort device list

You can refresh the list of the Digi devices that have RealPort enabled and configured. The list displays in the **Installed RealPort Devices** pane in the Digi Navigator.

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. Launch the **Digi Navigator**.
3. Click **Configure** > **Refresh Installed RealPort Device List** to refresh the list.



Review the COM ports configured for RealPort

You can open the Windows **Properties** dialog on your computer to access the configured COM ports. The number of COM ports configured for RealPort matches the number of serial ports on the device.

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. In the RealPort list section of the Digi Navigator, double-click on a name in the **Device** column.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Configure RealPort mode using the Digi Navigator



4. The standard Windows **Device Properties** dialog opens.
   a. Click the **General** tab.
   b. Click **Change settings**.
   c. Click the **Advanced** tab.
   d. Click **Properties**. The COM ports display.
   e. Click **OK** or **Cancel** to close the dialog.

Uninstall the RealPort device configuration from your computer

You can use the **Uninstall Device** option to remove the RealPort device configuration on your computer for a selected device. This ensures that your computer is not able to connect to the selected device.

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. In the RealPort list section of the **Digi Navigator**, find the device that you want to uninstall.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



4. Right-click on an IP address in the list to display the shortcut menu.
5. Click **Uninstall Device** to remove the RealPort configuration for this device from your computer.
6. When the process is complete, a **Success** message displays in a confirmation dialog.
7. Click **OK** to close the dialog.

Reconfigure RealPort on a device

After you have initially configured RealPort on a device and established a connection with your computer, you can reconfigure RealPort on the device as needed.


Note If you reconfigure RealPort on a device, you do not need to reconfigure your computer.

1. Make sure the Connect EZ 4 WS is powered and connected your local network or computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. A list of the devices discovered by the **Digi Navigator** displays. For information about how devices are discovered and how to add a device to the list, see Digi Navigator device discovery process.
4. Find the device that you want to configure and expand it to display the IP addresses for the device.
5. Use one of the following methods to begin configuring RealPort on the device:
   - **Configuration pane**: Click on the IP address to display options in the Configuration pane. Click **Configure Device for RealPort**. The **Enter Device Credentials** page displays.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **Shortcut menu**: Right-click on an IP address to display the shortcut menu, and click **Configure Device for RealPort**. The **Enter Device Credentials** page displays.

8. In the **Enter Device Credentials** page, enter the device's default user name and password in the **Username** and **Password** fields. The default user name is **admin** and the default password is the unique password printed on the label packaged with your device. If the defaults do not work, they may have been changed. Verify with your system administrator.
7. Click **OK**.
8. When RealPort configuration is complete, the **Success** message displays.



9. Click **OK** to close the message.
10. (Optional) If desired, you can verify the RealPort configuration. See Configure the serial port for RealPort mode and Configure the RealPort service.

Access a device's web UI from the Digi Navigator

You can access the device's web UI and log in from the Configuration pane in the **Digi Navigator**, or from the shortcut menu for the device's IP address.

The service options are available in the Configuration pane or the shortcut menu if these conditions are met:

- The service button must be included in the **Services** filter. See Filter the device list by service options.
- At least one device must be configured for the service. For known devices, see Specify the IP address to discover a Digi device.

To access a device's web UI:

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. A list of the devices discovered by the **Digi Navigator** displays. For information about how devices are discovered and how to add a device to the list, see Digi Navigator device discovery process.
4. Find the device that you want to access and expand it to display the IP addresses for the device.
5. Launch the web UI for the device using one of the following methods:
   - **Configuration pane**: Click on an IP address for the device to display the configured service button(s) in the Configuration pane. Click on any of the active buttons (**HTTP**, **HTTPS**, **SSH**) to access the web UI and log in.
   - **Shortcut menu**: Right-click on the IP address for a device to display the shortcut menu. Click on any of the service options (**HTTP**, **HTTPS**, **SSH**) to access the web UI and log in.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Generate a device setup script

You can generate a script of the RealPort configuration of the local PC. The script can be saved and used as a backup. The script is generated as a .cmd file.

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. Click **Configure** > **Generate Device Setup Script**. The standard Windows dialog to name a file displays.
   a. Select a location and enter a descriptive name.
   b. Click **Save**.
4. The script is generated; a confirmation dialog displays when complete.
5. Click **OK** to close the dialog.

Review Digi Navigator version information

You can review the Digi Navigator version information.

1. Make sure **Digi Navigator** is installed and the Connect EZ 4 WS is powered and connected to your local network or to your computer with an Ethernet cable.
2. Launch the **Digi Navigator**.
3. From the toolbar, click **Help** > **About**. The **About Digi Navigator** dialog displays.
4. Review the information.
5. Click **OK** to close the dialog.

Uninstall Digi Navigator 1.0

If you have Digi Navigator 1.0 installed, Digi recommends that you uninstall it, as both versions of the Digi Navigator are not needed.

1. If Digi Navigator 1.0 is open, close it before you begin.
2. Launch the Windows **Control Panel**.
3. Click the **Programs** option.
4. Click **Uninstall a Program**.
5. Scroll through the list of programs to find Digi Navigator 1.x.
6. Right-click on the program name to display the menu.
7. Click **Uninstall**. The **Digi Navigator Uninstall** wizard displays.
8. Click **Next**. The uninstall process begins.

> Note If Digi Navigator 1.0 is open, a confirmation dialog with the message "Digi Navigator is running. Click OK to close it." displays. Click **OK** to continue with the uninstall process.

9. When complete, the **Completing Digi Navigator Uninstall** page displays.
10. Click **Finish** to complete the uninstall process.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Copy a serial port configuration

You can copy the configuration defined for one serial port to other serial ports on the same device. This feature is useful if you have several ports that have the same or a similar configuration.


Web

1. Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.
2. On the menu, click **System**. Under **Configuration**, click **Serial Configuration**.



The **Serial Configuration** page is displayed.

3. Find the serial port that has the configuration that you want to copy.
4. You can drag-and-drop the selected configuration to copy it, or click the **copy configuration** icon.
   - **Drag-and-drop**: Click the **copy configuration** icon and drag it over a different serial port, then drop it.
   - **Click**: Click the **copy configuration** icon.



5. The **Copy Configuration** dialog displays.



6. Select the items you want to copy and specify the serial ports to which the configuration should be applied.

Copy Port X	Enter the serial port numbers to which the configuration should be

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Copy a serial port configuration

Field	Description
configuration to these ports	applied. You can select a single number or a group, such as: 2-5, 10, 13-15. If you used the drag-and-drop method, the serial port number on which you dropped the configuration is entered in this field by default. You can change the entry if needed.
Copy these settings	The setting sections available for the selected serial port mode are selected by default. You can click the box next to an item name to select or deselect it. If you select a setting section that is not available for the serial mode types, the settings are copied, but have no effect on the current serial port mode.
Set IP Port numbers to sequential values on these services	Note This feature is optional. Select a service, and then set the IP port number to a starting number in the **Base port** field. When the configuration is applied to each selected port, a sequential IP port number is applied to the defined serial ports. For example, serial port 1 has the TCP port set to a base port number, and you choose to apply sequential TCP port numbers to serial ports 2, 3, and 4. The TCP port numbers would be assigned as follows: • Serial port 1: base port number +1 • Serial port 2: base port number +2 • Serial port 3: base port number +3 • Serial port 4: base port number +4

7. Click **Copy**. The configuration is copied to the specified serial ports.
8. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **a** to access the Admin CLI.
2. At the command line, type **system serial copy** plus the parameters for the features you want to include. More than parameter can be specified so you can copy more settings.

```
system serial copy SOURCE DESTINATION [all] [autoconnect]
[autodetect] [base] [data_match] [framing] [hangup] [label]
[logging] [modem] [monitor] [ppp_static] [serial] [service]
[session] [udp]
```

where:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **SOURCE**: The serial port that you want to copy from. (Required)
- **DESTINATION**: A list of the serial ports to which you want to copy the configuration. Example: 1-4,8-10, or type **all**. (Required)

Syntax:

- **all**: Copy all serial port settings.
- **autoconnect**: Copy the autoconnect settings.
- **autodetect**: Copy the autodetect settings.
- **base**: Copy enable, mode, sharing, and signal settings.
- **data_match**: Copy the data matching settings.
- **framing**: Copy the data framing settings.
- **hangup**: Copy the hangup or signal loss settings.
- **label**: Copy the label settings.
- **logging**: Copy the logging settings.
- **modem**: Copy the modem emulator settings.
- **monitor**: Copy the signal change monitoring settings.
- **ppp_dialin**: Copy the PPP dial-in settings.
- **serial**: Copy the baud rate, data bits, parity, stop bits, and flow control settings.
- **service**: Copy SSH, TCP, and Telnet service settings.
- **session**: Copy escape, history, exclusive, and idle timeout settings.
- **udp**: Copy UDP serial settings.

3. (Optional) Set sequential TCP port numbers for a service on a list of ports.

```
system serial tcpport DESTINATION SERVICE BASE
```

Where:

- **DESTINATION**: Enter a list of serial ports to set TCP port numbers. Example: 1-4,8-10, or type **all**. (Required)
- **SERVICE**: The service type to set TCP port numbers. (Required)

  Where **SERVICE** is one of: **ssh**, **tcp**, **telnet**, or **udp**.
- **BASE**: Set service TCP port numbers to base port + serial port number. (Required)

4. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **q** to disconnect from the device.

Advanced RealPort configuration without using the Digi Navigator

You can configure the Connect EZ 4 WS to communicate with your computer using RealPort. RealPort mode enables communication between a device and your computer by exposing a serial port on a remote device as a standard COM/TTY port on a client computer.

Windows Operating System

This method can be used if your computer has a Windows OS installed and you choose not to use the Digi Navigator to discover devices and configure RealPort.

To complete the RealPort configuration process for Windows:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Step 1. Download the RealPort driver
Step 2. Configure RealPort on your computer
Step 3. Configure the serial port for RealPort mode
Step 4. Configure the RealPort service

Linux Operating System

To complete the RealPort configuration process for Linux OS:

Step 1. Download the RealPort driver

Step 2. To complete the RealPort configuration process, refer to the Set up and install RealPort for LINUX section in the **RealPort Installation User's Guide**.

Download the RealPort driver

The first step is to download the RealPort application and save it to a location that you can easily access.

1. Navigate to https://hub.digi.com/support/products/realport/.
2. Scroll down to the **Product Resources** tab, and in the **Drivers & Patches** section, click **RealPort Driver**.
3. From the list box, select the appropriate Microsoft Windows option from the list of driver options. The associated RealPort for Windows option displays.
4. Click the **download** link.
5. When the download is complete, navigate to your download folder. The application is in a .zip file.
6. You can leave the .zip file in the download folder, or copy the .zip file and paste it to a location that you can easily access.

Configure RealPort on your computer

RealPort must be installed on your computer, and then RealPort configured for the IP address of each device that should be allowed a RealPort connection.

You will run the RealPort Wizard for each device that you want to configure. RealPort is installed on your laptop the first time that you run the wizard. The installation process is ignored each subsequent time that you run the wizard.

Before you begin

- Download RealPort onto your laptop, and make note of the download location. See Download the RealPort driver.
- Have the IP address of the device that you want to configure.

Step 1: Implement RealPort

1. Navigate to the downloaded Realport .zip file.
2. Open the .zip file.
3. Click on **setup.exe** to launch the RealPort wizard. The **Welcome to the Digi RealPort Setup Wizard** screen displays.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


4. If this is not the first time you have run the wizard, select the **Add a New Device** option. If this is the first time running the wizard, no options are available on the screen.
5. Click **Next**. The **Select Device** screen displays.
   a. From the list of device options, select the **Device not listed** option.
6. Click **Next**. The **Describe the Device** screen displays.
   a. In the **Device Model Name** field, enter a descriptive name for the device.
   b. In the **Network Settings** section, select the **IP** option and enter the IP address in the associated field.
   c. In the **COM Port Settings** section, from the **No. Ports** list box, select the number of physical serial ports that you want to configure. You can specify from 1 to the maximum number of ports available on the device.
   d. In the **Device Features** section, select both the **Encryption** and **Authentication** options.
7. Click **Finish** to complete the process and close the wizard.

Note If this is the first time that you have run the RealPort wizard, Realport is installed on your laptop. If it is not the first time or if RealPort is already installed, it is not installed again.

Step 2: Configure a RealPort connection on your laptop for your device

1. Follow the standard Windows process to access the **Device Manager** from your computer's operating system.
2. Select **Multi-port Serial Adapters**.
3. Right-click on your device. Click the **Properties** menu option. The **Properties** dialog appears.
4. Click the **Advanced** tab.
5. Click **Properties**. The **Advanced Properties** dialog appears.
6. Click the **Security** tab.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



7. Select the **Encrypt Network Traffic** check box to enable encrypted network traffic. When you select this option, the **TCP Port for Encrypted Traffic** field becomes available.
8. The **TCP Port for Encrypted Traffic** field has a default value of 1027. The entry must match the device's TCP port setting.
9. (Optional) If you want to use authentication, configure the feature.
   a. From the the **Authentication Method** list box, select the **Shared Secret - SHA256** option.
   b. Enter the authentication password in the **Shared Secret** field.
10. Click **Apply**.
11. Click **OK** to close the **Advanced Properties** dialog.
12. Click **OK** to close the **Properties** window.

Configure the serial port for RealPort mode

RealPort mode allows you to use RealPort.

To change the configuration to match the serial configuration of the device to which you want to connect:

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **System**. Under **Configuration**, click **Serial Configuration**.



The **Serial Configuration** page is displayed.



Note You can also configure the serial port by using **Device Configuration > Serial**. Changes made by using either **Device Configuration** or **Serial Configuration** will be reflected in both.

2. Click the name of the port that you want to configure.



The serial port is enabled by default. To disable, toggle off **Enable**.

3. For **Mode**, select **RealPort**.
4. Select an option from the **Sharing Mode** list box to determine which user(s) can change the port settings, and whether users can receive data from the port.
   - **None**. Only the user that opened the port can change the port settings. All other users are rejected. No other users can receive data from the port. This is the default.
   - **Primary**. Only the user that opened the port can change the port settings. All other users that try to open the port receive all of the data read to the port.
   - **Peer**. Any user that tries to open the port can change the port settings. All users that try to open the port receive all of the data read to the port.
5. (Optional) For **Label**, enter a label that will be used when referring to this port.
6. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.
7. For **Signaling**, select the electrical signaling interface type used on this serial port.
   - RS-232
     - Enable **RTS Toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS-CTS flow control.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- For **RTS Pre-delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**.
- For **RTS Post-delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**.

- **RS-422**
  - Enable **Termination** if you want to enable electrical termination on this serial port.
- **RS-485**
  - Enable **Termination** if you want to enable electrical termination on this serial port.
  - Enable **Full Duplex** if you want to enable full duplex communication on this serial port.

The default is **RS-232**.

8. Expand **Logging Settings** to configure logging for this serial port.
   a. To enable logging, click to toggle on **Enable**.
   b. In the **Log file name** field, enter a descriptive name for the log file.
   c. For **Log file size**, type the size of the log file. When the log file reaches the size limit, the current file is saved and a new file is created. The default is 65536 bytes.
   d. From the **Type of data to log** list box, specify the type of data that should be saved.
      - **Received**
      - **Transmitted**
      - **Both**
      - **Both with arrows**. This is the default.
   e. If you want to log the time at which data was received or transmitted, click the **Timestamps** toggle to **Enable**.
   f. If you want to log the data as hexadecimal values, click the **Hexadecimal** toggle to **Enable**.

> Note You can review the message log in the **Serial Port Log** page. See Review the serial port message log.

9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. The serial port is enabled by default. To disable:

```
(config)> serial port1 enable false
(config)>
```

4. Set the mode:

```
(config)> serial port1 mode realport
(config)>
```

5. Set the sharing mode:

```
(config)> serial port1 sharing value
(config)>
```

where **value** is one of:

- **none**: Only the user that opened the port can change the port settings. All other users are rejected. No other users can receive data from the port. This is the default.
- **peer**: Any user that tries to open the port can change the port settings. All users that try to open the port receive all of the data read to the port.
- **primary**: Only the user that opened the port can change the port settings. All other users that try to open the port receive all of the data read to the port.

6. Set the signal mode:

```
(config)> serial port1 signal mode value
(config)>
```

where **value** is one of:

Set the signaling interface type used on this serial port.

- **rs232**
  - Enable **rts toggle** if you want to enable RTS toggling during transmission on this serial port. If enabled, this setting overrides RTS/CTS flow control:

    ```
    (config)> serial port1 rts_toggle true
    (config)>
    ```

  - For **rts pre delay**, enter the amount of time RTS is asserted before starting data transmission. The time is measured in milliseconds. The default is **0ms**:

    ```
    (config)> serial port1 rts_pre_delay value
    (config)>
    ```

  - For **rts post delay**, enter the amount of time RTS is deasserted before completing data transmission. The time is measured in milliseconds. The default is **0ms**:

    ```
    (config)> serial port1 rts_post_delay value
    (config)>
    ```

- **rs422**
  - Enable **termination** if you want to enable electrical termination on this serial port.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- rs-485
  - Enable **termination** if you want to enable electrical termination on this serial port:

```
(config)> serial ports termination true
(config)>
```

  - Enable **full duplex** if you want to enable full duplex communication on this serial port:

```
(config)> serial ports full_duplex true
(config)>
```

The default is rs-232.

f. Enable **Altpin** to use the Altpin feature. **Altpin** is disabled by default. If you enable **Altpin** in EIA-232 mode, the DCD and DSR signals are swapped. This allows use of DCD with 3-wire cables. **Altpin** has no impact on 422 or 485 mode. For more information, see Serial connector pinout.

```
(config)> serial ports altpin true
(config)>
```

g. Set a label that will be used when referring to this port.

```
(config)> serial ports label label
(config)>
```

h. (Optional) Set a label that will be used when referring to this port.

```
(config)> serial ports label label
(config)>
```

i. Configure serial port logging:

a. Enable serial port logging:

```
(config)>serial ports logging enable true
(config)>
```

b. Set the file name:

```
(config)>serial ports logging filename string
(config)>
```

c. Set the maximum allowed log size for the serial port log when starting the log:

```
(config)>serial ports logging size value
(config)>
```

Where **value** is the size of the log file in bytes. The default is **65535**.

d. Specify the data types:

```
(config)>serial ports logging type value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

where value is one of:

- received
- transmitted
- both
- arrows. This is the default.

e. Log the time at which data was received or transmitted:

```
(config)>serial ports tagging hex true
(config)>
```

f. Log data as hexadecimal values:

```
(config)>serial ports tagging timestamp true
(config)>
```

11. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

12. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the RealPort service

After you have configured RealPort mode on the Connect EZ 4 WS, you must enable and configure the RealPort service. When this step is complete, all of the serial ports on the Connect EZ 4 WS are configured to use the RealPort service.

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the menu, click **System > Configuration > Device Configuration**.
3. Expand **Services**.
4. Expand **RealPort**.
5. Click **Enable** to enable the RealPort service.
6. For **RealPort Server Port**, enter **1027**. This is the default.
7. For **Minimum TLS version**, select the minimum TLS version that the RealPort service will accept. The default is TLS version 1.2.
8. Enable **Encryption** to enable encryption of data. This is enabled by default.
9. (Optional) Configure the authentication method the RealPort server uses to authenticate clients.
   a. From the **Authentication Method** list box, select the **Shared Secret - SHA256** option.
   b. For **Shared Secret**, enter the authentication password to ensure secure communication. Leave this field blank to disable authentication.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

10. Enable **Exclusive Mode** to ensure that any connection from an IP address is closed when opening a new connection from the same IP address. It is disabled by default.
11. Enable **RealPort Keepalive** to send RealPort keepalive packets. It is enabled by default.
12. Enable **TCP Port Keepalive** to send TCP keepalive packets. It is disabled by default.
13. Enable **Device Initiated connections** so users can remotely connect to serial devices as if they had a native COM/TTY port on their PC. It is disabled by default.
14. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. RealPort is enabled by default. To disable:

```
(config)> service realport enable false
(config)>
```

4. Set the RealPort server port:

```
(config)> service realport port value
(config)>
```

   where **value** is the port you want to use for the RealPort service. The default is 1027.
5. Set the select the minimum TLS version that the RealPort service will accept:

```
(config)> service realport minimum_tls_version value
(config)>
```

   where **value** is one of:
   - TLS-1.0: This is the default.
   - TLS-1.1
   - TLS-1.2
   - TLS-1.3
6. Data encryption is enabled by default. To disable:

```
(config)> service realport encryption false
(config)>
```

7. (Optional) Configure authentication:

```
(config)> service realport auth value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where **value** is one of:

- **none**: Do not use authentication. This is the default.
- **shared_secret_sha256**: You must also define the authentication password to ensure secure communication. Leave this field blank to disable authentication.

```
(config)> service realport auth shared_secret_sha256 value
(config)
```

where **value** is the authentication password.

8. Exclusive mode is disabled by default. This mode ensures that any connection from an IP address is closed when opening a new connection from the same IP address. To enable:

```
(config)> service realport exclusive true
(config)
```

9. Use RealPort keepalive to send RealPort keepalive packets. This is enabled by default. To disable:

```
(config)> service realport realport_keepalive false
(config)>
```

10. TCP port keepalive to send TCP keepalive packets is disabled by default. To enable:

```
(config)> service realport tcp_keepalive true
(config)>
```

11. Device initiated connections allow users to remotely connect to serial devices as if they had a native COM / TTY port on their PC. This is disabled by default. To enable:

```
(config)> service realport device_initiated_enable true
(config)>
```

12. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

13. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Disconnect a user from a serial port

From the **Serial Status** page, you can disconnect any users connected to a serial port configured for one of these modes: Login, Remote Access, PPP Dial-in, or Modem Emulation.

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the menu, click **Status** > **Connections** > **Serial**. The **Serial Status** page displays.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Find the port for which you want to disconnect one or more users. Verify that the port is configured for one of the following modes: Login, Remote Access, PPP Device, or Modem Emulation.
4. Click the down arrow next to the user name in the **Users** column to display a pop-up box.
5. A list of the users currently connected to the port display in the pop-up box. Information about each user's connection displays. If more than one user is connected, a check box displays for each user.
   - **User**: The user's log in name or a connection type, such as Telnet, TCP, or SSH.
   - **Remote IP**: The user's IP address.
   - **Connected**: The length of time that the user has been connected to the port. The time is measured in seconds.
   - **Idle**: The length of time that connection has been idle. The time is measured in seconds.
6. Determine the user(s) that you want to disconnect.
   - If only one user is listed, that user will be selected for the disconnect by default.
   - If more than one user is connected to the port, by default the check box for each user is selected. Click on a check box to deselect a user. Click **All** to deselect or select all of the users.
7. Click **Disconnect**. The single user or set of selected users are disconnected from the serial port.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. (Optional) Review the users currently connected to the port.

```
show serial port
>
```

   Where *port* is the port number you want to review, such as "port2"; a string, such as "console"; or the name of a user-configured serial port, such as USB.
3. (Optional) Review information about the disconnect command.

```
> system serial disconnect ?
>
```

4. Disconnect a specific user from a port.

```
>system serial disconnect port <number> STRING user STRING
>
```

   Where *port* is the port number you want to review, such as "port2"; a string, such as "console"; or the name of a user-configured serial port, such as USB.
   Enter one or both of the following:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- remoteip STRING: The remote IP address to disconnect.
- user: The user name of the user that you want to disconnect.

5. Disconnect all users from a port.

```
system serial disconnect port
>
```

Where port is the port number you want to review, such as "port2", a string, such as "console", or the name of a user-configured serial port, such as USB.

6. Type **exit** to exit the Admin CLI. Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show serial port status and statistics

To show the status and statistics for the serial port:

Web

1. Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.
2. On the main menu, click **Status** > **Connections** > **Serial**. The **Serial Status** page displays. See Serial Status page for information about the features in this page.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Use the show serial command.

```
> show serial

Label    Port   Enable  Mode    Baudrate
-------- ------ ------- ------- ---------
Serial 1 port1  true    Login   9600
>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Serial Status page

The **Serial Status** page contains status information about all of the serial ports available on the device.

To navigate to the **Serial Status** page, log into the device's web UI and click **Status** > **Connections** > **Serial**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Serial port Show serial port status and statistics

Item	Description
configuration icon	Click the (configuration) icon in the upper right corner of the page to access the **Serial Configuration** page. See Serial port for more information.
Search ports	Use the Search ports field to limit the list of ports displayed on the page.
Ports per page	Select the number of **Ports per page** that you want to display. Click the appropriate number or click **ALL** to display all ports. You can also click **Next** or **Back** to display the next or previous set of ports. Note The number ports you can display is determined by the number of ports available on the device.
Status	Displays the connection status. • **CONNECTED**: A telnet, terminal, SSH, or TCP session is active. • **DISABLED**: The port is not enabled. • **NO SIGNAL**: CTS or DCD is not active on the port.
Port	A list of the ports on the device. The port number and name displays as a link when the port is configured for remote access. You can click the port number or name to connect to the port in the terminal page. 1. Click the link to connect to the port in the terminal page. 2. In the terminal screen, enter ~b? to display additional commands. See Access the terminal screen from the web UI for more information about the commands. While you are connected to the terminal, the port status displays in the **Status** column as CONNECTED, and the name of the user logged into the device displays in the **User** column.
Label	A description for the port. You can change this from the **Serial Configuration** page. Click the (configuration) icon in the upper right corner of the page to access that page. The port number and name displays as a link when the port is configured for remote access. You can click the port number or name to connect to the port in the terminal page. See the description for Port (above) for more information.
Log	If configured, you can open the **Serial Port Log** page for that port. Options are: • **Green Log button**: The serial port mode selected for the port supports serial port logging, and logging is enabled. Click the **Log** button to open the **Serial Port Log** page for that port. See Review the serial port message log for information about that page. • **Gray Log button**: The serial port mode selected for the port supports serial port logging, but logging is not enabled.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Item	Description
	▪ **No button**: The serial port mode selected for the port does not support serial port logging.
User	When the port is connected to a Telnet, Terminal, SSH, or RFC connection the name of the user logged into the device displays. See the description for Port (above) for more information. If a serial port is configured for one of these modes: Login, Remote Access, PPP Dial-in, or Modem Emulation, you can disconnect one or more users from the serial port using the **Disconnect** feature. See Disconnect a user from a serial port.
TX/RX Bytes	Displays the total number of bytes that have been transmitted and received.
Signals	Indicates the types of communication that the device is ready to send. DCD: Carrier Detected CTS: Clear to Send DTR: Data Terminal Ready RTS: Ready to Send

Review the serial port message log

Serial port messages can be reviewed from the **Serial Port Log** page.

A serial port message log is created and saved when serial port logging has been enabled and configured for one of the following serial port modes: Login, Remote Access, Real Port, or RCI* Serial. You can view the log file from the **Log** column in the **Serial Status** page.

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the main menu, click **Status**.
3. Under **Connections**, click **Serial**. The **Serial Status** page displays.
4. If a green **Log** button is displayed, the serial port mode selected for the port supports serial port logging, and logging is enabled. Click the **Log** button to open the **Serial Port Log** page for that port. The **Serial port log** window displays.

   Note If the **Log** button is gray, the serial port mode selected for the port supports serial port logging, but logging is not enabled. If there is no **Log** button, the serial port mode selected for the port does not support serial port logging.

5. Review the messages in the window.
   - Click **Refresh** to refresh the log display.
   - Click **Download** to download the serial port log to your local device. The log file is saved to the /opt/serial directory. Because this is being save to the device's memory, you should use serial logging for diagnostic purposes, rather than having it permanently enabled.
   - Click **Restart** to clear and restart the serial port log.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. To show the serial port's contents and logging status:

```
> system serial show port-number
Logging is active on port-number
>
```

3. To save the log to your local device:

```
> system serial save port-number path
>
```

   If a relative path is provided, /etc/configserial will be used as the root directory for the path and file. (Required)
   The log file is saved to the /opt/serial directory. Because this is being save to the device's memory, you should use serial logging for diagnostic purposes, rather than having it permanently enabled.
4. To clear and restart the log:

```
> system serial clear port-number
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Search for a port

In the **Serial Status** page, you can use the **Search ports** search box to search for a port, or a set of ports, that match the search entry. The search feature looks for matches in the following columns: **Status**, **Port**, **Label**, and **User**.

1. Access the Serial Status page in the web UI.
2. Enter your search entry in the **Search ports** field. As you type, the ports displayed in the page are limited to only the ports with information that matches the search entry.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Wi-Fi

This chapter contains the following topics:

Wi-Fi configuration
Configure the Wi-Fi radio's channel
Configure the Wi-Fi radio to support DFS channels in client mode
Configure the Wi-Fi radio's band and protocol
Configure the Wi-Fi radio's transmit power
Configure an open Wi-Fi access point
Configure a Wi-Fi access point with personal security
Configure a Wi-Fi access point with enterprise security
Isolate Wi-Fi clients
Configure a Wi-Fi client and add client networks
Show Wi-Fi access point status and statistics
Show Wi-Fi client status and statistics

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Wi-Fi configuration

The Connect EZ 4 WS device has one Wi-Fi radio. You can configure the Wi-Fi radio for Wi-Fi access point mode and Wi-Fi client mode. By default, the Connect EZ 4 WS radio is configured to use access point mode.

Default access point SSID and password

By default, the Connect EZ 4 WS device has one access point enabled. The default SSID for the access point is:

Digi-Connect EZ 4 WS-*serial_number*

The password for the default access point is the unique password as found on the device's label. See Change the default SSID and pre-shared key for the preconfigured Wi-Fi access point for information about changing the default SSID and password.

Default Wi-Fi configuration

The default Wi-Fi configuration of the Connect EZ 4 WS device is:

Wi-Fi radio

	Default setting
Enabled or disabled	Disabled
Frequency band	2.4 GHz
TX power percentage	100
Access point mode	802.11b/g/n
Channel	Automatic
Channel width	20/40 MHz
Beacon interval	100

Access point

	Default setting
Name	Digi AP
Enabled or disabled	Enabled
SSID	Digi-Connect EZ 4 WS-*serial_number*
SSID broadcast	Enabled
Encryption	WPA2 Personal (PSK)
Pre-shared key	The unique password printed on the bottom label of the device

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Group relay interval	10 minutes
Isolate clients	Enabled

Client mode connections

None.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure the Wi-Fi radio's channel

By default, the Wi-Fi radio is configured to automatically select the best channel to use with respect to other Wi-Fi networks. You can configure a specific channel to use for the Wi-Fi radio by using the following steps.

- **2.4 GHz band**—Channels 1 to 11 are supported. Channels 12, 13, and 14 are not supported.
- **5 GHz band**—By default, only non-Dynamic Frequency Selection (DFS) channels are supported. You can also enable support for DFS channels in client mode. See Configure the Wi-Fi radio to support DFS channels in client mode for information about enabling DFS support.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:


   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Wifi**.
4. For **Channel**, select the channel. Only channels appropriate for the band are displayed.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Set the channel for the radio:
   a. Determine the band for the radio:

```
(config)> network wifi radio phy0 band
1=2.4GHz
(config)>
```

   b. Set the channel for the Wi-Fi radio:

```
(config)> network wifi radio phy0 24GHz channel value
(config)>
```

   where *value* is:
   - For 2.4 GHz:
     - 1 through 11
     - **auto**
   - For 5 GHz:
     - 36
     - 40
     - 44
     - 48
     - **auto**
4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the Wi-Fi radio to support DFS channels in client mode

Dynamic Frequency Selection (DFS) is a mechanism for Wi-Fi connections to use 5 GHz frequencies that are normally reserved for non-Wi-Fi purposes. In addition to the standard non-DFS channels (36,

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

40, 44, and 48), your Connect EZ 4 WS can be configured to have one or more Wi-Fi clients that can connect to external Wi-Fi access points that support DFS channels.

- DFS channels 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, and 144
- Higher 5GHz non-DFS channels 149, 153, 157, 161, and 165

The Wi-Fi access point must also support connections on these channels.

If DFS functionality is enabled, the Connect EZ 4 WS must be rebooted after saving the configuration change to re-initialize the Wi-Fi module.

Note If DFS functionality is enabled, any access points enabled on the Connect EZ 4 WS device will not be started.

Required configuration items

- Enable DFS support.
- One or more configured Wi-Fi clients. See Configure a Wi-Fi client and add client networks for details.

Note Not all Digi devices currently support 5 GHz. Before you try to use this feature, verify that your device supports 5 GHz.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Wifi**.
4. For **Frequency band**, select **5 GHz**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Click to enable **DFS Client Support**.

   Note When **DFS Client Support** is enabled, any enabled access points that use this radio will not be started and cannot be used as access points.

6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Set the channel for the radio:

   a. Set the band for the radio to 5 GHz:

```
(config)> network wifi radio phy0 band 5000mhz
(config)>
```

   b. Enable DFS client support:

```
(config)> network wifi radio phy0 5000mhz dfs_client true
(config)>
```

   Note When DFS client support is enabled, any enabled access points that use this radio will not be started and cannot be used as access points.

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the Wi-Fi radio's band and protocol

For Wi-Fi radios that support both 2.4 GHz and 5 GHz modes, you can configure the band. **Wi-Fi radio** defaults to use 2.4 GHz b/g/n band.

Note Not all Digi devices currently support 5 GHz. Before you try to use this feature, verify that your device supports 5 GHz.

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.


   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Wifi**.
4. For **Frequency band**, select either **2.4 GHz** or **5 GHz**.
5. For **Access point mode**, select the appropriate mode. Only modes appropriate for the selected band are displayed.



6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Set channel for the radio:
   a. Set the band for the radio:

```
(config)> network wifi radio phy# band value
(config)>
```

   where value is either **2400mhz** or **5000mhz**.
   b. Set the mode for the Wi-Fi radio. For example:
      - If the Wi-Fi radio has a band of **2400mhz**:

```
(config)> network wifi radio phy# 2400mhz mode value
(config)>
```

      where value is one of **b**, **bg**, **bgn**, **g**, **gn**, or **n**.
      - If the Wi-Fi radio has a band of **5000mhz**:

```
(config)> network wifi radio phy# 5000mhz mode value
(config)>
```

      where value is one of **ac**, **acn**, or **n**.
4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the Wi-Fi radio's transmit power

The default Wi-Fi transmit power that the Wi-Fi radio will use when in access point or client mode is 100 percent. You can configure the Wi-Fi radio to transmit at a lower power.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:
   a. Locate your device as described in Use Digi Remote Manager to view and manage your device.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Network** > **Wifi**.
4. For **Tx power percentage**, type or select the appropriate percentage for the Wi-Fi radio's transmit power.



5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Set the transmit power percentage for the radio:

```
(config)> network wifi radio phy0 tx_power value
(config)>
```

where *value* is any integer between 1 and 100 and represents the percentage of transmit power that the Wi-Fi module should use.

4. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure an open Wi-Fi access point

This procedure configures a Wi-Fi access point that does not require a password for client connections.

By default, the Connect EZ 4 WS device comes with one preconfigured access point, **Digi AP**. You cannot delete default access points, but you can modify them or you can create your own access points.

Required configuration items

- Enable the Wi-Fi access point.
- The Service Set Identifier (SSID) for the access point.
- Configure open security for the access point.
- LAN/bridge assignment. Once you configure a Wi-Fi access point, you must assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

Additional configuration items

- Determine whether to broadcast the access point's SSID.
- Determine whether to isolate clients connected to this access point, so that they cannot communicate with each other.
- The amount of time to wait before changing the group key.

To configure a Wi-Fi access point with no security:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.




The **Configuration** window is displayed.

3. Click **Network** > **Wifi** > **Access points**.
4. Create a new access point or modify an existing access point:
   - To create a new access point, for **Add Wifi access point:**, type a name for the access point and click **+**.



   - To modify an existing access point, click to expand the access point.

The Wi-Fi access point configuration window is displayed.



5. For **SSID**, type the SSID. Up to 32 characters are allowed.
6. Enable **SSID broadcast** to configure the radio to broadcast the SSID.
7. (Optional) Enable **Isolate clients** if it isn't already enabled to prevent clients that are connected to this access point from communicating with each other. This setting is enabled by default. See [Isolate Wi-Fi clients] for information about how to prevent clients connected to different access points from communicating with each other.
8. For **Encryption**, select one of the following:
   - **Open (Unencrypted)**: No encryption is used.
   - **WPA3 Enhanced Open (OWE)**: Uses Opportunistic Wireless Encryption (OWE) technology to provide encryption for Wi-Fi networks that do not use password protection.

     Note: Only select **WPA3 Enhanced Open (OWE)** if you know that all Wi-Fi clients connecting to this device will have WPA3 capabilities.

9. (Optional) For **Group rekey interval**, type the amount of time to wait before changing the group key.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The group key is shared by all its clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

Allowed values are any number of days, hours, minutes, or seconds, and take the format **number[d|h|m|s]**.

For example, to set **Group rekey interval** to ten minutes, enter **10m** or **600s**.

Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to **0**. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

iii. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.

ii. Click **Apply** to save the configuration and apply the change.

Command line

Configure a new access point

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Create a new access point:

```
(config)> add network wifi ap new_AP
(config network wifi ap new_AP)>
```

   New access points are enabled by default.

4. Set the SSID for the Wi-Fi access point. Up to 32 characters are allowed.

```
(config network wifi ap new_AP)> ssid my_SSID
(config network wifi ap new_AP)>
```

   SSID broadcasting is enabled by default for new access points.

5. Set the security for the access point to an open security method:

```
(config network wifi ap new_AP)> encryption type value
(config network wifi ap new_AP)>
```

   where *value* is either:

   - **none**: No encryption is used.
   - **owe**: Uses WPA3 Enhanced Open, which uses Opportunistic Wireless Encryption (OWE) technology to provide encryption for Wi-Fi networks that do not use password

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

protection.

Note Only select **none** if you know that all Wi-Fi clients connecting to this device will have WPA3 capabilities.

6. (Optional) Determine whether to prevent clients that are connected to this access point from communicating with each other:

```
(config)> network wifi ap digi_ap isolate_clients true
(config)>
```

See Isolate Wi-Fi clients for information about how to prevent clients connected to different access points from communicating with each other.

7. (Optional) Set the amount of time to wait before changing the group key.

The group key is shared by all the clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

```
(config network wifi ap new_AP)> encryption group_rekey value
(config network wifi ap new_AP)>
```

where *value* is any number of days, hours, minutes or seconds, and takes the format **number** {**d**|**h**|**m**|**s**}.

For example, to set **group rekey interval** to ten minutes, enter either **10m** or **600s**:

```
(config network wireless ap new_AP)> encryption group_rekey 600s
(config network wireless ap new_AP)>
```

Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to **0**. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

1. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.

2. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

3. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Edit an existing Access point

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Show available access points:

```
(config)> network wifi ap ?

  Additional Configuration
  ------------------------------------------------------------------------------

  ------------
  digi_ap                    Digi AP

(config)>
```

4. Set the SSID for the appropriate access point:

```
(config)> network wifi ap digi_ap ssid my_SSID
(config)>
```

5. SSID broadcasting is enabled by default for the preconfigured access points. If SSID broadcasting is disabled:

```
(config)> network wifi ap digi_ap ssid_broadcast true
(config)>
```

6. Set the security for the access point to an open security method:

```
(config network wifi ap new_AP)> encryption type value
(config network wifi ap new_AP)>
```

where *value* is either:

- **none**: No encryption is used.
- **owe**: Uses WPA3 Enhanced Open, which uses Opportunistic Wireless Encryption (OWE) technology to provide encryption for Wi-Fi networks that do not use password protection.

  Note Only select **owe** if you know that all Wi-Fi clients connecting to this device will have WPA3 capabilities.

7. (Optional) Determine whether to prevent clients that are connected to this access point from communicating with each other:

```
(config)> network wifi ap digi_ap isolate_client true
(config)>
```

See Isolate Wi-Fi clients for information about how to prevent clients connected to different access points from communicating with each other.

8. (Optional) Set the amount of time to wait before changing the group key.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The group key is shared by all the clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

```
(config)> network wifi ap ctgt_ap encryption group_rekey value
(config)>
```

where *value* is any number of days, hours, minutes, or seconds, and takes the format *number* (*d|h|m|s*).

For example, to set **group rekey interval** to ten minutes, enter either **10m** or **600s**:

```
(config)> network wireless ap ctgt_ap encryption group_rekey 600s
(config)>
```

Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to **0**. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

1. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

   The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.
2. Save the configuration and apply the changes.

   ```
   (config)> save
   Configuration saved.
   >
   ```
3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure a Wi-Fi access point with personal security

The WPA and WPA2 personal security modes allow a Wi-Fi access point to authenticate clients by using a pre-shared key that the client enters when connecting to the access point.

By default, the Connect EZ 4 WS device comes with one preconfigured access point, **Digi AP**. You cannot delete default access points, but you can modify them or you can create your own access points.

Required configuration items

- Enable the Wi-Fi access point.
- The Service Set Identifier (SSID) for the access point.
- Configure security for the access point to use personal security.
- The password (pre-shared key) that clients will used to connect to the access point.
- LAN/bridge assignment. Once you configure a Wi-Fi access point, you must assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Additional configuration items

- Determine whether to broadcast the access point's SSID.
- Determine whether to isolate clients connected to this access point, so that they cannot communicate with each other.
- The amount of time to wait before changing the group key.

To configure a Wi-Fi access point to use personal security:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.


   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.


   The **Configuration** window is displayed.
3. Click **Network** > **Wifi** > **Access points**.
4. Create a new access point or modify an existing access point:
   - To create a new access point, for **Add Wifi access point:**, type a name for the access point and click **+**.

   - To modify an existing access point, click to expand the access point.

   The Wi-Fi access point configuration window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



5. For **SSID**, type the SSID. Up to 32 characters are allowed.
6. Enable **SSID broadcast** to configure the radio to broadcast the SSID.
7. (Optional) Enable **Isolate clients** if it isn't already enabled to prevent clients that are connected to this access point from communicating with each other. This setting is enabled by default. See Isolate Wi-Fi clients for information about how to prevent clients connected to different access points from communicating with each other.
8. For **Encryption**, select one of the following:
   - **WPA Personal (TSK)**: All Wi-Fi clients must support WPA to be able to authenticate.
   - **WPA/WPA2 Personal (TSK)**: Wi-Fi clients that support WPA and WPA2 are able to authenticate.
   - **WPA2 Personal (TSK)**: All Wi-Fi clients must support WPA2 to be able to authenticate.
   - **WPA2-TSK/WPA3-SAE mixed mode**: Wi-Fi clients that support WPA2 and WPA3 are able to authenticate.
   - **WPA3 Personal (SAE)**: All Wi-Fi clients must support WPA3 to be able to authenticate.

     Note Only select **WPA3 Personal (SAE)** if you know that all Wi-Fi clients connecting to this device will have WPA3 capabilities.
9. For **Pre-shared key**, enter the password that clients will use when connecting to the access point.

   Note If you need to configure a Wi-Fi passphrase with any non-printable ASCII characters, you can use the wpa_passphrase tool to generate the appropriate pre-shared key. The wpa_passphrase command is available in the shell console of a DAL OS Digi device. For details about the command, see the wpa_passphrase Linux command.
10. (Optional) For **Group rekey interval**, type the amount of time to wait before changing the group key.

    The group key is shared by all in clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

    Allowed values are any number of days, hours, minutes, or seconds, and take the format **number[dhms]**.

    For example, to set **Group rekey interval** to ten minutes, enter **10m** or **600s**.

    Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to **0**. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

11. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.
The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.
12. Click **Apply** to save the configuration and apply the change.

Command line

Configure a new access point

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Create a new access point:

```
(config)> add network wifi ap new_AP
(config network wifi ap new_AP)>
```

New access points are enabled by default.
4. Set the SSID for the Wi-Fi access point. Up to 32 characters are allowed.

```
(config network wifi ap new_AP)> ssid my_SSID
(config network wifi ap new_AP)>
```

SSID broadcasting is enabled by default for new access points.
5. Set the security for the access point to a personal security option:

```
(config network wifi ap new_AP)> encryption type value
(config network wifi ap new_AP)>
```

where *value* is one of:

- **psk**: Uses WPA Personal (PSK). All Wi-Fi clients must support WPA to be able to authenticate.

  Note If you need to configure a Wi-Fi passphrase with any non-printable ASCII characters, you can use the wpa_passphrase tool to generate the appropriate pre-shared key. The wpa_passphrase command is available on the shell console of a DAL OS Digi device. For details about the command, see the wpa_passphrase Linux command.

- **mixedpsk**: Uses mixed WPA/WPA2 Personal (PSK) mode. Wi-Fi clients that support WPA and WPA2 are able to authenticate.
- **psk2**: Uses WPA2 Personal (PSK) mode. All Wi-Fi clients must support WPA2 to be able to authenticate.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **psk2sae**: Uses WPA2-PSK/WPA3-AES mixed mode. Wi-Fi clients that support WPA2 and WPA3 are able to authenticate.
- **sae**: Uses WPA3 Personal mode. All Wi-Fi clients must support WPA3 to be able to authenticate.

```
(config network wifi ap new_AP)> encryption type psk2sae
(config network wifi ap new_AP)>
```

6. (Optional) Determine whether to prevent clients that are connected to this access point from communicating with each other:

```
(config)> network wifi ap digi_ap isolate_clients true
(config)>
```

See Isolate Wi-Fi clients for information about how to prevent clients connected to different access points from communicating with each other.

7. Set the password that clients will use when connecting to the access point:

```
(config network wifi ap new_AP)> encryption key_type password
(config network wifi ap new_AP)>
```

where *key_type* varies depending on the selection for encryption **type**, above:

- If **type** is set to **psk**, *key_type* is key **psk**.
- If **type** is set to **mixedpsk**, *key_type* is key **mixedpsk**.
- If **type** is set to **psk2**, *key_type* is key **psk2**.
- If **type** is set to **psk2sae**, *key_type* is key **psk2sae**.
- If **type** is set to **sae**, *key_type* is key **sae**.

For example, if **type** is set to **psk2sae**, set key **psk2sae** to the appropriate password:

```
(config network wifi ap new_AP)> encryption type psk2sae
(config network wifi ap new_AP)> encryption key_psk2sae abcd1234
(config network wifi ap new_AP)>
```

Note The encryption key type must correspond to the configured encryption type. If you set an encryption key type that does not correspond to the configured encryption type, you will not be able to save the configuration.

8. (Optional) Set the amount of time to wait before changing the group key.

The group key is shared by all its clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

```
(config network wifi ap new_AP)> encryption group_rekey value
(config network wifi ap new_AP)>
```

where *value* is any number of days, hours, minutes, or seconds, and takes the format *number*[d|h|m|s].

For example, to set **group rekey interval** to ten minutes, enter either *10m* or *600s*.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network wireless ap new_AP)> encryption group_rekey 1800
(config network wireless ap new_AP)>
```

Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to 0. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

1. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

   The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.
2. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Edit an existing Access point

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Show available access points:

```
(config)> network wifi ap ?

  Additional Configuration
  ------------------------

  digi_ap                 Digi AP

(config)>
```

4. Set the SSID for the appropriate access point:

```
(config)> network wifi ap digi_ap ssid my_SSID
(config)>
```

5. SSID broadcasting is enabled by default for the preconfigured access points. If SSID broadcasting is disabled,

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> network wifi ap ctg1_ap ssid_broadcast true
(config)>
```

6. Set the security for the access point to a personal security option:

```
(config network wifi ap new_AP)> encryption type value
(config network wifi ap new_AP)>
```

where *value* is one of:

- **psk**: Uses WPA Personal (PSK). All Wi-Fi clients must support WPA to be able to authenticate.

  Note If you need to configure a Wi-Fi passphrase with any non-printable ASCII characters, you can use the wpa_passphrase tool to generate the appropriate pre-shared key. The wpa_passphrase command is available in the shell console of a DAL OS Digi device. For details about the command, see the wpa_passphrase Linux command.

- **mixedpsk**: Uses mixed WPA/WPA2 Personal (PSK) mode. Wi-Fi clients that support WPA and WPA2 are able to authenticate.
- **psk2**: Uses WPA2 Personal (PSK) mode. All Wi-Fi clients must support WPA2 to be able to authenticate.
- **psk2aes**: Uses WPA2-PSK/WPA2-AES mixed mode. Wi-Fi clients that support WPA2 and WPA2 are able to authenticate.
- **aes**: Uses WPA2 Personal mode. All Wi-Fi clients must support WPA2 to be able to authenticate.

```
(config network wifi ap new_AP)> encryption type psk2aes
(config network wifi ap new_AP)>
```

7. (Optional) Determine whether to prevent clients that are connected to this access point from communicating with each other:

```
(config)> network wifi ap ctg1_ap isolate_client true
(config)>
```

See Isolate Wi-Fi clients for information about how to prevent clients connected to different access points from communicating with each other.

8. Set the password that clients will use when connecting to the access point:

```
(config)> network wifi ap ctg1_ap encryption key_psk2 password
(config)>
```

9. (Optional) Set the amount of time to wait before changing the group key.
The group key is shared by all the clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

```
(config)> network wifi ap ctg1_ap encryption group_rekey value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is any number of days, hours, minutes, or seconds, and takes the format **number** (**d**|**h**|**m**|**s**).

For example, to set **group rekey interval** to ten minutes, enter either **10m** or **600s**.

```
(config)> network wireless ap dig1_ap encryption group_rekey 600s
(config)>
```

Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to **0**. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

1. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

   The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.

2. Save the configuration and apply the change.

   ```
   (config)> save
   Configuration saved.
   >
   ```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure a Wi-Fi access point with enterprise security

The WPA2 enterprise security mode allows a Wi-Fi access point to authenticate clients by using one or more RADIUS servers. When the Wi-Fi access point receives a connection request from a client, it authenticates the client with the RADIUS server before allowing the client to connect.

Using enterprise security mode allows each client to have different usernames and passwords configured in the RADIUS server, rather than using preshared key on the Connect EZ 4 WS device.

By default, the Connect EZ 4 WS device comes with one preconfigured access point, **Digi AP**. You cannot delete default access points, but you can modify them or you can create your own access points.

Required configuration items

- Enable the Wi-Fi access point.
- The Service Set Identifier (SSID) for the access point.
- Configure security for the access point to WPA2 enterprise.
- The IP address for one or more RADIUS servers.
- The secret key for one or more RADIUS servers.
- LAN/bridge assignment. Once you configure a Wi-Fi access point, you must assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Additional configuration items

- Determine whether to broadcast the access point's SSID.
- Determine whether to isolate clients connected to this access point, so that they cannot communicate with each other.
- The server port for one or more RADIUS server.
- The amount of time to wait before changing the group key.

To configure a Wi-Fi access point with WPA2 enterprise security:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:


   a. Locate your device as described in Use Digi Remote Manager to view and manage your device.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Wifi** > **Access points**.
4. Create a new access point, or modify an existing access point:
   - To create a new access point, for **Add Wifi access point**, type a name for the access point, and click **+**.


   - To modify an existing access point, click to expand the access point.

   The Wi-Fi access point configuration window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



5. For **SSID**, type the SSID. Up to 32 characters are allowed.
6. Enable **SSID broadcast** to configure the radio to broadcast the SSID.
7. (Optional) Enable **Isolate clients** if it isn't already enabled to prevent clients that are connected to this access point from communicating with each other. This setting is enabled by default. See Isolate Wi-Fi clients for information about how to prevent clients connected to different access points from communicating with each other.
8. For **Encryption**, select **WPA2 Enterprise**.
9. Configure one or more RADIUS servers:
   a. Click to expand **RADIUS server list**.
   b. Click to expand **RADIUS server**.
   c. For **RADIUS IP/hostname**, type the IP address or hostname of the RADIUS server.
   d. (Optional) Change the **RADIUS port**. The default port is 1812.
   e. For **RADIUS secret key**, type the secret key as configured on the RADIUS server.



   f. To add additional RADIUS servers, click **+**.

10. (Optional) For **Group rekey interval**, type the amount of time to wait before changing the group key.

    The group key is shared by all the clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

    Allowed values are any number of days, hours, minutes, or seconds, and take the format **number[d|h|m|s]**.

    For example, to set **Group rekey interval** to ten minutes, enter **10m** or **600s**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to **0**. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

11. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

    The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.

12. Click **Apply** to save the configuration and apply the change.

Command line

Configure a new access point

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Create a new access point:

```
(config)> add network wifi ap new_AP
(config network wifi ap new_AP)>
```

   New access points are enabled by default.

4. Set the SSID for the Wi-Fi access point. Up to 32 characters are allowed.

```
(config network wifi ap new_AP)> ssid my_SSID
(config network wifi ap new_AP)>
```

   SSID broadcasting is enabled by default for new access points.

5. Set the security for the access point to **wpa2**.

```
(config network wifi ap new_AP)> encryption type wpa2
(config network wifi ap new_AP)>
```

6. (Optional) Determine whether to prevent clients that are connected to this access point from communicating with each other:

```
(config)> network wifi ap digi_ap isolate_clients true
(config)>
```

   See Isolate Wi-Fi clients for information about how to prevent clients connected to different access points from communicating with each other.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

f. Configure one or more RADIUS servers:

a. Set the IP address of the RADIUS server:

```
(config network wifi ap new_AP)> encryption radius_servers 0 host IP_
address
(config network wifi ap new_AP)>
```

b. Set the secret key as configured on the RADIUS server:

```
(config network wifi ap new_AP)> encryption radius_servers 0 key
secret_key
(config network wifi ap new_AP)>
```

c. (Optional) Set the RADIUS server's port. The default is 1812.

```
(config network wifi ap new_AP)> encryption radius_servers 0 port port
(config network wifi ap new_AP)>
```

d. (Optional) Add and configure additional radius servers:

i. Add a server:

```
(config network wifi ap new_AP)> add encryption radius_servers end
(config network wifi ap new_AP encryption radius_servers 1)>
```

ii. Configure the new server as described above. For example, set the server IP address.

```
(config network wifi ap new_AP encryption radius_servers 1)> host
IP_address
(config network wifi ap new_AP encryption radius_servers 1)>
```

iii. Repeat for additional radius servers.

g. (Optional) Set the amount of time to wait before changing the group key.

The group key is shared by all its clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

```
(config network wifi ap new_AP)> encryption group_rekey value
(config network wifi ap new_AP)>
```

where *value* is any number of days, hours, minutes, or seconds, and takes the format *number*(d|h|m|s).

For example, to set **group rekey interval** to ten minutes, enter either **10m** or **600s**:

```
(config network wireless ap new_AP)> encryption group_rekey 600s
(config network wireless ap new_AP)>
```

Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to **0**. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.
   The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.
2. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Edit an existing Access point

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Show available access points.

```
(config)> network wifi ap ?

  Additional Configuration
  ------------------------------------------------------------------------

  dtgi_ap                   Digi AP

(config)>
```

4. Set the SSID for the appropriate access point.

```
(config)> network wifi ap dtgi_ap ssid My_SSID
(config)>
```

5. SSID broadcasting is enabled by default for the preconfigured access points. If SSID broadcasting is disabled:

```
(config)> network wifi ap dtgi_ap ssid_broadcast true
(config)>
```

6. Set the security for the access point to **wpa2**.

```
(config network wifi ap new_AP)> encryption type wpa2
(config network wifi ap new_AP)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

7. (Optional) Determine whether to prevent clients that are connected to this access point from communicating with each other:

```
(config)> network wifi ap digi_ap isolate_client true
(config)>
```

See Isolate Wi-Fi clients for information about how to prevent clients connected to different access points from communicating with each other.

8. Set the IP address or hostname of the RADIUS server:

```
(config)> network wifi ap digi_ap encryption host_wpa2 hostname
(config)>
```

9. Set the secret key as configured on the RADIUS server:

```
(config)> network wifi ap digi_ap encryption key_wpa2 secret_key
(config)>
```

10. (Optional) Set the RADIUS server's port. The default is 1812:

```
(config)> network wifi ap digi_ap encryption port_wpa2 port
(config)>
```

11. (Optional) Set the amount of time to wait before changing the group key.

The group key is shared by all its clients of the access point, and after a client has disconnected, it will be able to use the group key to decrypt broadcast packets until the key is changed.

```
(config)> network wifi ap digi_ap encryption group_rekey value
(config)>
```

where **value** is any number of days, hours, minutes, or seconds, and takes the format **number**{**d**|**h**|**m**|**s**}.

For example, to set **group rekey interval** to ten minutes, enter either **10m** or **600s**:

```
(config)> network wireless ap digi_ap encryption group_rekey 600s
(config)>
```

Increasing the time between rekeys can improve connectivity issues in noisy environments. To disable group rekeys, set to **0**. This will allow any client that has previously connected to see all broadcast traffic on the wireless network until the Wi-Fi radio is restarted. The default is 10 minutes.

12. Assign the Wi-Fi access point to a LAN interface or to a bridge. See Configure a Local Area Network (LAN) and Configure a bridge for more information.

The access point must be assigned to an active LAN, or a bridge that is assigned to an active LAN.

13. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Isolate Wi-Fi clients

Client isolation prevents wireless clients connected to the Connect EZ 4 WS device from communicating with other clients. There are two mechanisms for client isolation configuration:

- Isolate clients connected to the same access point
- Isolate clients connected to different access points

This section provides instructions for both mechanisms.

Isolate clients connected to the same access point

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Wifi** > **Access points**.
4. Create a new access point or modify an existing access point. See Configure an open Wi-Fi access point, Configure a Wi-Fi access point with personal security, or Configure a Wi-Fi access point with enterprise security.
5. Check to ensure that **Isolate clients** is enabled. This setting is enabled by default.
6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode.

```
> config
[config]>
```

3. Create a new access point or modify an existing access point. See Configure an open Wi-Fi access point, Configure a Wi-Fi access point with personal security, or Configure a Wi-Fi access point with enterprise security.
4. (Optional) Set the client isolation to true, if it is not already set. This is enabled by default.

```
[config]> network wifi ap digi_ap isolate_client true
[config]>
```

5. Save the configuration and apply the changes.

```
[config]> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Isolate clients connected to different access points

Isolating clients that are on different access points involves the following steps:

1. Create new access points.
2. Assign the access points to separate LAN interfaces.
3. Assign those LAN interfaces to separate firewall zones.
4. Create firewall filters to prevent traffic between the two firewall zones.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Create a new access point.

By default, the Connect EZ 4 WS comes with one preconfigured access point, named **Digi AP**. In these instructions, we will use the existing **Digi AP** access point and create another new access point, named **new AP**.

a. Click **Network** > **Wifi** > **Access points**.

b. For **Add Wifi access point:**, type a name for the access point and click **+**.

c. For **SSID**, type the SSID. Up to 32 characters are allowed.

d. Select the appropriate type of **Encryption** and complete the encryption-related fields as appropriate. See Configure an open Wi-Fi access point, Configure a Wi-Fi access point with personal security, or Configure a Wi-Fi access point with enterprise security for details.

4. Configure the firewall:

a. Click **Firewall** > **Zones**.

b. In **Add Zone**, enter **LAN2 isolation zone** for the name of the zone and click **+**.

Note We will be creating **LAN2** later in the procedure.

c. Create a firewall filter to provide internet access for the **LAN2 isolation zone**.

i. For **Add packet filter**, click **+**.

ii. For **Label**, type **Allow LAN2 isolation zone to External**.

iii. For **Source zone**, select **LAN2 isolation zone**.

iv. For **Destination zone**, select **External**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

d. Create a firewall filter to drop traffic from the **Internal** zone (used by the **LAN1** interface) to the **LAN2 isolation zone**.

i. Click **Firewall** > **Packet filtering**.

ii. For **Add packet filter**, click **+**.

iii. For **Label**, type **Drop traffic from Internal to LAN2 isolation zone**.

iv. For **Action**, select **Drop**.

v. For **Source zone**, select **Internal**.

vi. For **Destination zone**, select **LAN2 isolation zone**.

e. Rearrange the firewall filters.

Firewall filters are applied in the order that they are listed. As a result, in order to drop traffic from the **Internal** zone to the **LAN2 isolation zone**, this filter must be listed prior to the **Allow all outgoing traffic filter**, which allows the **Internal** zone to have access to any zone.

To move the **Drop traffic from Internal to LAN2 isolation zone** filter to the top of the list:

i. Click the filter title.

ii. Drag-and-drop the filter to the top of the list.

5. Create a new LAN.

By default, the Connect EZ 4 WS device comes with one preconfigured LAN, which includes the default access point. We will use that LAN for the default access point, and create a new LAN for the second access point.

a. Click **Configuration** > **Network** > **Interfaces**.

b. For **Add interface**, type a name for the LAN and click **+**.

c. For **Zone**, select **LAN2 isolation zone**.

d. For **Device**, select the new Wi-Fi access point.

e. Click to expand **IPv4**.

f. For **Address**, type an IP address and subnet for the LAN.

g. Click to expand **DHCP server**.

h. **Enable** the DHCP server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Configure a new access point:

   a. Create a new access point:

```
(config)> add network wifi ap new_AP
(config network wifi ap new_AP)>
```

   New access points are enabled by default.

   b. Set the SSID for the Wi-Fi access point. Up to 32 characters are allowed:

```
(config network wifi ap new_AP)> ssid my_SSID
(config network wifi ap new_AP)>
```

   c. Set the security for the access point:

```
(config network wifi ap new_AP)> encryption type value
(config network wifi ap new_AP)>
```

   where value is one of:

   - **none**
   - **psk**
   - **psk2**
   - **wpa2**

   d. Complete other encryption-related fields as appropriate based on the type of encryption. See Configure an open Wi-Fi access point, Configure a Wi-Fi access point with personal security, or Configure a Wi-Fi access point with enterprise security for details.

4. Configure the firewall.

   a. Return to the root config prompt by typing three periods (...):

```
(config network wifi ap new_AP)> ...
(config)>
```

   b. Add a new firewall zone named **LAN2_isolation_zone**. We will be creating LAN2 later in the procedure:

```
(config)> add firewall zone LAN2_isolation_zone
(config firewall zone LAN2_isolation_zone)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Create a firewall filter to provide internet access for the **LAN2 isolation zone**.

i. Return to the root config prompt by typing three periods (...)

```
(config firewall zone LAN2_isolation_zone)> ...
(config)>
```

ii. Add the new packet filter:

```
(config)> add firewall filter end
(config firewall filter 1)>
```

iii. Set the label for the filter:

```
(config firewall filter 1)> label "allow LAN2_isolation_zone to
external"
(config firewall filter 1)>
```

iv. Set the source zone to **LAN2 isolation zone**:

```
(config firewall filter 1)> src_zone LAN2_isolation_zone
(config firewall filter 1)>
```

v. Set the destination zone to **external**:

```
(config firewall filter 1)> dst_zone external
(config firewall filter 1)>
```

d. Create a firewall filter to drop traffic from the **Internal** zone (used by the **LAN1** interface) to the **LAN2 isolation zone**.

Firewall filters are applied in the order that they are listed. As a result, in order to drop traffic from the **Internal** zone to the **LAN2 isolation zone**, this filter must be added before the **Allow all outgoing traffic** filter, which allows the **Internal** zone to have access to any zone. In this example, we will add this new to the first position in the list (index position **0**).

i. Add the new packet filter:

```
(config firewall filter 1)> add .. 0
(config firewall filter 0)>
```

ii. Set the label for the filter:

```
(config firewall filter 0)> label "drop traffic from Internal to
LAN2_isolation_zone"
(config firewall filter 0)>
```

iii. Set the source zone to **internal**:

```
(config firewall filter 0)> src_zone internal
(config firewall filter 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iv. Set the destination zone to **LAN2_isolation_zone**:

```
(config firewall filter 0)> dst_zone LAN2_isolation_zone
(config firewall filter 0)>
```

v. Set the filter to drop traffic between the zones:

```
(config firewall filter 0)> action drop
(config firewall filter 0)>
```

5. Create a new LAN:

By default, the Connect EZ 4 WS device comes with one preconfigured LAN, which includes the default access point. We will use that LAN for the default access point, and create a new LAN for the second access point.

a. Return to the root config prompt by typing three periods (...):

```
(config firewall filter 0)> ...
(config)>
```

b. Add the new LAN:

```
(config)> add network interface LAN2
(config network interface LAN2)>
```

c. Set the device to the new Wi-Fi access point:

```
(config network interface LAN2)> device /network/wifi/ap/new_AP
(config network interface LAN2)>
```

d. Set the zone to **LAN2_isolation_zone**:

```
(config network interface LAN2)> zone LAN2_isolation_zone
(config network interface LAN2)>
```

e. Set the IP address and subnet mask of the LAN:

```
(config network interface LAN2)> ipv4 address address/zone
(config network interface LAN2)>
```

f. Enable the DHCP server:

```
(config network interface LAN2)> ipv4 dhcp_server enable true
(config network interface LAN2)>
```

6. Save the configuration and apply the changes:

```
(config network interface LAN2)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure a Wi-Fi client and add client networks

Required configuration items

- Create the Wi-Fi client.
- The Connect EZ 4 WS device's Wi-Fi radio that the Wi-Fi client will use.
- SSID of the access point that the client will log into.
- The encryption type used by the access point.
  - If a personal or mixed mode option is selected, identify the Pre-shared key.
  - If an enterprise option is selected:
    - Select the Extensible Authentication Protocol (EAP), one of:
      - TLS: Client certificate authentication.

        If TLS is selected, include:
        - The username.
        - The CA certificate in PEM format.
        - The client certificate in PEM format.
        - The private key in PEM format.
        - (Optional) The private key passphrase.
      - PEAP: Username/password authentication.

        If 'PEAP' is selected, identify the username and password.
      - SCEP certificates: Simple Certificate Enrollment Protocol (SCEP) certificate management.

        If SCEP certificates is selected:
        - Identify the username.
        - Select the SCEP client. See Configure a Simple Certificate Enrollment Protocol client for information about SCEP clients.
- Once you configure a Wi-Fi client, you must assign the Wi-Fi client to a LAN.

Additional configuration items

- Enable and configure background scanning, which allows the Wi-Fi client to move between access points that have the same SSID as their signal strength varies.
- Additional access points that client will attempt to use. If connection to one access point fails, the device will attempt to connect to the next access point in the list.

To configure a Wi-Fi client:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.


Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.




The **Configuration** window is displayed.

3. Click **Network** > **Wifi** > **Client mode connections**.
4. For **Add Wifi client:**, type the name of the client and click **+**.



The Wi-Fi client configuration window is displayed.



New Wi-Fi clients are enabled by default. To disable, toggle off **Enable**.

5. Configure the Wi-Fi network that the client will use.
   a. Click to expand **SSID list**.
   b. Enter the **SSID** of the access point that the client will use to connect to the Wi-Fi network.
   c. Select the type of **Encryption** used by the access point.
      - If a personal or mixed mode is selected, for **Pre-shared key**, enter the password that the client will use to connect to the access point.

      Note If you need to configure a Wi-Fi passphrase with any non-printable ASCII characters, you can use the wpa_passphrase tool to generate the appropriate pre-shared key. The wpa_passphrase command is available in the shell console of a DAL OS Digi device. For details about the command, see the wpa_passphrase Linux command.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- If **WPA2 Enterprise** is selected:
  - Select the **Extensible Authentication Protocol (EAP)**, one of:
    - **TLS**: Client certificate authentication.

      If **TLS** is selected, include:
      - The **Username**.
      - The **CA certificate** in PEM format.
      - The **Client certificate** in PEM format.
      - The **Private key** in PEM format.
      - (Optional) The **Private key passphrase**.
    - **PEAP**: Username/password authentication.

      If **PEAP** is selected, identify the **Username** and **Password**.
    - **SCEP certificates**: Simple Certificate Enrollment Protocol (SCEP) certificate management.

      If **SCEP certificates** is selected:
      - Identify the **Username**.
      - Select the **SCEP Client**. See Configure a Simple Certificate Enrollment Protocol client for information about SCEP clients.

6. (Optional) Configure **Background scanning**.

   Background scanning allows the device to scan for nearby access points and to move between access points that have the same SSID that is configured for the client connection, based on the signal strength of the access points.

   a. Click to expand **Background scanning**.

   b. Click **Enable background scanning** to enable.

   c. For **Scan threshold**, enter a value in dBm that is used to determine the scanning frequency. The allowed value is an integer between -113 and 0.

   The **Scan threshold** works with the **Short interval** and **Long interval** options to determine how often the device should scan for available access points.

   - If the signal strength from the access point to which the client is currently connected is below the **Scan threshold**, it will use the **Short interval** to determine how often to scan for available access points.
   - If the signal strength from the access point to which the client is currently connected is stronger the **Scan threshold**, it will use the **Long interval** to determine how often to scan for available access points.
   - If **Short interval** and **Long interval** are set to the same value, **Scan threshold** is ignored. For example, the default configuration has both **Short interval** and **Long interval** set to 1 second, which means that the device will scan for access points once per second regardless of the **Scan threshold**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

e. For **Short interval**, type the number of seconds to wait between scans for access points, when the signal strength from the access point to which the client is currently connected is below the **Scan threshold**.

e. For **Long interval**, type the number of seconds to wait between scans for access points, when the signal strength from the access point to which the client is currently connected is stronger than the **Scan threshold**.

f. Click to expand **Scan frequencies list**. You must add one or more frequency to scan:

i. Click **+** to add a scan frequency.

ii. Select a frequency.

iii. Repeat for additional frequencies.

g. To add a channel, click **Add Scan frequency** and select the appropriate channel.

f. Click **Apply** to save the configuration and apply the change.

Once you configure a Wi-Fi client, you must assign the Wi-Fi client to a LAN.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Create a new Wi-Fi client:

```
(config)> add network wifi client new_client
(config network wifi client new_client)>
```

   New clients are enabled by default.
4. Configure the Wi-Fi network that the client will use:
   a. Set the SSID of the access point that the client will use to connect to the Wi-Fi network:

```
(config network wifi client new_client)> ssid = ssid value
(config network wifi client new_client)>
```

   where *value* is the SSID of the access point.
   b. Set the encryption type for the access point:

```
(config network wifi client new_client)> ssid = encryption type value
(config network wifi client new_client)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is the type of encryption used by the access point. Allowed values are:

- **none**: no encryption.
- **owe**: Wi-Fi Enhanced Open, which uses Opportunistic Wireless Encryption (OWE) technology to provide encryption for Wi-Fi networks that do not use password protection.
- **psk**: WPA personal encryption.
- **mixedpsk**: Uses both WPA and WPA2 personal encryption.
- **psk2**: WPA2 personal encryption.
- **psk2sae**: Uses WPA2-PSK/WPA3-R2S mixed mode.
- **sae**: Uses WPA3 Personal mode.
- **wpa2**: WPA2 enterprise encryption.

c. If the type of encryption is set to:

- **psk**, **mixedpsk**, **psk2**, **psk2sae**, or **sae**, set the password that the client will use to connect to the access point.

```
(config network wifi client new_client)> auto 0 encryption key_
psk2 password
(config network wifi client new_client)>
```

Note If you need to configure a Wi-Fi passphrase with any non-printable ASCII characters, you can use the wpa_passphrase tool to generate the appropriate pre-shared key. The wpa_passphrase command is available in the shell console of a DAL OS Digi device. For details about the command, see the wpa_passphrase Linux command.

- **wpa2**:
  1. Set the Extensible Authentication Protocol (EAP):

```
(config network wifi client new_client)> auto 0 encryption
eap_type value
(config network wifi client new_client)>
```

where value is one of:

- **peap**: Username/password authentication. If **peap** is set:
  a. Set the username:

```
(config network wifi client new_client)> auto 0
encryption tls_wpa2 username
(config network wifi client new_client)>
```

  b. Set the password:

```
(config network wifi client new_client)> auto 0
encryption password_wpa2 password
(config network wifi client new_client)>
```

- **scep**: Simple Certificate Enrollment Protocol (SCEP) certificate management. If **scep** is set:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

i. Set the username:

```
(config network wifi client new_client)> auth 8
encryption td_epsk username
(config network wifi client new_client)>
```

ii. Set the SCEP client:

1. Use the ? to determine available SCEP clients:

```
(config network wifi client new_client)> auth 8
encryption scep_client ?

SCEP client: The SCEP client which this Wi-Fi
client will use to download the
necessary keys and certificates from the SCEP
server.
Format:
  SCEP_test_client
  SCEP_test_client1
Current value:

(config network wifi client new_client)>
```

2. Set the SCEP client, for example:

```
(config network wifi client new_client)> auth 8
encryption scep_client SCEP_test_client
(config network wifi client new_client)>
```

See Configure a Simple Certificate Enrollment Protocol client for information about SCEP clients.

- For Client certificate authentication, if this is selected:

i. Set the username:

```
(config network wifi client new_client)> auth 8
encryption td_epsk username
(config network wifi client new_client)>
```

ii. Set the CA certificate by using the **ca_cert** parameter and pasting the certificate in PEM format:

```
(config network wifi client new_client)> auth 8
encryption ca_cert certificate
(config network wifi client new_client)>
```

iii. Set the client certificate by using the **client_cert** parameter and pasting the certificate in PEM format.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network wifi client new_client)> auth 8
encryption client_cert certificate
(config network wifi client new_client)>
```

iii. Set the private key by using the **private key** parameter and pasting the private key in PEM format.

```
(config network wifi client new_client)> auth 8
encryption private_key key
(config network wifi client new_client)>
```

iv. (Optional) Set the private key passphrase.

```
(config network wifi client new_client)> auth 8
encryption private_key_passphrase passphrase
(config network wifi client new_client)>
```

5. (Optional) Configure background scanning.

Background scanning allows the device to scan for nearby access points and to move between access points that have the same SSID that is configured for the client connection, based on the signal strength of the access points.

a. Enable background scanning.

```
(config network wifi client new_client)> background_scanning enable
true
(config network wifi client new_client)>
```

b. Set the scan threshold (**bgscan strength**), in dB, that is used to determine the scanning frequency.

```
(config network wifi client new_client)> bgscan_strength value
(config network wifi client new_client)>
```

where *value* is an integer between -113 and 0.

The scan threshold works with the short and long intervals (**bgscan short interval** and **bgscan long interval**) to determine how often the device should scan for available access points.

- If the signal strength from the access point to which the client is currently connected is below the value of **bgscan strength**, it will use **bgscan short interval** to determine how often to scan for available access points.
- If the signal strength from the access point to which the client is currently connected is stronger than the value of **bgscan strength**, it will use **bgscan long interval** to determine how often to scan for available access points.
- If **bgscan short interval** and **bgscan long interval** are set to the same value, **bgscan strength** is ignored. For example, the default configuration has both **bgscan short interval** and **bgscan long interval** set to 1 second, which means that the device will scan for access points once per second regardless of the value of **bgscan strength**.

c. Set the number of seconds to wait between scans for access points, when the signal strength from the access point to which the client is currently connected is below the

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

value of **bgscan strength**:

```
(config network wifi client new_client)> bgscan_short_interval value
(config network wifi client new_client)>
```

where value is any integer greater than 0. The default is 1.

c. Set the number of seconds to wait between scans for access points, when the signal strength from the access point to which the client is currently connected is greater than the value of **bgscan strength**:

```
(config network wifi client new_client)> bgscan_long_interval value
(config network wifi client new_client)>
```

where value is any integer greater than 0. The default is 1.

e. Configure the frequencies that will be scanned for available access points.

The Connect EZ 4 WS device has three preconfigured frequencies:

- 2412 MHz
- 2437 MHz
- 2462 MHz

You can delete the preconfigured frequencies and add additional frequencies. At least one frequencies is required.

i. To delete a preconfigured frequencies:

i. Use the **show** command to determine the index number of the channel to be deleted:

```
(config network wifi client new_client)> show background_scanning
scan_freq
0 2412
1 2437
2 2462
(config network wifi client new_client)>
```

ii. Use the appropriate index number to delete the channel. For example, to delete the 2412 frequency:

```
(config network wifi client new_client)> del 0
(config network wifi client new_client)>
```

ii. To add a frequency:

i. Use the ? with an existing index number to determine the allowed values for frequencies:

```
(config network wifi client new_client)> background_scanning scan_
freq 1

Scan frequency: Enable this frequency in the background scan.
Format:
  2412
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
  2417
  2422
  2427
  2432
  2437
  2442
  2447
  2452
  2457
  2462
Current value: 2437
```

4. Add the appropriate frequency. For example, to add the **2457** frequency to the end of the list:

```
(config network wifi client new_client)> add background_scanning
scan_freq end 2457
(config network wifi client new_client)>
```

5. Save the configuration and apply the changes.

```
(config network wireless client new_client)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Once you configure a Wi-Fi client, you must assign the Wi-Fi client to a LAN.

Show Wi-Fi access point status and statistics

You can show summary status for all Wi-Fi access points, and detailed status and statistics for individual Wi-Fi access points.

Web

Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.

1. On the main menu, click **Status**.
2. Under **Connections**, click **Wi-Fi** > **Access Points**.

Command line

Show summary of Wi-Fi access points

To show the status and statistics for Wi-Fi access points, use the `show wifi ap` command.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the Admin CLI prompt, type **show wifi ap**.

```
> show wifi ap

AP          Enabled  Status  SSID            BSSID
----------  -------  ------  --------------  -----------------
my_AP       true     up      my_SSID         00:40:9D:14:3D:3T
digi_ap     true     up      Digi3           00:40:9D:13:2D:3G

>
```

3. To view information about both active and inactive access points, include the **all** parameter:

```
> show wifi ap all

AP          Enabled  Status  SSID            BSSID
----------  -------  ------  --------------  -----------------
my_AP       true     up      my_SSID         00:40:9D:14:3D:3T
digi_ap     true     up      Digi3           00:40:9D:13:2D:3G
digi_ap2    false    down

>
```

Show detailed status and statistics of a specific Wi-Fi access point

To show a detailed status and statistics of a Wi-Fi access point, use the **show wifi ap name** *name* command:

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the Admin CLI prompt, type **show wifi ap name** *name*.

```
> show wifi ap name my_AP

my_AP Access Point Status
-------------------------
Enabled                 : true
Status                  : up

SSID                    : my_AP
Security                : none

Channel                 :
Channel Width           :
Radio                   : wifi
BSSID                   : 00:40:9D:14:3D:3T

Client          Signal  Rx Bytes  Tx Bytes  Uptime
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
cc:c0:17:6c:34:c5:a3  -59      155997    279491    881
>
```

Show Wi-Fi client status and statistics

You can show summary status for all Wi-Fi clients, and detailed status and statistics for individual Wi-Fi clients.

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **Status**.
2. Under **Connections**, click **Wi-Fi** > **Clients**.

Command line

Show summary of Wi-Fi clients

To show the status and statistics for Wi-Fi client, use the show wifi client command.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, type **show wifi client**:

```
> show wifi client

Client     Enabled  SSID      Status  Signal  MAC Address
---------- -------- --------- ------- ------- -----------------
my_client  true     my_SSID   up      -43     4a:fe:61:dc:6e:61

>
```

3. To view information about both active and inactive clients, include the **all** parameter:

```
> show wifi client all

Client     Enabled  SSID      Status  Signal  MAC Address
---------- -------- --------- ------- ------- -----------------
my_client  true     my_SSID   up      -43     4a:fe:61:dc:6e:61
client2    true     SSID2     down
>
```

Show detailed status and statistics of a specific Wi-Fi client

To show a detailed status and statistics of a Wi-Fi client, use the **show wifi client name** *name* command.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, type **show wifi client name** *name*.

```
> show wifi client name my_client

Client                  : my_client
Enabled                 : true
SSID                    : my_SSID
Status                  : up
Signal                  : -43
MAC Address             : 94:fe:06:a1:8e:da
Channel                 : 44
Radio                   : wifi1
TX Power                : 23
Link Quality            : 67/70
BSSID                   : 50:D6:DD:8D:5E:C4

>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Routing

This chapter contains the following topics:

IP routing 278
Show the routing table 284
Virtual Router Redundancy Protocol (VRRP) 285

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

IP routing

The Connect EZ 4 WS device uses IP routes to decide where to send a packet it receives for a remote network. The process for deciding on a route to send the packet is as follows:

1. The device examines the destination IP address in the IP packet, and looks through the IP routing table to find a match for it.
2. If it finds a route for the destination, it forwards the IP packet to the configured IP gateway or interface.
3. If it cannot find a route for the destination, it uses a default route.
4. If there are two or more routes to a destination, the device uses the route with the longest mask.
5. If there are two or more routes to a destination with the same mask, the device uses the route with the lowest metric.

This section contains the following topics:

Configure a static route 279
Delete a static route 282
Configure a routing policy 283
Routing services 287
Configure routing services 288

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure a static route

A static route is a manually configured routing entry. Information about the route is manually entered rather than obtained from dynamic routing traffic.

Required configuration items

- The destination address or network.
- The interface to use to reach the destination.

Additional configuration items

- A label used to identify this route.
- The IPv4 address of the gateway used to reach the destination.
- The metric for the route. When multiple routes are available to reach the same destination, the route with the lowest metric is used.
- The Maximum Transmission Units (MTU) of network packets using this route.

To configure a static route:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Routes** > **Static routes**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Click the **+** to add a new static route.

The new static route configuration page is displayed.

New static route configurations are enabled by default. To disable, toggle off **Enable**.

5. (Optional) For **Label**, type a label that will be used to identify this route.
6. For **Destination**, type the IP address or network of the destination of this route.

   For example, to route traffic to the 192.168.47.0 network that uses a subnet mask of 255.255.255.0, type **192.168.47.0/24**. The **any** keyword can also be used to route packets to any destination with this static route.
7. For **Interface**, select the interface on the Connect EZ 4 WS device that will be used with this static route.
8. (Optional) For **Gateway**, type the IPv4 address of the gateway used to reach the destination. Set to blank if the destination can be accessed without a gateway.
9. (Optional) For **Metric**, type the metric for the route. When multiple routes are available to reach the same destination, the route with the lowest metric is used.
10. (Optional) For **MTU**, type the Maximum Transmission Units (MTU) of network packets using this route.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a new static route:

```
(config)> add network route static end
(config network/N route static 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

New static route instances are enabled by default. To disable:

```
(config network route static 0)> enable false
(config network route static 0)>
```

4. (Optional) Set a label that will be used to identify this route. For example:

```
(config network route static 0)> label "route to accounting network"
(config network route static 0)>
```

5. Set the IP address or network of the destination of this route. For example:

```
(config network route static 0)> destination ip_address[/network]
(config network route static 0)>
```

For example, to route traffic to the 192.168.47.0 network that uses a subnet mask of 255.255.255.0:

```
(config network route static 0)> dst 192.168.47.0/24
(config network route static 0)>
```

The **any** keyword can also be used to route packets to any destination with this static route.

6. Set the interface on the Connect EZ 4 WS device that will be used with this static route:
   a. Use the ? to determine available interfaces.
   b. Set the interface. For example:

```
(config network route static 0)> interface /network/interface/eth1
(config network route static 0)>
```

7. (Optional) Set the IPv4 address of the gateway used to reach the destination. Set to blank if the destination can be accessed without a gateway.

```
(config network route static 0)> gateway IPv4_address
(config network route static 0)>
```

8. (Optional) Set the metric for the route. When multiple routes are available to reach the same destination, the route with the lowest metric is used.

```
(config network route static 0)> metric value
(config network route static 0)>
```

where *value* is an integer between 0 and 65535. The default is 0.

9. (Optional) Set the Maximum Transmission Units (MTU) of network packets using this route.

```
(config network route static 0)> mtu integer
(config network route static 0)>
```

10. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

11. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete a static route

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Routes** > **Static routes**.
4. Click the menu icon (...) for a static route and select **Delete**.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Determine the index number of the static route to be deleted:

```
[config]> show network route static
0
    dst 10.6.8.1
    enable true
    no gateway
    interface /network/interface/lan1
    label new_static_route
    metric 0
    mtu 0
1
    dst 192.168.1.1
    enable true
    gateway 192.168.2.1
    interface /network/interface/lan2
    label new_static_route_1
    metric 0
    mtu 0
[config]>
```

4. Use the index number to delete the static route:

```
[config]> del network route static 0
[config]>
```

5. Save the configuration and apply the change:

```
[config]> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure a routing policy

Required configuration items

- The packet matching parameters. It can any combination of the following:
  - Source interface.
  - Source address. This can be a firewall zone, an interface, a single IPv4/IPv6 address or network, or a MAC address.
  - Destination address. This can be a firewall zone, an interface, a single IPv4/IPv6 address or network, or a domain.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Protocol. This can be **any**, **tcp**, **udp** or **icmp**.
- Source port. This is only used if the protocol is set to **tcp** or **udp**.
- Destination port. This is only used if protocol is set to **tcp** or **udp**.

- The network interface used to reach the destination.

Additional configuration items

- A label for the routing policy.
- Whether packets that match this policy should be dropped when the gateway interface is disconnected, rather than forwarded through other interfaces.

To configure a routing policy:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Routes** > **Policy-based routing**.
4. Click the **+** to add a new route policy.

   The new route policy page is displayed.

   New route policies are enabled by default. To disable, toggle off **Enable**.
5. (Optional) For **Label**, type a label that will be used to identify this route policy.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. For **Interface**, select the interface on the Connect EZ 4 WS device that will be used with this route policy.
9. (Optional) Enable **Exclusive** to configure the policy to drop packets that match the policy when the gateway interface is disconnected, rather than forwarded through other interfaces.
10. For **IP version**, select **Any**, **IPv4**, or **IPv6**.
11. For **Protocol**, select **Any**, **TCP**, **UDP**, or **ICMP**.
    - If **TCP** or **UDP** is selected for **Protocol**, type the port numbers of the **Source port** and **Destination port**, or set to **any** to match for any port.
    - If **ICMP** is selected for **Protocol**, type the ICMP type and optional code, or set to **any** to match for any ICMP type.
12. For **DSCP**, type the 6-bit hexadecimal Differentiated Services Code Point (DSCP) field match criteria. This will match packets based on the DHCP field within the ToS field of the IP header.
13. Configure source address information:
    a. Click to expand **Source address**.
    b. For **Type**, select one of the following:
       - **Zone**: Matches the source IP address to the selected firewall zone. See Firewall configuration for more information about firewall zones.
       - **Interface**: Matches the source IP address to the selected interface's network address.
       - **IPv4 address**: Matches the source IP address to the specified IP address or network. Use the format *IPv4_address*[/*netmask*], or use **any** to match any IPv4 address.
       - **IPv6 address**: Matches the source IP address to the specified IP address or network. Use the format *IPv6_address*[/*prefix_length*], or use **any** to match any IPv6 address.
       - **MAC address**: Matches the source MAC address to the specified MAC address.
14. Configure the destination address information:
    a. Click to expand **Destination address**.
    b. For **Type**, select one of the following:
       - **Zone**: Matches the destination IP address to the selected firewall zone. See Firewall configuration for more information about firewall zones.
       - **Interface**: Matches the destination IP address to the selected interface's network address.
       - **IPv4 address**: Matches the destination IP address to the specified IP address or network. Use the format *IPv4_address*[/*netmask*], or use **any** to match any IPv4 address.
       - **IPv6 address**: Matches the destination IP address to the specified IP address or network. Use the format *IPv6_address*[/*prefix_length*], or use **any** to match any IPv6 address.
       - **Domain**: Matches the destination IP address to the specified domain names. To specify domains:
         i. Click to expand **Domains**.
         ii. Click the **+** to add a domain.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

iii. For **Domain**, type the domain name.

iv. Repeat to add additional domains.

- **Default route**. Matches packets destined for the default route, excluding routes for local networks.

13. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a new routing policy:

```
(config)> add network route policy end
(config network route policy 6)>
```

   New route policies are enabled by default. To disable:

```
(config network route policy 6)> enable false
(config network route policy 6)>
```

4. (Optional) Set the label that will be used to identify this route policy:

```
(config network route policy 6)> label "New route policy"
(config network route policy 6)>
```

5. Set the interface on the Connect EZ 4 WS device that will be used with this route policy:

   a. Use the ? to determine available interfaces.

   b. Set the interface. For example:

```
(config network route policy 6)> interface /network/interface/eth1
(config network route policy 6)>
```

6. (Optional) Enable **exclusive** to configure the policy to drop packets that match the policy when the gateway interface is disconnected, rather than forwarded through other interfaces:

```
(config network route policy 6)> exclusive true
(config network route policy 6)>
```

7. Select the IP version:

```
(config network route policy 6)> ip_version value
(config network route policy 6)>
```

   where *value* is one of **any**, **ipv4**, or **ipv6**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Set the protocol:

```
(config network route policy 0)> protocol value
(config network route policy 0)>
```

where value is one of:

- **any**: All protocols are matched.
- **tcp**: Source and destination ports are matched:
  a. Set the source port:

```
(config network route policy 0)> src_port value
(config network route policy 0)>
```

  where value is the port number, or the keyword **any** to match any port as the source port.

  b. Set the destination port:

```
(config network route policy 0)> dst_port value
(config network route policy 0)>
```

  where value is the port number, or the keyword **any** to match any port as the destination port.
- **udp**: Source and destination ports are matched:
  a. Set the source port:

```
(config network route policy 0)> src_port value
(config network route policy 0)>
```

  where value is the port number, or the keyword **any** to match any port as the source port.

  b. Set the destination port:

```
(config network route policy 0)> dst_port value
(config network route policy 0)>
```

  where value is the port number, or the keyword **any** to match any port as the destination port.
- **icmp**: The ICMP protocol is matched. Identify the ICMP type:

```
(config network route policy 0)> icmp_type value
(config network route policy 0)>
```

  where value is the ICMP type and optional code, or set to **any** to match for any ICMP type.

9. Set the source address type:

```
(config network route policy 0)> src type value
(config network route policy 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is one of:

- **zone**: Matches the source IP address to the selected firewall zone. Set the zone:
  a. Use the ? to determine available zones:

```
(config network route policy 4)> src zone ?

Zone: Match the IP address to the specified firewall zone.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

Default value: any
Current value: any

(config network route policy 4)> src zone
```

  b. Set the zone, for example:

```
(config network route policy 4)> src zone external
(config network route policy 4)>
```

  See Firewall configuration for more information about firewall zones.
- **interface**: Matches the source IP address to the selected interface's network address. Set the interface:
  a. Use the ? to determine available interfaces:
  b. Set the interface, for example:

```
(config network route policy 4)> src interface
/network/interface/eth1
(config network route policy 4)>
```

- **address**: Matches the source IPv4 address to the specified IP address or network. Set the address that will be matched:

```
(config network route policy 4)> src address value
(config network route policy 4)>
```

  where value uses the format *IPv4_address/netmask*, or **any** to match any IPv4 address.
- **address6**: Matches the source IPv6 address to the specified IP address or network. Set the address that will be matched:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network route policy 4)> src address4 value
(config network route policy 4)>
```

where value uses the format IPv4_address[/prefix_length], or any to match any IPv4 address.

- **mac**: Matches the source MAC address to the specified MAC address. Set the MAC address to be matched:

```
(config network route policy 4)> src mac MAC_address
(config network route policy 4)>
```

iii. Set the destination address type:

```
(config network route policy 4)> dst type value
(config network route policy 4)>
```

where value is one of:

- **zone**: Matches the destination IP address to the selected firewall zone. Set the zone:
  a. Use the ? to determine available zones:

```
(config network route policy 4)> dst zone ?

Zone: Match the IP address to the specified firewall zone.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

Default value: any
Current value: any

(config network route policy 4)> dst zone
```

  b. Set the zone. For example:

```
(config network route policy 4)> dst zone external
(config network route policy 4)>
```

  See Firewall configuration for more information about firewall zones.
- **interface**: Matches the destination IP address to the selected interface's network address. Set the interface:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Use the ? to determine available interfaces.

b. Set the interface. For example:

```
(config network route policy 4)> set interface
/network/interface/eth1
(config network route policy 4)>
```

- **address**: Matches the destination IPv4 address to the specified IP address or network. Set the address that will be matched:

```
(config network route policy 4)> set address value
(config network route policy 4)>
```

where value uses the format **IPv4_address[/netmask]**, or **any** to match any IPv4 address.

- **address6**: Matches the destination IPv6 address to the specified IP address or network. Set the address that will be matched:

```
(config network route policy 4)> set address6 value
(config network route policy 4)>
```

where value uses the format **IPv6_address[/prefix_length]**, or **any** to match any IPv6 address.

- **mac**: Matches the destination MAC address to the specified MAC address. Set the MAC address to be matched:

```
(config network route policy 4)> set mac MAC_address
(config network route policy 4)>
```

11. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

12. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Routing services

Your Connect EZ 4 WS includes support for dynamic routing services and protocols. The following routing services are supported:

Supported protocol	Information
BGP	The Border Gateway Protocol (BGP) service supports BGP-4 (RFC1771).
IS-IS	The IPv4 and IPv6 Intermediate System to Intermediate System (IS-IS) service (RFC1142).
NHRP	Next Hop Resolution Protocol (NHRP) (RFC2332). Does not support NHRP authentication.
OSPFv2	The IPv4 Open Shortest Path First (OSPF) service supports OSPFv2 (RFC2328).
OSPFv3	The IPv6 Open Shortest Path First (OSPF) service supports OSPFv3 (RFC2740).
RIP	The IPv4 Routing Information Protocol (RIP) service supports RIPv2 (RFC2453) and RIPv1 (RFC1058).
RIPng	The IPv6 Routing Information Protocol (RIP) service supports RIPng (RFC2080).

Configure routing services

Required configuration items

- Enable routing services.
- Enable and configure the types of routing services that will be used.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Network** > **Routes** > **Routing services**.
4. Click **Enable**.

The default firewall zone setting, **Dynamic routes**, is specifically designed to work with routing services and should be left as the default.

5. Configure the routing services that will be used:
   a. Click to expand a routing service.
   b. **Enable** the routing service.
   c. Complete the configuration of the routing service.
6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Enable routing services:

```
(config)> network route service enable true
(config)>
```

4. Configure routing services that will be used:
   a. Use the **?** to display available routing services.

```
(config)> network route service ?

Routing services: Settings for dynamic routing services and protocols.
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Parameters                  Current Value
------------------------------------------------------------------------
enable                      true            Enable
zone                        dynamic_router  Zone

Additional Configuration
------------------------------------------------------------------------
bgp                         BGP
isis                        IS-IS
nhrp                        NHRP
ospfv3                      OSPFv3
ospfv3                      OSPFv3
rip                         RIP
ripng                       RIPng

(config)>
```

5. Enable a routing service that will be used. For example, to enable the RIP service:

```
(config)> network route service rip enable true
(config)>
```

6. Complete the configuration of the routing service. For example, use the ?tu view the available parameters for the RIP service.

```
(config)> network route service rip ?

Parameters                  Current Value
------------------------------------------------------------------------
acap                        false           Allow ICMP
enable                      true            Enable

Additional Configuration
------------------------------------------------------------------------
interface                   Interfaces
neighbour                   Neighbours
redis                       Route redistribution
timer                       Timers

(config)>
```

7. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show the routing table

To display the routing table.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Status** > **Routes**.

   The **Network Routing** window is displayed.
4. Click **IPv4 Load Balance** to view IPv4 load balancing.
5. Click **IPv6 Load Balance** to view IPv6 load balancing.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, type show route

   You can limit the display to only IPV4 entries by using **show route ipv4**, or to IPV6 entries by using **show route ipv6**. You can also display more information by adding the **verbose** option to the **show route** and **show route ip_type** commands.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Virtual Router Redundancy Protocol (VRRP)

Virtual Router Redundancy Protocol (VRRP) is a standard for gateway device redundancy and failover that creates a "virtual router" with a floating IP address. Devices connected to the LAN then use this virtual router as their default gateway. Responsibility for the virtual router is assigned to one of the VRRP-enabled devices on a LAN (the "master router"), and this responsibility transparently fails over to backup VRRP devices if the master router fails. This prevents the default gateway from being a single point of failure, without requiring configuration of dynamic routing or router discovery protocols on every host.

Multiple Connect EZ 4 WS devices can be configured as VRRP devices and assigned a priority. The router with the highest priority will be used as the master router. If the master router fails, then the IP address of the virtual router is mapped to the backup device with the next highest priority. Each VRRP router is configured with a unique LAN IP address, and the same shared VRRP address.

Configure VRRP

This section describes how to configure VRRP on a Connect EZ 4 WS device.

Required configuration items

- Enable VRRP.
- The interface used by VRRP.
- The Router ID that identifies the virtual router instance. The Router ID must be the same on all VRRP devices that participate in the same VRRP device pool.
- The VRRP priority of this device.
- The shared virtual IP address for the VRRP virtual router. Devices connected to the LAN will use this virtual IP address as their default gateway.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Network** > **VRR**.
4. For **Add VRR instance**, type a name for the VRR instance and click **+**.

The new VRR instance configuration is displayed.

5. Click **Enable**.
6. For **Interface**, select the interface on which this VRR instance should run.
7. For **Router ID** field, type the ID of the virtual router instance. The Router ID must be the same on all VRR devices that participate in the same VRR device pool. Allowed values are from 1 and **255**, and it is configured to **50** by default.
8. For **Priority**, type the priority for this router in the group. The router with the highest priority will be used as the master router. If the master router fails, then the IP address of the virtual router is mapped to the backup device with the next highest priority. If this device's actual IP address is being used as the virtual IP address of the VRR pool, then the priority of this device should be set to **255**. Allowed values are from 1 and **255**, and it is configured to **100** by default.
9. (Optional) For **Password**, type a password that will be used to authenticate this VRR router with VRR peers. If the password length exceeds 8 characters, it will be truncated to 8 characters.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

10. Configure the virtual IP addresses associated with this VRRP instance:
    a. Click to expand **Virtual IP addresses**.
    b. Click **+** to add a virtual IP address.



    c. For **Virtual IP**, type the IPv4 or IPv6 address for a virtual IP of this VRRP instance.
    d. (Optional) Repeat to add additional virtual IPs.
11. See Configure VRRP for information about configuring VRRP.
12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a VRRP instance. For example:

```
(config)> add network vrrp VRRP_test
(config network vrrp VRRP_test)>
```

4. Enable the VRRP instance:

```
(config network vrrp VRRP_test)> enable true
(config network vrrp VRRP_test)>
```

5. Set the interface on which this VRRP instance should run:
    a. Use the ? to determine available interfaces.
    b. Set the interface, for example:

```
(config network vrrp VRRP_test)> interface /network/interface/eth2
(config network vrrp VRRP_test)>
```

    c. Repeat for additional interfaces.
6. Set the router ID. The Router ID must be the same on all VRRP devices that participate in the same VRRP device pool. Allowed values are from **1** and **255**, and it is configured to **50** by default.

```
(config network vrrp VRRP_test)> router_id int
(config network vrrp VRRP_test)>
```

7. Set the priority for this router in the group. The router with the highest priority will be used as the master router. If the master router fails, then the IP address of the virtual router is

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

mapped to the backup device with the next highest priority. If this device's actual IP address is being used as the virtual IP address of the VRP pool, then the priority of this device should be set to **255**. Allowed values are from **1** and **255**, and it is configured to **100** by default.

```
(config network vrrp VRRP_test)> priority int
(config network vrrp VRRP_test)>
```

8. (Optional) Set a password that will be used to authenticate this VRP router with VRP peers. If the password length exceeds 8 characters, it will be truncated to 8 characters.

```
(config network vrrp VRRP_test)> password pwd
(config network vrrp VRRP_test)>
```

9. Add a virtual IP address associated with this VRP instance. This can be an IPv4 or IPv6 address.

```
(config network vrrp VRRP_test)> add virtual_address end ip_address
(config network vrrp VRRP_test)>
```

Additional virtual IP addresses can be added by repeating this step with different values for **ip_address**.

10. Save the configuration and apply the change.

```
(config network vrrp new_vrrp_instance)> save
Configuration saved.
>
```

11. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show VRRP status and statistics

This section describes how to display VRP status and statistics for a Connect EZ device. VRP status is available from the Web UI only.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

Remote Manager

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Status** > **VRRP**.
The **Virtual Router Redundancy Protocol** window is displayed.

CLI Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, type show vrrp.

```
> show vrrp

VRRP        Status  Proto  State    Virtual IP
----        ------  -----  -----    ----------
VRRP_test1  Up      IPv4   Backup   10.10.10.1
VRRP_test2  Up      IPv4   Backup   100.100.100.1
>
```

3. To display additional information about a specific VRRP instance, at the Admin CLI prompt, type show vrrp name *name*.

```
> show vrrp name VRRP_test1

VRRP_test1 VRRP Status
----------------------
Enabled                 : True
Status                  : Up
Interface               : lan1

IPv4
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Virtual IP address(es) : 10.10.10.1, 200.200.200.1
Current State          : Master
Current Priority       : 100
Last Transition        : Tue Jan  1 00:00:38 2019
Become Master          : 1
Released Master        : 0
Adverts Sent           : 13
Adverts Received       : 4
Priority Zero Sent     : 0
Priority zero Received : 0
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Virtual Private Networks (VPN)

Virtual Private Networks (VPNs) are used to securely connect two private networks together so that devices can connect from one network to the other using secure channels.

This chapter contains the following topics:

IPsec 322
OpenVPN 348
Generic Routing Encapsulation (GRE) 371
Dynamic Multipoint VPN (DMVPN) 384
L2TP 401
L2TPv3 Ethernet 413
MACsec 419
WireGuard VPN 429

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

IPsec

IPsec is a suite of protocols for creating a secure communication link—an IPsec tunnel—between a local and a remote IP network or between two IP networks across a public network such as the Internet.

IPsec data protection

IPsec protects the data being sent across a public network by providing the following:

Data origin authentication
Authentication of data to validate the origin of data when it is received.

Data integrity
Authentication of data to ensure it has not been modified during transmission.

Data confidentiality
Encryption of data sent across the IPsec tunnel to ensure that an unauthorized device cannot read the data.

Anti-replay
Authentication of data to ensure an unauthorized device has not injected it into the IPsec tunnel.

IPsec mode

The Connect EZ 4 WS supports IPsec mode. You can set this mode to run using either the **Tunnel** or **Transport** options.

Tunnel
The entire IP packet is encrypted and/or authenticated and then encapsulated as the payload in a new IP packet.

Transport
Only the payload of the IP packet is encrypted and/or authenticated. The IP header is left untouched. This mode has limitations when using an authentication header, because the IP addresses in the IP header cannot be translated (for example, with Network Address Translation (NAT)), and would invalidate the authentication hash value.

Internet Key Exchange (IKE) settings

IKE is a key management protocol that allows IPsec to negotiate the security associations (SAs) that are used to create the secure IPsec tunnel. Both IKEv1 and IKEv2 are supported.

SA negotiations are performed in two phases, known as **phase 1** and **phase 2**.

Phase 1

In phase 1, IKE creates a secure authenticated communication channel between the device and the peer (the remote device which is at the other end of the IPsec tunnel) using the configured pre-shared key and the Diffie-Hellman key exchange. This creates the IKE SAs that are used to encrypt further IKE communications.

For IKEv1, there are two modes for the phase 1 negotiation: **Main mode** and **Aggressive mode**. IKEv2 does not use these modes.

Main mode
Main mode is the default mode. It is slower than aggressive mode, but more secure, in that all sensitive information sent between the device and its peer is encrypted.

Aggressive mode

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Aggressive mode is faster than main mode, but is not as secure as main mode, because the device and its peer exchange their IDs and hash information in clear text instead of being encrypted. Aggressive mode is usually used when one or both of the devices have a dynamic external IP address.

Phase 2

In phase 2, IKE negotiates the SAs for IPsec. This creates two unidirectional SAs, one for each direction. Once the phase 2 negotiation is complete, the IPsec tunnel should be fully functional.

IPsec and IKE renegotiation

To reduce the chances of an IPsec tunnel being compromised, the IPsec SAs and IKE SA are renegotiated at a regular interval. This results in different encryption keys being used in the IPsec tunnel.

Authentication

Client authentication

XAUTH (extended authentication) pre-shared key authentication mode provides additional security by using client authentication credentials in addition to the standard pre-shared key. The Connect EZ 4 WS device can be configured to authenticate with the remote peer as an XAUTH client.

RSA Signatures

With RSA signatures authentication, the Connect EZ 4 WS device uses a private RSA key to authenticate with a remote peer that is using a corresponding public key.

Certificate-based Authentication

X.509 certificate-based authentication makes use of private keys on both the server and client which are secured and never shared. Both the server and client have a certificate which is generated with their respective private key and signed by a Certificate Authority (CA).

The Connect EZ 4 WS implementation of IPsec can be configured to use X.509 certificate-based authentication using the private keys and certificates, along with a root CA certificate from the signing authority and, if available, a Certificate Revocation List (CRL).

Configure an IPsec tunnel

Configuring an IPsec tunnel with a remote device involves configuring the following items:

Required configuration items

- **IPsec tunnel configuration items:**
  - A name for the tunnel.

    Note If the tunnel name is more than eight characters, the name will be truncated in the underlying network interface to the first six characters followed by three digits, incrementing from 000. This affects any custom scripts or firewall rules that may be trying to adjust the tunnel's interface or routing table entries.

  - The mode: either tunnel or transport.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

- Enable the IPsec tunnel.

  The IPsec tunnel is enabled by default.
- The firewall zone of the IPsec tunnel.
- The routing metric for routes associated with this IPsec tunnel.
- The authentication type and pre-shared key or other applicable keys and certificates.

  If SCEP certificates will be selected as the Authentication type, create the SCEP client prior to configuring the IPsec tunnel. See Configure a Simple Certificate Enrollment Protocol client for instructions.
- The local endpoint type and ID values, and the remote endpoint host and ID values.

- **IKE configuration items**
  - The IKE version, either IKEv1 or IKEv2.
  - Whether to initiate a key exchange or wait for an incoming request.
  - The IKE mode, either main aggressive.
  - The IKE authentication protocol to use for the IPsec tunnel negotiation during phase 1 and phase 2.
  - The IKE encryption protocol to use for the IPsec tunnel negotiation during phase 1 and phase 2.
  - The IKE Diffie-Hellman group to use for the IPsec tunnel negotiation during phase 1 and phase 2.
- Enable dead peer detection and configure the delay and timeout.
- Destination networks that require source NAT.

Additional configuration items

The following additional configuration settings are not typically configured to get an IPsec tunnel working, but can be configured as needed:

- Determine whether the device should use UDP encapsulation even when it does not detect that NAT is being used.
- If using IPsec failover, identify the primary tunnel during configuration of the backup tunnel.
- The Network Address Translation (NAT) keep alive time.
- The protocol, either Encapsulating Security Payload (ESP) or Authentication Header (AH).
- The management priority for the IPsec tunnel interface. The active interface with the highest management priority will have its address reported as the preferred contact address for central management and direct device access.
- Enable XAUTH client authentication, and the username and password to be used to authenticate with the remote peer.
- Enable Mode configuration (MODECFG) to receive configuration information, such as the private IP address, from the remote peer.
- Disable the padding of IKE packets. This should normally not be done except for compatibility purposes.
- Destination networks that require source NAT.
- Depending on your network and firewall configuration, you may need to add a packet filtering rule to allow incoming IPsec traffic.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Tunnel and key renegotiating
  - The lifetime of the IPsec tunnel before it is renegotiated.
  - The amount of time before the IKE phase 1 lifetime expires.
  - The amount of time before the IKE phase 2 lifetime expires.
  - The lifetime margin, a randomizing amount of time before the IPsec tunnel is renegotiated.

Note If the remote networks for an IPsec tunnel overlap with the networks for a LAN interface connection (Ethernet or Wi-Fi), you must configure a static route to direct the traffic either through the IPsec tunnel, or through the LAN (outside of the IPsec tunnel). See Configure a static route for information about configuring a static route.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.


   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN** > **IPsec**.
4. Click to expand **Tunnels**.
5. For **Add IPsec tunnel**, type a name for the tunnel and click **+**.



The new IPsec tunnel configuration is displayed.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. The IPsec tunnel is enabled by default. To disable, toggle off **Enable**.
7. (Optional) **Preferred tunnel** provides an optional mechanism for IPsec failover behavior. See Configure IPsec failover for more information.
8. (Optional) Enable **Force UDP encapsulation** to force the tunnel to use UDP encapsulation even when it does not detect that NAT is being used.
9. For **Zone**, select the firewall zone for the IPsec tunnel. Generally this should be left at the default of **IPsec**.

Note Depending on your network configuration, you may need to add a packet filtering rule to allow incoming traffic. For example, for the **IPsec** zone:

a. Click to expand **Firewall > Packet filtering**.
b. For **Add packet filter**, click **+**.
c. For **Label**, type **Allow incoming IPsec traffic**.
d. For **Source zone**, select **IPsec**.

Leave all other fields at their default settings.




10. For **Metric**, enter or select the priority of routes associated with this IPsec tunnel. When more than one active route matches a destination, the route with the lowest metric is used.
11. For **Mode**, select **Tunnel mode**. **Transport mode** is not currently supported.
12. Select the Mode, either:
    - **Tunnel mode**: the entire IP packet is encrypted and/or authenticated and then encapsulated as the payload in a new IP packet.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **Transport mode**: Only the payload of the IP packet is encrypted and/or authenticated. The IP header is unencrypted.

13. Select the **Protocol**, either:
    - **ESP** (Encapsulating Security Payload): Provides encryption as well as authentication and integrity.
    - **AH** (Authentication Header): Provides authentication and integrity only.
14. **Strict routing** is disabled by default. Toggle on to enable.
    Strict routing makes IPsec behave like a policy-based VPN, rather than a route-based VPN.
15. Click to expand **Authentication**.



a. For **Authentication type**, select one of the following:
    - **Pre-shared key**: Uses a pre-shared key (PSK) to authenticate with the remote peer.
        i. Type the **Pre-shared key**.
    - **Asymmetric pre-shared keys**: Uses asymmetric pre-shared keys to authenticate with the remote peer.
        i. For **Local key**, type the local pre-shared key. This must be the same as the remote key on the remote host.
        ii. For **Remote key**, type the remote pre-shared key. This must be the same as the local key on the remote host.
    - **RSA signature**: Uses a private RSA key to authenticate with the remote peer.
        i. For **Private key**, paste the device's private RSA key in PEM format.
        ii. Type the **Private key passphrase** that is used to decrypt the private key. Leave blank if the private key is not encrypted.
        iii. For **Peer public key**, paste the peer's public RSA key in PEM format.
    - **SCEP certificates**: Uses Simple Certificate Enrollment Protocol (SCEP) to download a private key, certificates, and an optional Certificate Revocation List (CRL) to the Connect EZ 4 WS device from a SCEP server.
      You must create the SCEP client prior to configuring the IPsec tunnel. See Configure a Simple Certificate Enrollment Protocol client for instructions.
        i. For **SCEP Client**, select the SCEP client.
    - **X.509 certificate**: Uses private key and X.509 certificates to authenticate with the remote peer.
        i. For **Private key**, paste the device's private RSA key in PEM format.
        ii. Type the **Private key passphrase** that is used to decrypt the private key. Leave blank if the private key is not encrypted.
        iii. For **Certificate**, paste the local X.509 certificate in PEM format.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iv. For Peer verification, select either:

- **Peer certificate**: For **Peer certificate**, paste the peer's X.509 certificate in PEM format.
- **Certificate Authority**: For **Certificate Authority chain**, paste the Certificate Authority (CA) certificates. These must include all peer certificates in the chain up to the root CA certificate, in PEM format.

16. (Optional) For **Management Priority**, set the management priority for this IPsec tunnel. A tunnel that is up and has the highest priority will be used for central management and direct device access.
17. (Optional) To configure the device to connect to its remote peer as an XAUTH client:
    a. Click to expand **XAUTH client**.

    b. Click **Enable**.
    c. Type the **Username** and **Password** that the device will use to authenticate as an XAUTH client with the peer.
18. (Optional) Click **Enable MODECFG client** to receive configuration information, such as the private IP address, from the remote peer.
19. Click to expand **Local endpoint**.
    a. For **Type**, select either:
        - **Default route**: Uses the same network interface as the default route.
        - **Interface**: Select the **Interface** to be used as the local endpoint.
    b. Click to expand **ID**.
        i. Select the ID type:
            - **Auto**: The ID will be automatically determined from the value of the tunnel's endpoints.
            - **Raw**: Enter an ID and have it passed unmodified to the underlying IPsec stack.

              For **Raw ID value**, type the ID that will be passed.
            - **Any**: Any ID will be accepted.
            - **IPv4**: The ID will be interpreted as an IP address and sent as an ID_IPV4_ADDR IKE identity.

              For **IPv4 ID value**, type an IPv4 formatted ID. This can be a fully-qualified domain name or an IPv4 address.
            - **IPv6**: The ID will be interpreted as an IP address and sent as an ID_IPV6_ADDR IKE identity.

              For **IPv6 ID value**, type an IPv6 formatted ID. This can be a fully-qualified domain name or an IPv6 address.
            - **RFC822 Email**: The ID will be interpreted as an RFC822 (email address).

              For **RFC822 ID value**, type the ID in internet email address format.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **FQDN**: The ID will be interpreted as FQDN (Fully Qualified Domain Name) and sent as an ID_FQDN IKE identity.

  For **FQDN ID value**, type the ID as an FQDN.
- **KeyID**: The ID will be interpreted as a Key ID and sent as an ID_KEY_ID IKE identity.

  For **KeyID ID value**, type the key ID.
- **MAC address**: The device's primary MAC address will be used as the ID and sent as a ID_KEY_ID IKE identity.
- **Serial number**: The device's serial number will be used as the ID and sent as a ID_KEY_ID IKE identity.

20. Click to expand **Remote endpoint**.
    a. For **IP version**, select either **IPv4** or **IPv6**.
    b. For **Hostname list selection**, select one of the following:
       - **Round robin**: Attempts to connect to hostnames sequentially based on the list order.
       - **Random**: Randomly selects an IPsec peer to connect to from the hostname list.
       - **Priority ordered**: Selects the first hostname in the list that is resolvable.
    c. Click to expand **Hostname**.
       i. Click **+** next to **Add Hostname**.
       ii. For Hostname, type a hostname or IPv4 address. If your device is not configured to initiate the IPsec connection (see **IKE > Initiate connection**), you can also use the keyword **any**, which means that the hostname is dynamic or unknown.
       iii. Click **+** again to add additional hostnames.
    d. Click to expand **ID**.
       i. Select the ID type.
          - **Auto**: The ID will be automatically determined from the value of the tunnels endpoints.
          - **None**: Enter an ID and have it passed unmodified to the underlying IPsec stack.

            For **None ID value**, type the ID that will be passed.
          - **Any**: Any ID will be accepted.
          - **IPv4**: The ID will be interpreted as an IPv4 address and sent as an ID_IPV4_ADDR IKE identity.

            For **IPv4 ID value**, type an IPv4 formatted ID. This can be a fully-qualified domain name or an IPv4 address.
          - **IPv6**: The ID will be interpreted as an IPv6 address and sent as an ID_IPV6_ADDR IKE identity.

            For **IPv6 ID value**, type an IPv6 formatted ID. This can be a fully-qualified domain name or an IPv6 address.
          - **RFC822 Email**: The ID will be interpreted as an RFC822 (email address).

            For **RFC822 ID value**, type the ID in internet email address format.
          - **FQDN**: The ID will be interpreted as FQDN (Fully Qualified Domain Name) and sent as an ID_FQDN IKE identity.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

For **FQDN ID value**, type the ID as an FQDN.

- **KeyID**: The ID will be interpreted as a Key ID and sent as an ID_KEY_ID IKE identity.

  For **KeyID ID value**, type the key ID.
- **MAC address**: The device's primary MAC address will be used as the ID and sent as a ID_KEY_ID IKE identity.
- **Serial number**: The device's serial number will be used as the ID and sent as a ID_KEY_ID IKE identity.


21. Click to expand **Policies**.

Policies define the network traffic that will be encapsulated by this tunnel.

a. Click **+** to create a new policy.

The new policy configuration is displayed.

b. Click to expand **Local traffic selector**.



c. For **Type**, select one of the following:

- **Address**: The address of a local network interface.

  For **Address**, select the appropriate interface.
- **Network**: The subnet of a local network interface.

  For **Address**, select the appropriate interface.
- **Custom network**: A user-defined network.

  For **Custom network**, enter the IPv4 address and optional netmask.
- **Request a network**: Requests a network from the remote peer.
- **Dynamic**: Uses the address of the local endpoint.

d. For **Protocol**, select one of the following:

- **Any**: Matches any protocol.
- **ICI**: Matches ICI protocol only.
- **UDP**: Matches UDP protocol only.
- **ICMP**: Matches ICMP requests only.
- **Other protocol**: Matches an unlisted protocol.

  If **Other protocol** is selected, type the number of the protocol.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

e. For **Port**, type the port matching criteria.
Allowed values are a port number, a range of port numbers, or **any**.

f. (Optional) Click to expand **Remote traffic selector**.

g. For **Remote network**, enter the IP address and optional netmask of the remote network.

h. For **Protocol**, select one of the following:
- **Any**: Matches any protocol.
- **ICI**: Matches ICI protocol only.
- **UDP**: Matches UDP protocol only.
- **ICMP**: Matches ICMP requests only.
- **Other protocol**: Matches an unlisted protocol.
If **Other protocol** is selected, type the number of the protocol.

i. For **Port**, type the port matching criteria.
Allowed values are a port number, a range of port numbers, or **any**.

22. Click to expand **IKE**.



a. For **IKE version**, select either IKEv1 or IKEv2. This setting must match the peer's IKE version.

b. **Initiate connection** instructs the device to initiate the key exchange, rather than waiting for an incoming request. This must be disabled if **Remote endpoint** > Hostname is set to **any**.

c. For **Mode**, select either **Main mode** or **Aggressive mode**.

d. For **IKE fragmentation**, select one of the following:
- **If supported by the peer**: Send oversized IKE messages in fragments, if the peer supports receiving them.
- **Always**: Always send IKEv1 messages in fragments. For IKEv2, this option is equivalent to **If supported by the peer**.
- **Never**: Do not send oversized IKE messages in fragments.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **Accept**. Do not send oversized IKE messages in fragments, but announce support for fragmentation to the peer.

The default is **Always**.

e. For **Enable padding**, click to disable the padding of IKE packets. This should normally not be disabled except for compatibility purposes.

f. For **Phase 1 lifetime**, enter the amount of time that the IKE security association expires after a successful negotiation and must be re-authenticated.

Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

For example, to set **Phase 1 lifetime** to ten minutes, enter **10m** or **600s**.

g. For **Phase 2 lifetime**, enter the amount of time that the IKE security association expires after a successful negotiation and must be rekeyed.

Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

For example, to set **Phase 2 lifetime** to ten minutes, enter **10m** or **600s**.

h. For **Lifetime margin**, enter a randomizing amount of time before the IPsec tunnel is renegotiated.

Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

For example, to set **Lifetime margin** to ten minutes, enter **10m** or **600s**.

i. Click to expand **Phase 1 Proposals**.

i. Click **+** to create a new phase 1 proposal.

ii. For **Cipher**, select the type of encryption.

iii. For **Hash**, select the type of hash to use to verify communication integrity.

iv. For **Diffie-Hellman group**, select the type of Diffie-Hellman group to use for key exchange.

v. You can add additional Phase 1 proposals by clicking **+** next to **Add Phase 1 Proposal**.

j. Click to expand **Phase 2 Proposals**.

i. Click **+** to create a new phase 2 proposal.

ii. For **Cipher**, select the type of encryption.

iii. For **Hash**, select the type of hash to use to verify communication integrity.

iv. For **Diffie-Hellman group**, select the type of Diffie-Hellman group to use for key exchange.

v. You can add additional Phase 2 proposals by clicking **+** next to **Add Phase 2 Proposal**.

23. (Optional) Click to expand **Dead peer detection**. Dead peer detection is enabled by default. Dead peer detection uses periodic IKE transmissions to the remote endpoint to detect whether tunnel communications have failed, allowing the tunnel to be automatically restarted when failure occurs.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. To enable or disable dead peer detection, click **Enable**.

b. For **Delay**, type the number of seconds between transmissions of dead peer packets. Dead peer packets are only sent when the tunnel is idle.

c. For **Timeout**, type the number of seconds to wait for a response from a dead peer packet before assuming the tunnel has failed.

24. (Optional) Click to expand **NAT** to create a list of destination networks that require source NAT.

a. Click **+** next to **Add NAT destination**.

b. For **Destination network**, type the IPv4 address and optional netmask of a destination network that requires source NAT. You can also use **any**, meaning that any destination network connected to the tunnel will use source NAT.

25. (Optional) Click **Advanced** to set various IPsec-related timeout, keep alive, and retries values.

26. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add an IPsec tunnel. For example, to add an IPsec tunnel named **ipsec_example**:

```
(config)> add vpn ipsec tunnel ipsec_example
(config vpn ipsec tunnel ipsec_example)>
```

   The IPsec tunnel is enabled by default. To disable:

```
(config vpn ipsec tunnel ipsec_example)> enable false
(config vpn ipsec tunnel ipsec_example)>
```

4. (Optional) Set the tunnel to use UDP encapsulation even when it does not detect that NAT is being used:

```
(config vpn ipsec tunnel ipsec_example)> force_udp_encap true
(config vpn ipsec tunnel ipsec_example)>
```

5. Set the firewall zone for the IPsec tunnel. Generally this should be left at the default of **ipsec**.

```
(config vpn ipsec tunnel ipsec_example)> zone zone
(config vpn ipsec tunnel ipsec_example)>
```

   To view a list of available zones:

```
(config vpn ipsec tunnel ipsec_example)> zone ?

Zone: The firewall zone assigned to this IPsec tunnel. This can be used
by packet filtering rules
and access control lists to restrict network traffic on this tunnel.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup
Default value: ipsec
Current value: ipsec

(config vpn ipsec tunnel ipsec_example)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note Depending on your network configuration, you may need to add a packet filtering rule to allow incoming traffic. For example, for the IPsec zone:

a. Type .. to move to the root of the configuration:

```
(config vpn ipsec tunnel ipsec_example)> ...
(config)>
```

b. Add a packet filter:

```
(config)> add firewall filter end
(config firewall filter 2)>
```

c. Set the label to **Allow incoming IPsec traffic**:

```
(config config firewall filter 2)> label "Allow incoming IPsec
traffic"
(config firewall filter 2)>
```

d. Set the source zone to **ipsec**:

```
(config config firewall filter 2)> src_zone ipsec
(config firewall filter 2)>
```

6. Set the metric for the IPsec tunnel. When more than one active route matches a destination, the route with the lowest metric is used.

```
(config vpn ipsec tunnel ipsec_example)> metric value
(config vpn ipsec tunnel ipsec_example)>
```

where *value* is any integer between **0** and **65535**.

7. Set the mode:

```
(config vpn ipsec tunnel ipsec_example)> mode mode
(config vpn ipsec tunnel ipsec_example)>
```

where *mode* is either:

- **tunnel**: The entire IP packet is encrypted and/or authenticated and then encapsulated as the payload in a new IP packet.
- **transport**: Only the payload of the IP packet is encrypted and/or authenticated. The IP header is unencrypted.

The default is **tunnel**.

8. Set the protocol:

```
(config vpn ipsec tunnel ipsec_example)> type protocol
(config vpn ipsec tunnel ipsec_example)>
```

where *protocol* is either:

- **esp** (Encapsulating Security Payload): Provides encryption as well as authentication and integrity.
- **ah** (Authentication Header): Provides authentication and integrity only.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The default is **esp**.

9. (Optional) Set the management priority for this IPsec tunnel.

```
(config vpn ipsec tunnel ipsec_example)> mgmt value
(config vpn ipsec tunnel ipsec_example)>
```

where **value** is any integer between 0 and 9999.

10. Set the authentication type.

```
(config vpn ipsec tunnel ipsec_example)> auth type value
(config vpn ipsec tunnel ipsec_example)>
```

where **value** is one of:

- **secret**: Uses a pre-shared key (PSK) to authenticate with the remote peer.
  a. Set the pre-shared key.

```
(config vpn ipsec tunnel ipsec_example)> auth secret key
(config vpn ipsec tunnel ipsec_example)>
```

- **asymmetric-secrets**: Uses asymmetric pre-shared keys to authenticate with the remote peer.
  a. Set the local pre-shared key. This must be the same as the remote key on the remote host.

```
(config vpn ipsec tunnel ipsec_example)> auth local_secret key
(config vpn ipsec tunnel ipsec_example)>
```

  b. Set the remote pre-shared key. This must be the same as the local key on the remote host.

```
(config vpn ipsec tunnel ipsec_example)> auth remote_secret key
(config vpn ipsec tunnel ipsec_example)>
```

- **rsasig**: Uses a private RSA key to authenticate with the remote peer.
  a. For the **private key** parameter, paste the device's private RSA key in PEM format.

```
(config vpn ipsec tunnel ipsec_example)> auth private_key key
(config vpn ipsec tunnel ipsec_example)>
```

  b. Set the private key passphrase that is used to decrypt the private key. Leave blank if the private key is not encrypted.

```
(config vpn ipsec tunnel ipsec_example)> auth private_key_
passphrase passphrase
(config vpn ipsec tunnel ipsec_example)>
```

  c. For the **peer public key** parameter, paste the peer's public RSA key in PEM format.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config vpn ipsec tunnel ipsec_example)> auth peer_public_key
key
(config vpn ipsec tunnel ipsec_example)>
```

- **x509**: Uses private key and X.509 certificates to authenticate with the remote peer.
  a. For the **private key** parameter, paste the device's private RSA key in PEM format.

```
(config vpn ipsec tunnel ipsec_example)> auth private_key key
(config vpn ipsec tunnel ipsec_example)>
```

  b. Set the private key passphrase that is used to decrypt the private key. Leave blank if the private key is not encrypted.

```
(config vpn ipsec tunnel ipsec_example)> auth private_key_
passphrase passphrase
(config vpn ipsec tunnel ipsec_example)>
```

  c. For the **cert** parameter, paste the local X.509 certificate in PEM format.

```
(config vpn ipsec tunnel ipsec_example)> auth cert certificate
(config vpn ipsec tunnel ipsec_example)>
```

  d. Set the method for verifying the peer's X.509 certificate.

```
(config vpn ipsec tunnel ipsec_example)> auth peer_verify value
(config vpn ipsec tunnel ipsec_example)>
```

  Where **value** is either:

  - **cert**: Uses the peer's X.509 certificate in PEM format for verification.
    - For the **peer cert** parameter, paste the peer's X.509 certificate in PEM format.

```
(config vpn ipsec tunnel ipsec_example)> auth peer_cert
certificate
(config vpn ipsec tunnel ipsec_example)>
```

  - **ca**: Uses the Certificate Authority chain for verification.
    - For the **ca cert** parameter, paste the Certificate Authority (CA) certificates. These must include all peer certificates in the chain up to the root CA certificate, in PEM format.

```
(config vpn ipsec tunnel ipsec_example)> auth ca_cert cert_
chain
(config vpn ipsec tunnel ipsec_example)>
```

11. (Optional) Configure the device to connect to the remote peer as an XAUTH client:
  a. Enable XAUTH client functionality.

```
(config vpn ipsec tunnel ipsec_example)> xauth_client enable true
(config vpn ipsec tunnel ipsec_example)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Set the XAUTH client username:

```
(config vpn ipsec tunnel ipsec_example)> auth_client username user
(config vpn ipsec tunnel ipsec_example)>
```

c. Set the XAUTH client password:

```
(config vpn ipsec tunnel ipsec_example)> auth_client password pwd
(config vpn ipsec tunnel ipsec_example)>
```

12. (Optional) Enable MODECFG client functionality:

MODECFG client functionality configures the device to receive configuration information, such as the private IP address, from the remote peer.

a. Enable MODECFG client functionality:

```
(config vpn ipsec tunnel ipsec_example)> modecfg_client enable true
(config vpn ipsec tunnel ipsec_example)>
```

13. Configure the local endpoint:

a. Set the method for determining the local network interface:

```
(config vpn ipsec tunnel ipsec_example)> local type value
(config vpn ipsec tunnel ipsec_example)>
```

where **value** is either:

- **defaultroute**: Uses the same network interface as the default route.
- **interface**: Select the **interface** to be used as the local endpoint.

b. Set the ID type:

```
(config vpn ipsec tunnel ipsec_example)> local id type value
(config vpn ipsec tunnel ipsec_example)>
```

where **value** is one of:

- **auto**: The ID will be automatically determined from the value of the tunnels endpoints.
- **raw**: Enter an ID and have it passed unmodified to the underlying IPsec stack.

  Set the unmodified ID that will be passed:

  ```
  (config vpn ipsec tunnel ipsec_example)> local id type raw_id id
  (config vpn ipsec tunnel ipsec_example)>
  ```

- **any**: Any ID will be accepted.
- **ipv4**: The ID will be interpreted as an IPv4 address and sent as an ID_IPV4_ADDR IKE identity.

  Set an IPv4 formatted ID. This can be a fully-qualified domain name or an IPv4 address.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config vpn ipsec tunnel ipsec_example)> local id type ipv4_id
id
(config vpn ipsec tunnel ipsec_example)>
```

- **ipv6**: The ID will be interpreted as an IPV6 address and sent as an ID_IPV6_ADDR IKE identity.
  Set an IPV6 formatted ID. This can be a fully-qualified domain name or an IPV6 address.

```
(config vpn ipsec tunnel ipsec_example)> local id type ipv6_id
id
(config vpn ipsec tunnel ipsec_example)>
```

- **rfc822**: The ID will be interpreted as an RFC822 (email address).
  Set the ID in internet email address format.

```
(config vpn ipsec tunnel ipsec_example)> local id type rfc822_id
id
(config vpn ipsec tunnel ipsec_example)>
```

- **fqdn**: The ID will be interpreted as FQDN (Fully Qualified Domain Name) and sent as an ID_FQDN IKE identity.
- **keyid**: The ID will be interpreted as a Key ID and sent as an ID_KEY_ID IKE identity.
  Set the key ID.

```
(config vpn ipsec tunnel ipsec_example)> local id type keyid_id
id
(config vpn ipsec tunnel ipsec_example)>
```

- **mac address**: The device's MAC address will be used for the Key ID and sent as an ID_KEY_ID IKE identity.
- **serial number**: The ID device's serial number will be used for the Key ID and sent as an ID_KEY_ID IKE identity.

14. Configure the remote endpoint:
    a. Add a remote hostname.

```
(config vpn ipsec tunnel ipsec_example)> add remote hostname end value
(config vpn ipsec tunnel ipsec_example)>
```

    where **value** is the hostname or IPV4 address of the IPsec peer. If your device is not configured to initiate the IPsec connection (see the example), you can also use the keyword **any**, which means that the hostname is dynamic or unknown.
    Repeat for additional hostnames.
    b. Set the hostname selection type:

```
(config vpn ipsec tunnel ipsec_example)> remote hostname_selection
value
(config vpn ipsec tunnel ipsec_example)>
```

    where **value** is one of:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **round robin**: Attempts to connect to hostnames sequentially based on the list order.
- **random**: Randomly selects an IPsec peer to connect to from the hostname list.
- **priority**: Selects the first hostname in the list that is resolvable.

c. Set the ID type.

```
(config vpn ipsec tunnel ipsec_example)> remote id type value
(config vpn ipsec tunnel ipsec_example)>
```

where value is one of:

- **auto**: The ID will be automatically determined from the value of the tunnels endpoints.
- **raw**: Enter an ID and have it passed unmodified to the underlying IPsec stack.
  Set the unmodified ID that will be passed:

  ```
  (config vpn ipsec tunnel ipsec_example)> remote id type raw_id
  id
  (config vpn ipsec tunnel ipsec_example)>
  ```

- **any**: Any ID will be accepted.
- **ipv4**: The ID will be interpreted as an IPv4 address and sent as an ID_IPV4_ADDR IKE identity.
  Set an IPv4 formatted ID. This can be a fully-qualified domain name or an IPv4 address.

  ```
  (config vpn ipsec tunnel ipsec_example)> remote id type ipv4_id
  id
  (config vpn ipsec tunnel ipsec_example)>
  ```

- **ipv6**: The ID will be interpreted as an IPv6 address and sent as an ID_IPV6_ADDR IKE identity.
  Set an IPv6 formatted ID. This can be a fully-qualified domain name or an IPv6 address.

  ```
  (config vpn ipsec tunnel ipsec_example)> remote id type ipv6_id
  id
  (config vpn ipsec tunnel ipsec_example)>
  ```

- **rfc822**: The ID will be interpreted as an RFC822 (email address).
  Set the ID in Internet email address format.

  ```
  (config vpn ipsec tunnel ipsec_example)> remote id type rfc822_
  id id
  (config vpn ipsec tunnel ipsec_example)>
  ```

- **fqdn**: The ID will be interpreted as FQDN (Fully Qualified Domain Name) and sent as an ID_FQDN IKE identity.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **keyid**: The ID will be interpreted as a Key ID and sent as an ID_KEY_ID IKE identity. Set the key ID.

```
(config vpn ipsec tunnel ipsec_example)> remote id type keyid_id
id
(config vpn ipsec tunnel ipsec_example)>
```

- **mac address**: The device's MAC address will be used for the Key ID and sent as an ID_KEY_ID IKE identity.
- **serial number**: The ID device's serial number will be used for the Key ID and sent as an ID_KEY_ID IKE identity.

f. Configure IKE settings:

a. Set the IKE version:

```
(config vpn ipsec tunnel ipsec_example)> ike version value
(config vpn ipsec tunnel ipsec_example)>
```

where *value* is either **ikev1** or **ikev2**. This setting must match the peer's IKE version.

b. Determine whether the device should initiate the key exchange, rather than waiting for an incoming request. By default, the device will initiate the key exchange. This must be disabled if remote hostname is set to **any**. To disable:

```
(config vpn ipsec tunnel ipsec_example)> ike initiate false
(config vpn ipsec tunnel ipsec_example)>
```

c. Set the IKE phase 1 mode:

```
(config vpn ipsec tunnel ipsec_example)> ike mode value
(config vpn ipsec tunnel ipsec_example)>
```

where *value* is either **aggressive** or **main**.

d. Set the IKE fragmentation:

```
(config vpn ipsec tunnel ipsec_example)> ike fragmentation value
(config vpn ipsec tunnel ipsec_example)>
```

where *value* is one of:

- **# supported**: Send oversized IKE messages in fragments, if the peer supports receiving them.
- **always**: Always send IKEv1 messages in fragments. For IKEv2, this option is equivalent to **# supported**.
- **never**: Do not send oversized IKE messages in fragments.
- **accept**: Do not send oversized IKE messages in fragments, but announce support for fragmentation to the peer.

The default is **always**.

e. Padding of IKE packets is enabled by default and should normally not be disabled except for compatibility purposes. To disable:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config vpn ipsec tunnel ipsec_example)> ike pad false
(config vpn ipsec tunnel ipsec_example)>
```

i. Set the amount of time that the IKE security association expires after a successful negotiation and must be re-authenticated:

```
(config vpn ipsec tunnel ipsec_example)> ike phase1_lifetime value
(config vpn ipsec tunnel ipsec_example)>
```

where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number[w|d|h|m|s]**.

For example, to set **phase1 lifetime** to ten minutes, enter either **10m** or **600s**:

```
(config vpn ipsec tunnel ipsec_example)> ike phase1_lifetime 600s
(config vpn ipsec tunnel ipsec_example)>
```

The default is three hours.

ii. Set the amount of time that the IKE security association expires after a successful negotiation and must be rekeyed:

```
(config vpn ipsec tunnel ipsec_example)> ike phase2_lifetime value
(config vpn ipsec tunnel ipsec_example)>
```

where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number[w|d|h|m|s]**.

For example, to set **phase2 lifetime** to ten minutes, enter either **10m** or **600s**:

```
(config vpn ipsec tunnel ipsec_example)> ike phase2_lifetime 600s
(config vpn ipsec tunnel ipsec_example)>
```

The default is one hour.

iii. Set a randomizing amount of time before the IPsec tunnel is renegotiated:

```
(config vpn ipsec tunnel ipsec_example)> ike lifetime_margin value
(config vpn ipsec tunnel ipsec_example)>
```

where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number[w|d|h|m|s]**.

For example, to set **lifetime margin** to ten minutes, enter either **10m** or **600s**:

```
(config vpn ipsec tunnel ipsec_example)> ike lifetime_margin 600s
(config vpn ipsec tunnel ipsec_example)>
```

The default is nine minutes.

i. Configure the types of encryption, hash, and Diffie-Hellman group to use during phase 1:

i. Add a phase 1 proposal:

```
(config vpn ipsec tunnel ipsec_example)> add ike phase1_proposal
end
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 2)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iii. Set the type of encryption to use during phase 1.

```
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
cipher value
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
```

where value is one of:

- 3des
- aes128
- aes128gcm128
- aes128gcm64
- aes128gcm96
- aes192
- aes192gcm128
- aes192gcm64
- aes192gcm96
- aes256
- aes256gcm128
- aes256gcm64
- aes256gcm96
- null

The default is 3des.

iv. Set the type of hash to use during phase 1 to verify communication integrity.

```
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
hash value
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
```

where value is one of:

- md5
- sha1
- sha256
- sha384
- sha512

The default is sha1.

v. Set the type of Diffie-Hellman group to use for key exchange during phase 1.

i. Use the ? to determine available Diffie-Hellman group types.

```
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
dh_group ?
curve25519
curve448
ecp192
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
ecp224
...
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
```

ii. Set the Diffie-Hellman group type:

```
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
dh_group value
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
```

The default is modp2048.

v. (Optional) Add additional phase 1 proposals:

i. Move back one level in the schema:

```
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)>
..
(config vpn ipsec tunnel ipsec_example ike phase1_proposal)>
```

ii. Add an additional proposal:

```
(config vpn ipsec tunnel ipsec_example ike phase1_proposal)>
add end
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 1)>
```

Repeat the above steps to set the type of encryption, hash, and Diffie-Hellman group for the additional proposal.

iii. Repeat to add more phase 1 proposals.

j. Configure the types of encryption, hash, and Diffie-Hellman group to use during phase 2:

i. Move back two levels in the schema:

```
(config vpn ipsec tunnel ipsec_example ike phase1_proposal 0)> ...
..
(config vpn ipsec tunnel ipsec_example ike)>
```

ii. Add a phase 2 proposal:

```
(config vpn ipsec tunnel ipsec_example ike)> add ike phase2_
proposal end
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
```

iii. Set the type of encryption to use during phase 2:

```
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
cipher value
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
```

where value is one of:

- 3des
- aes128
- aes128gcm128

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- aes128gcm64
- aes128gcm96
- aes192
- aes192gcm128
- aes192gcm64
- aes192gcm96
- aes256
- aes256gcm128
- aes256gcm64
- aes256gcm96
- null

The default is 3des.

iv. Set the type of hash to use during phase 2 to verify communication integrity:

```
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
hash value
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
```

where value is one of:

- md5
- sha1
- sha256
- sha384
- sha512

The default is sha1.

v. Set the type of Diffie-Hellman group to use for key exchange during phase 2:

i. Use the ? to determine available Diffie-Hellman group types:

```
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
dh_group ?
curve25519
curve448
ecp192
ecp224
...
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
```

ii. Set the Diffie-Hellman group type:

```
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
dh_group value
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
```

The default is modp2048.

vi. (Optional) Add additional phase 2 proposals:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

i. Move back one level in the schema:

```
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)>
...
(config vpn ipsec tunnel ipsec_example ike phase2_proposal)>
```

ii. Add an additional proposal:

```
(config vpn ipsec tunnel ipsec_example ike phase2_proposal)>
add end
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 1)>
```

Repeat the above steps to set the type of encryption, hash, and Diffie-Hellman group for the additional proposal.

iii. Repeat to add more phase 2 proposals.

h. (Optional) Configure dead peer detection:

Dead peer detection is enabled by default. Dead peer detection uses periodic IKE transmissions to the remote endpoint to detect whether tunnel communications have failed, allowing the tunnel to be automatically restarted when failure occurs.

a. Change to the root of the configuration schema:

```
(config vpn ipsec tunnel ipsec_example ike phase2_proposal 0)> ...
(config)>
```

b. To disable dead peer detection:

```
(config)> vpn ipsec tunnel ipsec_example dpd enable false
(config)>
```

c. Set the number of seconds between transmissions of dead peer packets. Dead peer packets are only sent when the tunnel is idle. The default is **60**.

```
(config)> vpn ipsec tunnel ipsec_example dpd delay value
(config)>
```

d. Set the number of seconds to wait for a response from a dead peer packet before assuming the tunnel has failed. The default is **30**.

```
(config)> vpn ipsec tunnel ipsec_example dpd timeout value
(config)>
```

i. (Optional) Create a list of destination networks that require source NAT:

a. Add a destination network:

```
(config)> add vpn ipsec tunnel ipsec_example nat end
(config vpn ipsec tunnel ipsec_example nat 0)>
```

b. Set the IPv4 address and optional netmask of a destination network that requires source NAT. You can also use **any**, meaning that any destination network connected to the tunnel will use source NAT.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config vpn ipsec tunnel ipsec_example nat 0)> dst value
(config vpn ipsec tunnel ipsec_example nat 0)>
```

18. Configure policies that define the network traffic that will be encapsulated by this tunnel.
    a. Change to the root of the configuration schema.

```
(config vpn ipsec tunnel ipsec_example nat 0)> ...
(config)>
```

    b. Add a policy.

```
(config)> add vpn ipsec tunnel ipsec_example policy end
(config vpn ipsec tunnel ipsec_example policy 0)>
```

    c. Set the type of local traffic selector.

```
(config vpn ipsec tunnel ipsec_example policy 0)> local type value
(config vpn ipsec tunnel ipsec_example policy 0)>
```

    where value is one of:

    - **address**: The address of a local network interface.

      Set the address:

      i. Use the ?to determine available interfaces.

      ii. Set the interface. For example:

```
(config vpn ipsec tunnel ipsec_example policy 0)> local
address eth1
(config vpn ipsec tunnel ipsec_example policy 0)>
```

    - **network**: The subnet of a local network interface.

      Set the network:

      i. Use the ?to determine available interfaces.

      ii. Set the interface. For example:

```
(config vpn ipsec tunnel ipsec_example policy 0)> local
network eth1
(config vpn ipsec tunnel ipsec_example policy 0)>
```

    - **custom**: A user-defined network.

      Set the custom network:

```
(config vpn ipsec tunnel ipsec_example policy 0)> local custom
value
(config vpn ipsec tunnel ipsec_example policy 0)>
```

      where value is the IPv4 address and optional netmask. The keyword any can also be used.

    - **request**: Request a network from the remote peer.
    - **dynamic**: Uses the address of the local endpoint.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

e. Set the port matching criteria for the local traffic selector:

```
(config vpn ipsec tunnel ipsec_example policy 6)> local port value
(config vpn ipsec tunnel ipsec_example policy 6)>
```

where value is the port number, a range of port numbers, or the keyword **any**.

f. Set the protocol matching criteria for the local traffic selector:

```
(config vpn ipsec tunnel ipsec_example policy 6)> local protocol value
(config vpn ipsec tunnel ipsec_example policy 6)>
```

where value is one of:

- **any**: Matches any protocol.
- **tcp**: Matches TCP protocol only.
- **udp**: Matches UDP protocol only.
- **icmp**: Matches ICMP requests only.
- **other**: Matches an unlisted protocol.

  If **other** is used, set the number of the protocol:

  ```
  (config vpn ipsec tunnel ipsec_example policy 6)> local
  protocol_other int
  (config vpn ipsec tunnel ipsec_example policy 6)>
  ```

  Allowed values are an integer between 1 and **255**.

i. Set the IP address and optional netmask of the remote traffic selector:

```
(config vpn ipsec tunnel ipsec_example policy 6)> remote network value
(config vpn ipsec tunnel ipsec_example policy 6)>
```

g. Set the port matching criteria for the remote traffic selector:

```
(config vpn ipsec tunnel ipsec_example policy 6)> remote port value
(config vpn ipsec tunnel ipsec_example policy 6)>
```

where value is the port number, a range of port numbers, or the keyword **any**.

h. Set the protocol matching criteria for the remote traffic selector:

```
(config vpn ipsec tunnel ipsec_example policy 6)> remote protocol
value
(config vpn ipsec tunnel ipsec_example policy 6)>
```

where value is one of:

- **any**: Matches any protocol.
- **tcp**: Matches TCP protocol only.
- **udp**: Matches UDP protocol only.
- **icmp**: Matches ICMP requests only.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **other**: Matches an unlisted protocol.

  If **other** is used, set the number of the protocol:

```
(config vpn ipsec tunnel ipsec_example policy 0)> remote
protocol_other 1xx
(config vpn ipsec tunnel ipsec_example policy 0)>
```

  Allowed values are an integer between 1 and 255.

iii. (Optional) You can also configure various IPsec related time out, keep alive, and retries values.

a. Change to the root of the configuration schema:

```
(config vpn ipsec tunnel ipsec_example policy 0)> ...
(config)>
```

b. Use the ? to determine available options:

```
(config)> vpn ipsec advanced ?

Advanced: Advanced configuration that applies to all IPsec tunnels.

Parameters                  Current Value
-------------------------------------------------------------------------------
debug                       none            Debug level
ike_fragment_size           1288            Maximum IKE fragment size
ike_retransmit_tries        5               IKE retransmit tries
keep_alive                  40s             NAT keep alive time

Additional Configuration
-------------------------------------------------------------------------------
connection_retry_timeout    Connection retry timeout
connection_try_interval     Connection try interval
ike_timeout                 IKE timeout

(config)>
```

Generally, the default settings for these should be sufficient.

c. You can also enable debugging for IPsec:

```
(config)> vpn ipsec advanced debug value
(config)>
```

where value is one of:

- none
- basic auditing
- detailed control
- generic control

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- raw data
- sensitive data

20. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

21. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure IPsec failover

You can configure the Connect EZ 4 WS device to fail over from a primary IPsec tunnel to a backup tunnel.

- **Preferred tunnel**—When multiple IPsec tunnels are configured, one tunnel can be configured as a backup to another tunnel by defining a preferred tunnel for the backup device.

Required configuration items

- Two or more configured IPsec tunnels: the primary tunnel, and one or more backup tunnels.

IPsec failover using Preferred tunnel

Web

1. Configure the primary IPsec tunnel. See Configure an IPsec tunnel for instructions.
2. Create a backup IPsec tunnel. See Configure an IPsec tunnel for instructions.
3. During configuration of the backup IPsec tunnel, identify the primary IPsec tunnel in the **Preferred tunnel** parameter.



Command line

1. Configure the primary IPsec tunnel. See Configure an IPsec tunnel for instructions.
2. Create a backup IPsec tunnel. See Configure an IPsec tunnel for instructions.
3. During configuration of the backup IPsec tunnel, identify the primary IPsec tunnel.
   a. Use the ? to view a list of available tunnels.

```
(config vpn ipsec tunnel backup_ipsec_tunnel)> ipsec_failover ?

Preferred tunnel: This tunnel will not start until the preferred
tunnel has failed. It will continue
to operate until the preferred tunnel returns to full operation
status.
Format:
 primary_ipsec_tunnel
 backup_ipsec_tunnel
Optional: yes
Current value:

(config vpn ipsec tunnel backup_ipsec_tunnel)> ipsec_failover
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Set the primary IPsec tunnel:

```
(config vpn ipsec tunnel backup_ipsec_tunnel): ipsec_failover primary_
ipsec_tunnel
(config vpn ipsec tunnel backup_ipsec_tunnel):
```

Show IPsec status and statistics

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, select **Status** > **IPsec**.
   The **IPsec** page appears.
2. To view configuration details about an IPsec tunnel, click the (configuration) icon in the upper right of the tunnel's status pane.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. To display details about all configured IPsec tunnels, type the following at the prompt:

```
> show ipsec all

Name     Enable  Status    Hostname
-------  ------  --------  ---------------
ipsec1   true    up        192.168.2.1
vpn1     false   pending   192.168.2.1

>
```

3. To display details about a specific tunnel:

```
> show ipsec tunnel ipsec1

Tunnel                  : ipsec1
Enable                  : true
Status                  : pending
Hostname                : 192.168.2.1
Zone                    : ipsec
Mode                    : tunnel
Type                    : esp

>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

4. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Debug an IPsec configuration

If you experience issues with an IPsec tunnel not being successfully negotiated with the remote end of the tunnel, you can enable IPsec debug messages to be written to the system log. See View system and event logs for more information about viewing the system log.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN > IPsec**.
4. Click to expand **Advanced**.
5. For **Debug level**, select one of the following:
   - **Disable debug messages**.
   - **Basic auditing debug**: Logs basic auditing information, (for example, SA up/SA down).
   - **Generic control flow**: Select this for basic debugging information.
   - **Detailed control flow**: More detailed debugging control flow.
   - **Raw data**: Includes raw data dumps in hexadecimal format.
   - **Sensitive material**: Also includes sensitive material in dumps (for example, encryption keys).
6. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Set the IPsec debug value:

```
config> vpn ipsec advanced debug value
config>
```

   where **value** is one of:

   - **none**: (Default) No debug messages are written.
   - **basic auditing**: Logs basic auditing information, (for example, SA up/ SA down).
   - **generic control**: Select this for basic debugging information.
   - **detailed control**: More detailed debugging control flow.
   - **raw data**: Includes raw data dumps in hexadecimal format.
   - **sensitive data**: Also includes sensitive material in dumps (for example, encryption keys).
4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure a Simple Certificate Enrollment Protocol client

WARNING! The Simple Certificate Enrollment Protocol (SCEP) uses unencrypted HTTP communication. Please ensure you are utilizing a VPN to secure your communications.

Simple Certificate Enrollment Protocol (SCEP) is a mechanism that allows for large-scale X.509 certificate deployment. You can configure Connect EZ 4 WS device to function as a SCEP client that will connect to a SCEP server that is used to sign Certificate Signing Requests (CSRs), provide Certificate Revocation Lists (CRLs), and distribute valid certificates from a Certificate Authority (CA).

Required configuration

- Enable the SCEP client.
- The fully-qualified domain name of the SCEP server to be used for certificate requests.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- The challenge password provided by the SCEP server that the SCEP client will use when making SCEP requests.
- The distinguished name to be used for the CSR.

Additional configuration

- The number of days that the certificate enrollment can be renewed, prior to the request expiring.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **SCEP Client**.
4. For **Add clients**, enter a name for the SCEP client and click **+**.

   The new SCEP client configuration is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



5. Click **Enable** to enable the SCEP client.
6. For **Maximum Polling Time**, type the maximum time that the device will poll the SCEP server when operating in manual mode.

   Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

   For example, to set **Maximum Polling Time** to ten minutes, enter **10m** or **600s**.

   The default is **1d**.
7. For **Polling Interval**, type the amount of time that the device should wait between polling attempts, when operating in manual mode.

   Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

   For example, to set **Polling Interval** to ten minutes, enter **10m** or **600s**.

   The default is **5s**.
8. For **Key Length**, type the bit size of the private key. The default is **2048**.
9. For **Renewable Time**, type the number of days that the certificate enrollment can be renewed, prior to the request expiring. This value is configured on the SCEP server, and is used by the Connect EZ 4 WS device to determine when to start attempting to auto-renew an existing certificate. The default is **7**.
10. (Optional) Click **Debug** to enable verbose logging in */var/log/scep_client*.
11. Click to expand **SCEP server**.



12. For **FQDN**, type the fully qualified domain name or IP address of the SCEP server.
13. (Optional) For **CA identity**, type a string that will be understood by the certificate authority. For example, it could be a domain name or a user name. If the certificate authority has multiple CA certificates, this field can be used to distinguish which is required.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

14. For **Path**, type the HTTP URL path required for accessing the certificate authority. You should leave this option at the default of **/cgi-bin/pkiclient.exe** unless directed by the CA to use another path.
15. For **Password**, type the challenge password as configured on the SCEP server.
16. For **Encryption Algorithm**, select the PKCS#7 encryption algorithm. The default is **Auto**, which automatically selects the best algorithm.
17. For **Signature Algorithm**, select the PKCS#7 signature algorithm. The default is **Auto**, which automatically selects the best algorithm.
18. Click to expand **Distinguished Name**.



19. Type the value for each appropriate Distinguished Name attribute.
20. (Optional) Configure the certificate revocation list (CRL).
    a. Click to expand **CRL**.
    b. Click **Enable** to enable the CRL.
    c. For **Type**, select the type of CRL.
       - **URL**: The URL to the file name used to access the certificate revocation list from the CA.
       - **CRLDP**: The CRL distribution point.
       - **pdCRL**: A CRL query using the issuer name and serial number from the certificate whose revocation status is being queried.

       The default is **URL**.
    d. If **Type** is set to **URL**, for **URL**, type the URL to be used.
21. Configure certificate renewal.
    a. Click to expand **Renewal**.
    b. Click **Use New Private Key** to enable the creation of a new private key for renewal requests.
    c. **Use Client Certificate** is enabled by default. Click to disable the use of a client certificate for renewal requests.
22. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Virtual Private Networks (VPN) IPsec

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a new SCEP client:

```
(config)> add network scep_client scep_client_name
(config network scep_client scep_client_name
)>
```

4. Enable the SCEP client:

```
(config network scep_client scep_client_name)> enable true
(config network scep_client scep_client_name)>
```

5. Set the url parameter to the fully qualified domain name or IP address of the SCEP server:

```
(config network scep_client scep_client_name)> server url
https://scep.example.com
(config network scep_client scep_client_name)>
```

6. (Optional) Set a CA identity string that will be understood by the certificate authority. For example, it could be a domain name or a user name. If the certificate authority has multiple CA certificates, this field can be used to distinguish which is required.

```
(config network scep_client scep_client_name)> server ca_ident string
(config network scep_client scep_client_name)>
```

7. Set the HTTP URL path required for accessing the certificate authority. You should leave this option at the default of **/cgi-bin/pkiclient.exe** unless directed by the CA to use another path.

```
(config network scep_client scep_client_name)> server path path
(config network scep_client scep_client_name)>
```

8. Set the challenge password as configured on the SCEP server:

```
(config network scep_client scep_client_name)> server password challenge_
password
(config network scep_client scep_client_name)>
```

9. Set Distinguished Name attributes:

   a. Set the Domain Component:

```
(config network scep_client scep_client_name)> distinguished_name dc
value
(config network scep_client scep_client_name)>
```

   b. Set the two letter Country Code:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network scep_client scep_client_name)> distinguished_name c
value
(config network scep_client scep_client_name)>
```

c. Set the State or Province:

```
(config network scep_client scep_client_name)> distinguished_name st
value
(config network scep_client scep_client_name )>
```

d. Set the Locality:

```
(config network scep_client scep_client_name)> distinguished_name l
value
(config network scep_client scep_client_name)>
```

e. Set the Organization:

```
(config network scep_client scep_client_name)> distinguished_name o
value
(config network scep_client scep_client_name)>
```

f. Set the Organizational Unit:

```
(config network scep_client scep_client_name)> distinguished_name ou
value
(config network scep_client scep_client_name)>
```

g. Set the Common Name:

```
(config network scep_client scep_client_name)> distinguished_name cn
value
(config network scep_client scep_client_name)>
```

iii. (Optional) Configure the certificate revocation list (CRL):

a. Enable the CRL:

```
(config network scep_client scep_client_name)> crl enable true
(config network scep_client scep_client_name)>
```

b. Set the type of CRL:

```
(config network scep_client scep_client_name)> crl type value
(config network scep_client scep_client_name)>
```

where value is one of:

- **url**: the URL to the file name used to access the certificate revocation list from the CA.
- **crldp**: the CRL distribution point.
- **getCRL**: A CRL query using the issuer name and serial number from the certificate whose revocation status is being queried.

The default is url.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. If type is set to url, set the URL that should be used:

```
(config network scep_client scep_client_name)> crl_url value
(config network scep_client scep_client_name)>
```

11. Configure certificate renewal:

a. To enable the creation of a new private key for renewal requests:

```
(config network scep_client scep_client_name)> renewal new_key true
(config network scep_client scep_client_name)>
```

b. The use of a client certificate for renewal requests is enabled by default. To disable:

```
(config network scep_client scep_client_name)> renewal use_client_cert
false
(config network scep_client scep_client_name)>
```

12. Set the maximum time that the device will poll the SCEP server, when operating in manual mode:

```
(config network scep_client scep_client_name)> max_poll_time value
(config network scep_client scep_client_name)>
```

where value is any number of weeks, days, hours, minutes, or seconds, and takes the format number(w|d|h|m|s).

For example, to set max poll time to ten minutes, enter either 10m or 600s:

```
(config network scep_client scep_client_name)> max_poll_time 600s
(config network scep_client scep_client_name)>
```

The default is 1d.

13. Set the amount of time that the device should wait between polling attempts, when operating in manual mode:

```
(config network scep_client scep_client_name)> polling_interval value
(config network scep_client scep_client_name)>
```

where value is any number of weeks, days, hours, minutes, or seconds, and takes the format number(w|d|h|m|s).

For example, to set polling interval to ten minutes, enter either 10m or 600s:

```
(config network scep_client scep_client_name)> polling_interval 600s
(config network scep_client scep_client_name)>
```

The default is 5s.

14. Set the bit size of the private key:

```
(config network scep_client scep_client_name)> key_length bit
(config network scep_client scep_client_name)>
```

The default is 2048.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

15. Set the number of days that the certificate-enrollment can be renewed, prior to the request expiring. This value is configured on the SCEP server, and is used by the Connect EZ 4 WS device to determine when to start attempting to auto-renew an existing certificate. The default is 7.

```
(config network scep_client scep_client_name)> renewable_time integer
(config network scep_client scep_client_name)>
```

16. (Optional) Enable verbose logging in /var/log/scep_client:

```
(config network scep_client scep_client_name)> debug true
(config network scep_client scep_client_name)>
```

17. Save the configuration and apply the change.

```
(config network scep_client scep_client_name)> save
Configuration saved.
>
```

18. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Example: SCEP client configuration with Fortinet SCEP server

In this example configuration, we will configure the Connect EZ 4 WS device as a SCEP client that will connect to a Fortinet SCEP server.

Fortinet configuration

On the Fortinet server:

1. Enable ports for SCEP services.
   a. From the menu, select **Network** > **Interfaces**.
   b. Select the appropriate port and click **Edit**.
   c. For **Access Rights** > **Services**, enable the following services:
      - **HTTPS** > **SCEP**
      - **HTTPS** > **CRL Downloads**
      - **HTTP** > **SCEP**
      - **HTTP** > **CRL Downloads**
   d. The remaining fields can be left at their defaults or changed as appropriate.
   e. Click **OK**.
2. Create a Certificate Authority (CA).
   a. From the menu, click **Certificate Authorities** > **Local CAs**.
   b. Click **Create New**.
   c. Type a **Certificate ID** for the CA, for example, **fortinet_example_ca**.
   d. Complete the **Subject Information** fields.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

e. The remaining fields can be left at their defaults or changed as appropriate.

f. Click **OK**.

3. Edit SCEP settings:

a. From the menu, click **SCEP** > **General**.

b. Click **Enable SCEP** if it is not enabled.

c. For **Default enrollment password**, enter a password. The password entered here must correspond to the challenge password configured for the SCEP client on the Connect EZ 4 WS device.

d. The remaining fields can be left at their defaults or changed as appropriate.

e. Click **OK**.

4. Create an **Enrollment Request**:

a. From the menu, click **SCEP** > **Enrollment Requests**.

b. Click **Create New**.

c. For **Automatic request type**, select **Wildcard**.

d. For **Certificate authority**, select the CA created in step 1, above.

e. Complete the **Subject Information** fields. The Distinguished Name (DN) attributes entered here must correspond to the Distinguished Name attributes configured for the SCEP client on the Connect EZ 4 WS device.

f. For **Renewal** > **Allow renewal** *x* **days before the certified is expired**, type the number of days that the certificate enrollment can be renewed, prior to the request expiring. The **Renewable for** setting on the Connect EZ 4 WS device must match the setting of this parameter.

g. The remaining fields can be left at their defaults or changed as appropriate.

h. Click **OK**.

Connect EZ 4 WS configuration

On the Connect EZ 4 WS device:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.

2. Access the device configuration:

Remote Manager:

a. Locate your device as described in [illegible]

b. Click the **Device ID**.

c. Click **Settings**.

d. Click to expand **Config**.

Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Network** > **SCEP Client**.
4. For **Add clients**, enter a name for the SCEP client and click **+**.



The new SCEP client configuration is displayed.



5. Click **Enable** to enable the SCEP client.
6. For **Renewable time**, type the number of days that the certificate enrollment can be renewed, prior to the request expiring. This value must match the setting of the **Allow renewal x days before the certified is expired** option on the Portnet server.
7. (Optional) Click **Debug** to enable verbose logging in /var/log/scep_client.
8. Click to expand **SCEP server**.



ii. For **FQDN**, type the fully qualified domain name or IP address of the Portnet server.

iii. For **Password**, type the challenge password. This corresponds to the **Default enrollment password** on the Portnet server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

11. Click to expand **Distinguished Name**.



12. Type the value for each applicable Distinguished Name attribute. The values entered here must correspond to the DN attributes in the **Enrollment Request** on the Fortinet server.
13. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a new SCEP client, for example, **fortinet_SCEP_client**:

```
(config)> add network scep_client Fortinet_SCEP_client
(config network scep_client Fortinet_SCEP_client
)>
```

4. Enable the SCEP client:

```
(config network scep_client Fortinet_SCEP_client)> enable true
(config network scep_client Fortinet_SCEP_client)>
```

5. Set the url parameter to the fully qualified domain name or IP address of the SCEP server:

```
(config network scep_client Fortinet_SCEP_client)> server url
https://fortinet.example.com
(config network scep_client Fortinet_SCEP_client)>
```

6. Set the challenge password as configured on the SCEP server. This corresponds to the **Default enrollment password** on the Fortinet server.

```
(config network scep_client Fortinet_SCEP_client)> server password
challenge_password
(config network scep_client Fortinet_SCEP_client)>
```

7. Set Distinguished Name attributes. The values entered here must correspond to the DN attributes in the **Enrollment Request** on the Fortinet server.

   a. Set the Domain Component:

```
(config network scep_client Fortinet_SCEP_client)> dnattinguished_name
dc value
(config network scep_client Fortinet_SCEP_client)>
```

   b. Set the two letter Country Code:

```
(config network scep_client Fortinet_SCEP_client)> dnattinguished_name
c value
(config network scep_client Fortinet_SCEP_client)>
```

   c. Set the State or Province:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network scep_client Fortinet_SCEP_client)# distinguished_name
st value
(config network scep_client  Fortinet_SCEP_client)#
```

d. Set the Locality.

```
(config network scep_client Fortinet_SCEP_client)# distinguished_name
l value
(config network scep_client Fortinet_SCEP_client)#
```

e. Set the Organization.

```
(config network scep_client Fortinet_SCEP_client)# distinguished_name
o value
(config network scep_client Fortinet_SCEP_client)#
```

f. Set the Organizational Unit.

```
(config network scep_client Fortinet_SCEP_client)# distinguished_name
ou value
(config network scep_client Fortinet_SCEP_client)#
```

g. Set the Common Name.

```
(config network scep_client Fortinet_SCEP_client)# distinguished_name
cn value
(config network scep_client Fortinet_SCEP_client)#
```

8. Set the number of days that the certificate enrollment can be renewed, prior to the request expiring. This value must match the setting of the **Allow renewal x days before the certificate is expired** option on the Fortinet server.

```
(config network scep_client Fortinet_SCEP_client)# renewable_time integer
(config network scep_client Fortinet_SCEP_client)#
```

9. (Optional) Enable verbose logging in /var/log/scep_client.

```
(config network scep_client Fortinet_SCEP_client)# debug true
(config network scep_client Fortinet_SCEP_client)#
```

10. Save the configuration and apply the change.

```
(config network scep_client Fortinet_SCEP_client)# save
Configuration saved.
#
```

11. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

Show SCEP client status and information

You can show general SCEP client information for all SCEP clients, and specific information for an individual SCEP client.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

This procedure is only available from the Admin CLI.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. To display details about all configured SCEP clients, type the following at the prompt:

```
> show scep-client

SCEP   Enabled  Expiry
-----  -------  ------
test   true     Jun  4 19:02:26 2023 GMT
test1  false

>
```

3. To display details about a specific SCEP client:

```
> show scep-client name name
```

For example:

```
> show scep-client name test

test SCEP Status
----------------
Enabled      : true

Client Certificate
------------------
Subject      : C=US,ST=MA,L=BOS,O=Digi,OU=ITS,CN=dummy
Issuer       : CN=TA-SCEP-1-CA
Serial       : 1100000017A3653ED5D1B615780200000000000017
Expiry       : Jun  4 19:02:26 2023 GMT

Certificate Authority Certificate [1]
--------------------------------------
Subject      : C=US,CN=TA-SCEP-1-RSCEP-RA
Issuer       : CN=TA-SCEP-1-CA
Serial       : 1100000003A1E7500611C9C2F3460000000000D2
Expiry       : Apr 25 13:40:47 2023 GMT

Certificate Authority Certificate [2]
--------------------------------------
Subject      : C=US,CN=TA-SCEP-1-RSCEP-RA
Issuer       : CN=TA-SCEP-1-CA
Serial       : 1100000003310A4FBD1946DFCA7300000000000D2
Expiry       : Apr 25 13:42:46 2023 GMT
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

```
Certificate Authority Certificate [1]
--------------------------------------
Subject      : CN=TA-SCEP-1-CA
Issuer       : CN=TA-SCEP-1-CA
Serial       : 6A1G7868EFB7FCB74219C11DD9DD4647
Expiry       : Apr 30 13:26:41 2027 GMT

Certificate Revocation List
---------------------------
Issuer       : CN=TA-SCEP-1-CA
Last Update  : May 21 13:27:21 2023 GMT
```

4. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

OpenVPN

OpenVPN is an open-source Virtual Private Network (VPN) technology that creates secure point-to-point or site-to-site connections in routed or bridged configurations. OpenVPN uses a custom security protocol that is Secure Sockets Layer (SSL) / Transport Layer Security (TLS) for key exchange. It uses standard encryption and authentication algorithms for data privacy and authentication over TCP or UDP.

The OpenVPN server can push the network configuration, such as the topology and IP routes, to OpenVPN clients. This makes OpenVPN simpler to configure as it reduces the chances of a configuration mismatch between the client and server. OpenVPN also supports cipher negotiation between the client and server. This means you can configure the OpenVPN server and clients with a range of different cipher options and the server will negotiate with the client on the cipher to use for the connection.

For more information on OpenVPN, see www.openvpn.net.

OpenVPN modes:

There are two modes for running OpenVPN:

- Routing mode, also known as TUN.
- Bridging mode, also known as TAP.

Routing (TUN) mode

In routing mode, each OpenVPN client is assigned a different IP subnet from the OpenVPN server and other OpenVPN clients. OpenVPN clients use Network Address Translation (NAT) to route traffic from devices connected on the LAN interfaces to the OpenVPN server.

The manner in which the IP subnets are defined depends on the OpenVPN topology in use. The Connect EZ 4 WS device supports two types of OpenVPN topology:

OpenVPN topology	Virtual IP address method
net30	Each OpenVPN client is assigned a /30 subnet within the IP subnet specified in the OpenVPN server configuration. With net30 topology, pushed routes are used, with the exception of the default route. Automatic route pushing (exec) is not allowed, because this would not inform the firewall and would be blocked.
subnet	Each OpenVPN client connected to the OpenVPN server is assigned an IP address within the IP subnet specified in the OpenVPN server configuration. For the Connect EZ 4 WS device, pushed routes are not allowed; you will need to manually configure routes on the device.

For more information on OpenVPN topologies, see OpenVPN topology.

Bridging (TAP) mode

In bridging mode, a LAN interface on the OpenVPN server is assigned to OpenVPN. The LAN interfaces of the OpenVPN clients are on the same IP subnet as the OpenVPN server's LAN interface. This means that devices connected to the OpenVPN client's LAN interfaces are on the same IP subnet as devices. The Connect EZ 4 WS device supports two mechanisms for configuring an OpenVPN server in TAP mode:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- OpenVPN managed—the Connect EZ 4 WS device creates the interface and then uses its standard configuration to set up the connection (for example, its standard DHCP server configuration).
- Device only—IP addressing is controlled by the system, not by OpenVPN.

Additional OpenVPN information

For more information on OpenVPN, see these resources:

Bridging vs. routing

OpenVPN Routing

Configure an OpenVPN server

Required configuration items

- Enable the OpenVPN server.

  The OpenVPN server is enabled by default.
- The mode used by the OpenVPN server, one of:
  - **TUN (OpenVPN managed)**—Also known as routing mode. Each OpenVPN client is assigned a different IP subnet from the OpenVPN server and other OpenVPN clients. OpenVPN clients use Network Address Translation (NAT) to route traffic from devices connected on its LAN interfaces to the OpenVPN server.
  - **TAP - OpenVPN managed**—Also know as bridging mode. A more advanced implementation of OpenVPN. The Connect EZ 4 WS device creates an OpenVPN interface and uses standard interface configuration (for example, a standard DHCP server configuration).
  - **TAP - Device only**—An alternate form of OpenVPN bridging mode, in which the device, rather than OpenVPN, controls the interface configuration. If this method is is, the OpenVPN server must be included as a device in either an interface or a bridge.
- The firewall zone to be used by the OpenVPN server.
- The IP network and subnet mask of the OpenVPN server.
- The server's Certificate authority (CA) certificate, and public, private and Diffie-Hellman (DH) keys.
- An OpenVPN authentication group and an OpenVPN user.
- Determine the method of certificate management:
  - Certificates managed by the server.
  - Certificates created externally and added to the server.
- If certificates are created and added to the server, determine the level of authentication:
  - Certificate authentication only.
  - Username and password authentication only.
  - Certificate and username and password authentication.

  If username and password authentication is used, you must create an OpenVPN authentication group and user. See Configure an OpenVPN Authentication Group and User for instructions.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Certificates and keys:
  - The **CA certificate** (usually in a .crt or .pem file).
  - The **Public key** (for example, server.crt).
  - The **Private key** (for example, server.key).
  - The **Diffie Hellman key** (usually in dh2048.pem).

Additional configuration items

- The route metric for the OpenVPN server.
- The range of IP addresses that the OpenVPN server will provide to clients.
- The TCP/UDP port to use. By default, the Connect EZ 4 WS device uses port **1194**.
- Access control list configuration to restrict access to the OpenVPN server through the firewall.
- Additional OpenVPN parameters.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN** > **OpenVPN** > **Servers**.
4. For **Add**, type a name for the OpenVPN server and click **+**.

   The new OpenVPN server configuration is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



The OpenVPN server is enabled by default. To disable, toggle off **Enable**.

5. For **Device type**, select the mode used by the OpenVPN server, either:
   - **TUN (OpenVPN managed)**
   - **LAN - OpenVPN managed**
   - **LAN - Device only**

   See OpenVPN for information about OpenVPN server modes.
6. If **TUN (OpenVPN managed)** or **LAN - OpenVPN managed** is selected for **Device type**:
   a. For **Zone**, select the firewall zone for the OpenVPN server. For TUN device types, this should be set to **Internal** to treat clients as LAN devices.
   b. (Optional) Select the **Metric** for the OpenVPN server. If multiple active routes match a destination, the route with the lowest metric will be used. The default setting is 0.
   c. For **Address**, type the IP address and subnet mask of the OpenVPN server.
   d. (Optional) For **First IP address** and **Last IP address**, set the range of IP addresses that the OpenVPN server will use when providing IP addresses to clients. The default is from **50** to **99**.
7. (Optional) Set the **VPN port** that the OpenVPN server will use. The default is **1194**.
8. For **Server managed certificates**, determine the method of certificate management. If enabled, the server will manage certificates. If not enabled, certificates must be created externally and added to the server.
9. If **Server managed certificates** is not enabled:
   a. Select the **Authentication** type.
      - **Certificate only**: Uses only certificates for client authentication. Each client requires a public and private key.
      - **Username/password only**: Uses a username and password for client authentication. You must create an OpenVPN authentication group and user. See Configure an OpenVPN Authentication Group and User for instructions.
      - **Certificate and username/password**: Uses both certificates and a username and password for client authentication. Each client requires a public and private key, and you must create an OpenVPN authentication group and user. See Configure an OpenVPN Authentication Group and User for instructions.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Paste the contents of the **CA certificate** (usually in a .crt file), the **Public key** (for example, server.crt), the **Private key** (for example, server.key), and the **Diffie Hellman key** (usually in dh2048.pem) into their respective fields. The contents will be hidden when the configuration is saved.

iii. (Optional) Click to expand **Access control list** to restrict access to the OpenVPN server.

- To limit access to specified IPv4 addresses and networks:
  a. Click **IPv4 Addresses**.
  b. For **Add Address**, click **+**.
  c. For **Address**, enter the IPv4 address or network that can access the device's service-type. Allowed values are:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**: No limit to IPv4 addresses that can access the service-type.
  d. Click **+** again to list additional IP addresses or networks.
- To limit access to specified IPv6 addresses and networks:
  a. Click **IPv6 Addresses**.
  b. For **Add Address**, click **+**.
  c. For **Address**, enter the IPv6 address or network that can access the device's service-type. Allowed values are:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:db8::/48.
     - **any**: No limit to IPv6 addresses that can access the service-type.
  d. Click **+** again to list additional IP addresses or networks.
- To limit access to hosts connected through a specified interface on the device:
  a. Click **Interfaces**.
  b. For **Add Interface**, click **+**.
  c. For **Interface**, select the appropriate interface from the dropdown.
  d. Click **+** again to allow access through additional interfaces.
- To limit access based on firewall zones:
  a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
  b. For **Add Zone**, click **+**.
  c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
  d. Click **+** again to allow access through additional firewall zones.

11. (Optional) Click to expand **Advanced Options** to manually set additional OpenVPN parameters.
    a. Click **Enable** to enable the use of additional OpenVPN parameters.
    b. Click **Override** if the additional OpenVPN parameters should override default options.
    c. For **OpenVPN parameters**, type the additional OpenVPN parameters.
12. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 353 / 927

TS-TL-DGI-010

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> add vpn openvpn server name
(config vpn openvpn server name)>
```

   where **name** is the name of the OpenVPN server.

   The OpenVPN server is enabled by default. To disable the server, type:

```
(config vpn openvpn server name)> enable false
(config vpn openvpn server name)>
```

4. Set the mode used by the OpenVPN server:

```
(config vpn openvpn server name)> device_type value
(config vpn openvpn server name)>
```

   where *value* is one of:

   - **TUN (OpenVPN managed)**—Also known as routing mode. Each OpenVPN client is assigned a different IP subnet from the OpenVPN server and other OpenVPN clients. OpenVPN clients use Network Address Translation (NAT) to route traffic from devices connected on the LAN interfaces to the OpenVPN server.
   - **TAP - OpenVPN managed**—Also known as bridging mode. A more advanced implementation of OpenVPN. The Connect EZ 4 WS device creates an OpenVPN interface and uses standard interface configuration (for example, a standard DHCP server configuration).
   - **TAP - Device only**—An alternate form of OpenVPN bridging mode, in which the device, rather than OpenVPN, controls the interface configuration. If this method is in, the OpenVPN server must be included as a device in either an interface or a bridge.

   See OpenVPN for information about OpenVPN modes. The default is **tun**.

5. If **tap** or **tun** are set for **device type**:
   a. Set the IP address and subnet mask of the OpenVPN server:

```
(config vpn openvpn server name)> address ip_address/netmask
(config vpn openvpn server name)>
```

   b. Set the firewall zone for the OpenVPN server. For TUN device types, this should be set to **internal** to treat clients as LAN devices.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config vpn openvpn server name)> zone value
(config vpn openvpn server name)>
```

To view a list of available zones:

```
(config vpn openvpn server name)> firewall_zone ?

Zone: The zone for the local TUN interface. To treat clients as LAN
devices this would usually be
set to internal.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup
Current value:

(config vpn openvpn server name)>
```

c. (Optional) Set the route metric for the OpenVPN server. If multiple active routes match a destination, the route with the lowest metric will be used.

```
(config vpn openvpn server name)> metric value
(config vpn openvpn server name)>
```

where value is an integer between 0 and 65535. The default is 0.

d. (Optional) Set the range of IP addresses that the OpenVPN server will use when providing IP addresses to clients.

i. Set the first address in the range limit.

```
(config vpn openvpn server name)> server_first_ip value
(config vpn openvpn server name)>
```

where value is a number between 1 and 255. The number entered here will represent the first client IP address. For example, if **address** is set to 192.168.1.1/24 and **server first_ip** is set to 50, the first client IP address will be 192.168.1.50.

The default is from 50.

ii. Set the last address in the range limit.

```
(config vpn openvpn server name)> server_last_ip value
(config vpn openvpn server name)>
```

where value is a number between 1 and 255. The number entered here will represent the last client IP address. For example, if **address** is set to 192.168.1.1/24 and **server last_ip** is set to 99, the last client IP address will be 192.168.1.99.

The default is from 99.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. (Optional) Set the port that the OpenVPN server will use:

```
(config vpn openvpn server name)> port port
(config vpn openvpn server name)>
```

The default is **1194**.

7. Determine the method of certificate management:
   a. To allow the server to manage certificates:

```
(config vpn openvpn server name)> autogenerate true
(config vpn openvpn server name)>
```

   b. To create certificates externally and add them to the server:

```
(config vpn openvpn server name)> autogenerate false
(config vpn openvpn server name)>
```

   The default setting is **false**.
   c. If **autogenerate** is set to false:
      i. Set the authentication type:

```
(config vpn openvpn server name)> authentication value
(config vpn openvpn server name)>
```

      where **value** is one of:
      - **cert**: Uses only certificates for client authentication. Each client requires a public and private key.
      - **password**: Uses a username and password for client authentication. You must create an OpenVPN authentication group and user. See Configure an OpenVPN Authentication Group and User for instructions.
      - **cert password**: Uses both certificates and a username and password for client authentication. Each client requires a public and private key, and you must create an OpenVPN authentication group and user. See Configure an OpenVPN Authentication Group and User for instructions.

      ii. Paste the contents of the CA certificate (usually in a .crt or .file) into the value of the **cacert** parameter:

```
(config vpn openvpn server name)> cacert value
(config vpn openvpn server name)>
```

      iii. Paste the contents of the public key (for example, server.crt) into the value of the **server cert** parameter:

```
(config vpn openvpn server name)> server_cert value
(config vpn openvpn server name)>
```

      iv. Paste the contents of the private key (for example, server.key) into the value of the **server key** parameter.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config vpn openvpn server name)> server_key value
(config vpn openvpn server name)>
```

e. Paste the contents of the Diffie Hellman key (usually in dh2048.pem) into the value of the **diffie** parameter:

```
(config vpn openvpn server name)> diffie value
(config vpn openvpn server name)>
```

8. (Optional) Set the access control list to restrict access to the OpenVPN server:

- To limit access to specified IPv4 addresses and networks:

```
(config vpn openvpn server name)> add acl address end value
(config vpn openvpn server name)>
```

Where **value** can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- **any**: No limit to IPv4 addresses that can access the server type.

Repeat this step to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:

```
(config vpn openvpn server name)> add acl address6 end value
(config vpn openvpn server name)>
```

Where **value** can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IPv6 addresses that can access the server type.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config vpn openvpn server name)> add acl interface end value
(config vpn openvpn server name)>
```

Where **value** is an interface defined on your device.

Display a list of available interfaces.

Use **_ network interface** to display interface information.

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config vpn openvpn server name)> add acl zone end value
(config vpn openvpn server name)>
```

Where **value** is a firewall zone defined on your device, or the **any** keyword.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Display a list of available firewall zones:

Type `... firewall zone ?` at the config prompt:

```
(config vpn openvpn server name)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

 Additional Configuration
 ------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config vpn openvpn server name)>
```

Repeat this step to include additional firewall zones.

ii. (Optional) Set additional OpenVPN parameters.

a. Enable the use of additional OpenVPN parameters:

```
(config vpn openvpn server name)> advanced_options enable true
(config vpn openvpn server name)>
```

b. Configure whether the additional OpenVPN parameters should override default options:

```
(config vpn openvpn server name)> advanced_options override true
(config vpn openvpn server name)>
```

c. Set the additional OpenVPN parameters:

```
(config vpn openvpn server name)> extra_parameters
(config vpn openvpn server name)>
```

iii. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

11. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure an OpenVPN Authentication Group and User

If username and password authentication is used for the OpenVPN server, you must create an OpenVPN authentication group and user.

See Configure an OpenVPN server for information about configuring an OpenVPN server to use username and password authentication. See Connect EZ 4 WS user authentication for more information about creating authentication groups and users.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:


   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Add an OpenVPN authentication group:
   a. Click **Authentication** > **Groups**.
   b. For **Add Group**, type a name for the group (for example, **OpenVPN Group**) and click **+**.

   The new authentication group configuration is displayed.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



c. Click **OpenVPN access** to enable OpenVPN access rights for users of this group.
d. Click to expand the **OpenVPN** node.
e. Click **+** to add a tunnel.




f. For **Tunnel**, select an OpenVPN tunnel to which users of this group will have access.



g. Repeat to add additional OpenVPN tunnels.


4. Add an OpenVPN authentication user:
   a. Click **Authentication** > **Users**.
   b. For **Add**, type a name for the user (for example, **OpenVPN User**) and click **+**.




   c. Type a password for the user.
   This password is used for local authentication of the user. You can also configure the user to use RADIUS or TACACS+ authentication by configuring authentication methods. See User authentication methods for information.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

d. Click to expand the **Groups** node.



e. Click **+** to add a group to the list.



f. Select a **Group** with **OpenVPN access** enabled.



5. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Use the **add auth group** command to add a new authentication. For example, to add a group named **OpenVPN_Group**:

```
(config)> add auth group OpenVPN_Group
(config auth group OpenVPN_Group)>
```

4. Enable OpenVPN access rights for users of this group:

```
(config auth group OpenVPN_Group)> act openvpn enable true
```

5. Add an OpenVPN tunnel to which users of this group will have access:

   a. Determine available tunnels:

```
(config auth group OpenVPN_Group)> ... ... ... vpn openvpn server ?

Servers: A list of openvpn servers

  Additional Configuration
  ------------------------------------------------------------------------

  OpenVPN_server1              OpenVPN server

(config auth group OpenVPN_Group)>
```

   b. Add a tunnel:

```
(config auth group OpenVPN_Group)> add auth group test act openvpn
tunnels add /vpn/openvpn/server/OpenVPN_server1
(config auth group OpenVPN_Group)>
```

6. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure an OpenVPN client by using an .ovpn file

Required configuration items

- Enable the OpenVPN client.
  The OpenVPN client is enabled by default.
- The firewall zone to be used by the OpenVPN client.

Additional configuration items

- The route metric for the OpenVPN client.
- The login credentials for the OpenVPN client, if configured on the OpenVPN server.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:
   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:
   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN** > **OpenVPN** > **Clients**.
4. For **Add**, type a name for the OpenVPN client and click **+**.

   The new OpenVPN client configuration is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



5. The OpenVPN client is enabled by default. To disable, toggle off **Enable**.
6. The default behavior is to use an OVPN file for client configuration. To disable this behavior and configure the client manually, click **Use .ovpn file** to disable. If **Use .ovpn file** is disabled, see Configure an OpenVPN client without using an .ovpn file for configuration information.
7. For **Zone**, select the firewall zone for the OpenVPN client.
8. (Optional) Select the **Metric** for the OpenVPN client. If multiple active routes match a destination, the route with the lowest metric will be used.
9. (Optional) For **Username** and **Password**, type the login credentials as configured on the OpenVPN server.
10. For **OVPN file**, paste the content of the client .ovpn file.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> add vpn openvpn client name
(config vpn openvpn client name)>
```

   where **name** is the name of the OpenVPN server.

   The OpenVPN client is enabled by default. To disable the client, type:

```
(config vpn openvpn client name)> enable false
(config vpn openvpn client name)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Set the firewall zone for the OpenVPN client:

```
(config vpn openvpn client name)> zone value
(config vpn openvpn client name)>
```

To view a list of available zones:

```
(config vpn openvpn client name)> zone ?

Zone: The zone for the openvpn client interface.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup
Current value:

(config vpn openvpn client name)>
```

5. (Optional) Set the route metric for the OpenVPN server. If multiple active routes match a destination, the route with the lowest metric will be used.

```
(config vpn openvpn client name)> metric value
(config vpn openvpn client name)>
```

where value is an integer between 0 and 65535. The default is 0.

6. (Optional) Set the login credentials as configured on the OpenVPN server:

```
(config vpn openvpn client name)> username value
(config vpn openvpn client name)> password value
(config vpn openvpn client name)>
```

7. Paste the content of the client .ovpn file into the value of the **config_file** parameter:

```
(config vpn openvpn client name)> config_file value
(config vpn openvpn client name)>
```

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure an OpenVPN client without using an .ovpn file

Required configuration items

- Enable the OpenVPN client.
  The OpenVPN client is enabled by default.
- The mode used by the OpenVPN server, either routing (TUN), or bridging (TAP).
- The firewall zone to be used by the OpenVPN client.
- The IP address of the OpenVPN server.
- Certificates and keys:
  - The **CA certificate** (usually in a ca.crt file).
  - The **Public key** (for example, client.crt)
  - The **Private key** (for example, client.key).

Additional configuration items

- The route metric for the OpenVPN client.
- The login credentials for the OpenVPN client, if configured on the OpenVPN server.
- Additional OpenVPN parameters.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:


   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN** > **OpenVPN** > **Clients**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. For **Add**, type a name for the OpenVPN client and click **+**.



The new OpenVPN client configuration is displayed.



5. The OpenVPN client is enabled by default. To disable, toggle off **Enable**.
6. The default behavior is to use an OVPN file for client configuration. To disable this behavior and configure the client manually, click **Use .ovpn file** to disable.
7. For **Device type**, select the mode used by the OpenVPN server, either **TUN** or **TAP**.
8. For **Zone**, select the firewall zone for the OpenVPN client.
9. (Optional) Select the **Metric** for the OpenVPN client. If multiple active routes match a destination, the route with the lowest metric will be used.
10. (Optional) For **Username** and **Password**, type the login credentials as configured on the OpenVPN server.
11. For **VPN server IP**, type the IP address of the OpenVPN server.
12. (Optional) Set the **VPN port** used by the OpenVPN server. The default is **1194**.
13. Paste the contents of the **CA certificate** (usually in a ca.crt file), the **Public key** (for example, client.crt), and the **Private key** (for example, client.key) into their respective fields. The contents will be hidden when the configuration is saved.
14. (Optional) Click to expand **Advanced Options** to manually set additional OpenVPN parameters.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Click **Enable** to enable the use of additional OpenVPN parameters.

b. Click **Override** if the additional OpenVPN parameters should override default options.

c. For **OpenVPN parameters**, type the additional OpenVPN parameters. For example, to override the configuration by using a configuration file, enter **--config filename**, for example, **--config /etc/config/openvpn.config**.

15. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> add vpn openvpn client name
(config vpn openvpn client name)>
```

   where **name** is the name of the OpenVPN server.
   The OpenVPN client is enabled by default. To disable the client, type:

```
(config vpn openvpn client name)> enable false
(config vpn openvpn client name)>
```

4. The default behavior is to use an OVPN file for client configuration. To disable this behavior and configure the client manually:

```
(config vpn openvpn client name)> use_file false
(config vpn openvpn client name)>
```

5. Set the mode used by the OpenVPN server:

```
(config vpn openvpn client name)> device_type value
(config vpn openvpn client name)>
```

   where **value** is either **tun** or **tap**. The default is **tun**.
6. Set the firewall zone for the OpenVPN client:

```
(config vpn openvpn client name)> zone value
(config vpn openvpn client name)>
```

   To view a list of available zones:

```
(config vpn openvpn client name)> zone ?

Zone: The zone for the openvpn client interface.
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup
Current value:

(config vpn openvpn client name)>
```

7. (Optional) Set the route metric for the OpenVPN server. If multiple active routes match a destination, the route with the lowest metric will be used.

```
(config vpn openvpn client name)> metric value
(config vpn openvpn client name)>
```

where value is an integer between 0 and 65535. The default is 0.

8. (Optional) Set the login credentials as configured on the OpenVPN server:

```
(config vpn openvpn client name)> username value
(config vpn openvpn client name)> password value
(config vpn openvpn client name)>
```

9. Set the IP address of the OpenVPN server:

```
(config vpn openvpn client name)> server ip_address
(config vpn openvpn client name)>
```

10. (Optional) Set the port used by the OpenVPN server:

```
(config vpn openvpn client name)> port port
(config vpn openvpn client name)>
```

The default is 1194.

11. Paste the contents of the CA certificate (usually in a ca.crt file) into the value of the **cacert** parameter:

```
(config vpn openvpn client name)> cacert value
(config vpn openvpn client name)>
```

12. Paste the contents of the public key (for example, client.crt) into the value of the **public_cert** parameter:

```
(config vpn openvpn client name)> public_cert value
(config vpn openvpn client name)>
```

13. Paste the contents of the private key (for example, client.key) into the value of the **private_key** parameter:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config vpn openvpn client name)> private_key value
(config vpn openvpn client name)>
```

14. (Optional) Set additional OpenVPN parameters.
    a. Enable the use of additional OpenVPN parameters:

    ```
    (config vpn openvpn client name)> advanced_options enable true
    (config vpn openvpn client name)>
    ```

    b. Configure whether the additional OpenVPN parameters should override default options:

    ```
    (config vpn openvpn client name)> advanced_options override true
    (config vpn openvpn client name)>
    ```

    c. Set the additional OpenVPN parameters:

    ```
    (config vpn openvpn client name)> advanced_options extra parameters
    (config vpn openvpn client name)>
    ```

15. Save the configuration and apply the changes.

    ```
    (config)> save
    Configuration saved.
    >
    ```

16. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show OpenVPN server status and statistics

You can view status and statistics for OpenVPN servers from either the web interface or the command line.

Web

Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.

1. On the menu, select **Status > OpenVPN > Servers**.

   The **OpenVPN Servers** page appears.

2. To view configuration details about an OpenVPN server, click the (configuration) icon in the upper right of the OpenVPN server's status pane.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. To display details about all configured OpenVPN servers, type the following at the prompt:

```
> show openvpn server all

Server           Enable  Type  Zone      IP Address        Port
---------------  ------  ----  --------  ----------------  ----
OpenVPN_server1  true    tun   internal  192.168.30.1/24   1194
OpenVPN_server2  false   tun   internal  192.168.40.1/24   1194

>
```

3. To display details about a specific server:

```
> show openvpn server name OpenVPN_server1

Server                  : OpenVPN_server1
Enable                  : true
Type                    : tun
Zone                    : internal
IP Address              : 192.168.30.1/24
Port                    : 1194
Use File                : true
Retrits                 : 0
Protocol                : udp
First IP                : 50
Last IP                 : 99

>
```

4. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show OpenVPN client status and statistics

You can view status and statistics for OpenVPN clients from either web interface or the command line.

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, select **Status** > **OpenVPN** > **Clients**.

   The **OpenVPN Clients** page appears.

2. To view configuration details about an OpenVPN client, click the (configuration) icon in the upper right of the OpenVPN client's status pane.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an Access selection menu. Type **admin** to access the Admin CLI.

2. To display details about all configured OpenVPN clients, type the following at the prompt:

```
> show openvpn client all

Client           Enable  Status     Username  Use File  Zone
---------------  ------  ---------  --------  --------  --------
OpenVPN_Client1  true    connected            true      internal
OpenVPN_Client2  true    pending              true      internal

>
```

3. To display details about a specific client:

```
> show openvpn client name OpenVPN_client1

Client                  : OpenVPN_client1
Enable                  : true
Status                  : up
Username                : user1
IP address              : 111.111.111.120
Remote                  : 120.111.222.111
MTU                     : 1402
Zone                    : internal
IP Address              : 192.168.30.1/24
Port                    : 1194
Use File                : true
Metric                  : 0
Protocol                : udp
Port                    : 1194
Type                    : tun

>
```

4. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an Access selection menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Generic Routing Encapsulation (GRE)

Generic Routing Encapsulation (GRE) is an IP packet encapsulation protocol that allow for networks and routes to be advertised from one network device to another. You can use GRE to encapsulate a wide variety of network layer protocols inside virtual point-to-point links over an IP network.

Configuring a GRE tunnel

Configuring a GRE tunnel involves the following items.

Required configuration items

- A GRE loopback endpoint interface.
- GRE tunnel configuration:
  - Enable the GRE tunnel.

    The GRE tunnels are enabled by default.
  - The local endpoint interface.
  - The IP address of the remote device/peer.

Additional configuration items

- A GRE key.
- Enable the device to respond to keepalive packets.

Task One: Create a GRE loopback endpoint interface

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Network** > **Interfaces**.
4. For **Add interface**, type a name for the GRE loopback endpoint interface and click **+**.
5. **Enable** the interface.
   New interfaces are enabled by default. To disable, toggle off **Enable**.
6. For **Interface type**, select **Ethernet**.
7. For **Zone**, select **Internal**.
8. For **Device**, select **Ethernet: Loopback**.
9. Click to expand **IPv4**.
10. For **Address**, enter the IP address and subnet mask of the local GRE endpoint, for example **10.10.1.1/24**.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Add the GRE endpoint interface. For example, to add an interface named **gre_endpoint**:

```
(config)> add network interface gre_interface
(config network interface gre_interface)>
```

4. Set the interface zone to **internal**.

```
(config network interface gre_interface)> zone internal
(config network interface gre_interface)>
```

5. Set the interface device to **loopback**.

```
(config network interface gre_interface)> device /network/device/loopback
(config network interface gre_interface)>
```

6. Set the IP address and subnet mask of the local GRE endpoint. For example, to set the local GRE endpoint's IP address and subnet mask to **10.10.1.1/24**:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network interface gre_interface)> ipv4 address 10.10.1.1/24
(config network interface gre_interface)>
```

7. Save the configuration and apply the changes.

```
(config network interface gre_interface)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Task Two: Configure the GRE tunnel

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:
   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:
   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN > IP Tunnels**.
4. For **Add IP tunnel**, type a name for the GRE tunnel and click **+**.
5. **Enable** the tunnel.
   New tunnels are enabled by default. To disable, toggle off **Enable**.
6. For **Mode**, select one of the following options:
   - **GRE**: Standard GRE point-to-point protocol.
   - **mGRE**: multipoint GRE protocol.
   - **GRETAP**: Ethernet over GRE.
7. For **Local endpoint**, select the GRE endpoint interface created in Task One.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. If **GRE** is selected for the **Mode**, for **Remote endpoint**, type the IP address of the GRE endpoint on the remote peer.
9. If **GRETAP** is selected for **Mode**, for **Local endpoint**, select the interface.
10. (Optional) For **Key**, enter a key that will be inserted in GRE packets created by this tunnel. It must match the key set by the remote endpoint. Allowed value is an integer between 0 and 4294967295, or an IP address.
11. (Optional) **Enable keepalive reply** to enable the device to reply to Cisco GRE keepalive packets.
12. (Optional) **Enable open routing** to enable packets destined for an address which is not explicitly in the routing table to exit the IP tunnel.
13. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add the GRE endpoint tunnel. For example, to add a tunnel named **gre_example**:

```
(config)> add vpn iptunnel gre_example
(config vpn iptunnel gre_example)>
```

   GRE tunnels are enabled by default. To disable:

```
(config vpn iptunnel gre_example)> enable false
(config vpn iptunnel gre_example)>
```

4. Set the mode:

```
(config vpn iptunnel gre_example)> type value
(config vpn iptunnel gre_example)>
```

   where *value* is either:

   - **gre**: Standard GRE point-to-point protocol.
   - **mgre**: multipoint GRE protocol.
   - **GRETAP**: Ethernet over GRE.
5. Set the local endpoint to the GRE endpoint interface created in Task One, for example:

```
(config vpn iptunnel gre_example)> local /network/interface/gre_endpoint
(config vpn iptunnel gre_example)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library

TS-TL-DGI-010

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025

㈜테솔 · www.tessol.com TS-TL-DGI-010 376 / 927

8. If **type** is set to **gre**, set the IP address of the GRE endpoint on the remote peer:

```
(config vpn iptunnel gre_example)> remote ip_address
(config vpn iptunnel gre_example)>
```

7. (Optional) Set a key that will be inserted in GRE packets created by this tunnel.

   The key must match the key set by the remote endpoint.

```
(config vpn iptunnel gre_example)> key value
(config vpn iptunnel gre_example)>
```

   where value is an integer between 0 and 4294967295, or an IP address.

8. (Optional) Enable the device to reply to Cisco GRE keepalive packets:

```
(config vpn iptunnel gre_example)> keepalive true
(config vpn iptunnel gre_example)>
```

9. (Optional) Enable the device to allow packets destined for an address which is not explicitly in the routing table to exit this IP tunnel.

```
(config vpn iptunnel gre_example)> open_routing true
(config vpn iptunnel gre_example)>
```

10. Save the configuration and apply the changes.

```
(config vpn iptunnel gre_example)> save
Configuration saved.
>
```

11. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Show GRE tunnels

To view information about currently configured GRE tunnels

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **Status** > **IP tunnels**.
   The **IP tunnels** page appears.
2. To view configuration details about a GRE tunnel, click the (configuration) icon in the upper right of the tunnel's status pane.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Example: GRE tunnel over an IPSec tunnel

The Connect EZ 4 WS device can be configured as an advertised set of routes through an IPSec tunnel. This allows you to leverage the dynamic route advertisement of GRE tunnels through a secured IPSec tunnel.

The example configuration provides instructions for configuring the Connect EZ 4 WS device with a GRE tunnel through IPsec.

Connect EZ 4 WS-1 configuration tasks

1. Create an IPsec tunnel named **ipsec gre1** with:
   - A pre-shared key.
   - **Remote endpoint** set to the public IP address of the Connect EZ 4 WS-2 device.
   - A policy with:
     - **Local network** set to the IP address and subnet of the local GRE tunnel, 172.30.0.1/32.
     - **Remote network** set to the IP address and subnet of the remote GRE tunnel, 172.30.0.2/32.
2. Create an IPsec endpoint interface named **ipsec endpoint1**:
   a. **Zone** set to **Internal**.
   b. **Device** set to **Ethernet: Loopback**.
   c. IPv4 Address set to the IP address of the local GRE tunnel, 172.30.0.1/32.
3. Create a GRE tunnel named **gre tunnel1**:
   a. **Local endpoint** set to the IPsec endpoint interface, **Interface: ipsec endpoint1**.
   b. Remote endpoint set to the IP address of the GRE tunnel on Connect EZ 4 WS-2, 172.30.0.2.
4. Create an interface named **gre interface1** and add it to the GRE tunnel:
   a. **Zone** set to **Internal**.
   b. **Device** set to **IP tunnel: gre tunnel1**.
   c. IPv4 Address set to a virtual IP address on the GRE tunnel, 172.31.0.1/30.

Connect EZ 4 WS-2 configuration tasks

1. Create an IPsec tunnel named **ipsec gre2** with:
   - The same pre-shared key as the **ipsec gre1** tunnel on Connect EZ 4 WS-1.
   - **Remote endpoint** set to the public IP address of Connect EZ 4 WS-1.
   - A policy with:
     - **Local network** set to the IP address and subnet of the local GRE tunnel, 172.30.0.2/32.
     - **Remote network** set to the IP address of the remote GRE tunnel, 172.30.0.1/32.
2. Create an IPsec endpoint interface named **ipsec endpoint2**:
   a. **Zone** set to **Internal**.
   b. **Device** set to **Ethernet: Loopback**.
   c. IPv4 Address set to the IP address of the local GRE tunnel, 172.30.0.2/32.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Create a GRE tunnel named **gre_tunnel2**.
   a. **Local endpoint** set to the IPsec endpoint interface, **Interface: ipsec_endpoint2**.
   b. **Remote endpoint** set to the IP address of the GRE tunnel on Connect EZ 4 WS-1, **172.30.0.1**.
4. Create an interface named **gre_interface2** and add it to the GRE tunnel.
   a. **Zone** set to **Internal**.
   b. **Device** set to **IP tunnel: gre_tunnel2**.
   c. IPv4 Address set to a virtual IP address on the GRE tunnel, **172.31.0.2/30**.

Configuration procedures

Configure the Connect EZ 4 WS-1 device
Task one: Create an IPsec tunnel

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:
   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:
   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN** > **IPsec** > **Tunnels**.
4. For **Add IPsec tunnel**, type **ipsec_gre1** and click **+**.

5. Click to expand **Authentication**.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. For **Pre-shared key**, type **testkey**.

7. Click to expand **Remote endpoint**.
8. For **Hostname**, type public IP address of the Connect EZ 4 WS-2 device.

9. Click to expand **Policies**.
10. For **Add Policy**, click **+** to add a new policy.

11. Click to expand **Local network**.
12. For **Type**, select **Custom network**.
13. For **Address**, type the IP address and subnet of the local GRE tunnel, **172.30.0.1/32**.
14. For **Remote network**, type the IP address and subnet of the remote GRE tunnel, **172.30.0.2/32**.



15. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Add an IPsec tunnel named **ipsec_gre1**.

```
(config)> add vpn ipsec tunnel ipsec_gre1
(config vpn ipsec tunnel ipsec_gre1)>
```

4. Set the pre-shared key to **testkey**.

```
(config vpn ipsec tunnel ipsec_gre1)> auth secret testkey
(config vpn ipsec tunnel ipsec_gre1)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Set the remote endpoint to public IP address of the Connect EZ 4 WS-2 device.

```
(config vpn ipsec tunnel ipsec_gre1)> remote hostname 192.168.161.1
(config vpn ipsec tunnel ipsec_gre1)>
```

6. Add a policy.

```
(config vpn ipsec tunnel ipsec_gre1)> add policy eval
(config vpn ipsec tunnel ipsec_gre1 policy 0)>
```

7. Set the local network policy type to **custom**.

```
(config vpn ipsec tunnel ipsec_gre1 policy 0)> local type custom
(config vpn ipsec tunnel ipsec_gre1 policy 0)>
```

8. Set the local network address to the IP address and subnet of the local GRE tunnel, **172.30.0.1/32**.

```
(config vpn ipsec tunnel ipsec_gre1 policy 0)> local custom 172.30.0.1/32
(config vpn ipsec tunnel ipsec_gre1 policy 0)>
```

9. Set the remote network address to the IP address and subnet of the remote GRE tunnel, **172.30.0.2/32**.

```
(config vpn ipsec tunnel ipsec_gre1 policy 0)> remote network
172.30.0.2/32
(config vpn ipsec tunnel ipsec_gre1 policy 0)>
```

10. Save the configuration and apply the change.

```
(config ipsec tunnel ipsec_gre1 policy 0)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Task two: Create an IPsec endpoint interface

Web

1. Click **Network** > **Interfaces**.
2. For **Add Interface**, type **ipsec endpoint1** and click **+**.



3. For **Zone**, select **Internal**.
4. For **Device**, select **Ethernet: loopback**.



5. Click to expand **IPv4**.
6. For **Address**, type the IP address of the local GRE tunnel, 172.30.0.1/32.



7. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

2. Add an interface named **ipsec endpoint1**.

```
(config)> add network interface ipsec_endpoint1
(config network interface ipsec_endpoint1)>
```

3. Set the zone to **ethernet**.

```
(config network interface ipsec_endpoint1)> zone internal
(config network interface ipsec_endpoint1)>
```

4. Set the device to **/network/device/loopback**.

```
(config network interface ipsec_endpoint1)> device
/network/device/loopback
(config network interface ipsec_endpoint1)>
```

5. Set the IPv4 address to the IP address of the local GRE tunnel, **172.30.0.1/32**.

```
(config network interface ipsec_endpoint1)> ipv4 address 172.30.0.1/32
(config network interface ipsec_endpoint1)>
```

6. Save the configuration and apply the changes.

```
(config vpn ipsec tunnel ipsec_endpoint1 policy 0)> save
Configuration saved.
>
```

Task three: Create a GRE tunnel

Web

1. Click **VPN > IP Tunnels**.
2. For **Add IP Tunnel**, type **gre_tunnel1** and click **+**.

3. For **Local endpoint**, select the IPsec endpoint interface created in Task two (**Interface: ipsec endpoint1**).
4. For **Remote endpoint**, type the IP address of the GRE tunnel on Connect EZ 4 WS-2, **172.30.0.2**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

2. Add a GRE tunnel named **gre_tunnel1**.

```
(config)> add vpn iptunnel gre_tunnel1
(config vpn iptunnel gre_tunnel1)>
```

3. Set the local endpoint to the IPsec endpoint interface created in [task two](#) (**/network/interface/ipsec_endpoint1**).

```
(config vpn iptunnel gre_tunnel1)> local /network/interface/ipsec_
endpoint1
(config vpn iptunnel gre_tunnel1)>
```

4. Set the remote endpoint to the IP address of the GRE tunnel on Connect EZ 4 WS-2, **172.30.0.2**.

```
(config vpn iptunnel gre_tunnel1)> remote 172.30.0.2
(config vpn iptunnel gre_tunnel1)>
```

5. Save the configuration and apply the change.

```
(config vpn iptunnel gre_tunnel1)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


Task four: Create an interface for the GRE tunnel device

Web

1. Click **Network** > **Interfaces**.
2. For **Add Interface**, type **gre interface1** and click **+**.



3. For **Zone**, select **Internal**.
4. For **Device**, select the GRE tunnel created in Task three (**tunnel: gre tunnel1**).



5. Click to expand **IPv4**.
6. For **Address**, type 172.31.6.1/30 for a virtual IP address on the GRE tunnel.



7. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

2. Add an interface named **gre_interface1**:

```
(config)> add network interface gre_interface1
(config network interface gre_interface1)>
```

3. Set the zone to **internal**:

```
(config network interface gre_interface1)> zone internal
(config network interface gre_interface1)>
```

4. Set the device to the GRE tunnel created in Task three (**/vpn/ipsec/gre_tunnel1**):

```
(config network interface gre_interface1)> device /vpn/ipsec/gre_
tunnel1
(config network interface gre_interface1)>
```

5. Set **172.31.8.1/30** as the virtual IP address on the GRE tunnel:

```
(config network interface gre_interface1)> ipv4 address 172.31.8.1/30
(config network interface gre_interface1)>
```

6. Save the configuration and apply the changes:

```
(config network interface gre_interface1)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the Connect EZ 4 WS-2 device
Task one: Create an IPsec tunnel

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **VPN** > **IPsec** > **Tunnels**.
4. For **Add IPsec tunnel**, type **ipsec_gre2** and click **+**.

5. Click to expand **Authentication**.
6. For **Pre-shared key**, type the same pre-shared key that was configured for the Connect EZ 4 WS-1 (**testkey**).

7. Click to expand **Remote endpoint**.
8. For **Hostname**, type public IP address of the Connect EZ 4 WS-1 device.

9. Click to expand **Policies**.
10. For **Add Policy**, click **+** to add a new policy.

11. Click to expand **Local network**.
12. For **Type**, select **Custom network**.
13. For **Address**, type the IP address and subnet of the local GRE tunnel, **172.30.0.2/32**.
14. For **Remote network**, type the IP address and subnet of the remote GRE tunnel, **172.30.0.1/32**.



15. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add an IPsec tunnel named **ipsec_gre2**:

```
(config)> add vpn ipsec tunnel ipsec_gre2
(config vpn ipsec tunnel ipsec_gre2)>
```

4. Set the pre-shared key to the same pre-shared key that was configured for the Connect EZ 4 WS-1 (**testkey**):

```
(config vpn ipsec tunnel ipsec_gre2)> auth secret testkey
(config vpn ipsec tunnel ipsec_gre2)>
```

5. Set the remote endpoint to public IP address of the Connect EZ 4 WS-1 device:

```
(config vpn ipsec tunnel ipsec_gre2)> remote hostname 192.168.100.1
(config vpn ipsec tunnel ipsec_gre2)>
```

6. Add a policy:

```
(config vpn ipsec tunnel ipsec_gre2)> add policy end
(config vpn ipsec tunnel ipsec_gre2 policy 0)>
```

7. Set the local network policy type to **custom**:

```
(config vpn ipsec tunnel ipsec_gre2 policy 0)> local type custom
(config vpn ipsec tunnel ipsec_gre2 policy 0)>
```

8. Set the local network address to the IP address and subnet of the local GRE tunnel, **172.30.0.2/32**:

```
(config vpn ipsec tunnel ipsec_gre2 policy 0)> local custom 172.30.0.2/32
(config vpn ipsec tunnel ipsec_gre2 policy 0)>
```

9. Set the remote network address to the IP address and subnet of the remote GRE tunnel, **172.30.0.1/32**:

```
(config vpn ipsec tunnel ipsec_gre2 policy 0)> remote network
172.30.0.1/32
(config vpn ipsec tunnel ipsec_gre2 policy 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iii. Save the configuration and apply the change.

```
(config vpn ipsec tunnel ipsec_gre2 policy 0)# save
Configuration saved.
#
```

Task two: Create an IPsec endpoint interface

Web

1. Click **Network** > **Interfaces**.
2. For **Add interface**, type **ipsec endpoint2** and click **+**.



3. For **Zone**, select **Internal**.
4. For **Device**, select **Ethernet: loopback**.



5. Click to expand **IPv4**.
6. For **Address**, type the IP address of the local GRE tunnel, 172.30.0.2/32.



7. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

2. Add an interface named **ipsec endpoint2**:

```
[config]> add network interface ipsec_endpoint2
[config network interface ipsec_endpoint2]>
```

3. Set the zone to **internal**:

```
[config network interface ipsec_endpoint2]> zone internal
[config network interface ipsec_endpoint2]>
```

4. Set the device to **/network/device/loopback**:

```
[config network interface ipsec_endpoint2]> device
/network/device/loopback
[config network interface ipsec_endpoint2]>
```

5. Set the IPv4 address to the IP address of the local GRE tunnel, **172.30.0.2/32**:

```
[config network interface ipsec_endpoint2]> ipv4 address 172.30.0.2/32
[config network interface ipsec_endpoint2]>
```

6. Save the configuration and apply the change:

```
[config vpn ipsec tunnel ipsec_endpoint2]> save
Configuration saved.
>
```

Task three: Create a GRE tunnel

Web

1. Click **VPN > IP Tunnels**.
2. For **Add IP Tunnel**, type **gre_tunnel2** and click **+**.

3. For **Local endpoint**, select the IPsec endpoint interface created in Task two (**Interface: ipsec endpoint2**).
4. For **Remote endpoint**, type the IP address of the GRE tunnel on Connect EZ 4 WS-1, **172.30.0.1**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

5. Click **Apply** to save the configuration and apply the change.

Command line

1. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

2. Add a GRE tunnel named **gre_tunnel2**.

```
(config)> add vpn iptunnel gre_tunnel2
(config vpn iptunnel gre_tunnel2)>
```

3. Set the local endpoint to the IPsec endpoint interface created in [task two] (**/network/interface/ipsec_endpoint2**).

```
(config vpn iptunnel gre_tunnel2)> local /network/interface/ipsec_
endpoint2
(config vpn iptunnel gre_tunnel2)>
```

4. Set the remote endpoint to the IP address of the GRE tunnel on Connect EZ 4 WS-1, **172.30.0.1**.

```
(config vpn iptunnel gre_tunnel2)> remote 172.30.0.1
(config vpn iptunnel gre_tunnel2)>
```

5. Save the configuration and apply the change.

```
(config vpn iptunnel gre_tunnel2)> save
Configuration saved.
>
```

Task four: Create an interface for the GRE tunnel device

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Click **Network** > **Interfaces**.
2. For **Add Interface**, type **gre interface2** and click **+**.



3. For **Zone**, select **Internal**.
4. For **Device**, select the GRE tunnel created in [illegible] (**tunnel: gre tunnel2**).



5. Click to expand **IPv4**.
6. For **Address**, type **172.31.0.2/30** for a virtual IP address on the GRE tunnel.



7. Click **Apply** to save the configuration and apply the change.

Command line

1. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

2. Add an interface named **gre interface2**.

```
(config)> add network interface gre_interface2
(config network interface gre_interface2)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Set the zone to **external**:

```
(config network interface gre_interface2)> zone external
(config network interface gre_interface2)>
```

4. Set the device to the GRE tunnel created in Task Three (**/vpn/tunnel/gre_tunnel2**):

```
(config network interface gre_interface2)> device /vpn/tunnel/gre_
tunnel2
(config network interface gre_interface2)>
```

5. Set **172.31.0.2/30** as the virtual IP address on the GRE tunnel:

```
(config network interface gre_interface2)> ipv4 address 172.31.0.2/30
(config network interface gre_interface2)>
```

6. Save the configuration and apply the change:

```
(config network interface gre_interface2)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Dynamic Multipoint VPN (DMVPN)

Dynamic Multipoint Virtual Private Network (DMVPN) is a dynamic tunneling form of a virtual private network (VPN), using a multi spoke-to-hub network in which the network addresses of the spoke routers do not need to be known, and therefore do not need to be configured in the hub router.

One advantage to this form of VPN is a scalable network in which the size of the hub configuration is minimized. When one spoke of the network needs to send traffic to another spoke, a direct transfer is possible without having to add any load onto the hub. This is achieved by the creation of a dynamic GRE tunnel directly to the other spoke. The network address of the target spoke is resolved with the use of Next Hop Resolution Protocol (NHRP).

This section contains the following topics:

Configure a DMVPN spoke 384

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure a DMVPN spoke

To configure a DMVPN spoke:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.


   

   The **Configuration** window is displayed.

3. Create an IP tunnel:

   a. Click **VPN > IP Tunnels**.


   b. In **Add IP Tunnel**, type the name of the tunnel and click **+**.

   c. For **Mode**, select **mGRE**.

   d. For **Local endpoint**, select the interface that will serve as the local endpoint of the tunnel.

   e. For **Key**, type a four-octet value that matches the key on the remote endpoint.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

i. (Optional) **Enable keep-alive reply** to enable the device to reply to Cisco GRE keep-alive packets.

ii. (Optional) **Enable open routing** to enable packets destined for an address which is not explicitly in the routing table to exit the IP tunnel.

4. Assign an IP address to the IP tunnel.

a. Click **Network** > **Interfaces**.

b. For **Add Interface**, type a name for the interface and click **+**.



c. For **Zone**, select **Internal**.

d. For **Device**, select the IP tunnel created above.

e. Click to expand **IPv4**.

f. For **Address**, type the IP address and netmask of the tunnel. The netmask must be set to /32.



5. Configure **NHRP**.

a. Click **Network** > **Routing Services**.

b. **Enable** routing services.

c. Click to expand **NHRP**.

d. **Enable** NHRP.

e. Click to expand **Network**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

f. Click + to add a network.



g. For **Interface**, select the interface created above.
h. For **Tunnel**, select the IP tunnel created above.
i. Click to expand **Next hop servers**.
j. Click + to add a server.
k. For **NBMA address**, type the hostname or IP address of the node that will be the next hop server.



6. To enable redirection of packets between spokes, configure OSPF routing.
   a. Click **Network** > **Routes** > **Routing services** > **OSPF**.
   b. **Enable** OSPF.
   c. For **ABR behavior**, choose the Area Border Router for the network.
   d. For **Reference bandwidth**, type the link bandwidth.
   e. **Enable** the Opaque-LSA standard.
   f. **Enable** the RFC1583 standard.
7. Configure the overlay connection.
   a. Click **Network** > **Routing services** > **BGP**.
   b. **Enable** BGP.
   c. For **AS number**, type the autonomous system number for this device.
   d. For **Best path criteria**, select **Multipath**.
   e. Click to expand **Neighbours**.
   f. Click + to add a neighbour.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

g. For **IP address**, type the IP address of the hub.

h. Click to toggle on **eBGP multihop**.



8. Repeat to add additional spokes.

9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Create an IP tunnel.
   a. Add an IP tunnel. For example, to add a tunnel named **dmvpn_tunnel**:

```
(config)> add vpn iptunnel dmvpn_tunnel
(config vpn iptunnel dmvpn_tunnel)>
```

   b. Set the type to multipoint:

```
(config vpn iptunnel dmvpn_tunnel)> type multipoint
(config vpn iptunnel dmvpn_tunnel)>
```

   c. Set the local interface:
      i. Use the ?to determine available interfaces.
      ii. Set the interface. For example:

```
(config vpn iptunnel dmvpn_tunnel)> local /network/interface/eth1
(config vpn iptunnel dmvpn_tunnel)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Set the key to a host-ordered value that matches the key on the remote endpoint. For example:

```
(config vpn iptunnel dmvpn_tunnel)> key 1.1.1.1
(config vpn iptunnel dmvpn_tunnel)>
```

e. (Optional) Enable the device to reply to Cisco GRE keepalive packets:

```
(config vpn iptunnel dmvpn_tunnel)> keepalive true
(config vpn iptunnel dmvpn_tunnel)>
```

f. (Optional) Enable the device to allow packets destined for an address which is not explicitly in the routing table to exit the IP tunnel:

```
(config vpn iptunnel dmvpn_tunnel)> open_routing true
(config vpn iptunnel dmvpn_tunnel)>
```

4. Assign an IP address to the IP tunnel:

a. Type `...` to return to the top level of the configuration schema:

```
(config vpn iptunnel dmvpn_tunnel)> ...
(config)>
```

b. Add a network interface. For example, to add an interface named dmvpn_tunnel_interface:

```
(config)> add network interface dmvpn_tunnel_interface
(config network interface dmvpn_tunnel_interface)>
```

c. Set the zone to **internal**:

```
(config network interface dmvpn_tunnel_interface)> zone internal
(config network interface dmvpn_tunnel_interface)>
```

d. Set the device to the IP tunnel created above:

```
(config network interface dmvpn_tunnel_interface)> device
/vpn/iptunnel/dmvpn_tunnel
(config network interface dmvpn_tunnel_interface)>
```

e. Set the IP address and netmask of the tunnel. The netmask must be set to /32. For example, to set the IP address to **10.20.1.4/32**:

```
(config network interface dmvpn_tunnel_interface)> ipv4 address
10.20.1.4/32
(config network interface dmvpn_tunnel_interface)>
```

5. Configure NHRP:

a. Type `...` to return to the top level of the configuration schema:

```
(config network interface dmvpn_tunnel_interface)> ...
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Enable routing services:

```
(config)> network route service enable true
(config)>
```

c. Enable NHRP:

```
(config)> network route service nhrp enable true
(config)>
```

d. Add an NHRP network:

```
(config)> add network route service nhrp network end
(config network route service nhrp network 0)>
```

e. Set the interface to the interface that was created above:

```
(config network route service nhrp network 0)> interface dmvpn_tunnel_
interface
(config network route service nhrp network 0)>
```

f. Set the tunnel to the IP tunnel created above:

```
(config network route service nhrp network 0)> tunnel
/vpn/iptunnel/dmvpn_tunnel
(config network route service nhrp network 0)>
```

g. Add a real hub server:

```
(config network route service nhrp network 0)> add nhs end
(config network route service nhrp network 0 nhs 0)>
```

6. Set the hostname or IP address of the node that will be the real hub server:

```
(config network route service nhrp network 0 nhs 0)> nbma hostname/IP_
address
(config network route service nhrp network 0 nhs 0)>
```

7. Configure OSPF routing:

```
(config network route service ospf)
(config)>
```

8. Configure the overlay connection using BGP:

a. Type .. to return to the top level of the configuration scheme:

```
(config network interface dmvpn_tunnel_interface)> ..
(config)>
```

b. Enable BGP:

```
(config)> network route service bgp enable true
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Set the autonomous system number for this device. For example, to set the autonomous system number to 65001:

```
(config)> network route service bgp asn 65001
(config)>
```

d. Set the best path criteria to multipath:

```
(config)> network route service bgp as_path multipath-relax
(config)>
```

e. Add a neighbour:

```
(config)> add network route service bgp neighbour end
(config network route service bgp neighbour 0)>
```

f. Set ip to the IP address of the hub. For example:

```
(config network route service bgp neighbour 0)> ip 10.20.1.3
(config network route service bgp neighbour 0)>
```

g. Enable eBGP multihop:

```
(config network route service bgp neighbour 0)> ebgp_multihop true
(config network route service bgp neighbour 0)>
```

h. Repeat to add additional spokes.

i. Save the configuration and apply the change:

```
(config)> save
Configuration saved.
>
```

ii. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

L2TP

Your Connect EZ 4 WS device supports L2TP (Layer 2 Tunneling Protocol).

Configure a PPP-over-L2TP tunnel

Your Connect EZ 4 WS device supports L2TP (Layer 2 Tunneling Protocol). The tunnel endpoints are known as L2TP Access Concentrators (LAC) and L2TP Network Servers (LNS). Each endpoint terminates the PPP session.

Required configuration items

- For L2TP access concentrators:
  - The hostname or IP address of the L2TP network server.
  - The firewall zone for the tunnel.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- For L2TP network servers:
  - The IP address of the L2TP access concentrator.
  - The local IP address assigned to the L2TP virtual network interface.
  - The IP address assigned to the remote peer.
  - The firewall zone for the tunnel.

Additional configuration items

- The UDP port that L2TP servers will listen on, if other than the default of **1701**.
- Access control for the L2TP tunnel.
- For L2TP access concentrators:
  - L2TP network server port.
  - The username and password of the L2TP server.
  - The metric for the tunnel.
  - Enable custom PPP configuration options for the tunnel.
    - Whether to override the default configuration and only use the custom options.
    - Optional configuration data in the format of a pppd options file.
- For L2TP network servers:
  - The Authentication method.
  - The metric for the tunnel.
  - Enable custom PPP configuration options for the tunnel.
    - Whether to override the default configuration and only use the custom options.
    - Optional configuration data in the format of a pppd options file.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The **Configuration** window is displayed.

3. Click **VPN** > **L2TP**.
4. (Optional) Type the **UDP listening port** that L2TP servers will listen on, if other than the default of **1701**.
5. Set the access control for L2TP tunnels:
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's service-types. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the service-types.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv6 address or network that can access the device's service-types. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 2001:db8::/48.
        - **any**: No limit to IPv6 addresses that can access the service-types.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the device:
     a. Click **Interfaces**.
     b. For **Add Interface**, click **+**.
     c. For **Interface**, select the appropriate interface from the dropdown.
     d. Click **+** again to allow access through additional interfaces.
   - To limit access based on firewall zones:
     a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
     b. For **Add Zone**, click **+**.
     c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
     d. Click **+** again to allow access through additional firewall zones.
6. To add an L2TP access concentrator:
   a. Click to expand **L2TP access concentrators**.
   b. For **Add L2TP access concentrator**, type a name for the LAC and click **+**.
   c. LACs are enabled by default. To disable, toggle off **Enable**.
   d. For **L2TP network server**, type the hostname or IP address of the L2TP network server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

e. (Optional) Type the **L2TP network server port** to use to connect to the server, if other than the default of **1701**.

f. (Optional) Type the **Username** to use to log into the server.

g. (Optional) Type the **Password** to use to log into the server.

h. (Optional) Type the **Metric** for the tunnel, if other than the default of **1**.

i. Select a firewall **Zone** for the tunnel. This is used by packet filtering rules and access control lists to restrict network traffic on the tunnel.

j. (Optional) Custom PPP configuration.

i. **Enable** custom PPP configuration.

ii. Enable **Override** if the custom configuration should override the default configuration and only use the custom options.

iii. For **Configuration file**, paste or type the configuration data in the format of a pppd options file.

7. To add an L2TP network server:

a. Click to expand **L2TP network servers**.

b. For **Add L2TP network server**, type a name for the LNS and click **+**.

c. LNSs are enabled by default. To disable, toggle off **Enable**.

d. For **L2TP access concentrator**, type the IP address of the L2TP access concentrator that this server will allow connections from. This can also be:

- A range of IP addresses, using the format x.x.x.x-y.y.y.y, for example **192.168.189.1-192.168.189.254**.
- The keyword **any**, which means that the server will accept connections from any IP address.

e. For **Local IP address**, type the IP address of the L2TP virtual network interface.

f. For **Remote IP address**, type the IP address to assign to the remote peer.

g. (Optional) For **Authentication method**, select one of the following:

- **None**: No authentication is required.
- **Automatic**: The device will attempt to connect using CHAP first, and then PAP.
- **CHAP**: Uses the Challenge Handshake Authentication Protocol (CHAP) to authenticate.
- **PAP**: Uses the Password Authentication Protocol (PAP) to authenticate.

If **Automatic**, **CHAP**, or **PAP** is selected, enter the **Username** and **Password** required to authenticate.

The default is **None**.

h. (Optional) For **Authentication method**, select the authentication method, one of:

- **None**: No authentication is required.
- **Automatic**: The device will attempt to connect using CHAP first, and then PAP.
- **CHAP**: Uses the Challenge Handshake Authentication Protocol (CHAP) to authenticate.
- **PAP**: Uses the Password Authentication Protocol (PAP) to authenticate.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **MS-CHAPv2**: Uses the Microsoft version of the Challenge Handshake Authentication Protocol (CHAP) to authenticate.
- If **Automatic**, **CHAP**, **PAP**, or **MS-CHAPv2** is selected, enter the **Username** and **Password** required to authenticate.
- The default is **None**.

i. (Optional) Type the **Metric** for the tunnel, if other than the default of 1.

j. Select a firewall **Zone** for the tunnel. This is used by packet filtering rules and access control lists to restrict network traffic on the tunnel.

k. (Optional) Custom PPP configuration.

i. **Enable** custom PPP configuration.

ii. Enable **Override** if the custom configuration should override the default configuration and only use the custom options.

iii. For **Configuration file**, paste or type the configuration data in the format of a pppd options file.

8. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. (Optional) Set the UDP listening port that L2TP servers will listen on:

```
(config)> vpn l2tp port value
(config)>
```

   where *value* is an integer between 1 and 65535. The default is 1701.

4. Set the access control for L2TP tunnels:
   - To limit access to specified IPv4 addresses and networks:

```
(config)> add vpn l2tp acl address=x.x.x.x value
(config)>
```

     Where *value* can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**: No limit to IPv4 addresses that can access the service type.

     Repeat this step to list additional IP addresses or networks.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to specified IPv6 addresses and networks:

```
(config)> add vpn l2tp acl address4 end value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IPv6 addresses that can access the service-type.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add vpn l2tp acl interface end value
(config)>
```

Where value is an interface defined on your device.

Display a list of available interfaces:

Use **... network interface ?** to display interface information:

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add vpn l2tp acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type **... firewall zone ?** at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------

------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

------------------------------------------------------------
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)>
```

Repeat this step to include additional firewall zones.

5. To add an L2TP access concentrator:

a. Add an LAC:

```
(config)> add vpn l2tp lac name
(config add vpn l2tp lac name)>
```

where name is the name of the LAC. For example, to add an LAC named lac_tunnel:

```
(config)> add vpn l2tp lac lac_tunnel
(config vpn l2tp lac lac_tunnel)>
```

LACs are enabled by default. To disable:

```
(config vpn l2tp lac lac_tunnel)> enable false
(config vpn l2tp lac lac_tunnel)>
```

b. Set the host name or IP address of the L2TP network server:

```
(config vpn l2tp lac lac_tunnel)> lns hostname
(config vpn l2tp lac lac_tunnel)>
```

c. (Optional) Set the UDP port to use to connect to the L2TP network server:

```
(config vpn l2tp lac lac_tunnel)> port int
(config vpn l2tp lac lac_tunnel)>
```

where int is an integer between 1 and 65535. The default is 1701.

d. (Optional) Set the username to use to log into the server:

```
(config vpn l2tp lac lac_tunnel)> username username
(config vpn l2tp lac lac_tunnel)>
```

e. (Optional) Set the password to use to log into the server:

```
(config vpn l2tp lac lac_tunnel)> password password
(config vpn l2tp lac lac_tunnel)>
```

f. (Optional) Set the metric for the tunnel:

```
(config vpn l2tp lac lac_tunnel)> metric int
(config vpn l2tp lac lac_tunnel)>
```

where int is an integer between 0 and 65535. The default is 1.

g. Set the firewall zone for the tunnel. This is used by packet filtering rules and access control lists to restrict network traffic on the tunnel.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

i. Use the ? to determine available zones:

```
(config vpn l2tp lac lac_tunnel)> zone ?

Zone: The firewall zone assigned to this tunnel. This can be used
by packet
filtering rules and access control lists to restrict network
traffic on this
tunnel.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup
Current value:

(config vpn l2tp lac lac_tunnel)>
```

ii. Set the zone:

```
(config vpn l2tp lac lac_tunnel)> zone zone
(config vpn l2tp lac lac_tunnel)>
```

h. (Optional) Custom PPP configuration:

i. Enable custom PPP configuration:

```
(config vpn l2tp lac lac_tunnel)> custom enable true
(config vpn l2tp lac lac_tunnel)>
```

ii. Enable overriding, if the custom configuration should override the default configuration and only use the custom options:

```
(config vpn l2tp lac lac_tunnel)> custom override true
(config vpn l2tp lac lac_tunnel)>
```

iii. Paste or type the configuration data in the format of a pppd options file:

```
(config vpn l2tp lac lac_tunnel)> custom config_file data
(config vpn l2tp lac lac_tunnel)>
```

8. To add an L2TP network server:

a. Add an LNS:

```
(config)> add vpn l2tp lns name
(config add vpn l2tp lac name)>
```

where name is the name of the LNS. For example, to add an LNS named lns_server:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> add vpn l2tp lns lns_server
(config vpn l2tp lns lns_server)>
```

LACs are enabled by default. To disable:

```
(config vpn l2tp lns lns_server)> enable false
(config vpn l2tp lns lns_server)>
```

b. Set the IP address of the L2TP access concentrator that this server will allow connections from:

```
(config vpn l2tp lns lns_server)> lac IP_address
(config vpn l2tp lns lns_server)>
```

This can also be:

- A range of IP addresses, using the format x.x.x.x-y.y.y.y, for example **192.168.168.1-192.168.168.254**.
- The keyword **any**, which means that the server will accept connections from any IP address.

c. Set the IP address of the L2TP virtual network interface:

```
(config vpn l2tp lns lns_server)> local_address IP_address
(config vpn l2tp lns lns_server)>
```

d. Set the IP address to assign to the remote peer:

```
(config vpn l2tp lns lns_server)> remote_address IP_address
(config vpn l2tp lns lns_server)>
```

e. (Optional) Set the authentication method:

```
(config vpn l2tp lns lns_server)> auth method
(config)>
```

where **method** is one of the following:

- **none**: No authentication is required.
- **auto**: The device will attempt to connect using CHAP first, and then PAP.
- **chap**: Uses the Challenge Handshake Authentication Protocol (CHAP) to authenticate.
- **pap**: Uses the Password Authentication Protocol (PAP) to authenticate.
- **mschapv2**: Uses the Microsoft version of the Challenge Handshake Authentication Protocol (CHAP) to authenticate.

If **auto**, **chap**, **pap** or **mschapv2** is selected, enter the **Username** and **Password** required to authenticate:

```
(config vpn l2tp lns lns_server)> username username
(config vpn l2tp lns lns_server)> password password
(config vpn l2tp lns lns_server)>
```

The default is **none**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

i. (Optional) Set the metric for the tunnel.

```
(config vpn l2tp 1>> 1>> 1>>_server)> metric int
(config vpn l2tp 1>> 1>> 1>>_server)>
```

where int is an integer between 0 and 65535. The default is 1.

g. Set the firewall zone for the tunnel. This is used by packet filtering rules and access control lists to restrict network traffic on the tunnel.

i. Use the ? to determine available zones.

```
(config vpn l2tp 1>> 1>>_server)> zone ?

Zone: The firewall zone assigned to this tunnel. This can be used
by packet
filtering rules and access control lists to restrict network
traffic on this
tunnel.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup
Current value:

(config vpn l2tp 1>> 1>>_server)>
```

ii. Set the zone.

```
(config vpn l2tp 1>> 1>>_server)> zone zone
(config vpn l2tp 1>> 1>>_server)>
```

h. (Optional) Custom PPP configuration.

i. Enable custom PPP configuration.

```
(config vpn l2tp 1ac 1nc 1>>_server)> custom enable true
(config vpn l2tp 1>> 1>>_server)>
```

ii. Enable overriding, if the custom configuration should override the default configuration and only use the custom options.

```
(config vpn l2tp 1>> 1>>_server)> custom override true
(config vpn l2tp 1>> 1>>_server)>
```

iii. Paste or type the configuration data in the format of a pppd options file.

```
(config vpn l2tp 1>> 1>>_server)> custom config_file data
(config vpn l2tp 1>> 1>>_server)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

7. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

L2TP with IPsec

L2TP is commonly used in conjunction with IPsec in transport mode (to provide security).

Your Connect EZ 4 WS supports L2TP with IPsec by configuring a transport-mode IPsec tunnel between the two endpoints, and then an L2TP tunnel with its LNS and LAC configured the same as the IPsec tunnel's endpoints. See Configure an IPsec tunnel for information about configuring an IPsec tunnel.

Note The Connect EZ 4 WS does not currently support the configuration of IPsec protocol/port traffic selectors. This means that you cannot restrict traffic on the IPsec tunnel to L2TP traffic (typically UDP port 1701).

While multiple L2TP clients are supported on the Connect EZ 4 WS by configuring a separate LNS for each client, multiple clients behind a Network Address Translation (NAT) device are not supported, because they will all appear to have the same IP address.

Show L2TP tunnel status

Web

Show the status of L2TP access connectors from the WebUI

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, select **Status** (under VPN), select **L2TP** > **Access Connectors**.

   The **L2TP Access Connectors** page appears.

2. To view configuration details about an L2TP access connector, click the (configuration) icon in the upper right of the tunnel's status pane.

Show the status of L2TP network servers from the WebUI

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, select **Status** (under VPN), select **L2TP** > **Network Servers**.

   The **L2TP Network Servers** page appears.

2. To view configuration details about an L2TP network server, click the (configuration) icon in the upper right of the tunnel's status pane.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Show the status of L2TP access connectors from the Admin CLI

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. To display details about all configured L2TP access connectors, type the following at the prompt:

```
> show l2tp tac

Name        Enabled  Status   Device
----------  -------  -------  ------------
tac_test1   true     up       test_device0
tac_test2   true     pending

>
```

3. To display details about a specific tunnel:

```
> show l2tp tac name tac_test2

tac_test2 L2TP Access Concentrator Status
-----------------------------------------
Enabled          : true
Status           : pending

>
```

4. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show the status of L2TP network servers from the Admin CLI

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. To display details about all configured L2TP access connectors, type the following at the prompt:

```
> show l2tp lns

Name        Enabled  Status   Device
----------  -------  -------  ------------
lns_test1   true     up       test_device0
lns_test2   true     pending

>
```

3. To display details about a specific tunnel:

```
> show l2tp tnx name tnx_test1

tnx_test1 L2TP Access Concentrator Status
-----------------------------------------
Enabled          : true
Status           : pending

>
```

4. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

L2TPv3 Ethernet

Your Connect EZ 4 WS device supports Layer 2 Tunneling Protocol Version 3 (L2TPv3) static unmanaged Ethernet tunnels.

Configure an L2TPv3 tunnel

Your Connect EZ 4 WS device supports Layer 2 Tunneling Protocol Version 3 (L2TPv3) static unmanaged Ethernet tunnels.

Required configuration items

- A name for the L2TPv3 tunnel.
- Enable the tunnel.
- The remote endpoint IP address.
- The local endpoint IP address.
- The session ID.
- The peer session ID.

Additional configuration items

- Encapsulation type. If UDP is selected:
  - The ID for the tunnel.
  - The ID of the peer's tunnel.
  - Determine whether to enable UDP checksum.
- The session cookie.
- The peer session cookie.
- The Layer2Specificheader type.
- The Sequence numbering control.

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN** > **L2TPv3 ethernet**.
4. For **Add L2TPv3 ethernet tunnel**, type a name for the tunnel and click **+**.
5. For **Remote endpoint**, type the IPv4 address of the remote endpoint.
6. For **Local endpoint**, select the interface that will be the local endpoint.
7. For **Tunnel ID**, type the tunnel identifier for this tunnel. This must match the value for **Peer tunnel ID** on the remote peer. Allowed value is any integer between 1 and 4294967295.
8. For **Peer tunnel ID**, type the **Tunnel ID** of the remote peer.
9. (Optional) For **Encapsulation type**, select either **UDP** or **IP**. If **UDP** is selected:
   a. For **UDP source port**, type the number of the source UDP port to be used for the tunnel.
   b. For **UDP destination port**, type the number of the destination UDP port to be used for the tunnel.
   c. (Optional) Click to enable **UDP checksum** to calculate and check the UDP checksum.
10. Click to expand **Sessions**.
    a. For **Add Session**, type a name for a session carried by the parent tunnel and click **+**.
    b. For **Session ID**, type the session identifier for this session. This must match the value for **Peer session ID** on the remote peer. Allowed value is any integer between 1 and 4294967295.
    c. For **Peer session ID**, type the **Session ID** of the remote peer.
    d. (Optional) For **Cookie**, type the cookie value to be assigned to the session. Allowed value is 8 or 16 hex digits.
    e. (Optional) For **Peer cookie**, type the **Cookie** value of the remote peer.
    f. For **Layer2SpecificHeader type**, select the Layer2Specific header type. This must match what is configured on the remote peer.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

g. For **Sequence numbering control**, determine the sequence number control to prevent or detect out of order packets. Allowed values are:
   - **None**: No sequence numbering.
   - **Send**: Add a sequence number to each outgoing packet.
   - **Receive**: Reorder packets if they are received out of order.
   - **Both**: Add a sequence number to each outgoing packet, and reorder packets if they are received out of order.

   The default is **None**.

h. Repeat for additional sessions.

11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Add a L2TPv3 Ethernet tunnel. For example, to add a tunnel named **L2TPv3_example**:

```
[config]> add vpn l2tpv3 L2TPv3_example
[config vpn l2tpeth L2TPv3_example]>
```

   The tunnel is enabled by default. To disable:

```
[config vpn l2tpeth L2TPv3_example]> enable false
[config vpn l2tpeth L2TPv3_example]>
```

4. Set the IPv4 address of the remote endpoint:

```
[config vpn l2tpeth L2TPv3_example]> remote IP_address
[config vpn l2tpeth L2TPv3_example]>
```

5. Set the interface of the local endpoint:
   i. Use the ?\0 to determine available interfaces.
   ii. Set the interface. For example:

```
[config vpn l2tpeth L2TPv3_example]> local /network/interface[eth1
[config vpn l2tpeth L2TPv3_example]>
```

6. Set the tunnel identifier for this tunnel. This must match the value for peer tunnel ID on the remote peer:

```
[config vpn l2tpeth L2TPv3_example]> tunnel_id value
[config vpn l2tpeth L2TPv3_example]>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is any integer between 1 and 4294967295.

7. Set the tunnel ID of the remote peer:

```
(config vpn l2tpeth L2TPv3_example)> peer_tunnel_id value
(config vpn l2tpeth L2TPv3_example)>
```

where value is any integer between 1 and 4294967295.

8. (Optional) Set the encapsulation type:

```
(config vpn l2tpeth L2TPv3_example)> encapsulation value
(config vpn l2tpeth L2TPv3_example)>
```

where value is either **udp** or **ip**. The default is **upd**.

If **udp** is set:

a. Set the source UDP port to be used for the tunnel:

```
(config vpn l2tpeth L2TPv3_example)> udp_source_port port
(config vpn l2tpeth L2TPv3_example)>
```

b. Set the destination UDP port to be used for the tunnel:

```
(config vpn l2tpeth L2TPv3_example)> udp_destination_port port
(config vpn l2tpeth L2TPv3_example)>
```

c. (Optional) to calculate and check the UDP checksum:

```
(config vpn l2tpeth L2TPv3_example)> udp_checksum true
(config vpn l2tpeth L2TPv3_example)>
```

9. Add a session carried by the parent tunnel:

```
(config vpn l2tpeth L2TPv3_example)> add session session_example
(config vpn l2tpeth L2TPv3_example session_example)>
```

10. Set the session identifier for this session. This must match the value for peer session ID on the remote peer.

```
(config vpn l2tpeth L2TPv3_example session_example)> session_id value
(config vpn l2tpeth L2TPv3_example session_example)>
```

where value is any integer between 1 and 4294967295.

11. Set the session ID of the remote peer:

```
(config vpn l2tpeth L2TPv3_example session_example)> peer_session_id
value
(config vpn l2tpeth L2TPv3_example session_example)>
```

where value is any integer between 1 and 4294967295.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

12. (Optional) Set the cookie value to be assigned to the session.

```
(config vpn l2tpeth L2TPv3_example session_example)> cookie value
(config vpn l2tpeth L2TPv3_example session_example)>
```

Allowed value is 8 or 16 hex digits.

13. (Optional) Set the cookie value of the remote peer.

```
(config vpn l2tpeth L2TPv3_example session_example)> peer cookie value
(config vpn l2tpeth L2TPv3_example session_example)>
```

Allowed value is 8 or 16 hex digits.

14. Set the Layer2Specific header type. This must match what is configured on the remote peer.

```
(config vpn l2tpeth L2TPv3_example session_example)> l2spec_type value
(config vpn l2tpeth L2TPv3_example session_example)>
```

where value is either **none** or **default**. The default is **default**.

15. Set the sequence number control to prevent or detect out of order packets.

```
(config vpn l2tpeth L2TPv3_example session_example)> seq value
(config vpn l2tpeth L2TPv3_example session_example)>
```

where value is one of:

- **none**: No sequence numbering.
- **send**: Add a sequence number to each outgoing packet.
- **recv**: Reorder packets if they are received out of order.
- **both**: Add a sequence number to each outgoing packet, and reorder packets if they are received out of order.

The default is **none**.

16. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

17. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show L2TPv3 tunnel status

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, select **Status**. Under VPN, select **L2TPv3 Ethernet**.

The **L2TPv3 Ethernet** page appears.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

2. To view configuration details about an L2TPv3 tunnel, click the (configuration) icon in the upper right of the tunnel's status pane.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. To display details about all configured L2TPv3 Ethernet tunnels, type the following at the prompt:

```
> show l2tpeth

Tunnel Session      Enabled  Device          Status
------------------  -------  --------------  ------
test/session/test   true     le_test_test    up

>
```

3. To display details about a specific tunnel:

```
> show l2tpeth name /vpn/l2tpeth/test/session/test

test/session/test Tunnel Session Status
---------------------------------------
Enabled                 : true
Status                  : up

Local IP                : 4.3.2.1
Remote IP               : 10.10.10.1
Tunnel ID               : 40964
Peer Tunnel ID          : 10.10.10.1 === 4.3.2.1
Session ID              : 255
Peer Session ID         : 5475
Lifetime (Actual)       : 3600

Device                  : le_test_test
RX Packets              : 3,183
RX Bytes                : 462
TX Packets              : 2,787
TX Bytes                : 3,128

>
```

4. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

MACsec

MACsec (Media Access Control Security) is a 802.1ae (Layer2) VPN protocol that can be used to create a secure MACsec tunnel over a wired Ethernet LAN. The MACsec uses keys to provide multiple authentications between hosts in a network.

A MACsec tunnel must be tied to a physical interface. You cannot create a MACsec tunnel for a bridge.

Security modes

Two security modes are available for a MACsec tunnel.

- **Automatic**: Uses a pre-shared key to generate association key information, which is periodically rotated through using 802.1x.
- **Manual**: Uses connectivity association key information that is manually entered in the **CAK** and **CKN** fields.

Configure a MACsec tunnel

Your Connect EZ 4 WS device supports MACsec (Layer 2 Tunneling Protocol).

Required configuration items

- The local network device to connect to the peer device.
- When using **Manual** mode, the connectivity association key and key name.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **VPN** > **MACsec**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. For **Add MACsec tunnel**, click **+**.
5. Click **Enable**.
6. For **Local endpoint**, select the local network device you want to use to connect to the peer device.
7. For **Security mode**, select your desired mode.
   - **Automatic**: Uses a pre-shared key to generate association key information, which is periodically rotated through using 802.1x.
   - **Manual**: Uses connectivity association key information that is manually entered in the **CAK** and **CKN** fields.
8. If you selected **Manual**, additional required fields display.
   a. For **CAK**, enter the connectivity associated key. The key format is 16 hex digits.
   b. For **CKN**, enter the connectivity associated key name. The key format is 32 hex digits.
9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Name the tunnel. At the config prompt, type:

```
(config)> add vpn macsec name
(config)>
```

   where **name** is a string.
4. Enable the tunnel:

```
(config vpn macsec tunnel1)> enable true
(config vpn macsec tunnel1)>
```

5. Specify the local endpoint:

```
(config vpn macsec tunnel1)> local value
(config vpn macsec tunnel1)>
```

   where **value** is one of the available options.
6. Specify the security mode:

```
(config vpn macsec tunnel1)> type value
(config vpn macsec tunnel1)>
```

   where **value** is one of the following:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **automatic**: Uses a pre-shared key to generate association key information, which is periodically rotated through using 802.1x.
- **manual**: Uses connectivity association key information that is manually entered.

7. If you specified the **manual** security mode, enter the connectivity association key and key name.
   a. Specify the connectivity association key:

   ```
   (config vpn macsec tunnel1) association cak value
   (config  vpn macsec tunnel1)#
   ```

   where **value** is the association key. The key format is 16 hex digits.
   b. Specify the connectivity association key name:

   ```
   (config vpn macsec tunnel1) association ckn value
   (config  vpn macsec tunnel1)#
   ```

   where **value** is the association key name. The key format is 32 hex digits.
8. Save the configuration and apply the change.

   ```
   (config)> save
   Configuration saved.
   >
   ```

9. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

WireGuard VPN

WireGuard is a VPN that is a protocol that operates at the network layer to provide communication between devices over a public network. It encrypts and encapsulates traffic to protect information. WireGuard supports full networking capabilities including standard, policy-based, and static routes, as well as firewalls. In addition to having it's inside the tunnel, like IPSec and OpenVPN, you can use this WireGuard tunnel for policy-based routing, send only certain traffic through the tunnel or use it for static routes to send routing and networking through regardless of the source IP. You can also have multiple tunnels.

There are two modes available when configuring a WireGuard VPN:

- **Client mode**: Configure the Connect EZ 4 WS device to act as a client, so it establishes an outbound WireGuard VPN tunnel to a remote server.
- **Server mode**: Configure the Connect EZ 4 WS device to act as a server, so one or more remote devices can establish an inbound WireGuard VPN tunnel to the device.

Configure the WireGuard VPN

Your Connect EZ 4 WS device supports using WireGuard VPN. You can configure the device for either client or server mode. For client mode, your Connect EZ 4 WS is establishing an outbound WireGuard VPN connection to the WireGuard server. For server mode, your Connect EZ 4 WS is acting as a

Virtual private networks

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

WireGuard server and accepts incoming WireGuard VPN connections from one or more client devices. Regardless of how you configure the device, you will need to to create a Wireguard tunnel and corresponding interface.

Before you begin

Decide whether you want your device to establish an outbound WireGuard VPN connection or if you want it to act as a WireGuard server. Each mode requires different information.

For client mode
You need the following information from the WireGuard server:

- Private key
- Remote endpoint address or hostname
- Remote endpoint port
- Remote endpoint public key
- Preshared key (optional)
- Local and remote IP addresses

For server mode
You need the following information:

- Client public key

  Note This key can come from the client device or you can generate it from the Digi device's Admin CLI console using the `wireguard generate [tunnel_name] [client_name]` command after configuring the Wireguard server settings on the Digi device.

- Preshared key (optional)
- Local and remote IP addresses

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

1. To create a WireGuard tunnel, navigate to **VPN** > **WireGuard** > **WireGuard tunnel**.
2. Click **+** to add a new WireGuard tunnel.
3. Type a name for the tunnel.
4. Click **OK**.

The settings for your new tunnel appear.

[illegible]	[illegible]
Enable	The new tunnel is enabled by default. It can be disabled if the tunnel is being set up for future use or if you want to stop the tunnel while testing other configuration changes.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Tunnel setting	Configuration
Peers	a. Click + to add a new peer. • If the Connect EZ 4 WS is the WireGuard client, then only add one peer. The peer is the remote Wireguard server to which it connects. • If the Connect EZ 4 WS is the WireGuard server, add one or more peers. The peer(s) are the remote WireGuard clients that will connect to this device. b. Configure the settings for the new peer (s). If the new peer is to act as the WireGuard server, make sure to configure the following settings: • [Remote] Public key • [Remote] Pre-shared key (optional) • [Remote] Allowed addresses: Only traffic destined for an IP address added here is sent to this peer. • [Remote] Endpoint address • [Remote] Endpoint port If the new peer is to act as a remote WireGuard client, make sure to configure the following settings: • [Client] Public key • [Client] Pre-shared key (optional) • [Local and Remote] Allowed addresses
Device managed private key	Enable to allow the Connect EZ 4 WS to generate its own public and private keys. If this setting is enabled, it triggers the Connect EZ 4 WS to automatically generate a private key and corresponding public key. This private and public key is used to establish the encrypted communication between the client and peer via the Wireguard tunnel. To see the public key, navigate to **Status > VPN > WireGuard**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Tunnel setting	UI configuration
Private key	Type the private key for the Wireguard tunnel. If the **Device managed private key** setting is disabled.
Endpoint port	The WireGuard connection value of **51820** is populated by default.

5. Modify the settings.
6. To create the WireGuard interface, navigate to **Network > Interfaces > Interface**.
7. Click **+** to add a new interface.
8. Type a name for the interface.
9. Click **OK**.
10. The settings for your new interface appear.

Tunnel setting	UI configuration
Enable	The new interface is enabled by default. It can be disabled if it is being set up for future use or if you want to stop using the interface while testing other configuration changes.
Zone	Select **External**.
Device	Select the device the interface will use, which is the new WireGuard tunnel you created.
IPv4	a. Click **IPv4** to expand the settings menu. b. For **Address**, type the IP address and netmask assigned to this interface (CIDR IPv4 address/netmask). For example, `10.200.200.1/24`. c. Click to expand **DNS servers**. d. Click **+** to add a new DNS server. e. For DNS Server, type the IP address of the DNS server (CIDR IPv4 address). For example, `10.200.200.1`.

11. Click **Apply** to save the new configuration settings.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Save the configuration and apply the change:

```
(config vpn tptunnel gre_example)> save
Configuration saved.
>
```

4. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

5. At the command line, type **VPN** to enter configuration mode for VPN:

```
> config vpn
(config vpn)>
```

6. Type **wireguard** to enter configuration mode for WireGuard:

```
> config vpn wireguard
(config vpn wireguard)>
```

7. The table below lists the required settings for creating and configuring a client WireGuard tunnel.

Configuration	Description

add	Add a new WireGuard tunnel.
	`> config vpn wireguard add name`
	`(config)>`
	Where **name** is the name of the new WireGuard tunnel. For example, **nextunnel**.

enable	The WireGuard tunnel is enabled by default. You may want to temporarily disable the tunnel while it is being set up for future use, or if you want to stop the tunnel while testing other configuration changes.
	To disable:
	`(config)> vpn wireguard name enable false`
	`(config)>`
	To enable:
	`(config)> vpn wireguard name enable true`
	`(config)>`

peer	a. Determine if the Connect EZ 4 WS will act as a client or server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- If this Connect EZ 4 WS is the WireGuard client, then only add one peer. The peer is the remote Wireguard server to which it connects.
- If this Connect EZ 4 WS is the WireGuard server, add one or more peers. The peer(s) are the remote WireGuard clients that will connect to this device.

b. Create the peer(s).

```
(config)> vpn wireguard name add peer
(config)>
```

For a peer that acts as the remote Wireguard server, configure the following settings:

- [Remote] Device managed public key

```
(config vpn wireguard [name])> generate

Parameters:
tunnel          Tunnel Name (Required)
peer            Peer (Required)
```

- [Remote] Public key

```
(config)> vpn wireguard name peer public_key
(config)>
```

- [Remote] Pre-shared key (optional)

```
(config)> vpn wireguard name peer psk
(config)>
```

- [Remote] Allowed addresses: Only traffic destined for an IP address added here will be sent to this peer.

```
(config)> vpn wireguard name peer overlay
(config)>
```

- [Remote] Endpoint address

```
(config)> vpn wireguard name peer endpoint
(config)>
```

- [Remote] Endpoint port

```
(config)> vpn wireguard name peer port
(config)>
```

For a peer(s) that acts as the remote WireGuard client, configure the following settings:

- [Client] Public key

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

	(config)> vpn wireguard name peer public_key (config)> • [Client] Pre-shared key (optional) (config)> vpn wireguard name peer psk (config)> • [Local and Remote] Allowed addresses
autogenerate	Enable to allow the Connect EZ 4 WS to generate its own public and private keys. If this setting is enabled, it triggers the Connect EZ 4 WS to automatically generate a private key and corresponding public key. To enable: > config vpn wireguard add name autogenerate true (config)> To disable: > config vpn wireguard add name autogenerate false (config)>
port	The WireGuard connection value of **51820** is populated by default. (config)> vpn wireguard name port (config)>
private-key	Type the private key for the Wireguard tunnel, if the **Device managed private key** setting is disabled. > config vpn wireguard add name private key value (config)> With value being a 32-byte string encoded in base-64.

8. The table below lists the required settings for creating and configuring a new interface.

Configuration	Description
add	Add a new interface. > (config network interface) > add name (config)> Where **name** is the name of the new interface. For example, add **newWGtunnel1**.
enable	The interface is enabled by default. You may want to temporarily disable the tunnel while it is being set up, for future use, or if you want to stop the tunnel while testing other configuration

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

	changes.
	To disable:
	`(config network interface ) > name enable false`
	`(config)>`
	To enable:
	`(config network interface) > name enable true`
	`(config)>`
	Where name is the name of the new interface.

zone	Set the zone to external.
	`(config network interface [name]) > zone external`
	`(config)>`

device	Add the network device used by this interface.
	`(config network interface [name]) > device /vpn/wireguard/`
	`[name]`
	For example, device /vpn/wireguard/newWGtunnel1.

IPv4	a. Add the address and netmask assigned to this interface.
	`config network interface [name] ipv4 > address IPv4_`
	`[IPaddress]/[netmask]`
	For example, ipv4_10.100.200.1/24.
	b. Add the IP address of the DNS server.
	`(config network interface [name] ipv4) > dns`
	`(config network interface [name] ipv4 dns) > ipv4_`
	`[address]_`
	Address is the IP address of the DNS server.
	For example, ipv4_10.100.200.1.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services

This chapter contains the following topics:

Allow remote access for web administration and SSH 431
Configure the web administration service 434
Configure SSH access 443
Use SSH with key authentication 451
Configure telnet access 457
Configure DNS 458
Simple Network Management Protocol (SNMP) 460
Location information 472
Modbus gateway 475
System time synchronization 477
Network Time Protocol 484
Configure a multicast route 487
Ethernet network bonding 494
Enable service discovery (mDNS) 508
Use the IPerf service 511
Configure the ping responder service 516

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Allow remote access for web administration and SSH

By default, only devices connected to the Connect EZ 4 WS's LAN have access to the device via web administration and SSH. To enable these services for access from remote devices:

- The Connect EZ 4 WS device must have a publicly reachable IP address.
- The **External** firewall zone must be added to the web administration or SSH service. See Firewall configuration for information on zones.
- See Set the idle timeout for Connect EZ 4 WS users for information about setting the inactivity timeout for the web administration and SSH services.

To allow web administration or SSH for the External firewall zone:

Add the External firewall zone to the web administration service

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **Web administration** > **Access Control List** > **Zones**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Allow remote access for web administration and SSH.

4. For **Add Zone**, click **+**.

5. Select **external**.



6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Add the external zone to the web administration service.

```
(config)> add service web_admin acl zone end external
(config)>
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Add the External firewall zone to the SSH service

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Allow remote access for web administration and SSH.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.


   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Configuration** > **Services** > **SSH** > **Access Control List** > **Zones**.
4. For **Add Zone**, click **+**.

5. Select **External**.

   
6. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add the **internal** zone to the SSH service:

```
(config)> add service ssh acl zone end external
(config)>
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the web administration service

The web administration service allows you to monitor and configure the Connect EZ 4 WS device by using the WebUI, a browser-based interface.

By default, the web administration service is enabled and uses the standard HTTPS port, 443. The default access control for the service uses the **Internal** firewall zone, which means that only devices connected to the Connect EZ 4 WS's LAN can access the WebUI. If this configuration is sufficient for your needs, no further configuration is required. See Allow remote access for web administration and SSH for information about configuring the web administration service to allow access from remote devices.

Required configuration items

- The web administration service is enabled by default.
- Configure access control for the service.

Additional configuration items

- Port to use for web administration service communication.
- Multicast DNS (mDNS) support.
- An SSL certificate to use for communications with the service.
- Support for legacy encryption protocols.

See Set the idle timeout for Connect EZ 4 WS users for information about setting the inactivity timeout for the web administration services.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Enable or disable the web administration service

The web administration service is enabled by default. To disable the service, or enable it if it has been disabled:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in User Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **Web administration**.
4. Click **Enable**.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable or disable the web administration service:
   - To enable the service:

```
(config)> service web_admin enable true
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To disable the service:

```
(config)> service web_admin enable false
(config)>
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the service

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

b. Click the **Device ID**.

c. Click **Settings**.

d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Services** > **Web administration**.
4. (Optional) For **Port**, enter the port number for the service. Normally this should not be changed.
5. Click **Access control list** to configure access control.
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's web administration service. Allowed values are:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- **any**: No limit to IPv4 addresses that can access the web administration service.

d. Click ✚ again to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:
  a. Click **IPv6 Addresses**.
  b. For **Add Address**, click ✚.
  c. For **Address**, enter the IPv6 address or network that can access the device's web administration service. Allowed values are:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:cbd:../48.
     - **any**: No limit to IPv6 addresses that can access the web administration service.
  d. Click ✚ again to list additional IP addresses or networks.
- To limit access to hosts connected through a specified interface on the device:
  a. Click **Interfaces**.
  b. For **Add Interface**, click ✚.
  c. For **Interface**, select the appropriate interface from the dropdown.
  d. Click ✚ again to allow access through additional interfaces.
- To limit access based on firewall zones:
  a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
  b. For **Add Zone**, click ✚.
  c. For **Zone**, select the appropriate firewall zone from the dropdown.
  See Firewall configuration for information about firewall zones.
  d. Click ✚ again to allow access through additional firewall zones.

8. Multicast DNS (mDNS) is enabled by default. mDNS is a protocol that resolves host names in small networks that do not have a DNS server. To disable mDNS, or enable it if it has been disabled, click **Enable mDNS**.
9. For **SSL certificate**, if you have your own signed SSL certificate, paste the certificate and private key. If **SSL certificate** is blank, the device will use an automatically-generated, self-signed certificate.
   - The SSL certificate and private key must be in PEM format.
   - The private key can use one of the following algorithms:
     - RSA
     - DSA
     - ECDSA
     - EDDH

     Note Password-protected certificate keys are not supported.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Example:

a. Generate the SSL certificate and private key, for example:

```
# openssl req -newkey rsa:1048 -nodes -keyout key.pem -x509 -days 365
-out certificate.pem
```

b. Paste the contents of **certificate.pem** and **key.pem** into the **SSL certificate** field. The contents of the **certificate.pem** must be first. For example:



8. **View** is set to **Auto** by default and normally should not be changed.
9. **Legacy port redirection** is used to redirect client HTTP requests to the HTTPS service. Legacy port redirection is enabled by default, and normally these settings should not be changed. To disable legacy port redirection, click to expand **Legacy port redirection** and deselect **Enable**.
10. For **Maximum TLS version**, select the maximum TLS version that can be used by client to negotiate the HTTPS session.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Configure access control:
   - To limit access to specified IPv4 addresses and networks:

```
(config)> add service web_admin acl address <ip value>
(config)>
```

   Where **value** can be:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- **any**: No limit to IPv4 addresses that can access the web administration service.

Repeat this step to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:

```
(config)> add service web_admin acl addresses6 end value
(config)>
```

Where **value** can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IPv6 addresses that can access the web administration service.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add service web_admin acl interface end value
(config)>
```

Where **value** is an interface defined on your device.

Display a list of available interfaces:

Use **_ network interface** ?to display interface information.

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add service web_admin acl zone end value
(config)>
```

Where **value** is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type **_ firewall zone ?**at the config prompt.

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------
  ------------------------
    any
    dynamic_routes
    edge
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
  external
  internal
  ipsec
  loopback
  setup

[config]>
```

Repeat this step to include additional firewall zones.

4. (Optional) If you have your own signed SSL certificate, set the certificate and private key by pasting their contents into the **service web admin cert** command. Enclose the certificate and private key contents in quotes (").

```
[config]> service web_admin cert "<cert-and-private-key"
[config]>
```

- If **SSL certificate** is blank, the device will use an automatically-generated, self-signed certificate.
- The SSL certificate and private key must be in PEM format.
- The private key can use one of the following algorithms:
  - RSA
  - DSA
  - ECDSA
  - ECDH

Note Password-protected certificate keys are not supported.

Example

a. Generate the SSL certificate and private key, for example:

```
# openssl req -newkey rsa:2048 -nodes -keyout key.pem -x509 -days 365
-out certificate.pem
```

b. Paste the contents of **certificate.pem** and **key.pem** into the **service web admin cert** command. Enclose the contents of **certificate.pem** and **key.pem** in quotes. For example:

```
(config)> service web_admin cert "-----BEGIN CERTIFICATE-----
MIIGdTCCBN2gAwIBAgIUL3wmzpbnQmTCVpT9tswCfvBkWQwDQYJKoZIhvcNAQEL
BQAwgYsxCzAJBgNVBAYTAlVTMQswCQYDVQQIDAJPcmVnb24xETAPBgNVBAcMCEJl
bGxhaWRnZTEVMBMGA1UECgwMVGVzc2VyYWN0LCBJbmMuMRIwEAYDVQQLDAlTb2Z0
d2FyZSBUZWFtMRIwEAYDVQQDDAlsb2NhbGhvc3QxKTAnBgkqhkiG9w0BCQEWGnN1
cHBvcnRAdGVzc2VyYWN0LmNvbTAeFw0yNTA3MDkxNTU1MjBaFw0yNjA3MDkxNTU1
MjBaMIGLMQswCQYDVQQGEwJVUzEOMAwGA1UECAwFT3JlZ29uMREwDwYDVQQHDAhC
ZWxsYWlyZ2UxFTATBgNVBAoMDFRlc3NlcmFjdCwgSW5jLjESMBAGA1UECwwJU29m
dHdhcmUgVGVhbTESMBAGA1UEAwwJbG9jYWxob3N0MSkwJwYJKoZIhvcNAQkBFhpz
dXBwb3J0QHRlc3NlcmFjdC5jb20wggEiMA0GCSqGSIb3DQEBAQUAA4IBDwAwggEK
AoIBAQCqGRADBnsGAGGLUDGp1Yt4MZgbbTwNwDCYGeIIDGIIgHt/+hLVBIIiwVv
iJDgiuNVxIwwBvlvIPNDJGtryEIXxBZdQ8hwt/cRyN14vrIDkjGDrVbb/NdTWLIw
2zcMeT+jzDyUKtmbGpcWs+tuAzFTjbMfNIzwGpbBfrL+5tcIdIjnCAIuYqBEhfIa
kxyGs4MOdyTUsFNZtbaBaIIjejG+lkcc+eIIbAWtbWtDIoN+NUHtvQyCuwIYw/
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
...
-----END CERTIFICATE-----
-----BEGIN PRIVATE KEY-----
...
-----END PRIVATE KEY-----"
(config)#
```

5. (Optional) Configure Multicast DNS (mDNS)

mDNS is a protocol that resolves host names in small networks that do not have a DNS server. mDNS is enabled by default. To disable mDNS or enable it if it has been disabled:

- To enable the mDNS protocol:

```
(config)# service web_admin mdns enable true
(config)#
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To disable the mDNS protocol:

```
(config)> service web_admin mdns enable false
(config)>
```

6. (Optional) Set the port number for this service.

   The default setting of 443 normally should not be changed.

```
(config)> service web_admin port 444
(config)>
```

7. (Optional) Set the minimum TLS version that can be used by client to negotiate the HTTPS session.

```
(config)> service web_admin legacy_encryption value
(config)>
```

   where *value* is one of:

   - TLS-1.1
   - TLS-1.2
   - TLS-1.3

   The default is TLS-1.2.

8. (Optional) Disable legacy port redirection.

   Legacy port redirection is used to redirect client HTTP requests to the HTTPS service. Legacy port redirection is enabled by default, and normally these settings should not be changed.

   To disable legacy port redirection:

```
(config)> service web_admin legacy enable false
(config)>
```

9. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

10. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure SSH access

The Connect EZ 4 WS's default configuration has SSH access enabled, and allows SSH access to the device from authorized users within the **Internal** firewall zone. If this configuration is sufficient for your needs, no further configuration is required. See Allow remote access for web administration and SSH for information about configuring the SSH service to allow access from remote devices.

Required configuration items

- Enable SSH access.
- Configure access control for the SSH service.

Additional configuration items

- Port to use for communications with the SSH service.
- Multicast DNS (mDNS) support.
- A private key to use for communications with the SSH service.
- Create custom SSH configuration settings.

See Set the idle timeout for Connect EZ 4 WS users for information about setting the inactivity timeout for the SSH service.

Enable or disable the SSH service

The SSH service is enabled by default. To disable the service, or enable it if it has been disabled:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click **Services** > **SSH**.
4. Click **Enable**.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable or disable the SSH service:
   - To enable the service:

```
(config)> service ssh enable true
(config)>
```

   - To disable the service:

```
(config)> service ssh enable false
(config)>
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the service

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:
   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Services** > **SSH**.
4. (Optional) For **Port**, enter the port number for the service. Normally this should not be changed.
5. Click **Access control list** to configure access control.
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's SSH service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the SSH service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv6 address or network that can access the device's SSH service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 2001:cbd:/48.
        - **any**: No limit to IPv6 addresses that can access the SSH service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the device:
     a. Click **Interfaces**.
     b. For **Add Interface**, click **+**.
     c. For **Interface**, select the appropriate interface from the dropdown.
     d. Click **+** again to allow access through additional interfaces.
   - To limit access based on firewall zones:
     a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
     b. For **Add Zone**, click **+**.
     c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Click ✚ again to allow access through additional firewall zones.

6. Multicast DNS (mDNS) is enabled by default. mDNS is a protocol that resolves host names in small networks that do not have a DNS server. To disable mDNS, or enable it if it has been disabled, click **Enable mDNS**.
7. For **Private key**, type the private key in PEM format. If **Private key** is blank, the device will use an automatically-generated key.
8. To create custom SSH configuration settings:
   a. Click to expand **Custom configuration**.
   b. Click **Enable**.
   c. For **Override**:
      - If **Override** is enabled, entries in **Configuration file** will be used in place of the standard SSH configuration.
      - If **Override** is not enabled, entries in **Configuration file** will be added to the standard SSH configuration.
   d. For **Configuration file**, type configuration settings in the form of an OpenSSH sshd_config file.

      For example, to enable the diffie-hellman-group-sha-14 key exchange algorithm:
      i. Click **Enable** to enable SSH custom configuration.
      ii. Leave **Override** disabled.
      iii. For **Configuration file**, type the following:

```
KexAlgorithms +diffie-hellman-group14-sha1
```

9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Configure access control:
   - To limit access to specified IPv4 addresses and networks:

```
(config)> add service ssh acl address_and_value
(config)>
```

   Where **value** can be:
   - A single IP address or host name.
   - A network designation in CIDR notation, for example, 192.168.1.0/24.
   - **any**. No limit to IPv4 addresses that can access the SSH service.

   Repeat this step to list additional IP addresses or networks.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to specified IPv6 addresses and networks:

```
(config)> add service ssh acl address1 end value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IPv6 addresses that can access the SSH service.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add service ssh acl1 to=interface end value
(config)>
```

Where value is an interface defined on your device.

Display a list of available interfaces:

Use **... network interface ?** to display interface information:

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add service ssh acl1 zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type **... firewall zone ?** at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

 Additional Configuration
 ------------------------------------------------------------

------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

------------------------------------------------------------
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)>
```

Repeat this step to include additional firewall zones.

4. (Optional) Set the private key in PEM format. If not set, the device will use an automatically-generated key.

```
(config)> service ssh key key.pem
(config)>
```

5. (Optional) Configure Multicast DNS (mDNS)

mDNS is a protocol that resolves host names in small networks that do not have a DNS server. mDNS is enabled by default. To disable mDNS or enable it if it has been disabled:

- To enable the mDNS protocol:

```
(config)> service ssh mdns enable true
(config)>
```

- To disable the mDNS protocol:

```
(config)> service ssh mdns enable false
(config)>
```

6. (Optional) Set the port number for this service.

The default setting of 22 normally should not be changed.

```
(config)> service ssh port 24
(config)>
```

7. To create custom SSH configuration settings:

a. Enable custom configurations:

```
(config)> service ssh custom enable true
(config)>
```

b. To override the standard SSH configuration and only use the **config file** parameter:

```
(config)> service ssh custom override true
(config)>
```

- If **override** is set to **true**, entries in **Configuration file** will be used in place of the standard SSH configuration.
- If **override** is set to **false**, entries in **Configuration file** will be added to the standard SSH configuration.

The default is **false**.

c. Set the configuration settings:

```
(config)> service ssh custom config_file value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is one or more entries in the form of an OpenSSH sshd_config file. For example, to enable the diffie-hellman-group-sha-14 key exchange algorithm:

```
(config)> service ssh custom config_file "KexAlgorithms +diffie-
hellman-group14-sha1"
(config)>
```

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use SSH with key authentication

Rather than using passwords, you can use SSH keys to authenticate users connecting via SSH. SSH keys provide security and scalability.

- **Security**. Using SSH keys for authentication is more secure than using passwords. Unlike a password that can be guessed by an unauthorized user, SSH key pairs provide more sophisticated security. A public key configured on the Connect EZ device is paired with a private key on the user's PC. The private key, once generated, remains on the user's PC.
- **Scalability**. SSH keys can be used on more than one Connect EZ device.

Generating SSH key pairs

On a Microsoft Windows PC, you can generate SSH key pairs using a terminal emulator application, such as PuTTY or Tera Term.

On a Linux host, an SSH key pair is usually created automatically in the user's .ssh directory. The private and public keys are named id_rsa and id_rsa.pub. If you need to generate an SSH key pair, you can use the ssh-keygen application.

For example, the following entry generates an RSA key pair in the user's .ssh directory:

```
ssh-keygen -t rsa -f ~/.ssh/id_rsa
```

The private key file is named id_rsa and the public key file is named id_rsa.pub. (The .pub extension is automatically appended to the name specified for the private key output file.)

Required configuration items

- Name for the user
- SSH public key for the user

Additional configuration items

- If you want to access the Connect EZ device using SSH over a LAN interface, configure the access control list for the SSH service to allow SSH access for the **Edge** firewall zone.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Authentication** > **Users**.
4. Select an existing user or create a new user. See [illegible] for information about creating a new user.
5. Click **SSH keys**.
6. In **Add SSH key**, enter a name for the SSH key and click **+**.
7. Enter the public SSH key by pasting or typing a public encryption key that this user can use for passwordless SSH login.
8. Click **Apply** to save the configuration and apply the change.

Command line

You can also configure passwordless SSH login for an existing user or include the support when creating a new user. See [illegible] for information about creating a new user. These instructions assume an existing user named **temp_user**.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add an SSH key for the user by using the ssh_key command and pasting or typing a public encryption key:

```
(config)> add auth user marta ssh_key key_name key
(config)>
```

where:

- **key_name** is a name for the key.
- **key** is a public SSH key, which you can enter by pasting or typing a public encryption key that this user can use for passwordless SSH login.

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Use SSH with key authentication

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure telnet access

By default, the telnet service is disabled.

Note Telnet is an insecure protocol and should only be used for backward-compatibility reasons, and only if the network connection is otherwise secured.

Required configuration items

- Enable telnet access.
- Configure access control for the telnet service.

Additional configuration items

- Port to use for communications with the telnet service.
- Multicast DNS (mDNS) support.

See Set the idle timeout for Command Line (CLI) sessions for information about setting the inactivity timeout for the telnet service.

Enable the telnet service

The telnet service is disabled by default. To enable the service:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The Configuration window is displayed.
3. Click **Services > telnet**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Click **Enable**.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Enable the telnet service:

```
[config]> service telnet enable true
[config]>
```

4. Save the configuration and apply the change.

```
[config]> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure the service

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Services** > **telnet**.
4. (Optional) For **Port**, enter the port number for the service. Normally this should not be changed.
5. Click **Access control list** to configure access control:
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's telnet service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the telnet service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv6 address or network that can access the device's telnet service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 2001:db8::/48.
        - **any**: No limit to IPv6 addresses that can access the telnet service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the device:
     a. Click **Interfaces**.
     b. For **Add Interface**, click **+**.
     c. For **Interface**, select the appropriate interface from the dropdown.
     d. Click **+** again to allow access through additional interfaces.
   - To limit access based on firewall zones:
     a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
     b. For **Add Zone**, click **+**.
     c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
     d. Click **+** again to allow access through additional firewall zones.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Multicast DNS (mDNS) is disabled by default. mDNS is a protocol that resolves host names in small networks that do not have a DNS server. To enable mDNS, click **Enable mDNS**.
9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Configure access control:
   - To limit access to specified IPv4 addresses and networks:

```
(config)> add service telnet acl address end value
(config)>
```

     Where **value** can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**. No limit to IPv4 addresses that can access the telnet service.

     Repeat this step to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:

```
(config)> add service telnet acl address end value
(config)>
```

     Where **value** can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:cdba::/48.
     - **any**. No limit to IPv6 addresses that can access the telnet service.

     Repeat this step to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add service telnet acl interface end value
(config)>
```

     Where **value** is an interface defined on your device.

     Display a list of available interfaces:

     Use **_ network interface** *?* to display interface information:

     Repeat this step to list additional interfaces.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access based on firewall zones:

```
(config)> add service telnet acl zone <value>
(config)>
```

Where <value> is a firewall zone defined on your device, or the any keyword.

Display a list of available firewall zones:

Type ... firewall zone ? at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------
  ------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

4. (Optional) Configure Multicast DNS (mDNS)

mDNS is a protocol that resolves host names in small networks that do not have a DNS server. mDNS is disabled by default. To enable:

```
(config)> service telnet mdns enable true
(config)>
```

5. (Optional) Set the port number for this service.

The default setting of 23 normally should not be changed.

```
(config)> service telnet port 23
(config)>
```

6. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure DNS

The Connect EZ 4 WS device includes a caching DNS server which forwards queries to the DNS servers that are associated with the network interfaces, and caches the results. This server is used within the device, and cannot be disabled. Use the access control list to restrict external access to this server.

Required configuration items

- Configure access control for the DNS service.

Additional configuration items

- Whether the device should cache negative responses.
- Whether the device should always perform DNS queries to all available DNS servers.
- Whether to prevent upstream DNS servers from returning private IP addresses.
- Additional DNS servers, in addition to the ones associated with the device's network interfaces.
- Specific host names and their IP addresses.

  The device is configured by default with the host name **digi.device**, which corresponds to the 192.168.210.1 IP address.

To configure the DNS server:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Services** > **DNS**.
4. Click **Access control list** to configure access control:
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's DNS service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the DNS service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv6 address or network that can access the device's DNS service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 2001:db8::/48.
        - **any**: No limit to IPv6 addresses that can access the DNS service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the device:
     a. Click **Interfaces**.
     b. For **Add Interface**, click **+**.
     c. For **Interface**, select the appropriate interface from the dropdown.
     d. Click **+** again to allow access through additional interfaces.
   - To limit access based on firewall zones:
     a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
     b. For **Add Zone**, click **+**.
     c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
     d. Click **+** again to allow access through additional firewall zones.
5. (Optional) **Cache negative responses** is enabled by default. Disabling this option may improve performance on networks with transient DNS results, when one or more DNS servers may have positive results. To disable, click to toggle off **Cache negative responses**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. (Optional) **Query all servers** is enabled by default. This option is useful when only some DNS servers will be able to resolve hostnames. To disable, click to toggle off **Query all servers**.
9. (Optional) **Rebind protection**: If enabled, prevents upstream DNS servers from returning private IP addresses. To enable, click **Rebind protection**.
10. (Optional) **Allow localhost rebinding** is enabled by default if **Rebind protection** is enabled. This is useful for Real-time Black List (RBL) servers.
11. (Optional) Type the IP address of the **fallback server**. This is a DNS server to be used in the absence of any other server. The default is **8.8.8.8**.
12. (Optional) To add additional DNS servers:
    a. Click **DNS servers**.
    b. For **Add Server**, click **+**.
    c. (Optional) Enter a label for the DNS server.
    d. For **DNS server**, enter the IP address of the DNS server.
    e. **Domain** restricts the device's use of this DNS server based on the domain. If no domain are listed, then all queries may be sent to this server.
13. (Optional) To add host names and their IP addresses that the device's DNS server will resolve:
    a. Click **Additional DNS hostnames**.
    b. For **Add Host**, click **+**.
    c. Type the **IP address** of the host.
    d. For **Name**, type the host name.
14. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Configure access control:
   - To limit access to specified IPv4 addresses and networks:

```
(config)> add service dns acl address_and_value
(config)>
```

   Where **value** can be:
   - A single IP address or host name.
   - A network designation in CIDR notation, for example, 192.168.1.0/24.
   - **any**: No limit to IPv4 addresses that can access the DNS service.

   Repeat this step to list additional IP addresses or networks.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to specified IPV6 addresses and networks:

```
(config)> add service dns acl address1 ext value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**: No limit to IPV6 addresses that can access the DNS service.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add service dns acl1 ext1interface ext2 value
(config)>
```

Where value is an interface defined on your device.

Display a list of available interfaces:

Use **... network interface ?** to display interface information:

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add service dns acl1 zone ext2 value
(config)>
```

Where value is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type **... firewall zone ?** at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------

------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

------------------------------------------------------------
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)>
```

Repeat this step to include additional firewall zones.

4. (Optional) Cache negative responses

By default, the device's DNS server caches negative responses. Disabling this option may improve performance on networks with transient DNS results, when one or more DNS servers may have positive results. To disable:

```
(config)> service dns cache_negative_responses false
(config)>
```

5. (Optional) Query all servers

By default, the device's DNS server queries all available DNS servers. Disabling this option may improve performance on networks with transient DNS results, when one or more DNS servers may have positive results. To disable:

```
(config)> service dns query_all_servers false
(config)>
```

6. (Optional) Rebind protection

By default, rebind protection is disabled. If enabled, this prevents upstream DNS servers from returning private IP addresses. To enable:

```
(config)> service dns stop_dns_rebind false
(config)>
```

7. (Optional) Allow localhost rebinding

By default, localhost rebinding is enabled by default if rebind protection is enabled. This is useful for Real-time Black List (RBL) servers. To disable:

```
(config)> service dns rebind_localhost_ok false
(config)>
```

8. (Optional) Fallback server

Configure the IP address of the DNS server to be used in the absence of any other server. The default is 8.8.8.8.

```
(config)> service dns fallback_server value
(config)>
```

9. (Optional) Add additional DNS servers

a. Add a DNS server:

```
(config)> add service dns server end
(config service dns server 6)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Set the IP address of the DNS server:

```
(config service dns server 0)> address ip-addr
(config service dns server 0)>
```

c. To restrict the device's use of this DNS server based on the domain, use the **domain** command. If no domain are listed, then all queries may be sent to this server.

```
(config service dns server 0)> domain domain
(config service dns server 0)>
```

d. (Optional) Set a label for this DNS server:

```
(config service dns server 0)> label label
(config service dns server 0)>
```

m. (Optional) Add host names and their IP addresses that the device's DNS server will resolve.

a. Add a host:

```
(config)> add service dns host end
(config service dns host 0)>
```

b. Set the IP address of the host:

```
(config service dns host 0)> address ip-addr
(config service dns host 0)>
```

c. Set the host name:

```
(config service dns host 0)> name host-name
(config service dns host 0)>
```

n. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

o. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show DNS server

You can display status for DNS servers. This command is available only at the Admin CLI.

Command line

Show DNS information

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an Access selection menu. Type **admin** to access the Admin CLI.

2. Use the show cms command at the system prompt:

```
> show cms

Interface  Label  Server                          Domain
---------  -----  ------------------------------  ------
eth1              192.168.3.1
eth1              fd00:3704::1
eth1              fe80::227:4ff:fe26:3e12
eth1              fe80::227:4ff:fe44:1858
eth1              fe80::240:ffff:fe88:23b8

>
```

3. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an Access selection menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Simple Network Management Protocol (SNMP)

Simple Network Management Protocol (SNMP) is a protocol for remotely managing and monitoring network devices. Network administrators can use the SNMP architecture to manage nodes, including servers, workstations, routers, switches, hubs, and other equipment on an IP network, manage network performance, find and solve network problems, and plan for network growth.

The Connect EZ 4 WS device supports both SNMPv3 and SNMPv2c in read-only mode. Both are disabled by default. SNMPv1 is not supported.

SNMP Security

By default, the Connect EZ 4 WS device automatically blocks SNMP packets from being received over LAN interfaces. As a result, if you want a Connect EZ 4 WS device to receive SNMP packets, you must configure the SNMP access control list to allow the device to receive the packets. See Configure Simple Network Management Protocol (SNMP).

Standard and custom Management Information Bases (MIB)

The standard MIB defines the properties and access permissions for various managed objects so that you can query standard information about a device, like **system contact** or **system location** via SNMP monitoring. The custom MIB defines the unique properties and access permissions not found in the standard MIB. To view the MIB list, see Download MIBs.

Dynamic SNMP

To expose a specific device property for SNMP monitoring that is not included in the standard MIB - properties like **serial number**, **system firmware version**, **hardware model name**, and **dynamic properties** - you can query the runtime database for the property value and then add a Dynamic SNMP. The device property is added to the custom MIB.

Configure Simple Network Management Protocol (SNMP)

Required configuration items

- Enable SNMP.
- Firewall configuration using access control to allow remote connections to the SNMP agent.
- The user name and password used to connect to the SNMP agent.

Additional configuration items

- The port used by the SNMP agent.
- Authentication type (either MD5 or SHA1).
- Privacy protocol (either DES or AES128).
- Privacy passphrase, if different than the SNMP user password.
- Enable Multicast DNS (mDNS) support.

To configure the SNMP agent on your Connect EZ 4 WS device:

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services > SNMP**.
4. Click **Enable**.
5. Click **Access control list** to configure access control:
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's SNMP agent. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the SNMP agent.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv6 address or network that can access the device's SNMP agent. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 2001:db8::/48.
        - **any**: No limit to IPv6 addresses that can access the SNMP agent.
     d. Click **+** again to list additional IP addresses or networks.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to hosts connected through a specified interface on the device:
  a. Click **Interfaces**.
  b. For **Add Interface**, click **+**.
  c. For **Interface**, select the appropriate interface from the dropdown.
  d. Click **+** again to allow access through additional interfaces.
- To limit access based on firewall zones:
  a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
  b. For **Add Zone**, click **+**.
  c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
  d. Click **+** again to allow access through additional firewall zones.

8. Type the **Username** used to connect to the SNMP agent.
7. Type the **Password** used to connect to the SNMP agent.
8. (Optional) For **Port**, type the port number. The default is **161**.
9. (Optional) Multicast DNS (mDNS) is disabled by default. mDNS is a protocol that resolves host names in small networks that do not have a DNS server. To enable mDNS, click **Enable mDNS**.
10. (Optional) Select the **Authentication type**, either **MD5** or **SHA1**. The default is **MD5**.
11. (Optional) Type the **Privacy passphrase**. If not set, the password, entered above, is used.
12. (Optional) Select the **Privacy protocol**, either **DES** or **AES128**. The default is **DES**.
13. (Optional) Add **Dynamic SNMP Properties** to expose specific details about your device for SNMP monitoring that are not included in the standard MIB. To query the runtime database to find the device property you want to expose to SNMP, see Use the device runtime to access the runtime database.
    a. Click **+**.
    b. For **Property**, type the device property (e.g., "system.cpu.temp" or "system.name").
    c. Click **+** again to add another dynamic SNMP property.
14. (Optional) Enable read-only access to SNMP versions 1 and 2c.
    a. Click **Enable version 1 and 2c access** to enable read-only access to SNMP versions 1 and 2c.
    b. The **Read-only community name** field displays. The default name is **public**. You can change the name if needed.
15. (Optional) Enable read and write access to SNMP versions 1 and 2c.
    a. Click **Enable version 1 and 2c write access** to enable read and write access to SNMP versions 1 and 2c.
    b. The **Read/write community name** field displays and is blank by default. You are required to enter a name.
16. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Enable the SNMP agent:

```
[config]> service snmp enable true
[config]>
```

4. Configure access control:

   - To limit access to specified IPv4 addresses and networks:

```
[config]> add service snmp acl address end value
[config]>
```

     Where **value** can be:

     - A single IP address or host name
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**: No limit to IPv4 addresses that can access the SNMP services.

     Repeat this step to list additional IP addresses or networks.

   - To limit access to specified IPv6 addresses and networks:

```
[config]> add service snmp acl address6 end value
[config]>
```

     Where **value** can be:

     - A single IP address or host name
     - A network designation in CIDR notation, for example, 2001:db8::/48.
     - **any**: No limit to IPv6 addresses that can access the SNMP services.

     Repeat this step to list additional IP addresses or networks.

   - To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
[config]> add service snmp acl interface end value
[config]>
```

     Where **value** is an interface defined on your device.

     Display a list of available interfaces:

     Use **... network interface** ? to display interface information:

     Repeat this step to list additional interfaces.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access based on firewall zones:

```
(config)> add service snmp acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the any keyword.

Display a list of available firewall zones:

Type ... firewall zone ? at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------
------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

5. Set the name of the user that will be used to connect to the SNMP agent.

```
(config)> service snmp username name
(config)>
```

6. Set the password for the user that will be used to connect to the SNMP agent.

```
(config)> service snmp password pwd
(config)>
```

7. (Optional) Set the port number for the SNMP agent. The default is 161.

```
(config)> service snmp port port
(config)>
```

8. (Optional) Configure Multicast DNS (mDNS)

mDNS is a protocol that resolves host names in small networks that do not have a DNS server. For the SNMP agent, mDNS is disabled by default. To enable:

```
(config)> service snmp mdns enable true
(config)>
```

10. (Optional) Set the authentication type. Allowed values are **MD5** or **SHA1**. The default is **MD5**.

```
(config)> service snmp auth_type SHA1
(config)>
```

11. (Optional) Set the privacy passphrase. If not set, the password, entered above, is used.

```
(config)> service snmp privacy_pass
(config)>
```

12. (Optional) Set the privacy protocol, either **DES** or **AES128**. The default is **DES**.

```
(config)> service snmp privacy_protocol AES128
(config)>
```

13. (Optional) Add **Dynamic SNMP Properties** to expose specific details about your device for SNMP monitoring that are not included in the standard MIB.

```
(config) service snmp runtime add end value
(config)>
```

Where **value** can be any element in the runtime table you want to expose to SNMP monitoring (for example, "system.cpu.temp" or "system.name").

14. (Optional) Enable read-only access to to SNMP versions 1 and 2c.

```
(config)> service snmp enable_2c true
(config)>
```

The community name is set to **public** by default. You can change it if desired.

```
(config)> service snmp community_name <name>
(config)>
```

Where **name** is the read-only community name.

15. (Optional) Enable read/write access to to SNMP versions 1 and 2c.

```
(config)> service snmp enable_write true
(config)>
```

The read/write community name is blank by default. You are required to enter a name when read/write access to to SNMP versions 1 and 2c is enabled.

```
(config)> service snmp rw_community_name <name>
(config)>
```

Where **name** is the read/write community name.

16. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

16. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Download MIBs

This procedure is available from the WebUI only.

Required configuration items

- Enable SNMP.

To download a .zip archive of the SNMP MIBs supported by this device:

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. Enable SNMP.

   See Configure Simple Network Management Protocol (SNMP) for information about enabling and configuring SNMP support on the Connect EZ 4 WS device.
3. On the main menu, click **Status**. Under **Services**, click **SNMP**.

   Note If you have recently enabled SNMP and the SNMP option is not visible, refresh your browser.



The **SNMP** page is displayed.



4. Click **Download**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

Location information

Your Connect EZ 4 WS device can be configured to use the following location sources:

- User-defined static location.
- Location messages forwarded to the device from other location-enabled devices.

You can also configure your Connect EZ 4 WS device to forward location messages, either from the Connect EZ 4 WS device or from external sources, to a remote host. Additionally, the device can be configured to use a geofence, to allow you to determine actions that will be taken based on the physical location of the device.

This section contains the following topics:

Enable modem GNSS support 473
Configure the device to use a user-defined static location 474
Configure the device to accept location messages from external sources 477
Forward location information to a remote host 480
Configure geofencing 488
Show location information 491

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 472 / 927

Enable modem GNSS support

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:


   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **Location** > **Location sources** > **modem**.
4. (Optional) Type a **Label** for the Modem GNSS location source.
5. For **Type of location source**, leave the selection as **Modem GNSS**.
6. Click **Enable the location source** to disable the GNSS receiver, or to enable it if it has been disabled.
7. Alternatively, you can also delete the **modem** location source.

   a. Click the menu icon (...) next to the **modem** location source.

   b. Click **Delete**.

   
8. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Enable or disable the modem GNSS module:

   a. Use the show command to determine the index number of the modem GNSS location source:

```
(config)> show service location source
0
        enable true
        no label
        type modem
(config)>
```

   b. Use the index number to enable or disable the module:

   - To enable the module:

```
(config)> service location source 0 enable true
(config)>
```

   - To disable the module:

```
(config)> service location source 0 enable false
(config)>
```

   Alternatively, you can use the index number to delete the USB location source:

```
(config)> del service location 0
(config)>
```

4. (Optional) Set a label for the location source:

```
(config)> service location source 0 label "label"
(config)>
```

5. Save the configuration and apply the change:

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure the device to use a user-defined static location

You can configured your Connect EZ 4 WS device to use a user-defined static location.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **Location** > **Location sources**.
4. Click **+** to add a location source.
5. (Optional) Type a **Label** for this location source.
6. For **Type of location source**, select **User-defined location**.
7. The location source is enabled by default. Click **Enable the location source** to disable the location source, or to enable it if it has been disabled.
8. For **Latitude**, type the latitude of the device. Allowed values are **-90** and **90**, with up to six decimal places.
9. For **Longitude**, type the longitude of the device. Allowed values are **-180** and **180**, with up to six decimal places.
10. For **Altitude**, type the altitude of the device. Allowed values are an integer followed by **m** or **km**, for example, **100m** or **1km**.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a location source:

```
(config)> add service location source end
(config service location source 4)>
```

The location source is enabled by default. To disable:

```
(config service location source 4)> enable false
(config service location source 4)>
```

4. (Optional) Set a label for this location source:

```
(config service location source 4)> label "label"
(config)>
```

5. Set the **type** of location source to **user_defined**:

```
(config service location source 4)> type user_defined
(config service location source 4)>
```

6. Set the latitude of the device:

```
(config service location source 4 coordinates latitude int
(config service location source 4)>
```

where *int* is any integer between **-90** and **90**, with up to six decimal places.

7. Set the longitude of the device:

```
(config service location source 4 coordinates longitude int
(config service location source 4)>
```

where *int* is any integer between **-180** and **180**, with up to six decimal places.

8. Set the altitude of the device:

```
(config service location source 4 coordinates altitude alt
(config service location source 4)>
```

Where *alt* is an integer followed by **m** or **km**, for example, **100m** or **1km**.

9. Save the configuration and apply the changes:

```
(config)> save
Configuration saved.
>
```

10. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure the device to accept location messages from external sources

You can configure the Connect EZ 4 WS device to accept NMEA and TAIP messages from external sources. For example, location-enabled devices connected to the Connect EZ 4 WS device can forward their location information to the device, and then the Connect EZ 4 WS device can serve as a central repository for this location information and forward it to a remote host. See Forward location information to a remote host for information about configuring the Connect EZ 4 WS device to forward location messages.

This procedure configures a UDP port on the Connect EZ 4 WS device that will be used to listen for incoming messages.

Required configuration items

- The location server must be enabled.
- UDP port that the Connect EZ device will listen to for incoming location messages.
- Access control list configuration to provide access to the port through the firewall.

To configure the device to accept location messages from external sources:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **Location** > **Location sources**.
4. Click **+** to add a location source.
5. (Optional) Type a **Label** for this location source.
6. For **Type of location source**, select **Server**.
7. For **Location server port**, type the number of the UDP port that will receive incoming location messages.
8. Click **Access control list** to configure access control.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

- To limit access to specified IPv4 addresses and networks:
  a. Click **IPv4 Addresses**.
  b. For **Add Address**, click **+**.
  c. For **Address**, enter the IPv4 address or network that can access the device's location server UDP port. Allowed values are:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**: No limit to IPv4 addresses that can access the location server UDP port.
  d. Click **+** again to list additional IP addresses or networks.
- To limit access to specified IPv6 addresses and networks:
  a. Click **IPv6 Addresses**.
  b. For **Add Address**, click **+**.
  c. For **Address**, enter the IPv6 address or network that can access the device's location server UDP port. Allowed values are:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:db8::/48.
     - **any**: No limit to IPv6 addresses that can access the location server UDP port.
  d. Click **+** again to list additional IP addresses or networks.
- To limit access to hosts connected through a specified interface on the device:
  a. Click **Interfaces**.
  b. For **Add Interface**, click **+**.
  c. For **Interface**, select the appropriate interface from the dropdown.
  d. Click **+** again to allow access through additional interfaces.
- To limit access based on firewall zones:
  a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
  b. For **Add Zone**, click **+**.
  c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
  d. Click **+** again to allow access through additional firewall zones.

3. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Add a location source:

```
(config)> add service location source end
(config service location source 6)>
```

4. (Optional) Set a label for this location source:

```
(config service location source 6)> label "label"
(config service location source 6)>
```

5. Set the **type** of location source to **server**:

```
(config service location source 6)> type server
(config service location source 6)>
```

6. Set the UDP port that will receive incoming location messages:

```
(config service location source 6)> server port port
(config service location source 6)>
```

7. Click **Access control list** to configure access control:
   - To limit access to specified IPv4 addresses and networks:

     ```
     (config)> add service location source 1 acl address end value
     (config)>
     ```

     Where **value** can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**: No limit to IPv4 addresses that can access the location server UDP port.

     Repeat this step to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:

     ```
     (config)> add service location source 1 acl address6 end value
     (config)>
     ```

     Where **value** can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:db8::/48.
     - **any**: No limit to IPv6 addresses that can access the location server UDP port.

     Repeat this step to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

     ```
     (config)> add service location source 1 acl interface end value
     (config)>
     ```

     Where **value** is an interface defined on your device.

     Display a list of available interfaces:

     Use **_ network interface** to display interface information.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add service location source 1 acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type **... firewall zone ?** at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

 Additional Configuration
 ------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

2. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Forward location information to a remote host

You can configure location clients on the Connect EZ 4 WS device that forward location messages in either NMEA or TAIP format to a remote host.

Required configuration items

- Enable the location service.
- The hostname or IP address of the remote host to which the location messages will be forwarded.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- The communication protocol, either TCP or UDP.
- The destination port on the remote host to which the messages will be forwarded.
- Message protocol type of the messages being forwarded, either NMEA or TAIP.

Additional configuration items

- Additional remote hosts to which the location messages will be forwarded.
- Location update interval, which determines how often the device will forward location information to the remote hosts.
- A description of the remote hosts.
- Specific types of NMEA or TAIP messages that should be forwarded.
- If the message protocol is NMEA, configure a talker ID to be used for all messages.
- Text that will be prepended to the forwarded message.
- A vehicle ID that is used in the TAIP ID message sent can also be prepended to the forwarded message.

Configure the Connect EZ device to forward location information.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services > Location > Destination servers**.
4. For **Add destination server**, click **+**.
5. (Optional) For **Label**, type a description of the location destination server.
6. For **Destination server**, enter the hostname or IP address of the remote host to which location messages will be sent.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

7. For **Destination server port**, enter the UDP or TCP port on the remote host to which location messages will be sent.
8. For **Communication protocol**, select either **UDP** or **TCP**.
9. For **Forward interval multiplier**, select the number of **Location update intervals** to wait before forwarding location data to this server.
10. For **NMEA filters**, select the filters that represent the types of messages that will be forwarded. By default, all message types are forwarded.
    - To remove a filter:
      a. Click the down arrow (▾) next to the appropriate message type.
      b. Click **Delete**.
    - To add a message type:
      a. For **Add NMEA filter** or **Add IAP filter**, click ✚.
      b. Select the filter type. Allowed values are:
         - **GGA**: Reports time, position, and fix related data.
         - **GLL**: Reports position data: position fix, time of position fix, and status.
         - **GSA**: Reports GPS/GLO and active satellites.
         - **GSV**: Reports the number of SVs in view, PRN, elevation, azimuth, and SNR.
         - **RMC**: Reports position, velocity, and time.
         - **VTG**: Reports direction and speed over ground.
11. For **IAP filters**, select the filters that represent the types of messages that will be forwarded. By default, all message types are forwarded.
    - To remove a filter:
      a. Click the down arrow (▾) next to the appropriate message type.
      b. Click **Delete**.
    - To add a message type:
      a. For **Add NMEA filter** or **Add IAP filter**, click ✚.
      b. Select the filter type. Allowed values are:
         - **AL**: Reports altitude and vertical velocity.
         - **CP**: Compact position: reports time, latitude, and longitude.
         - **ID**: Reports the vehicle ID.
         - **LN**: Long navigation: reports the latitude, longitude, and altitude, the horizontal and vertical speed, and heading.
         - **PV**: Position/velocity: reports the latitude, longitude, and heading.
12. For **Outgoing message type**, select either **NMEA** or **IAP** for the type of message that the device will forward to a remote host.

    (Optional) If **NMEA** is selected:

    a. Select a **Talker ID**.

    The talker ID is a two-character prefix in the NMEA message that identifies the source type. The talker ID set here will override the talker ID from all sources, and all forwarded sentences will use the configured ID. The default setting is **Default**, which means that the talker ID provided by the source will be used.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Determine the **Behavior when fix is invalid**:

- **None**: No messages are sent.
- **Empty**: Send messages with empty fields.
- **Last fix**: Send messages with information from the last valid fix.

13. (Optional) For **Prepend text**, enter text to prepend to the forwarded message. Two variables can be included in the prepended text:
    - **%s**: Includes the Connect EZ device's serial number in the prepended text.
    - **%v**: Includes the vehicle ID in the prepended text.

    For example, to include both the device's serial number and vehicle ID in the prepend message, you can enter the following in the **Prepend** field:

```
__[%s]__[%v]__
```

14. Type a four-digit alphanumeric **Vehicle ID** that will be included with to location messages. If no vehicle ID is configured, this setting defaults to 0000.
15. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a remote host to which location messages will be sent:

```
(config)> add service location forward end
(config service location forward 0)>
```

4. Set the hostname or IP address of the remote host to which location messages will be sent:

```
(config service location forward 0)> server host
(config service location forward 0)>
```

5. Set the communication protocol to either **upd** or **tcp**:

```
(config service location forward 0)> protocol protocol
(config service location forward 0)>
```

6. Set the TCP or UDP port on the remote host to which location messages will be sent:

```
(config service location forward 0)> server_port 8888
(config service location forward 0)>
```

7. Set the number of **Location update intervals** to wait before forwarding location data to this server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config service location forward 0)> interval_multiplier 1m
(config service location forward 0)>
```

8. Set the protocol type for the messages. Allowed values are **tcp** or **nmea**. The default is **tcp**.

```
(config service location forward 0)> type nmea
(config service location forward 0)>
```

(Optional) If the protocol type is set to **nmea**:

a. Configure a **talker ID**.

The talker ID is a two-character prefix in the NMEA message that identifies the source type. The talker ID set here will override the talker ID from all sources, and all forwarded sentences will use the configured ID.

i. Use the **?** to determine available talker IDs:

```
(config service location forward 0)> talker_id ?

Talker ID: Setting a talker ID will override the talker ID from
all remote
sources, and all forwarded sentences from remote sources will use
the configured
ID.
Format:
  Default
  GA
  GB
  GI
  GL
  GN
  GP
  GQ
Default value: Default
Current value: Default

(config service location forward 0)>
```

ii. Set the talker ID:

```
(config service location forward 0)> talker_id value
(config service location forward 0)>
```

The default setting is **Default**, which means that the talker ID provided by the source will be used.

b. Determine the behavior when it is invalid:

```
(config service location forward 0)> na_fix value
(config service location forward 0)>
```

where value is one of:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **none**: No messages are sent.
- **empty**: Send messages with empty fields.
- **last fix**: Send messages with information from the last valid fix.

The default is **empty**.

9. (Optional) Set the text to prepend to the forwarded message. Two variables can be included in the prepended text:
   - **%a**: Includes the Connect EZ device's serial number in the prepended text.
   - **%v**: Includes the vehicle ID in the prepended text.

```
(config service location forward 0)> prepend "%a %v"
(config service location forward 0)>
```

10. (Optional) Set the vehicle ID.

    Allowed value is a four digit alphanumerical string (for example, 0143 or 12D4). If no vehicle ID is configured, this setting defaults to 0000.

```
(config service location forward 0)> vehicle-id 12D4
(config service location forward 0)>
```

11. (Optional) Provide a description of the remote host.

```
(config service location forward 0)> label "Remote host 1"
(config service location forward 0)>
```

12. (Optional) Specify types of messages that will be forwarded. Allowed values vary depending on the message protocol type. By default, all message types are forwarded.
    - If the message protocol type is NMEA:

      Allowed values are:
      - **gga**: Reports time, position, and fix related data.
      - **gll**: Reports position data: position fix, time of position fix, and status.
      - **gsa**: Reports GPS DOP and active satellites.
      - **gsv**: Reports the number of SVs in view, PRN, elevation, azimuth, and SNR.
      - **rmc**: Reports position, velocity, and time.
      - **vtg**: Reports direction and speed over ground.

      To remove a message type:

      a. Use the **show** command to determine the index number of the message type to be deleted.

```
(config service location forward 0)> show filter_msgs
0 gga
1 gll
2 gsa
3 gsv
4 rmc
5 vtg
(config service location forward 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Use the index number to delete the message type. For example, to delete the **gxa** (index number 2) message type:

```
(config service location forward 4)> del filter_nmea 2
(config service location forward 4)>
```

To add a message type:

a. Change to the **filter_nmea** node:

```
(config service location forward 4)> filter_nmea
(config service location forward 4 filter_nmea)>
```

b. Use the **add** command to add the message type. For example, to add the **gxa** message type:

```
(config service location forward 4 filter_nmea)> add gxa end
(config service location forward 4 filter_nmea)>
```

- If the message protocol type is TAIP:

  Allowed values are:

  - **al**: Reports altitude and vertical velocity.
  - **cp**: Compact position: reports time, latitude, and longitude.
  - **id**: Reports the vehicle ID.
  - **ln**: Long navigation: reports the latitude, longitude, and altitude, the horizontal and vertical speed, and heading.
  - **pv**: Position velocity: reports the latitude, longitude, and heading.

  To remove a message type:

  a. Use the **show** command to determine the index number of the message type to be deleted:

```
(config service location forward 4)> show filter_taip
# id
1 cp
2 id
3 ln
4 pv
(config service location forward 4)>
```

  b. Use the index number to delete the message type. For example, to delete the **id** (index number 2) message type:

```
(config service location forward 4)> del filter_taip 2
(config service location forward 4)>
```

  To add a message type:

  a. Change to the **filter_taip** node:

```
(config service location forward 4)> filter_taip
(config service location forward 4 filter_taip)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Location information

b. Use the **add** command to add the message type. For example, to add the **at** message type:

```
(config service location forward s filter_table)> add to end
(config service location forward s filter_table)>
```

13. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

14. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure geofencing

Geofencing is a mechanism to create a virtual perimeter that allows you configure your Connect EZ 4 WS device to perform actions when entering or exiting the perimeter. For example, you can configure a device to factory default if its location service indicates that it has been moved outside of the geofence.

Multiple geofences can be defined for one device, allowing for a complex configuration in which different actions are taken depending on the physical location of the device.

Required configuration items

- Location services must be enabled.
- The geofence must be enabled.
- The boundary type of the geofence, either circular or polygonal.
  - If boundary type is circular, the latitude and longitude of the center point of the circle, and the radius.
  - If boundary type is polygonal, the latitude and longitude of the polygon's vertices (a vertex is the point at which two sides of a polygon meet). Three vertices will create a triangular polygon; four will create a square, etc. Complex polygons can be defined.
- Actions that will be taken when the device's location triggers a geofence event. You can define actions for two types of events:
  - Actions taken when the device enters the boundary of the geofence, or is inside the boundary when the device boots.
  - Actions taken when the device exits the boundary of the geofence, or is outside the boundary when the device boots.

  For each event type:
  - Determine if the action(s) associated with the event type should be performed when the device boots inside or outside of the geofence boundary.
  - The number of update intervals that should take place before the action(s) are taken.

  Multiple actions can be configured for each type of event. For each action:
  - The type of action, either a factory erase or executing a custom script.
  - If a custom script is used:
    - The script that will be executed.
    - Whether to log output and errors from the script.
    - The maximum memory that the script will have available.
    - Whether the script should be executed within a sandbox that will prevent the script from affecting the system itself.

Additional configuration items

- Update interval, which determines the amount of time that the geofence should wait between polling for updated location data.

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Location information

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **Location** > **Geofence**.
4. For **Add Geofence**, type a name for the geofence and click **+**.

   The geofence is enabled by default. To disable, toggle off **Enable**.
5. For **Update interval**, type the amount of time that the geofence should wait between polling for updated location data. The default is one minute.

   Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*(w|d|h|m|s).

   For example, to set **Update interval** to ten minutes, enter **10m** or **600s**.
6. For **Boundary type**, select the type of boundary that the geofence will have.
   - If **Circular** is selected:
     a. Click to expand **Center**.
     b. Type the **Latitude** and **Longitude** of the center point of the circle. Allowed values are:
        - For **Latitude**, any integer between **-90** and **90**, with up to six decimal places.
        - For **Longitude**, any integer between **-180** and **180**, with up to six decimal places.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. For **Radius**, type the radius of the circle. Allowed values are an integer followed by m or km, for example, **100m** or **1km**.

- If **Polygonal** is selected:
  a. Click to expand **Coordinates**.
  b. Click **+** to add a point that represents a vertex of the polygon. A vertex is the point at which two sides of a polygon meet.
  c. Type the **Latitude** and **Longitude** of one of the vertices of the polygon. Allowed values are:
     - For **Latitude**, any integer between **-90** and **90**, with up to six decimal places.
     - For **Longitude**, any integer between **-180** and **180**, with up to six decimal places.
  d. Click **+** again to add an additional point, and continue adding points to create the desired polygon.

For example, to configure a square polygon around the Digi headquarters, configure a polygon with four points:



This defines a square-shaped polygon equivalent to the following:



7. Define actions to be taken when the device's location triggers a geofence event:
   - To define actions that will be taken when the device enters the geofence, or is inside the geofence when it boots:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Click to expand **On entry**.



b. (Optional) Enable **Bootup action** to configure the device to perform the **On entry** actions if the device is inside the geofence when it boots.

c. For **Number of intervals**, type or select the number of Update intervals that must take place prior to performing the **On entry** actions.

For example, if the **Update interval** is **1m** (one minute) and the **Number of intervals** is **3**, the **On entry** actions will not be performed until the device has been inside the geofence for three minutes.

d. Click to expand **Actions**.

e. Click **+** to create a new action.



f. For **Action type**, select either:

- **Factory erase** to erase the device configuration when the action is triggered.
- **Custom script** to execute a custom script when the action is triggered.

If **Custom script** is selected:

i. Click to expand **Custom script**.

ii. For **Commands**, type the script that will be executed when the action is triggered. If the script begins with **#!**, then the proceeding file path will be used to invoke the script interpreter. If not, then the default shell will be used.

iii. Enable **Log script output** to log the output of the script to the system log.

iv. Enable **Log script errors** to log errors from the script to the system log.

v. (Optional) For **Maximum memory**, type the maximum amount of system memory that will be available for the script and it spawned processes.

Allowed values are any integer followed by one of the following: **b**(bytes) **K**(kilobytes) **M**(megabytes) **G**(gigabytes).

For example, to allocate one megabyte of memory to the script and its spawned processes, type **1M** or **1M**.

vi. **Sandbox** is enabled by default. This prevents the script from adversely affecting the system. If you disable **Sandbox**, the script may render the system unusable.

vii. Repeat for any additional actions.

- To define actions that will be taken when the device exits the geofence, or is outside the geofence when it boots:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Click to expand **On exit**.

b. (Optional) Enable **Bootup action** to configure the device to perform the **On exit** actions if the device is inside the geofence when it boots.

c. For **Number of intervals**, type or select the number of Update intervals that must take place prior to performing the **On exit** actions.
For example, if the **Update interval** is **1m** (one minute) and the **Number of intervals** is **3**, the **On entry** actions will not be performed until the device has been inside the geofence for three minutes.

d. Click to expand **Actions**.

e. Click **+** to create a new action.

f. For Action type, select either:
- **Factory erase** to erase the device configuration when the action is triggered.
- **Custom script** to execute a custom script when the action is triggered.

If **Custom script** is selected:

i. Click to expand **Custom script**.

ii. For **Commands**, type the script that will be executed when the action is triggered. If the script begins with **#!**, then the proceeding file path will be used to invoke the script interpreter. If not, then the default shell will be used.

iii. Enable **Log script output** to log the output of the script to the system log.

iv. Enable **Log script errors** to log errors from the script to the system log.

v. (Optional) For **Maximum memory**, type the maximum amount of system memory that will be available for the script and it spawned processes.
Allowed values are any integer followed by one of the following:
b(bytes)/**K**(**k**)/**M**(**m**)/**G**(**g**)/**T**(**t**).
For example, to allocate one megabyte of memory to the script and its spawned processes, type **1MB** or **1M**.

vi. **Sandbox** is enabled by default. This prevents the script from adversely affecting the system. If you disable **Sandbox**, the script may render the system unusable.

vii. Repeat for any additional actions.

g. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a geofence:

```
(config)> add service location geofence name
(config service location geofence name)>
```

   where **name** is a name for the geofence. For example:

```
(config)> add service location geofence test_geofence
(config service location geofence test_geofence)>
```

   The geofence is enabled by default. To disable:

```
(config service location geofence test_geofence)> enable false
(config service location geofence test_geofence)>
```

4. Set the amount of time that the geofence should wait between polling for updated location data:

```
(config service location geofence test_geofence)> update_interval value
(config service location geofence test_geofence)>
```

   where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number(w|d|h|m|s)**.

   For example, to set **update_interval** to ten minutes, enter either **10m** or **600s**:

```
(config service location geofence test_geofence)> update_interval 600s
(config service location geofence test_geofence)>
```

   The default is **1m** (one minute).
5. Set the boundary type for the geofence:

```
(config service location geofence test_geofence)> boundary value
(config service location geofence test_geofence)>
```

   where **value** is either **circular** or **polygonal**.

   - If **boundary** is set to **circular**:
     a. Set the latitude and longitude of the center point of the circle:

```
(config service location geofence test_geofence)> center
latitude int
(config service location geofence test_geofence)> center
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Location information

```
longitude int
(config service location geofence test_geofence)>
```

where int is:

- For **latitude**, any integer between **-90** and **90**, with up to six decimal places.
- For **longitude**, any integer between **-180** and **180**, with up to six decimal places.

b. Set the radius of the circle:

```
(config service location geofence test_geofence)> radius radius
(config service location geofence test_geofence)>
```

Where **radius** is an integer followed by **m** or **km**, for example, **100m** or **1km**.

- If **boundary** is set to **polygonal**:
  a. Set the coordinates of one vertex of the polygon. A vertex is the point at which two sides of a polygon meet:
     i. Add a vertex:

```
(config service location geofence test_geofence)> add
coordinates end
(config service location geofence test_geofence coordinates
0)>
```

     ii. Set the latitude and longitude of the vertex:

```
(config service location geofence test_geofence coordinates
0)> latitude int
(config service location geofence test_geofence coordinates
0)> longitude int
(config service location geofence test_geofence coordinates
0)>
```

where int is:

- For **latitude**, any integer between **-90** and **90**, with up to six decimal places.
- For **longitude**, any integer between **-180** and **180**, with up to six decimal places.

     iii. Configure additional vertices:

```
(config service location geofence test_geofence coordinates
0)> ..
(config service location geofence test_geofence coordinates)>
add end
(config service location geofence test_geofence coordinates
1)> latitude int
(config service location geofence test_geofence coordinates
1)> longitude int
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config service location geofence test_geofence coordinates
1)>
```

where int is:

- For **latitude**, any integer between -90 and 90, with up to six decimal places.
- For **longitude**, any integer between -180 and 180, with up to six decimal places.

Repeat for each vertex of the polygon.
For example, to configure a square polygon around the Digi headquarters, configure a polygon with four points:

```
(config service location geofence test_geofence)> add
coordinates end
(config service location geofence test_geofence coordinates
0)> latitude 44.922220
(config service location geofence test_geofence coordinates
0)> longitude -93.399200
(config service location geofence test_geofence coordinates
0)> ..
(config service location geofence test_geofence coordinates)>
add end
(config service location geofence test_geofence coordinates
1)> latitude 44.922220
(config service location geofence test_geofence coordinates
1)> longitude -93.39599
(config service location geofence test_geofence coordinates
1)> ..
(config service location geofence test_geofence coordinates)>
add end
(config service location geofence test_geofence coordinates
2)> latitude 44.915151
(config service location geofence test_geofence coordinates
2)> longitude -93.39599
(config service location geofence test_geofence coordinates
2)> ..
(config service location geofence test_geofence coordinates)>
add end
(config service location geofence test_geofence coordinates
3)> latitude 44.915151
(config service location geofence test_geofence coordinates
3)> longitude -93.399200
(config service location geofence test_geofence coordinates
3)>
```

This defines a square-shaped polygon equivalent to the following:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



6. Define actions to be taken when the device's location triggers a geofence event:
   - To define actions that will be taken when the device enters the geofence, or to make the geofence when it boots:
     a. (Optional) Configure the device to perform the actions if the device is inside the geofence when it boots:

```
(config)> service location geofence test_geofence on_entry
bootup true
(config)>
```

     b. Set the number of update intervals that must take place prior to performing the actions:

```
(config)> service location geofence test_geofence on_entry num_
intervals 10
(config)>
```

     For example, if the update interval is 1m (one minute) and the **num intervals** is set to 3, the actions will not be performed until the device has been inside the geofence for three minutes.
     c. Add an action:
        i. Type .. to return to the root of the configuration:

```
(config service location geofence test_geofence coordinates
3)> ..
(config)>
```

        ii. Add the action:

```
(config)> add service location geofence test_geofence on_
entry action end
(config service location geofence test_geofence on_entry
action 0)>
```

     d. Set the type of action:

```
(config service location geofence test_geofence on_entry action
0)> type value
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Location information

```
(config service location geofence test_geofence on_entry action
0)>
```

where value is either:

- **factory erase**—Erases the device configuration when the action is triggered.
- **script**—Executes a custom script when the action is triggered.

factory erase or **script**.

If **type** is set to **script**:

i. Type or paste the script, closed in quote marks.

```
(config service location geofence test_geofence on_entry
action 0)> commands "script"
(config service location geofence test_geofence on_entry
action 0)>
```

If the script begins with **#!**, then the processing file path will be used to invoke the script interpreter. If not, then the default shell will be used.

ii. To log the output of the script to the system log:

```
(config service location geofence test_geofence on_entry
action 0)> syslog_stdout true
(config service location geofence test_geofence on_entry
action 0)>
```

iii. To log the errors from the script to the system log:

```
(config service location geofence test_geofence on_entry
action 0)> syslog_stderr true
(config service location geofence test_geofence on_entry
action 0)>
```

iv. (Optional) Set the maximum amount of system memory that will be available for the script and its spawned processes.

```
(config service location geofence test_geofence on_entry
action 0)> max_memory value
(config service location geofence test_geofence on_entry
action 0)>
```

where **value** is any integer followed by one of the following:

b|kb|kib|KB|KiB|MB|MiB|GB|GiB|TB|TiB

For example, the allocate one megabyte of memory to the script and its spawned processes:

```
(config service location geofence test_geofence on_entry
action 0)> max_memory 1MB
(config service location geofence test_geofence on_entry
action 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

v. A sandbox is enabled by default to prevent the script from adversely affecting the system. To disable the sandbox:

```
(config service location geofence test_geofence on_entry
action 0)> sandbox false
(config service location geofence test_geofence on_entry
action 0)>
```

If you disable the sandbox, the script may render the system unusable.

vi. Repeat for any additional actions.

- To define actions that will be taken when the device exits the geofence, or is outside the geofence when it boots:
  a. (Optional) Configure the device to perform the actions if the device is outside the geofence when it boots:

```
(config)> service location geofence test_geofence on_exit bootup
true
(config)>
```

  b. Set the number of update intervals that must take place prior to performing the actions:

```
(config)> service location geofence test_geofence on_exit num_
intervals int
(config)>
```

For example, if the update interval is 1m (one minute) and the num_intervals is set to 3, the actions will not be performed until the device has been outside the geofence for three minutes.

  c. Add an action:
    i. Type .. to return to the root of the configuration:

```
(config service location geofence test_geofence coordinates
2)> ..
(config)>
```

    ii. Add the action:

```
(config)> add service location geofence test_geofence on_exit
action end
(config service location geofence test_geofence on_exit
action 0)>
```

    iii. Set the type of action:

```
(config service location geofence test_geofence on_exit actio
0)> type cellw
(config service location geofence test_geofence on_exit actio
0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Where value is either:

- **factory erase**—Erases the device configuration when the action is triggered.
- **script**—Executes a custom script when the action is triggered.

factory erase or script.

If type is set to script:

i. Type or paste the script, closed in quote marks:

```
(config service location geofence test_geofence on_exit
action 0)# commands "#/script"
(config service location geofence test_geofence on_exit
action 0)#
```

If the script begins with #!, then the processing file path will be used to invoke the script interpreter. If not, then the default shell will be used.

ii. To log the output of the script to the system log:

```
(config service location geofence test_geofence on_exit
action 0)# syslog_stdout true
(config service location geofence test_geofence on_exit
action 0)#
```

iii. To log the errors from the script to the system log:

```
(config service location geofence test_geofence on_exit
action 0)# syslog_stderr true
(config service location geofence test_geofence on_exit
action 0)#
```

iv. (Optional) Set the maximum amount of system memory that will be available for the script and it spawned processes:

```
(config service location geofence test_geofence on_exit
action 0)# max_memory value
(config service location geofence test_geofence on_exit
action 0)#
```

where value is any integer followed by one of the following:
b|bytes|KB|k|MB|M|GB|G|TB|T.

For example, the allocate one megabyte of memory to the script and its spawned processes:

```
(config service location geofence test_geofence on_exit
action 0)# max_memory 1MB
(config service location geofence test_geofence on_exit
action 0)#
```

v. A sandbox is enabled by default to prevent the script from adversely affecting the system. To disable the sandbox:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config service location geofence test_geofence on_exit
action 4)> sandbox false
(config service location geofence test_geofence on_exit
action 4)>
```

If you disable the sandbox, the script may render the system unusable.

vi. Repeat for any additional actions.

7. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show location information

You can view status and statistics about location information from either the WebUI or the command line.

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **Status**.
2. Under **Services**, click **Location**.

   The device's current location is displayed, along with the status of any configured geofences.

Command line

Show location information

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Use the show location command at the system prompt.

```
> show location

Location Status
---------------

State          : enabled
Source         : 192.168.2.3
Latitude       : 44° 01' 34.889" N (44.026078)
Longitude      : 93° 24' 47.262" W (-93.413128)
Altitude       : 276 meters
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Velocity            : 0 meters per second
Direction           : None
Quality             : Standard GNSS (2D/3D)
UTC Date and Time   : Fri, Jan 12, 2024 12:18:58 GMT
No. of Satellites   : 7
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show geofence information

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Use the show location geofence command at the system prompt.

```
> show location geofence

Geofence        Status  State    Transitions  Last Transition
--------------  ------  -------  -----------  ---------------
test_geofence   Up      Inside   0
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Modbus gateway

The Connect EZ 4 WS supports the ability to function as a Modbus gateway, to provide serial-to-Ethernet connectivity to Programmable Logic Controllers (PLCs), Remote Terminal Units (RTUs), and other industrial devices. MODBUS provides client/server communication between devices connected on different types of buses and networks, and the Modbus gateway allows for communication between buses and networks that use the Modbus protocol.

This section contains the following topics:

Configure the Modbus gateway 502
Modbus hardening 515
Show Modbus gateway status and statistics 516

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure the Modbus gateway

Required configuration items

- Server configuration:
  - Enable the server.
  - Connection type, either socket or serial.
    - If the connection type is socket, the IP protocol to be used.
    - If the connection type is serial, the serial port to be used.
- Client configuration:
  - Enable the client.
  - Connection type, either socket or serial.
    - If the connection type is socket:
      - The IP protocol to be used.
      - The hostname or IPv4 address of the remote host on which the Modbus server is running.
    - If the connection type is serial:
      - The serial port to be used.
  - Modbus address or addresses to determine if messages should be forwarded to a destination device.

Additional configuration items

- Server configuration:
  - The packet mode.
  - The maximum time between bytes in a packet.
  - If the connection type is set to socket:
    - The port to use.
    - The inactivity timeout.
    - Access control list.
  - If the connection type is set to serial:
    - Whether to use half duplex (two wire) mode.
- Client configuration:
  - The packet mode.
  - The maximum time between bytes in a packets.
  - Whether to send broadcast messages.
  - Response timeout.
  - If connection type is set to socket:
    - The port to use.
    - The inactivity timeout.
  - If connection type is set to serial:
    - Whether to use half duplex (two wire) mode.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Whether packets should be delivered to a fixed Modbus address.
- Whether packets should have their Modbus address adjusted downward before it delivery.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **Modbus Gateway**.

4. Click **Enable** to enable the gateway.
5. Click **Debug** to allow verbose logging in the system log.


Configure gateway servers

1. Click to expand **Gateway Servers**.
2. For **Add Modbus server**, type a name for the server and click **+**.

   The new Modbus gateway server configuration is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



3. The new Modbus gateway server is enabled by default. Toggle off **Enable the server** to disable.
4. For **Connection type**, select **Socket** or **Serial**. Available options in the gateway server configuration vary depending on this setting.
   - If **Socket** is selected for **Connection type**:
     a. For **IP Protocol**, select **ICI** or **UDP**. The default is **ICI**.
     b. For **Port**, enter or select an appropriate port. The default is port **502**.
   - If **Serial** is selected for **Connection type**:
     a. For **Serial port**, select the appropriate serial port on the Connect EZ 4 WS device.
5. For **Packet mode**, select **RTU** or **RAW** (if **Connection type** is set to **Socket**) or **ASCII** (if **Connection type** is set to **Serial**) for the type of packet that will be used by this connection. The default is **RTU**.
6. For **Packet idle gap**, type the maximum allowable time between bytes in a packet.
   Allowed values are between 10 milliseconds and one second, and take the format **number(ms|s)**.
   For example, to set **Packet idle gap** to 20 milliseconds, enter **20ms**.
7. If **Connection type** is set to **Socket**, for **Inactivity timeout**, type the amount of time to wait before disconnecting the socket when it has become inactive.
   Allowed values are any number of minutes or seconds up to a maximum of 15 minutes, and take the format **number(m|s)**.
   For example, to set **Inactivity timeout** to ten minutes, enter **10m** or **600s**.
8. (Optional) If **Connection type** is set to **Serial**, click **Half duplex** to enable half duplex (two wire) mode.
9. (Optional) If **Connection type** is set to **Socket**, click to expand **Access control list**.
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's web administration service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the web administration service.
     d. Click **+** again to list additional IP addresses or networks.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to specified IPv6 addresses and networks:
  a. Click **IPv6 Addresses**.
  b. For **Add Address**, click **+**.
  c. For **Address**, enter the IPv6 address or network that can access the device's web administration service. Allowed values are:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:db8::/45.
     - **any**. No limit to IPv6 addresses that can access the web administration service.
  d. Click **+** again to list additional IP addresses or networks.
- To limit access to hosts connected through a specified interface on the device:
  a. Click **Interfaces**.
  b. For **Add Interface**, click **+**.
  c. For **Interface**, select the appropriate interface from the dropdown.
  d. Click **+** again to allow access through additional interfaces.
- To limit access based on firewall zones:
  a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
  b. For **Add Zone**, click **+**.
  c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
  d. Click **+** again to allow access through additional firewall zones.

iii. Repeat these steps to configure additional servers.

Configure clients

1. Click to expand **Clients**.
2. For **Add Modbus client**, type a name for the client and click **+**.



The new Modbus gateway client configuration is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



3. The new Modbus gateway client is enabled by default. Toggle off **Enable the client** to disable.
4. For **Connection type**, select **Socket** or **Serial**. Available options in the gateway server configuration vary depending on this setting.
   - If **Socket** is selected for **Connection type**:
     a. For **IP Protocol**, select **IP4** or **IP6**. The default is **IP4**.
     b. For **Port**, enter or select an appropriate port. The default is port **502**.
     c. For **Remote host**, type the hostname or IP address of the remote host on which the Modbus server is running.
   - If **Serial** is selected for **Connection type**:
     a. For **Serial port**, select the appropriate serial port on the Connect EZ 4 WS device.
5. For **Packet mode**, select **RTU** or **RAW** (if **Connection type** is set to **Socket**) or **ASCII** (if **Connection type** is set to **Serial**) for the type of packet that will be used by this connection. The default is **RTU**.
6. For **Packet idle gap**, type the maximum allowable time between bytes in a packet.
   Allowed values are between 10 milliseconds and one second, and take the format **number(ms|s)**.
   For example, to set **Packet idle gap** to 20 milliseconds, enter **20ms**.
7. If **Connection type** is set to **Socket**, for **Inactivity timeout**, type the amount of time to wait before disconnecting the socket when it has become inactive.
   Allowed values are any number of minutes or seconds up to a maximum of 15 minutes, and take the format **number(m|s)**.
   For example, to set **Inactivity timeout** to ten minutes, enter **10m** or **600s**.
8. (Optional) If **Connection type** is set to **Serial**, click **Half duplex** to enable half duplex (two wire) mode.
9. (Optional) If **Connection type** is set to **Socket**, click to expand **Access control list**.
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's web administration service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **any**. No limit to IPv4 addresses that can access the web administration service.

d. Click **+** again to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:

a. Click **IPv6 Addresses**.

b. For **Add Address**, click **+**.

c. For **Address**, enter the IPv6 address or network that can access the device's web administration service. Allowed values are:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- **any**. No limit to IPv6 addresses that can access the web administration service.

d. Click **+** again to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the device:

a. Click **Interfaces**.

b. For **Add Interface**, click **+**.

c. For **Interface**, select the appropriate interface from the dropdown.

d. Click **+** again to allow access through additional interfaces.

- To limit access based on firewall zones:

a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.

b. For **Add Zone**, click **+**.

c. For **Zone**, select the appropriate firewall zone from the dropdown.

See Firewall configuration for information about firewall zones.

d. Click **+** again to allow access through additional firewall zones.

10. (Optional) Enable **Send broadcast messages** to configure the gateway to send broadcast messages to this client.

11. For **Response timeout**, type the maximum time to wait for a response to a message.

Allowed values are between 1 millisecond and 750 milliseconds, and take the format **<number>ms**.

For example, to set **Response timeout** to 100 milliseconds, enter **100ms**. The default is **750ms**.

12. Click to expand **Modbus address filter**.


This filter is used by the gateway to determine if a message should be forwarded to a destination device. If the Modbus address in the message matches one or more of the filters, the message is forwarded. If it does not match the filters, the message is not forwarded.

13. For **Address or address range**, type a Modbus address or range of addresses. Allowed values are 1 through **255** or a hyphen-separated range.

For example, to have this client filter for incoming messages that contain the Modbus address of 10, type **10**. To filter for all messages with addresses in the range of 20 to 30, type **20-30**.

To add additional address filters for this client, click **+**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



14. For **Fixed Modbus server address**, if request messages handled by this client should always be forwarded to a specific device, type the device's Modbus address. Leave at the default setting of 0 to allow messages that match the **Modbus address filter** to be forwarded to devices based on the Modbus address in the message.
15. For **Adjust Modbus server address**, type a value to adjust the Modbus server address downward by the specified value prior to delivering the message. Allowed values are 0 through 255. Leave at the default setting of 0 to not adjust the server address.

    If a packet contains a Modbus server address above the amount entered here, the address will be adjusted downward by this amount before the packet is delivered. This allows you to configure clients on the gateway that will forward messages to remote devices with the same Modbus address on different buses. For example, if there are two devices on two different buses that have the same Modbus address of 10, you can create two clients on the gateway.

    - Client one:
      - **Modbus address filter** set to **10**.

      This will configure the gateway to deliver all messages that have the Modbus server address of 10 to this device.
    - Client two:
      - **Modbus address filter** set to **20**.
      - **Adjust Modbus server address** set to **10**.

      This will configure the gateway to deliver all messages that have the Modbus server address address of 20 to the device with address 10.
16. Repeat these steps to configure additional clients.
17. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable the Modbus gateway:

```
(config)> service modbus_gateway enable true
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Configure servers:
   a. Add a server:

```
(config)> add service modbus_gateway server name
(config service modbus_gateway server name)>
```

   where **name** is a name for the server, for example:

```
(config)> add service modbus_gateway server test_modbus_server
(config service modbus_gateway server test_modbus_server)>
```

   The Modbus server is enabled by default. To disable:

```
(config service modbus_gateway server test_modbus_server)> enable
false
(config service modbus_gateway server test_modbus_server)>
```

   b. Set the connection type:

```
(config service modbus_gateway server test_modbus_server)> connection_
type type
(config service modbus_gateway server test_modbus_server)>
```

   where *type* is either **socket** or **serial**. The default is **socket**.

   - If **connection type** is set to **socket**:
     i. Set the IP protocol:

```
(config service modbus_gateway server test_modbus_server)>
socket protocol value
(config service modbus_gateway server test_modbus_server)>
```

     where *value* is either **tcp** or **udp**.
     ii. Set the port:

```
(config service modbus_gateway server test_modbus_server)>
socket port
(config service modbus_gateway server test_modbus_server)>
```

     where *port* is an integer between **1** and **65535**. The default is **502**.
     iii. Set the packet mode:

```
(config service modbus_gateway server test_modbus_server)>
socket packet_mode value
(config service modbus_gateway server test_modbus_server)>
```

     where *value* is either **rtu** or **raw**. The default is **rtu**.
     iv. Set the maximum allowable time between bytes in a packet:

```
(config service modbus_gateway server test_modbus_server)>
socket idle_gap value
(config service modbus_gateway server test_modbus_server)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is any number between 10 milliseconds and one second, and takes the format number[ms|s].

For example, to set idle_gap to 20 milliseconds, enter 20ms.

c. Set the amount of time to wait before disconnecting the socket when it has become inactive:

```
(config service modbus_gateway server test_modbus_server)>
inactivity_timeout value
(config service modbus_gateway server test_modbus_server)>
```

where value is any number of minutes or seconds up to a maximum of 15 minutes, and takes the format number[m|s].

For example, to set inactivity_timeout to ten minutes, enter either 10m or 600s:

```
(config service modbus_gateway server test_modbus_server)>
inactivity_timeout 600s
(config service modbus_gateway server test_modbus_server)>
```

- If connection type is set to serial:

  i. Set the serial port:

  i. Use the ?tty to determine available serial ports:

  ```
  (config service modbus_gateway server test_modbus_
  server)> ... serial port ?

  Serial

    Additional Configuration
    ------------------------------------------------------------
  ------------------------

    port1                          Port 1

  (config service modbus_gateway server test_modbus_
  server)>
  ```

  ii. Set the port:

  ```
  (config service modbus_gateway server test_modbus_
  server)> serial port
  (config service modbus_gateway server test_modbus_
  server)>
  ```

  ii. Set the packet mode:

  ```
  (config service modbus_gateway server test_modbus_server)>
  serial packet_mode value
  (config service modbus_gateway server test_modbus_server)>
  ```

  where value is either rtu or ascii. The default is rtu.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iii. Set the maximum allowable time between bytes in a packet:

```
(config service modbus_gateway server test_modbus_server)>
serial idle_gap value
(config service modbus_gateway server test_modbus_server)>
```

where **value** is any number between 10 milliseconds and one second, and takes the format **number[ms|s]**.

For example, to set idle_gap to one second, enter **1000ms** or **1s**.

iv. (Optional) Enable half-duplex (two wire) mode:

```
(config service modbus_gateway server test_modbus_server)>
serial half_duplex true
(config service modbus_gateway server test_modbus_server)>
```

c. Repeat the above instructions for additional servers.

5. Configure clients:

a. Type **..** to return to the root of the configuration:

```
(config)> add service modbus_gateway server test_modbus_server)> ...
(config)>
```

b. Add a client:

```
(config)> add service modbus_gateway client name
(config service modbus_gateway  client name)>
```

where **name** is a name for the client, for example:

```
(config)> add service modbus_gateway client test_modbus_client
(config service modbus_gateway client test_modbus_client)>
```

The Modbus client is enabled by default. To disable:

```
(config service modbus_gateway client test_modbus_client)> enable
false
(config service modbus_gateway client test_modbus_client)>
```

c. Set the connection type:

```
(config service modbus_gateway client test_modbus_client)> connection_
type type
(config service modbus_gateway client test_modbus_client)>
```

where **type** is either **socket** or **serial**. The default is **socket**.

- If **connection type** is set to **socket**:

i. Set the IP protocol:

```
(config service modbus_gateway client test_modbus_client)>
socket protocol value
(config service modbus_gateway client test_modbus_client)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is either tcp or udp.

ii. Set the port:

```
(config service modbus_gateway client test_modbus_client)>
socket port
(config service modbus_gateway client test_modbus_client)>
```

where port is an integer between 1 and 65535. The default is 502.

iii. Set the packet mode:

```
(config service modbus_gateway client test_modbus_client)>
socket packet_mode value
(config service modbus_gateway client test_modbus_client)>
```

where value is either rtu or ascii. The default is rtu.

iv. Set the maximum allowable time between bytes in a packet:

```
(config service modbus_gateway client test_modbus_client)>
socket idle_gap value
(config service modbus_gateway client test_modbus_client)>
```

where value is any number between 10 milliseconds and one second, and takes the format number[ms|s].

For example, to set idle_gap to 20 milliseconds, enter 20ms.

v. Set the amount of time to wait before disconnecting the socket when it has become inactive:

```
(config service modbus_gateway client test_modbus_client)>
inactivity_timeout value
(config service modbus_gateway client test_modbus_client)>
```

where value is any number of minutes or seconds up to a maximum of 15 minutes, and takes the format number[m|s].

For example, to set inactivity_timeout to ten minutes, enter either 10m or 600s.

```
(config service modbus_gateway client test_modbus_client)>
inactivity_timeout 600s
(config service modbus_gateway client test_modbus_client)>
```

vi. Set the hostname or IP address of the remote host on which the Modbus server is running:

```
(config service modbus_gateway client test_modbus_client)>
remote_host ip_address|hostname
(config service modbus_gateway client test_modbus_client)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- If connection type is set to serial:
  i. Set the serial port:
    i. Use the ? to determine available serial ports:

```
(config service modbus_gateway client test_modbus_
client)> ... serial port ?

Serial

  Additional Configuration

  ports                         Port 1

(config service modbus_gateway client test_modbus_
client)>
```

    ii. Set the port:

```
(config service modbus_gateway client test_modbus_
client)> serial port
(config service modbus_gateway client test_modbus_
client)>
```

  ii. Set the packet mode:

```
(config service modbus_gateway client test_modbus_client)>
serial packet_mode value
(config service modbus_gateway client test_modbus_client)>
```

  where value is either rtu or ascii. The default is rtu.
  iii. Set the maximum allowable time between bytes in a packet:

```
(config service modbus_gateway client test_modbus_client)>
serial idle_gap value
(config service modbus_gateway client test_modbus_client)>
```

  where value is any number between 10 milliseconds and one second, and takes the format number[ms|s].

  For example, to set idle_gap to one second, enter 1000ms or 1s.
  iv. (Optional) Enable half-duplex (two wire) mode:

```
(config service modbus_gateway client test_modbus_client)>
serial half_duplex true
(config service modbus_gateway client test_modbus_client)>
```

- (Optional) Enable the gateway to send broadcast messages to this client.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config service modbus_gateway client test_modbus_client)> broadcast
true
(config service modbus_gateway client test_modbus_client)>
```

e. Set the maximum time to wait for a response to a message:

```
(config service modbus_gateway client test_modbus_client)> response_
timeout value
(config service modbus_gateway client test_modbus_client)>
```

Allowed values are between 1 millisecond and 700 milliseconds, and take the format **number**ms.

For example, to set response_timeout to 100 milliseconds:

```
(config service modbus_gateway client test_modbus_client)> response_
timeout 100ms
(config service modbus_gateway client test_modbus_client)>
```

The default is **700ms**.

f. Configure the address filter:

This filter is used by the gateway to determine if a message should be forwarded to a destination device. If the Modbus address in the message matches one or more of the filters, the message is forwarded. If it does not match the filters, the message is not forwarded. Allowed values are 1 through **255** or a hyphen-separated range.

For example:

- To have the client filter for incoming messages that contain the Modbus address of 10, set the index **0** entry to **10**:

```
(config service modbus_gateway client test_modbus_client)>
filter 0 10
(config service modbus_gateway client test_modbus_client)>
```

- To filter for all messages with addresses in the range of 20 to 30, set the index **0** entry to **20-30**:

```
(config service modbus_gateway client test_modbus_client)>
filter 0 20-30
(config service modbus_gateway client test_modbus_client)>
```

To add additional filters, increment the index number. For example, to add an additional filter for addresses in the range of 50-100:

```
(config service modbus_gateway client test_modbus_client)> filter 1
50-100
(config service modbus_gateway client test_modbus_client)>
```

g. If request messages handled by this client should always be forwarded to a specific device, use **fixed server address** to set the device's Modbus address.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config service modbus_gateway client test_modbus_client)> fixed_
server_address value
(config service modbus_gateway client test_modbus_client)>
```

Leave at the default setting of **0** to allow messages that match the Modbus address filter to be forwarded to devices based on the Modbus address in the message.

h. To adjust the Modbus server address downward by the specified value prior to delivering the message, use **adjust server address**.

```
(config service modbus_gateway client test_modbus_client)> adjust_
server_address value
(config service modbus_gateway client test_modbus_client)>
```

where **value** is an integer from **0** to **255**. Leave at the default setting of **0** to not adjust the server address.

If a packet contains a Modbus server address above the amount entered here, the address will be adjusted downward by this amount before the packet is delivered. This allows you to configure clients on the gateway that will forward messages to remote devices with the same Modbus address on different buses. For example, if there are two devices on two different buses that have the same Modbus address of 10, you can create two clients on the gateway:

- Client one:
  - **filter** set to **10**.

  This will configure the gateway to deliver all messages that have the Modbus server address of 10 to this device.
- Client two:
  - **filter** set to **20**.
  - **adjust server address** set to **10**.

  This will configure the gateway to deliver all messages that have the Modbus server address address of 20 to the device with address 10.

i. Repeat the above instructions for additional clients.

6. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Modbus hardening

Modbus hardening refers to the process of enhancing the security and reliability of Modbus communications between devices over a network by implementing various protective measures. This includes configuring the Modbus systems to minimize vulnerabilities, applying access controls, using encryption, segmenting networks, upgrading firmware on the devices, as well as monitoring and logging. Modbus hardening is about making the serial communication between devices over a network more secure against cyber threats.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Hardening can involve implementing various security measures, such as:

- **Access control**

  Update the **Services > Modbus Gateway > Gateway servers > Access control list** settings to only allow access to the Modbus service on the specific network interfaces, firewall zones, and source IP addresses that you expect the Modbus queries to come from. See Configure the Modbus gateway for more information.

- **Encryption**

  Further lock down access to the Modbus gateway service on the Connect EZ 4 WS by configuring it to establish a VPN tunnel, then update the access control list as mentioned above to only allow access to the Modbus service through the VPN connection.

- **Network segmentation**

  Use a separate firewall zone for the network interface(s) and/or VPN tunnels that the user will be accessing the Modbus gateway service through to ensure that the Modbus access is separate from other network traffic.

- **Monitoring and logging**

  Utilize Digi Remote Manager or an external logging service to monitor the activity on your Digi router.

- **Firmware upgrades**

  Keep your firmware current so your Connect EZ 4 WS has the most recent security patches and bug fixes.

Note To see how you can implement security measures for you Modbus gateway service, see Use case | Secure your Modbus gateway service.

Use case | Secure your Modbus gateway service

Do you want to secure Modbus messaging across an internet connection to safeguard the information being communicated between Digi devices over your network?
You can by implementing security measures, such as access control, encryption, network segmentation, monitoring and logging, and firmware upgrades to ensure the integrity and confidentiality of Modbus communications between Digi devices on your network.

1. Determine the devices on your network that need to communicate with each other via the Modbus Gateway service.
2. Isolate Modbus traffic using VLANS or separate network interfaces.
3. Implement strong authentication.
4. Define access policies.

   Update the **Services > Modbus Gateway > Gateway servers > Access control list** settings to only allow access to the Modbus service on the specific network interfaces, firewall zones, and source IP addresses that you expect the Modbus queries to come from. See Configure the Modbus gateway for more information.
5. Create a VPN tunnel, such as IPsec or Wireguard, to protect data in transit between your devices.
6. Configure firewalls to monitor and control incoming and outgoing traffic.

By implementing these advanced security protocols and ensuring reliable data transmission, this service effectively addresses the challenges of data integrity and privacy on your network.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Show Modbus gateway status and statistics

You can view status and statistics about location information from either the WebUI or the command line.

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, select **Status** > **Modbus Gateway**.

   The **Modbus Gateway** page appears.

   Statistics related to the Modbus gateway server are displayed. If the message **Server connections not available** is displayed, this indicates that there are no connected clients.

   - To view information about Modbus gateway clients, click **Clients**.
   - To view statistics that are common to both the clients and server, click **Common Statistics**.
   - To view configuration details about the gateway, click the (configuration) icon in the upper right of the gateway's status pane.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Use the show modbus-gateway command at the system prompt:

```
> show modbus-gateway

Server Connection  IP Address    Port   Uptime
-----------------  ------------  -----  ------
modbus_socket      10.42.1.120   49578  6
modbus_socket      10.42.1.120   49586  11

Client                Uptime
--------------------  ------
modbus_socket_41      0
modbus_socket_21      0
modbus_serial_client  426

>
```

   If the message **Server connections not available** is displayed, this indicates that there are no connected clients.

3. Use the show modbus-gateway verbose command at the system prompt to display more information:

```
> show modbus-gateway verbose

Client:               Uptime:
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
------------------------  -------
modbus_socket_41          0
modbus_socket_31          0
modbus_serial_client      580

Common Statistics
-----------------
Configuration Updates          : 1
Client Configuration Failure   : 0
Server Configuration Failure   : 0
Configuration Load Failure     : 0
Incoming Connections           : 4
Internal Error                 : 0
Resource Shortages             : 0

Servers
-------

modbus_socket
-------------
Client Lookup Errors           : 0
Incoming Connections           : 4
Packet Errors                  : 0
RX Broadcasts                  : 0
RX Requests                    : 13
TX Exceptions                  : 0
TX Responses                   : 13

Clients
-------

modbus_socket_41
----------------
Address Translation Errors     : 0
Connection Errors              : 0
Packet Errors                  : 0
RX Responses                   : 4
RX Timeouts                    : 0
TX Broadcasts                  : 0
TX Requests                    : 4

modbus_socket_31
----------------
Address Translation Errors     : 0
Connection Errors              : 0
Packet Errors                  : 0
RX Responses                   : 4
RX Timeouts                    : 0
TX Broadcasts                  : 0
TX Requests                    : 4
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
modbus_serial_client
--------------------
Address Translation Errors    : 0
Connection Errors             : 0
Packet Errors                 : 0
RX Responses                  : 4
RX Timeouts                   : 0
TX Broadcasts                 : 0
TX Requests                   : 4
```

4. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

System time synchronization

System time synchronization refers to the process of coordinating the system time of your Connect EZ 4 WS device with an external, more accurate time source. By default, this synchronization occurs one time per day, but will also synchronize at startup, and in response to a change in the route. There are two configuration parameters that control system time synchronization: **ntpdate** and **system.time.resync_interval**.

The **ntpdate** default configuration includes the following:

- Time zone: **UTC**
- NTP server: the Digi NTP server, **time.digicloud.com**

The **system.time.resync_interval** default configuration includes the following:

- Frequency of the synchronization: **1d** (one day). Set to **0** (zero) for no synchronization except at startup and route change.

No additional configuration is required for the synchronization if the default configuration is sufficient for your setup. However, you can change per-day synchronization, the default time zone, and the default NTP server, as well as adding additional NTP servers. If multiple NTP servers are added, time samples are obtained from each server. Selection algorithms are used to determine the most accurate time. See Configure the system time synchronization for details about changing the default configuration.

The Connect EZ 4 WS device can also be configured to serve as an NTP server, providing NTP services to downstream devices. See Network Time Protocol for more information about NTP server support.

You can also set the local date and time manually, if there is no access to the configured NTP servers or other sources. See Manually set the system date and time for more information.

Configure the system time synchronization

To configure or change the system time synchronization:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **System** > **Time**.
4. Modify the settings.

CAUTION If you enable the NTP service, either disable the server configured in `system time` or make sure to match the server(s) configured in `service ntp server`. If you do not do one of these options, then the System time synchronization may fail, which could result in the following error message: `ntpdate[2981]: the NTP socket is in use, exiting`.

System time setting	UI Configuration
Timezone	Choose the time zone closest to where the device is located. The default time zone is **UTC**.
Resynchronization interval	Type the frequency of the daily update. The default is **1d** (one day). Set to **0** (zero) for no synchronization.
Time sources	a. Click **+** to add a new time source. The time source is now enabled by default. b. In **Type of time source**, choose **NTP** as the external source to which the device synchronizes. • If using an NTP, click **+** to add the **Server** hostname. The default is time.devicecloud.com. Note If multiple NTP servers are added, time samples are obtained from each server. Selection algorithms are used to determine the most accurate time.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Type **system time** to enter configuration mode for system time.

```
> config system time
[config system time]>
```

4. Add a new time source or modify the settings.

CAUTION If you enable the NTP service, either disable the server configured in **system time** or make sure to match the server(s) configured in **service ntp server**. If you do not do one of these options, then the System time synchronization may fail, which could result in the following error message: **ntpdate[3981]: the NTP socket is in use, exiting**.

System time settings	NTP configuration

timezone	(Optional) Set the timezone for the location of your Connect EZ 4 WS device. The default is UTC.
	`(config)> system time timezone value`
	`(config)>`
	Where value is the timezone using the format specified with the following command:
	`(config)> system time timezone ?`
	Timezone: The timezone for the location of this device. This is used to adjust the time for log messages. It also affects actions that occur at a specific time of day.
	Format:
	Africa/Abidjan
	Africa/Accra
	Africa/Addis_Ababa
	...
	`(config)>`

ntpsynchronization interval	Type the frequency of the daily update.
	The default is 1d (one day). Set to 0 (zero) for no synchronization.
	`(config) system time ntpsync_interval value`
	`(config) >`
	Where value is [w][d][h][m][s]. For more information:
	`(config)> system time ntpsync_interval ?`

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services System time synchronization

System time setting	NTP configuration
	Format: number (w|d|h|m|s)... Optional: yes Default value: 1 d Current value: 1 d (config)>
time sources	Add a new time source. Note The default NTP server is time.devicecloud.com. • If adding one or more NTP servers: add service ntp server 0 time.server.com Note If multiple NTP servers are added, time samples are obtained from each server. Selection algorithms are used to determine the most accurate time. Note This list is synchronized with the list of servers included with NTP server configuration, and changes made to one will be reflected in the other. See Configure the device as an NTP server for more information about NTP server configuration.

5. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Test the connection to the NTP servers

The following procedure tests the configured NTP servers for connectivity. This test does not affect the device's current local date and time.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. Test the configured NTP servers for connectivity:

```
> system time test
Testing NTP server time.devicecloud.com on UDP port 123...
server 52.2.48.156, stratum 2, offset -0.000216, delay 0.01000
server 35.164.164.56, stratum 2, offset -0.000994, delay 0.07166
24 Aug 22:04:38 ntpdate[26496]: adjust time server 52.2.48.156 offset -
0.000216 sec
NTP test sync successful

Testing NTP server time.acns.com on UDP port 123...
server 128.136.167.138, stratum 3, offset -0.001671, delay 0.00422
24 Aug 22:04:38 ntpdate[26497]: adjust time server 128.136.167.138 offset
-0.001672 sec
NTP test sync successful
>
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Manually synchronize with the NTP server

The following procedure performs a NTP query to the configured servers and set the local time to the first server that responds.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Synchronize the device's local date and time:

```
> system time sync
24 Aug 22:04:38 ntpdate[2328]: step time server 52.2.48.156 offset -
0.000487 sec
NTP sync to time.devicecloud.com successful
>
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Manually set the system date and time

If your network restricts access to NTP servers, use this procedure to set the local date and time.

This procedure is available at the Admin CLI only.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Set the device's local date and time:

```
> system time set value
>
```

   where *value* is the date in year-month-day hour:minute:second format. The *value* must be surrounded by double quotes. For example:

```
> system time set "2024-01-12 13:18:00"
>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Network Time Protocol

Network Time Protocol (NTP) enables devices connected on local and worldwide networks to synchronize their internal software and hardware clocks to the same time source. The Connect EZ 4 WS device can be configured as an NTP server, allowing downstream hosts that are attached to the device's Local Area Network to synchronize with the device.

When the device is configured as an NTP server, it also functions as an NTP client. The NTP client will be consistently synchronized with one or more upstream NTP servers, which means that NTP packets are transferred every few seconds. A minimum of one upstream NTP server is required. Additional NTP servers can be configured. If multiple servers are configured, a number of time samples are obtained from each of the servers and a subset of the NTP clock filter and selection algorithms are applied to select the best of these.

See Configure the device as an NTP server for information about configuring your device as an NTP server.

Configure the device as an NTP server

Required Configuration Items

- Enable the NTP service.
- At least one upstream NTP server for synchronization. The default setting is the Digi NTP server, time.devicecloud.com.

Additional Configuration Options

- Additional upstream NTP servers.
- Access control list to limit downstream access to the Connect EZ 4 WS device's NTP service.
- The time zone setting, if the default setting of UTC is not appropriate.

To configure the Connect EZ 4 WS device's NTP service:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services > NTP**.
4. Enable the Connect EZ 4 WS device's NTP service by clicking **Enable**.
5. (Optional) Configure the access control list to limit downstream access to the Connect EZ 4 WS device's NTP service.
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's NTP service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the NTP service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv6 address or network that can access the device's NTP service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 2001:cdb8::/48.
        - **any**: No limit to IPv6 addresses that can access the NTP service.
     d. Click **+** again to list additional IP addresses or networks.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access to hosts connected through a specified interface on the device:
  a. Click **Interfaces**.
  b. For **Add Interface**, click **+**.
  c. For **Interface**, select the appropriate interface from the dropdown.
  d. Click **+** again to allow access through additional interfaces.
- To limit access based on firewall zones:
  a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
  b. For **Add Zone**, click **+**.
  c. For **Zone**, select the appropriate firewall zone from the dropdown.
  See Firewall configuration for information about firewall zones.
  d. Click **+** again to allow access through additional firewall zones.

Note By default, the access control list for the NTP service is empty, which means that all downstream hosts connected to the Connect EZ 4 WS device can use the NTP service.

6. Enable **Fall back to local clock** to allow the device's local system clock to be used as backup time source.
7. (Optional) Add upstream NTP servers that the device will use to synchronize its time. The default setting is **time.devicecloud.com**.
   - To change the default value of the NTP server:
     a. Click **NTP servers**.
     b. For **Server**, type a new server name.
   - To add an NTP server:
     a. Click **NTP servers**.
     b. For **Add Server**, click **+**.
     c. For **Server**, enter the hostname of the upstream NTP server that the device will use to synchronize its time.
     d. Click **+** to add additional NTP servers. If multiple servers are included, servers are tried in the order listed until one succeeds.

Note This list is synchronized with the list of servers included with NTP client configuration, and changes made to one will be reflected in the other. See Configure the system time synchronization for more information about NTP client configuration.

8. (Optional) Configure the system time zone. The default is **UTC**.
   a. Click **System > Time**.
   b. Select the **timezone** for the location of your Connect EZ 4 WS device.
9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable the ntp service:

```
(config)> service ntp enable true
(config)>
```

4. (Optional) Add an upstream NTP server that the device will use to synchronize its time to the appropriate location in the list of NTP servers. The default setting is **time.devicecloud.com**.
   - To delete the default NTP server, **time.devicecloud.com**:

```
(config)> del service ntp server 0
(config)>
```

   - To add the NTP server to the beginning of the list, use the index value of **0** to indicate that it should be added as the first server.

```
(config)> add service ntp server 0 time.server.com
(config)>
```

   - To add the NTP server to the end of the list, use the index keyword **end**:

```
(config)> add service ntp server end time.server.com
(config)>
```

   - To add the NTP server in another location in the list, use an index value to indicate the appropriate position. For example:

```
(config)> add service ntp server 1 time.server.com
(config)>
```

Note This list is synchronized with the list of servers included with NTP client configuration, and changes made to one will be reflected in the other. See Configure the system time synchronization for more information about NTP client configuration.

5. Allow the device's local system clock to be used as backup time source:

```
(config)> service ntp local true
(config)>
```

6. (Optional) Configure the access control list to limit downstream access to the Connect EZ 4-WS device's NTP service.
   - To limit access to specified IPv4 addresses and networks:

```
(config)> add service ntp acl address end value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 192.168.1.0/24.
- any: No limit to IPv4 addresses that can access the NTP server agent.

Repeat this step to list additional IP addresses or networks.

- To limit access to specified IPv6 addresses and networks:

```
(config)> add service ntp acl address4 end value
(config)>
```

Where value can be:

- A single IP address or host name.
- A network designation in CIDR notation, for example, 2001:db8::/48.
- any: No limit to IPv6 addresses that can access the NTP server agent.

Repeat this step to list additional IP addresses or networks.

- To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add service ntp acl interface end value
(config)>
```

Where value is an interface defined on your device.

Display a list of available interfaces:

Use **... network interface ?** to display interface information:

Repeat this step to list additional interfaces.

- To limit access based on firewall zones:

```
(config)> add service ntp acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the **any** keyword.

Display a list of available firewall zones:

Type **... firewall zone ?** at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------
  ------------------------

    any
    dynamic_routes
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

Note By default, the access control list for the NTP service is empty, which means that all downstream hosts connected to the Connect EZ 4 WS device can use the NTP service.

7. (Optional) Set the timezone for the location of your Connect EZ 4 WS device. The default is UTC:

```
(config)> system time timezone value
(config)>
```

Where *value* is the timezone using the format specified with the following command:

```
(config)> system time timezone ?

Timezone: The timezone for the location of this device. This is used to
adjust the time for log
messages. It also affects actions that occur at a specific time of day.
Format:
  Africa/Abidjan
  Africa/Accra
  Africa/Addis_Ababa
  ...

(config)>
```

8. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

Show status and statistics of the NTP server

You can display status and statistics for active NTP servers.

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.

1. On the main menu, click **Status**.
2. Under **Services**, click **NTP**.
   The NTP server status page is displayed.

Command line

Show NTP information

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Use the show ntp command at the system prompt:

```
> show ntp

NTP Status Status
-----------------

Status      : up
Sync Status : up

Remote          Refid          ST  T  when  Poll  Reach  Delay
Offset  Jitter
--------------  -------------  --  -  ----  ----  -----  ------  ------
 +ec2-52-2-46-158 129.6.15.33    2  u   181   1024+  377    33.078
+1.364   0.094
 139.130.197.128 139.227.205.3   3  u   153   1024+  3      43.183  -
1.865   0.382

>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure a multicast route

Multicast routing allows a device to transmit data to a single multicast address, which is then distributed to a group of devices that are configured to be members of that group.

To configure a multicast route:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

b. Click the **Device ID**.

c. Click **Settings**.

d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Services** > **Multicast**.
4. For **Add Multicast route**, type a name for the route and click **+**.
5. The new route is enabled by default. To disable, toggle off **Enable**.
6. Type the **Source address** for the route. This must be a multicast IP address between 224.0.0.1 and 239.255.255.255.
7. Select a **Source interface** where multicast packets will arrive.
8. To add one or more destination interfaces that the Connect EZ 4 WS device will send multicast packets to:
   a. Click to expand **Destination interfaces**.
   b. Click **+**.
   c. For **Destination interface**, select the interface.
   d. Repeat for additional destination interfaces.
9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add the multicast route. For example, to add a route named **test**:

```
(config)> add service multicast test
(config service multicast test)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. The multicast route is enabled by default. If it has been disabled, enable the route:

```
(config service multicast test)> enable true
(config service multicast test)>
```

5. Set the source address for the route. This must be a multicast IP address between 224.0.0.1 and 239.255.255.255.

```
(config service multicast test)> set ip-address
(config service multicast test)>
```

6. Set the source interface for the route where multicast packets will arrive:
   a. Use the ? to determine available interfaces.
   b. Set the interface. For example:

```
(config service multicast test)> src_interface /network/interface/eth1
(config service multicast test)>
```

7. Set a destination interface that the Connect EZ 4 WS device will send multicast packets to:
   a. Use the ? to determine available interfaces.
   b. Set the interface. For example:

```
(config service multicast test)> add interface end
/network/interface/eth1
(config service multicast test)>
```

   c. Repeat for each additional destination interface.
8. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Ethernet network bonding

The Connect EZ 4 WS device supports bonding mode for the Ethernet network. This allows you to configure the device so that Ethernet ports share one IP address. When both ports are being used, they act as one Ethernet network port.

Required configuration items

- Enable Ethernet bonding.
- The mode, either:
  - Active-backup. Provides fault tolerance.
  - Round-robin. Provides load balancing as well as fault tolerance.
- The Ethernet devices in the bonded pool.
- Create a new network interface for the bonded Ethernet devices, and disable the any interfaces associated with those Ethernet devices.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.


   The **Configuration** window is displayed.
3. Click **Network** > **Ethernet bonding**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


4. For **Add bond device**, click **+**

The bond device is enabled by default. To disable, toggle off **Enable**.

5. For **Mode**, select either:
   - **Active-backup**: Transmits data on only one of the bonded devices at a time. When the active device fails, the next available device in the list is chosen. This mode provides for fault tolerance.
   - **Round-robin**: Alternates between bonded devices to provide load balancing as well as fault tolerance.
6. Click to expand **Devices**.
7. Add Ethernet devices:
   a. For **Add device**, click **+**.




   b. For **Device**, select an Ethernet device to participate in the bond pool.
   c. Repeat for each appropriate Ethernet device.



8. Create a new network interface that is linked to the Ethernet bond:
   a. Click **Network > Interface**.
   b. For **Add interface**, type a name for the interface and click **+**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. For **Device**, select the Ethernet bond created above.



d. Complete the rest of the interface configuration. See Configure a Local Area Network (LAN) for further information.

e. Disable any other interfaces associated with the devices that were added to the Ethernet bond.

For example, if ETH1 and ETH2 were added to the Ethernet bond, disable the ETH1 and ETH2 interfaces.

In some cases, the device may be a part of a bridge, in which case you should remove the device from the bridge.

See Configure a bridge for more information.

3. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a network bond:

```
(config)> add network bond name
(config network bond name)>
```

For example, to create an Ethernet bond named eth_bond:

```
(config)> add network bond eth_bond
(config network bond eth_bond)>
```

4. The new network bond is enabled by default. To disable:

```
(config network bond eth_bond)> enable false
(config network bond eth_bond)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Set the mode:

```
(config network bond eth_bond)> mode value
(config network bond eth_bond)>
```

where value is either:

- **active-backup**: Transmits data on only one of the bonded devices at a time. When the active device fails, the next available device in the list is chosen. This mode provides for fault tolerance.
- **round-robin**: Alternates between bonded devices to provide load balancing as well as fault tolerance.

6. Add Ethernet devices:
   a. Use the ? to determine available devices:

```
(config network bond eth_bond)> ..., network device ?

 Additional Configuration
 ------------------------------------------------------------------------
 -------

 loopback

(config network bond eth_bond)>
```

   b. To add the device name to the end of the list:

```
(config network bond eth_bond)> add device end /network/device
(config network bond eth_bond)>
```

   c. Repeat to add additional device names to the list.
7. Create a new network interface that is linked to the Ethernet bond:
   a. Type .. to return to the root of the configuration:

```
(config network bond eth_bond)> ..
(config)>
```

   b. Create a new interface, for example:

```
(config)> add network interface eth_bond_interface
(config network interface eth_bond_interface)>
```

   c. For **device**, select the Ethernet bond created above:

```
(config network interface eth_bonding_interface)> device
/network/bond/eth_bond
(config network interface eth_bonding_interface)>
```

   d. Complete the rest of the interface configuration. See Configure a Local Area Network (LAN) for further information.
8. Disable any other interfaces associated with the devices that were added to the Ethernet bond.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

For example, if ETH1 and ETH2 were added to the Ethernet bond, and they are included with the ETH1 and ETH2 interfaces:

a. Type .. to return to the root of the configuration:

```
(config network interface eth_bonding_interface)> ..
(config)>
```

b. Disable the interfaces:

```
(config)> network interface eth1 enable false
(config)> network interface eth2 enable false
(config)>
```

In some cases, the device may be a part of a bridge, in which case you should remove the device from the bridge.

See Configure a bridge for more information.

9. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

10. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Enable service discovery (mDNS)

Multicast DNS (mDNS) is a protocol that resolves host names in small networks that do not have a DNS server. You can enable the Connect EZ 4 WS device to use mDNS.

Note: This feature is enabled by default.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Services** > **Service Discovery (mDNS)**.
4. The mDNS service is enabled by default. To disable, click to toggle off **Enable**.
5. Click **Access control list** to configure access control.
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's mDNS service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the mDNS service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv6 address or network that can access the device's mDNS service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 2001:db8::/48.
        - **any**: No limit to IPv6 addresses that can access the mDNS service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the device:
     a. Click **Interfaces**.
     b. For **Add Interface**, click **+**.
     c. For **Interface**, select the appropriate interface from the dropdown.
     d. Click **+** again to allow access through additional interfaces.
   - To limit access based on firewall zones:
     a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
     b. For **Add Zone**, click **+**.
     c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
     d. Click **+** again to allow access through additional firewall zones.
8. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. The mDNS service is enabled by default. To disable:

```
(config)> service adns enable false
(config)>
```

4. Configure access control:

   - To limit access to specified IPv4 addresses and networks:

```
(config)> add service adns acl address end value
(config)>
```

     Where **value** can be:

     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**: No limit to IPv4 addresses that can access the mDNS service.

     Repeat this step to list additional IP addresses or networks.

   - To limit access to specified IPv6 addresses and networks:

```
(config)> add service adns acl address6 end value
(config)>
```

     Where **value** can be:

     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:db8::/48.
     - **any**: No limit to IPv6 addresses that can access the mDNS service.

     Repeat this step to list additional IP addresses or networks.

   - To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

```
(config)> add service adns acl interface end value
(config)>
```

     Where **value** is an interface defined on your device.

     Display a list of available interfaces:

     Use **... network interface** ? to display interface information:

     Repeat this step to list additional interfaces.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access based on firewall zones:

```
(config)> add service sdkm act zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the any keyword.

Display a list of available firewall zones:

Type ... firewall zone ? at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------
------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

5. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

6. Type exit to exit the Admin CLI.

Depending on your device configuration, you may be presented with an Access selection menu. Type quit to disconnect from the device.

Use the iPerf service

Your Connect EZ 4 WS device includes an iPerf3 server that you can use to test the performance of your network.

iPerf3 is a command-line tool that measures the maximum network throughput an interface can handle. This is useful when diagnosing network speed issues.

The Connect EZ 4 WS implementation of iPerf3 supports testing with both TCP and UDP.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note Using iPerf clients that are at a version earlier than iPerf3 to connect to the Connect EZ 4 WS device's iPerf3 server may result in unpredictable results. As a result, Digi recommends using an iPerf client at version 3 or newer to connect to the Connect EZ 4 WS device's iPerf3 server.

Required configuration items

- Enable the iPerf server on the Connect EZ 4 WS device.
- An iPerf3 client installed on a remote host. iPerf3 software can be downloaded at https://iperf.fr/iperf-download.php.

Additional configuration items

- The port that the Connect EZ 4 WS device's iPerf server will use to listen for incoming connections.
- The access control list for the iPerf server.

  When the iPerf server is enabled, the Connect EZ 4 WS device will automatically configure its firewall rules to allow incoming connections on the configured listening port. You can restrict access by configuring the access control list for the iPerf server.

To enable the iPerf3 server:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **iPerf**.
4. Click **Enable**.
5. (Optional) For **iPerf Server Port**, type the appropriate port number for the iPerf server listening port.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Use the iPerf service

8. (Optional) Click to expand **Access control list** to restrict access to the iPerf server.
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv4 address or network that can access the device's iperf service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation. For example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the iperf service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click **+**.
     c. For **Address**, enter the IPv6 address or network that can access the device's iperf service. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation. For example, 2001:db8::/48.
        - **any**: No limit to IPv6 addresses that can access the iperf service.
     d. Click **+** again to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the device:
     a. Click **Interfaces**.
     b. For **Add Interface**, click **+**.
     c. For **Interface**, select the appropriate interface from the dropdown.
     d. Click **+** again to allow access through additional interfaces.
   - To limit access based on firewall zones:
     a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
     b. For **Add Zone**, click **+**.
     c. For **Zone**, select the appropriate firewall zone from the dropdown.
     See Firewall configuration for information about firewall zones.
     d. Click **+** again to allow access through additional firewall zones.
7. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Enable the iPerf server:

```
[config]> service iperf enable true
[config]>
```

4. (Optional) Set the port number for the iPerf server listening port. The default is 5201.

```
[config]> service iperf port port_number
[config]>
```

5. (Optional) Set the access control list to restrict access to the iPerf server:
   - To limit access to specified IPv4 addresses and networks:

     ```
     [config]> add service iperf acl address end value
     [config]>
     ```

     Where **value** can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**: No limit to IPv4 addresses that can access the service type.

     Repeat this step to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:

     ```
     [config]> add service iperf acl address6 end value
     [config]>
     ```

     Where **value** can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:db8::/48.
     - **any**: No limit to IPv6 addresses that can access the service type.

     Repeat this step to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

     ```
     [config]> add service iperf acl interface end value
     [config]>
     ```

     Where **value** is an interface defined on your device.

     Display a list of available interfaces.

     Use **... network interface** ? to display interface information.

     Repeat this step to list additional interfaces.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access based on firewall zones

```
(config)> add service tperf acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the any keyword.

Display a list of available firewall zones:

Type ... firewall zone ? at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------
  ------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

7. Type exit to exit the Admin CLI.

Depending on your device configuration, you may be presented with an Access selection menu. Type quit to disconnect from the device.

Example performance test using iPerf3

On a remote host with iPerf3 installed, enter the following command:

```
$ iperf3 -c device_ip
```

where device_ip is the IP address of the Connect EZ 4 WS device. For example:

```
$ iperf3 -c 192.168.2.1
Connecting to host 192.168.2.1, port 5201
[  4] local 192.168.1.100 port 54924 connected to 192.168.1.1 port 5201
[ ID] Interval           Transfer     Bandwidth       Retr  Cwnd
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
[  4]   0.00-1.00   sec  26.7 MBytes   224 Mbits/sec    0   2.16 MBytes
[  4]   1.00-2.00   sec  28.4 MBytes   238 Mbits/sec   28   1.19 MBytes
[  4]   2.00-3.00   sec  29.6 MBytes   248 Mbits/sec    0   1.40 MBytes
[  4]   3.00-4.00   sec  31.3 MBytes   263 Mbits/sec    0   1.51 MBytes
[  4]   4.00-5.00   sec  32.1 MBytes   269 Mbits/sec    0   1.56 MBytes
[  4]   5.00-6.00   sec  32.5 MBytes   273 Mbits/sec    0   1.58 MBytes
[  4]   6.00-7.00   sec  33.5 MBytes   281 Mbits/sec    0   1.60 MBytes
[  4]   7.00-8.00   sec  33.7 MBytes   283 Mbits/sec    0   1.61 MBytes
[  4]   8.00-9.00   sec  33.5 MBytes   281 Mbits/sec    0   1.60 MBytes
[  4]   9.00-10.00  sec  33.2 MBytes   279 Mbits/sec    0   1.59 MBytes
- - - - - - - - - - - - - - - - - - - - - - - - -
[ ID] Interval           Transfer     Bandwidth       Retr
[  4]   0.00-10.00  sec   313 MBytes   264 Mbits/sec   28             sender
[  4]   0.00-10.00  sec   313 MBytes   262 Mbits/sec                  receiver

iperf Done.
$
```

Configure the ping responder service

Your Connect EZ 4 WS device's ping responder service replies to ICMP and ICMPv6 echo requests. The service is enabled by default. You can disable the service, or you can configure the service to use an access control list to limit the service to specified IP addresses, interfaces, and/or zones.

To enable the ping responder service:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Services** > **Ping responder**.

   The ping responder service is enabled by default. Click **Enable** to disable all ping responses.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Click to expand **Access control list** to restrict ping responses to specified IP addresses, interfaces, and/or zones.
   - To limit access to specified IPv4 addresses and networks:
     a. Click **IPv4 Addresses**.
     b. For **Add Address**, click ✚.
     c. For **Address**, enter the IPv4 address or network that can access the device's ping responder. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 192.168.1.0/24.
        - **any**: No limit to IPv4 addresses that can access the ping responder.
     d. Click ✚ again to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:
     a. Click **IPv6 Addresses**.
     b. For **Add Address**, click ✚.
     c. For **Address**, enter the IPv6 address or network that can access the device's ping responder. Allowed values are:
        - A single IP address or host name.
        - A network designation in CIDR notation, for example, 2001:cbb::/48.
        - **any**: No limit to IPv6 addresses that can access the ping responder.
     d. Click ✚ again to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the device:
     a. Click **Interfaces**.
     b. For **Add Interface**, click ✚.
     c. For **Interface**, select the appropriate interface from the dropdown.
     d. Click ✚ again to allow access through additional interfaces.
   - To limit access based on firewall zones:
     a. Click **Zones**. By default, there are three firewall zones already configured: Internal, Edge, and IPsec.
     b. For **Add Zone**, click ✚.
     c. For **Zone**, select the appropriate firewall zone from the dropdown.
        See Firewall configuration for information about firewall zones.
     d. Click ✚ again to allow access through additional firewall zones.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Enable the tftef server:

```
[config]> service tperf enable true
[config]>
```

4. (Optional) Set the port number for the tftef server listening port. The default is 5201.

```
[config]> service tperf port port_number
[config]>
```

5. (Optional) Set the access control list to restrict access to the tftef server:
   - To limit access to specified IPv4 addresses and networks:

     ```
     [config]> add service tperf acl address end value
     [config]>
     ```

     Where **value** can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 192.168.1.0/24.
     - **any**: No limit to IPv4 addresses that can access the service type.

     Repeat this step to list additional IP addresses or networks.
   - To limit access to specified IPv6 addresses and networks:

     ```
     [config]> add service tperf acl address6 end value
     [config]>
     ```

     Where **value** can be:
     - A single IP address or host name.
     - A network designation in CIDR notation, for example, 2001:db8::/48.
     - **any**: No limit to IPv6 addresses that can access the service type.

     Repeat this step to list additional IP addresses or networks.
   - To limit access to hosts connected through a specified interface on the Connect EZ 4 WS device:

     ```
     [config]> add service tperf acl interface end value
     [config]>
     ```

     Where **value** is an interface defined on your device.

     Display a list of available interfaces.

     Use **... network interface** ?to display interface information.

     Repeat this step to list additional interfaces.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To limit access based on firewall zones

```
(config)> add service tperf acl zone end value
(config)>
```

Where value is a firewall zone defined on your device, or the any keyword.

Display a list of available firewall zones

Type ... firewall zone ? at the config prompt:

```
(config)> ... firewall zone ?

Zones: A list of groups of network interfaces that can be
referred to by packet
filtering rules and access control lists.

  Additional Configuration
  ------------------------------------------------------------
  ------------------------

  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup

(config)>
```

Repeat this step to include additional firewall zones.

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

7. Type exit to exit the Admin CLI.

Depending on your device configuration, you may be presented with an Access selection menu. Type quit to disconnect from the device.

Example performance test using iPerf3

On a remote host with Iperf3 installed, enter the following command:


```
$ tperf3 -c device_ip
```

where device_ip is the IP address of the Connect EZ 4 WS device. For example:

```
$ tperf3 -c 192.168.2.1
Connecting to host 192.168.2.1, port 5201
[  4] local 192.168.2.100 port 54924 connected to 192.168.2.1 port 5201
[ ID] Interval           Transfer     Bandwidth       Retr  Cwnd
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Services Configure the ping responder service



Digi Connect EZ 4 WS User Guide 660

Applications

The Connect EZ 4 WS supports Python 3.8 and provides you with the ability to run Python applications on the device interactively or from a file. You can also specify Python applications and other scripts to be run each time the device system restarts, at specific intervals, or at a specified time.

This chapter contains the following topics:

Develop Python applications 552
Set up the Connect EZ 4 WS to automatically run your applications 555
Start an interactive Python session 557
Run a Python application at the shell prompt 560
Configure scripts to run manually 562
Start a manual script 563
Python versions and corresponding DAL OS firmware versions 564

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Develop Python applications

The Connect EZ4 WS features a standard Python 3.8 distribution. Python is a dynamic, object-oriented language for developing software applications, from simple programs to complex embedded applications. Digi offers the Digi for PyCharm Plugin to help you while writing, building, and testing your application. See Create and test a Python application.

In addition to the standard Python library, the Connect EZ4 WS includes a set of extensions to access its configuration and interfaces. See Python modules.

The Connect EZ4 WS provides you with the ability to:

- Run Python applications on the device interactively or from a file.
- Specify Python applications and other scripts to be run each time the device system restarts, at specific intervals, or at a specified time. See Configure scripts to run automatically.
- Use pip to install Python packages.

> **Note** Although pip is provided to help facilitate the installation of Python packages, there are limitations in Python package support due to package dependencies, storage limitations, and other issues.

This section contains the following topics:

Set up the Connect EZ4 WS for Python development 553
Create and test a Python application 555
Python modules 567

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 552 / 927

Set up the Connect EZ 4 WS for Python development

1. Access the Connect EZ 4 WS local web interface.
   a. Use an Ethernet cable to connect the Connect EZ 4 WS to your local laptop or PC. The factory Setup IP address is **192.168.2.1**.
   b. Log into the Connect EZ 4 WS WebUI as a user with full admin access rights. The default user name is **admin** and the default password is the unique password printed on the label packaged with your device.
2. Go to the Configuration window.
   a. On the menu, click **System**.
   b. Under **Configuration**, click **Device Configuration**. The Configuration window displays.
3. Enable service discovery (mDNS).
   a. Click **Services** > **Service Discovery (mDNS)**.
   b. **Enable** the mDNS service.

Note For more information, see Enable service discovery (mDNS).

4. Configure SSH access.
   a. Click **Services** > **SSH**.
   b. Click **Enable**.

Note For more information, see the following topics: Configure SSH access, Use SSH with key authentication, and Allow remote access for web administration and SSH.

5. Enable shell access.
   a. Click **Authentication** > **Groups** > **admin**.
   b. Click the **Interactive shell access** option.
   c. If this option is not displayed, see Enable shell access.
6. Click **Apply** to save the configuration and apply the changes. The **Apply** button is located at the top of the WebUI page. You may need to scroll to the top of the page to locate it.

Create and test a Python application

To develop a Python application for the Connect EZ 4 WS:

1. Set up the Connect EZ 4 WS for Python development.
2. Create and test your application with:

- PyCharm. You can create, build, and remotely launch your application in the Connect EZ 4 WS.
- Your preferred editor and manually transfer the application, install dependencies, and launch in the Connect EZ 4 WS.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Develop an application in PyCharm

The Digi Iot PyCharm Plugin allows you to write, build and run Python applications for Digi devices in a quick and easy way. See the Digi XBee PyCharm IDE Plugin User Guide for details.

This is what you can do with it:

- Create Python projects from scratch or import one of the available examples.
- Get help while you write your code thanks to the syntax highlight, quick documentation, and code completion features.
- Build and upload Python applications to your Digi device with just one click.
- Add libraries that facilitate the usage of external peripherals or non-standard APIs.
- Communicate with your Digi device through the integrated SSH console to see the application output or execute quick tests.

Manually install and launch an application

To create, build, and launch your application:

1. Write your Python application code. Code can include:
   - Any Python 3.8 standard features.
   - Access to the Connect EZ 4 WS configuration and hardware with the Python modules.
   - Third-party modules included in the Connect EZ 4 WS, for example:
     - pySerial 3.4
     - Eclipse Paho MQTT Python Client
   - Any other third-party module implemented in Python.
2. Install the application in **/etc/config/scripts** directory.
3. Launch your application:
   - Run your application at the shell prompt.
   - Configure your application to run automatically.

PyCharm FAQ: My Connect EZ 4 WS is not listed in Digi Device Selector

If an Connect EZ 4 WS does not appear on the list of the Digi Device Selector:

- Ensure that your device has the mDNS service enabled and is on the same network as the computer. See Set up the Connect EZ 4 WS for Python development.
- Or click the link **Click here to add it manually** to specify the IP address, port, username, and password.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



Example: Configure a custom port to listen for incoming socket connections

The following example Python script configures a custom port, port 9999, to accept incoming socket connections.

You will also need to add a custom firewall rule to accept the incoming traffic on this port.

Example script

```
import socket
import socketserver

class MyTCPHandler(socketserver.BaseRequestHandler):
    """
    The request handler class for our server.

    It is instantiated once per connection to the server, and must
    override the handle() method to implement communication to the
    client.
    """

    def handle(self):
        # self.request is the TCP socket connected to the client
        self.data = self.request.recv(1024).strip()
        print("{} wrote:".format(self.client_address[0]))
        print(self.data)
        # just send back the same data, but upper-cased
        self.request.sendall(self.data.upper())
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
if __name__ == "__main__":
    HOST, PORT = '', 9999

    # Create the server, binding to localhost on port 9999
    with socketserver.TCPServer((HOST, PORT), MyTCPHandler) as server:
        # Activate the server; this will keep running until you
        # interrupt the program with Ctrl-C
        print("Waiting for data...")
        server.serve_forever()
```

Create a custom firewall rule

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.


   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Firewall** > **Custom rules**.
4. **Enable** the custom rules.
5. For **Rules**, type the following:

```
iptables -I INPUT -p tcp --dport 9999 -j ACCEPT
```



6. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable custom firewall rules:

```
(config)> firewall custom enable true(config)>
```

4. Set the shell command that will execute the custom firewall rules script:

```
(config)> firewall custom rules "iptables -I INPUT -p tcp --dport 9999 -j
ACCEPT"
(config)>
```

5. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Python modules

The Connect EZ 4 WS supports Python 3.8 and provides you with the ability to run Python applications on the device interactively or from a file. It also offers extensions to manage your Connect EZ 4 WS.

- The **digidevice** module provides platform-specific extensions that allow you to interact with the device's configuration and interfaces.
  The following submodules are included with the **digidevice** module.
  - LEDs: **digidevice.led**
  - SMS: **digidevice.sms**
  - GPS: **digidevice.location**
  - Digi Remote Manager:
    - **digidevice.datapoint**
    - **digidevice.device_request**
    - **digidevice.name**
  - Device configuration: **digidevice.config**
  - Command line interface: **digidevice.cli**

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Access runtime database: **digidevice.runt**
- Set the maintenance window: **digidevice.maintenance**

- Use the Python **serial** module—pyserial—to access the serial ports.
- Eclipse Paho MQTT Python client enables applications to connect to an MQTT broker to publish messages, and to subscribe to topics and receive published messages.

Note Module-related documentation is in the Digidevice modules section.

Digidevice module

The Python **digidevice** module provides platform-specific extensions that allow you to interact with the device's configuration and interfaces. The following submodules are included with the **digidevice** module:

This section contains the following topics:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use digidevice.cli to execute CLI commands

Use the **digidevice.cli** Python module to issue CLI commands from Python to retrieve status and statistical information about the device.

For example, to display the system status and statistics by using an interactive Python session, use the show system command with the cli module.

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 30 2023, 22:47:13) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **cli** submodule:

```
>>> from digidevice import cli
>>>
```

4. Execute a CLI command using the **cli.execute(command)** function. For example, to print the system status and statistics to stdout using the **show system** command:

```
>>> response = cli.execute("show system")
>>>
>>> print (response)

  Model                    : Digi Connect EZ 4 WS
  Serial Number            : Connect EZ 4 WSxxxxxxxxyyyyyyy
  SKU                      : Connect EZ 4 WS
  Hostname                 : Connect EZ 4 WS
  MAC Address              : BF:3D:E3:4F:11:19

  Hardware Version         : 30001947-01 1P
  Firmware Version         : 23.3
  Alt. Firmware Version    : 23.3
  Alt. Firmware Build Date : Fri, Jan 12, 2024 12:10:00
  Bootloader Version       : 19.7.23.6-13f93daaed

  Current Time             : Thu, Jan 11, 2024 12:10:00 +0000
  CPU                      : 1.4%
  Uptime                   : 6 days, 6 hours, 31 minutes, 57 seconds
(Celsius)
  Temperature              : 40C
  Location                 :
  Contact                  :

>>>
```

5. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Help for using Python to execute Connect EZ 4 WS CLI commands

Get help executing a CLI command from Python by accessing help for **cli.execute**.

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 30 2022, 23:47:11) [GCC 11.3.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **cli** submodule:

```
>>> from digidevice import cli
>>>
```

4. Use the help command with **cli.execute**:

```
>>> help(cli.execute)
Help on function execute in module digidevice.cli:

execute(command, timeout=0)
Execute a CLI command with the timeout specified returning the results.
...
```

5. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Use digidevice.datapoint to upload custom datapoints to Digi Remote Manager

Use the **datapoint** Python module to upload custom datapoints to Digi Remote Manager.

The following characteristics can be defined for a datapoint:

- Stream ID
- Value
- (Optional) Data type
  - integer
  - long
  - float
  - double
  - string
  - binary
- Unit's (optional)
- Timestamp (optional)
- Location (optional)

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Tuple of latitude, longitude and altitude
- Description (optional)
- Quality (optional)
  - An integer describing the quality of the data point

For example, to use an interactive Python session to upload datapoints related to velocity, temperature, and the state of the emergency door:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.
2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.4 (main, Mar 30 2022, 22:47:13) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **datapoint** submodule and other necessary modules:

```
>>> from digidevice import datapoint
>>> import time
>>>
```

4. Upload the datapoints to Remote Manager:

```
>>> datapoint.upload("Velocity", 60, unit="mph")
>>> datapoint.upload("Temperature", 34, geo_location=(34.406458, -
1.113632, 129))
>>> datapoint.upload("Emergency_Door", "closed", timestamp=time.time())
```

5. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

You can also upload multiple datapoints:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.
2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.4 (main, Mar 30 2022, 22:47:13) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Import the **datapoint** submodule and other necessary modules:

```
>>> from etgidevice import datapoint
>>> import time
>>>
```

4. Create datapoint objects:

```
>>> p1 = datapoint.DataPoint("Velocity", 10, units="mph")
>>> p2 = datapoint.DataPoint("Temperature", 24, geo_location=[34.468418,
-1.710836, 229])
>>> p3 = datapoint.DataPoint("Emergency_Door", "closed",
timestamp=time.time())
>>>
```

5. Upload the datapoints to Remote Manager:

```
>>> datapoint.upload_multiple([p1, p2, p3])
>>>
```

6. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Once the datapoints have been uploaded to Remote Manager, they can be viewed via Remote Manager or accessed using Web Services calls. See the Digi Remote Manager Programmers Guide for more information on web services and datapoints.

Help for using Python to upload custom datapoints to Remote Manager

Get help for uploading datapoints to your Digi Remote Manager account by accessing help for **datapoint.upload** and **datapoint.upload_multiple**.

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 30 2020, 22:47:11) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **datapoint** submodule and other necessary modules:

```
>>> from etgidevice import datapoint
>>>
```

4. Use the help command with **datapoint.upload**:

```
>>> help(datapoint.upload)
Help on function upload in module etgidevice.datapoint:
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
upload(stream_id:str, data, *, description:str=None,
timestamp:float=None, units:str=None,
geo_location:Tuple[float, float, float]=None, quality:int=None,
data_type:digidevice.datapoint.DataType=None, timeout:float=None)
...
```

5. Use the help command with **datapoint.upload_multiple**:

```
>>> help(datapoint.upload_multiple)
Help on function upload_multiple in module digidevice.datapoint:

upload_multiple(datapoints:list[digidevice.datapoint.DataPoint],
timeout:float=None)
...
```

6. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Use digidevice.config for device configuration

Use the **config** Python module to access and modify the device configuration.

Read the device configuration

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 30 2022, 23:47:13) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **config** submodule:

```
>>> from digidevice import config
>>>
```

4. Use **config.load()** and the **get()** method to return the device's configuration:

   a. Return the entire configuration:

```
>>> from pprint import pprint # use pprint vs. print to make the
output easier to read
>>> cfg = config.load()
>>> pprint(cfg.dump().splitlines())
```

   This returns the device configuration:

```
...
network.interface.lan1.device:/network/bridge/lan1
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
network.interface.lan1.enableIpv4
network.interface.lan1.ipv4.addressWithMask.192.168.2.1/24
network.interface.lan1.ipv4.connectionMonitor.activeProbe
...
```

b. Print a list of available interfaces:

```
>>> cfg = config.load()
>>> interfaces = cfg.get("network.interface")
>>> print(interfaces.keys())
```

This returns the following:

```
['setupIp', 'setupIpWhenLocal', 'lan1', 'loopback', 'wan1']
```

c. Print the IPv4 address of the LAN interface:

```
>>> cfg = config.load()
>>> interfaces = cfg.get("network.interface")
>>> print(interfaces.get("lan.ipv4.address"))
```

Which returns:

```
192.168.2.1/24
```

Modify the device configuration

Use the **set()** and **commit()** methods to modify the device configuration:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 30 2023, 22:47:23) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **config** submodule:

```
>>> from digidevice import config
>>>
```

4. Use **config.load(writable=True)** to enable write mode for the configuration:

```
>>> cfg = config.load(writable=True)
>>>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Use the **set()** method to make changes to the configuration:

```
>>> cfg_set("system_name", "New-Name")
>>>
```

6. Use the **commit()** method to save the changes:

```
>>> cfg_commit()
True
>>>
```

7. Use the **get()** method to verify the change:

```
>>> print(cfg.get("system_name"))
New-Name
>>>
```

Help for using Python to read and modify device configuration

Get help for reading and modifying the device configuration by accessing help for **digidevice.config**:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 2.x.x (main, Mar 30 2022, 23:47:13) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **config** submodule:

```
>>> from digidevice import config
>>>
```

4. Use the help command with **config**:

```
>>> help(config)
Help on module acl.config in acl:

NAME
acl.config - Python interface to ACL configuration (libconfig).
...:
```

5. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Use Python to respond to Digi Remote Manager SCI requests

The **device_request** Python module allows you to interact with Digi Remote Manager by using Remote Manager's Server Command Interface (SCI), a web service that allows users to access information and perform commands that relate to their devices.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use Remote Manager's SCI interface to create SCI requests that are sent to your Connect EZ 4 WS device, and use the **device_request** module to send responses to those requests to Remote Manager.

See the Digi Remote Manager Programmers Guide for more information on SCI.

Task one: Use the device_request module on your Connect EZ 4 WS device to create a response

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.
2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 10 2023, 13:47:13) [GCC 11.3.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **device_request** module:

```
>>> from digidevice import device_request
>>>
```

4. Create a function to handle the request from Remote Manager:

```
>>> def handler(target, request):
...     print ("received request %s for target %s" % (request, target))
...     return "OK"
...
>>>
```

5. Register a callback up function that will be called when the device receives a SCI request from Remote Manager.

```
>>> device_request.register("myTarget", handler)
>>>
```

Note Leave the interactive Python session active while completing task two, below. Once you have completed task two, exit the interactive session by using **Ctrl-D**. You can also exit the session using **exit()** or **quit()**.

Task two: Create and send an SCI request from Digi Remote Manager

The second step in using the **device_request** module is to create an SCI request that Remote Manager will forward to the device. For example, you can create an SCI request in the Remote Manager API explorer.

1. In Remote Manager, click **Documentation > API Explorer**.
2. Select the device to use as the SCI target:
   a. Click **SCI Targets**.
   b. Click **Add Targets**.
   c. Enter or select the device ID of the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

d. Click **Add**.

e. Click **OK**.

3. Click **Examples** > **SCI** > **Data Service** > **Send Request**.

Code similar to the following will be displayed in the HTTP message body text box:

```
<sci_request version="1.0">
  <data_service>
  <targets>
    <device id="00000000-00000000-00000FFF-A41CFCA2"/>
  </targets>
    <requests>
      <device_request target_name="myTarget">
        My payload string
      </device_request>
    </requests>
  </data_service>
</sci_request>
```

Note The value of the **target_name** parameter in the **device_request** element must correspond to the **target** parameter of the **device_request.register** function in the Python script. In this example, the two are the same.

4. Click **Send**.

Once that the request has been sent to the device, the handler on the device is executed.

- On the device, you will receive the following output:

```
>>> received request
      My payload string
    for target myTarget
>>>
```

- In Remote Manager, you will receive a response similar to the following:

```
<sci_reply version="1.0">
  <data_service>
    <device id="00000000-00000000-00000FFF-A41CFCA2">
      <requests>
        <device_request target_name="myTarget"
status="0">OK</device_request>
      </requests>
    </device>
  </data_service>
</sci_reply>
```

Example: Use digidevice.sci with digidevice.device_request

In this example, we will use the **digidevice.sci** module in conjunction with the **digidevice.device_request** module to return information about multiple devices to Remote Manager.

1. Create a Python application, called showsystem.py, that uses the **digidevice.sci** module to create a response containing information about device and the **device_request** module to respond with this information to a request from Remote Manager.

```
from digidevice import device_request
from digidevice import cli
import time

def handler(target, request):
    return cli.execute("show system verbose")

def status_cb(error_code, error_description):
    if error_code != 0:
        print("error handling showSystem device request: %s" % error_
description)

device_request.register("showSystem", handler, status_callback = status_
cb)

# Do not let the process finish so that it handles device requests
while True:
    time.sleep(10)
```

2. Upload the showsystem.py application to the /etc/config/scripts directory on two or more Digi devices. In this example, we will upload it to two devices, and use the same request in Remote Manager to query both devices.

   See Configure scripts to run automatically for information about uploading Python applications to your device. You can also create the script on the device by using the vi command when logged in with shell access.

3. For both devices:

   a. Configure the device to automatically run the showsystem.py application on reboot, and to restart the application if it crashes. This can be done from either the WebUI or the command line.

      Web

      i. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.

      ii. Access the device configuration:

      Remote Manager:

      i. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

      ii. Click the **Device ID**.

      iii. Click **Settings**.

      iv. Click to expand **Config**.

      Local Web UI:

      i. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The **Configuration** window is displayed.

iii. Click **System** > **Scheduled tasks** > **Custom scripts**.

iv. Click **+** to add a custom script.

v. For **Label**, type **Show system application**.

vi. For **Run mode**, select **On boot**.

vii. For **Boot action**, select **Restart script**.

viii. For **Commands**, type **python /etc/config/scripts/showsystem.py**.



ix. Click **Apply** to save the configuration and apply the change.

Command line

i. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

ii. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

iii. Add an application entry:

```
(config)> add system schedule script end
(config system schedule script 4)>
```

Scheduled scripts are enabled by default. To disable:

```
(config system schedule script 4)> enable false
(config system schedule script 4)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iv. Provide a label for the script:

```
(config system schedule script 0)> label "Show system application"
```

v. Configure the application to run automatically when the device reboots:

```
(config system schedule script 0)> when boot
(config system schedule script 0)>
```

vi. Configure the application to restart if it crashes:

```
(config system schedule script 0)> exit_action restart
(config system schedule script 0)>
```

vii. Set the command that will execute the application:

```
(config system schedule script 0)> command "python
/etc/config/scripts/showsystem.py"
(config system schedule script 0)>
```

viii. Save the configuration and apply the change:

```
(config)> save
Configuration saved.
>
```

b. Run the showsystem.py application. You can run the application by either rebooting the device, or by running it from the shell prompt.

- To reboot the device:
  i. From the WebUI:
     i. From the main menu, click **System**.
     ii. Click **Reboot**.
  ii. From the command line, at the Admin CLI prompt, type:

```
> reboot
```

- To run the application from the shell prompt:
  i. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

  Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.
  ii. Type the following at the shell prompt:

```
# python /etc/config/scripts/showsystem.py &
#
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iii. Exit the shell:

```
# exit
```

4. In Remote Manager, click **Documentation > API Explorer**.
5. Select the devices to use as the SCI target:
   a. Click **SCI Targets**.
   b. Click **Add Targets**.
   c. Enter or select the device ID of one of the devices.
   d. Click **Add**.
   e. Enter or select the device ID of the second device and click **Add**.
   f. Click **OK**.
6. Click **Examples > SCI > Data Service > Send Request**.
   Code similar to the following will be displayed in the HTTP message body text box:

```
<sci_request version="1.0">
  <data_service>
  <targets>
    <device id="00000000-00000000-00000FFF-A63CFCA2"/>
    <device id="00000000-00000000-00000FFF-4A57A8BC"/>
  </targets>
    <requests>
      <device_request target_name="myTarget">
        My payload string
      </device_request>
    </requests>
  </data_service>
</sci_request>
```

7. For the **device_request** element, replace the value of **target_name** with **showSystem**. This matches the **target** parameter of the **device_request.register** function in the showsystem.py application.

```
      <device_request target_name="showSystem">
```

8. Click **Send**.
   You should receive a response similar to the following:

```
<sci_reply version="1.0">
  <data_service>
    <device id="00000000-00000000-00000FFF-A63CFCA2">
      <requests>
        <device_request target_name="showSystem" status="0">Model
          : Digi Connect EZ 4 WS
          Serial Number          : Connect EZ 4 WS-000000
          Hostname               : Connect EZ 4 WS
          MAC                    : 00:40:9D:13:35:36

          Hardware version       : 10001809-01 A
          Firmware version       : 25.3
          Bootloader Version     : 1
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
            Firmware Build Date       : Fri, Jan 12, 2024 12:10:00
            Schema Version            : 461

            Timezone                  : UTC
            Current Time              : Thu, Jan 11, 2024 12:10:00
            CPU                       : 1.1
            Uptime                    : 1 day, 11 hours, 46 minutes, 47
seconds (135607s)
            Temperature               : 39C

            Contact                   : Dave Smith

            Disk
            ----
            Load Average              : 0.10, 0.02, 0.00
            RAM Usage                 : 60.17MB/256.49MB(24%)
            Disk /etc/config Usage    : 0.050MB/13.41MB(1%)
            Disk /opt Usage           : 47.73MB/5388.75MB(1%)
            Disk /overlay Usage       : MB/MB(%)
            Disk /tmp Usage           : 0.004MB/46.90MB(0%)
            Disk /var Usage           : 0.020MB/33.71MB(2%)</device_
response>
        </requests>
    </device>
    <device id="00000000-00000000-0000FFFF-ACC7ABBC"/>
      </requests>
        <device_request target_name="show_system" status="0">Model
          : Digi Connect EZ 4 WS
            Serial Number             : Connect EZ 4 WS-000010
            Hostname                  : Connect EZ 4 WS
            MAC                       : 00:40:9D:2C:79:1C

            Hardware Version          : 100010010-01 A
            Firmware Version          : 23.3
            Bootloader Version        : 1
            Firmware Build Date       : Fri, Jan 12, 2024 12:10:00
            Schema Version            : 461

            Timezone                  : UTC
            Current Time              : Thu, Jan 11, 2024 12:10:00
            CPU                       : 1.1
            Uptime                    : 4 day, 13 hours, 43 minutes, 22
seconds (393802s)
            Temperature               : 37C

            Contact                   : Dear Ahead
            Disk
            ----
            Load Average              : 0.10, 0.05, 0.00
            RAM Usage                 : 60.17MB/256.49MB(24%)
            Disk /etc/config Usage    : 0.050MB/13.41MB(1%)
            Disk /opt Usage           : 47.73MB/5388.75MB(1%)
            Disk /overlay Usage       : MB/MB(%)
            Disk /tmp Usage           : 0.004MB/46.90MB(0%)
            Disk /var Usage           : 0.020MB/33.71MB(2%)</device_
response>
        </requests>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
    </device>
  </data_service>
</sci_request>
```

Help for using Python to respond to Digi Remote Manager SCI requests

Get help for responding to Digi Remote Manager Server Command Interface (SCI) requests by accessing help for **digidevice.device_request**:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 10 2023, 10:47:11) [GCC 11.3.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **device_request** submodule:

```
>>> from digidevice import device_request
>>>
```

4. Use the help command with **device_request**:

```
>>> help(device_request)
Help on module digidevice.device_request in digidevice:

NAME
digidevice.device_request - APIs for registering device request handlers
...
```

You can also use the help command with available **device_request** functions:

- Use the help command with **device_request.register**:

```
>>> help(device_request.register)
Help on function register in module digidevice.device_request:

register(target:str, response_callback:Callable[[str, str], str],
status_callback:Callable[[int, str], NoneType]:None, xml_
encoding:str:'UTF-8')
...
```

- Use the help command with **device_request.unregister**:

```
>>> help(device_request.unregister)
Help on function unregister in module digidevice.device_request:
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Unregistered(target=ctr) -> bool
...
```

5. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Use digidevice.runtime to access the runtime database

Use the **runt** submodule to access and modify the device runtime database.

Read from the runtime database

Use the **keys()** and **get()** methods to read the device configuration:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.4 (main, Mar 30 2023, 23:47:13) [GCC 11.3.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **runt** submodule:

```
>>> from digidevice import runt
>>>
```

4. Use the **start()** method to open the runtime database:

```
>>> runt.start()
>>>
```

5. Use the **keys()** method to display available keys in the runtime database, and use the **get()** method to print information from the runtime database:

   a. Print available keys:

```
>>> print(runt.keys(""))
```

   This returns available keys:

```
['advanced', 'dns', 'firmware', 'location', 'manufacture', 'metrics',
'ppp', 'network', 'psm', 'serial', 'system']
```

   b. Print available keys for the system key:

```
>>> print(runt.keys("system"))
```

   This will return the following:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
['boot_count', 'chassis', 'cpu_temp', 'cpu_usage', 'disk', 'load_avg',
'local_time', 'mac', 'mcu', 'model', 'ram', 'serial', 'uptime']
```

c. Use the **get()** method to print the device's MAC address:

```
>>> print(runt.get("system.mac"))
```

This will return the MAC address of the device.

6. Use the **stop()** method to close the runtime database.
7. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Modify the runtime database

Use the **set()** method to modify the runtime database.

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 30 2022, 02:47:23) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **runt** automodule:

```
>>> from digidevice import runt
>>>
```

4. Use **start()** method to open the runtime database:

```
>>> runt.start()
>>>
```

5. Use the **set()** method to make changes to the runtime database:

```
>>> runt.set("my-variable", "my-value")
>>>
```

6. Use the **get()** method to verify the change:

```
>>> print(runt.get("my-variable"))
my-variable
>>>
```

7. Close the runtime database:

```
>>> runt.stop()
>>>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Use Ctrl+D to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Help for using Python to access the runtime database

Get help for reading and modifying the device runtime database by accessing help for **digidevice.runt**:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.
2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

   ```
   # python
   Python 3.10.1 (main, Mar 10 2023, 13:47:13) [GCC 11.3.0] on linux
   Type "help", "copyright", "credits" or "license" for more information.
   >>>
   ```
3. Import the **runt** submodule:

   ```
   >>> from digidevice import runt
   >>>
   ```
4. Use the help command with **runt**:

   ```
   >>> help(runt)

   Help on module acl.runt in digidevice:

   NAME
   acl.runt - Python interface to ACL runtime database (runt).
   ...
   ```
5. Use Ctrl+D to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Use Python to upload the device name to Digi Remote Manager

The **name** submodule can be used to upload a custom name for your device to Digi Remote Manager.

When you use the **name** submodule to upload a custom device name to Remote Manager, the following issues apply:

- If the name is being used by to another device in your Remote Manager account, the name will be removed from the previous device and added to the new device.
- If Remote Manager is configured to apply a profile to a device based on the device name, changing the name of the device may cause Remote Manager to automatically push a profile onto the device.

Together, these two features allow you to swap one device for another by using the **name** submodule to change the device name, while guaranteeing that the new device will have the same configuration as the previous one.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note Because causing a profile to be automatically pushed from Remote Manager may change the behavior of the device, including overwriting existing usernames and passwords, the **name** automodule should be used with caution. As a result, support for this functionality is disabled by default on Remote Manager.

Enable support on Digi Remote Manager for uploading custom device names

1. In Remote Manager, click **API Explorer**.
2. For the HTTP method, select **PUT**.
3. For **Enter and API or select an example**, type **/ws/v1/settings/inventory/AllowDeviceToSetOwnNameEnabled**.
4. In the HTTP message body text box, type the following:

```
{
   "name" : "AllowDeviceToSetOwnNameEnabled",
   "value" : "true"
}
```

5. Click **Send**.

Upload a custom name

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.
2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 2.x.x (main, Mar 30 2022, 23:47:13) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **name** automodule:

```
>>> from digidevice import name
```

4. Upload the name to Remote Manager:

```
>>> name.upload("my_name")
```

5. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Help for uploading the device name to Digi Remote Manager

Get help for uploading the device name to Digi Remote Manager by accessing help for **digidevice.name**:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 577 / 927

TS-TL-DGI-010

line as a user with shell access.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 30 2022, 03:47:23) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **name** submodule:

```
>>> from digidevice import name
>>>
```

4. Use the help command with **name**:

```
>>> help(name)

Help on module digidevice.name in digidevice:

NAME
    digidevice.name - API for uploading name from the device

...
```

5. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Use Python to set the maintenance window

The **maintenance** Python module allows you to set the service state of a device. When the module sets the device to out of service, this can be used as trigger to begin maintenance activity. See Schedule system maintenance tasks for more details.

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 30 2022, 03:47:23) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **maintenance** module:

```
>>> from digidevice import maintenance
>>>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. To determine the current service state of the device:

```
>>> maintenance.state()
'IN_SERVICE'
>>>
```

5. To set the device to out of service:

```
>>> maintenance.out_of_service()
>>> maintenance.state()
'OUT_OF_SERVICE'
>>>
```

6. To set the device to in service:

```
>>> maintenance.in_service()
>>> maintenance.state()
'IN_SERVICE'
>>>
```

Note Leave the interactive Python session active while completing task two, below. Once you have completed task two, exit the interactive session by using **Ctrl-D**. You can also exit the session using **exit()** or **quit()**.

Help for the digidevice maintenance module

Get help for the **digidevice** maintenance module.

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.4 (main, Mar 30 2023, 22:47:33) [GCC 11.3.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Import the **maintenance** submodule:

```
>>> from digidevice import maintenance
>>>
```

4. Use the help command with **maintenance**:

```
>>> help(maintenance)
Help on module digidevice.maintenance in digidevice:

NAME
    digidevice.maintenance
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
DESCRIPTION
    API for setting the device's service state. The service state is
stored
    in runt.
...
```

5. Use Ctrl+D to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Use Python to send and receive SMS messages

You can create Python scripts that send and receive SMS message in tandem with the Digi Remote Manager by using the digidevice.sms module. To use a script to send or receive SMS messages, you must also enable the ability to schedule SMS scripting.

Enable the ability to schedule SMS scripting

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **System** > **Scheduled tasks**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Click to enable **Allow scheduled scripts to handle SMS**.



5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> system schedule sms_script_handling true
(config)>
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

See Configure scripts to run automatically for more information about scheduling scripts.

Example digidevice.sms script

The following example script receives an SMS message and sends a response:

```
#!/usr/bin/python3.10.1

import os
import threading
import sys
from digidevice.sms import Callback, send
COND = threading.Condition()
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
def sms_test_callback(sms, info):
    print(f"SMS message from {info['content.number']} received")
    print(sms)
    print(info)
    COND.acquire()
    COND.notify()
    COND.release()

def send_sms(destination, msg):
    print("sending SMS message", msg)
    if len(destination) == 10:
        destination = "+1" + destination
    send(destination, msg)

if __name__ == "__main__":
    if len(sys.argv) > 1:
        dest = sys.argv[1]
    else:
        dest = '+15555550000'
    my_callback = Callback(sms_test_callback, metadata=True)
    send_sms(dest, 'Hello World!')
    print("Please send an SMS message now.")
    print("Execution halted until a message is received or 60 seconds have
passed.")
    # acquire the semaphore and wait until a callback occurs
    COND.acquire()
    try:
        COND.wait(60.0)
    except Exception as err:
        print("exception occurred while waiting")
        print(err)
    COND.release()
    my_callback.unregister_callback()
```

Example script using digidevice.sms to send CLI commands

The following example script listens for an incoming SMS message from a specific phone number (2222334444) and then executes the SMS message as a CLI command. If the CLI command being run has output, it will send that output as a response SMS message. If the CLI command being run has no output but ran successfully, the script will instead send an OK response SMS message. Errors in running the CLI will have those error messages sent as a SMS response.

```
#!/usr/bin/python

# Take an incoming SMS message from a specified phone number and run it as
# a CLI command. Send a response SMS to the sender before running the command

import os
import threading
import sys
from digidevice import cli
from digidevice.sms import Callback, send
COND = threading.Condition()
allowed_incoming_phone_number = '2222334444'

def sms_test_callback(sms, info):
    if info['content.number'] == allowed_incoming_phone_number:
        print(f"SMS message from {info['content.number']} received")
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
        print(sms)
        print(info)
        #if sms == "Reboot":
        #  send_sms(dest, "Reboot message received, rebooting device...")
        #  response = cli.execute("reboot")
        #  print (response)
        send_sms(dest, "Message received (" + sms + "). Performing as CLI
command...")
        response = cli.execute(sms)
        if not response:
            response = "OK"
        send_sms(dest, "CLI results: " + response)
        print (response)
    COND.acquire()
    COND.notify()
    COND.release()

def send_sms(destination, msg):
    print("sending SMS message", msg)
    if len(destination) == 10:
    destination = "+1" + destination
    send(destination, msg)

if __name__ == '__main__':
    if len(sys.argv) > 1:
        dest = sys.argv[1]
    else:
        dest = allowed_incoming_phone_number
    my_callback = Callback(sms_rest_callback, metadata=True)
    thsend_sms(dest, "Ready to receive incoming SMS message")
    print("Waiting up to 60 seconds for incoming SMS message")
    # acquire the semaphore and wait until a callback occurs
    COND.acquire()
    try:
        COND.wait(60.0)
    except Exception as err:
        print("exception occurred while waiting")
        print(err)
    COND.release()
    my_callback.unregister_callback()
    os.system('rm -f /var/run/sms/scripts/*') # remove all stored SMS messages,
since we've processed them
    print("SMS script finished.  Please re-run if you want to check for more
incoming SMS messages")
    os._exit(0)
```

Use Python to access serial ports

You can use the Python **serial** module to access serial ports on your Connect EZ 4 WS device that are configured to be in Application mode. See Configure Application mode for a serial port for information about configuring a serial port in Application mode.

To use Python to access serial ports:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. Determine the path to the serial port:

```
# ls /dev/serial/
by-id   by-path   port1
#
```

3. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.4 (main, Mar 30 2023, 22:47:33) [GCC 11.3.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

4. Import the **serial** module:

```
>>> import serial
>>>
```

5. You can now perform operations on the serial port. For example, to write a message to the serial port:

```
>>> s = serial.Serial("/dev/serial/port1", 115200)
>>> s.write(b"Hello from serial port")
20
>>>
```

6. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

Use the Paho MQTT python library

Your Connect EZ 4 WS device includes support for the Paho MQTT python library. MQTT is a lightweight messaging protocol used to communicate with various applications including cloud-based applications such as Amazon Web Services and Microsoft Azure. The following is example code that reads CPU and RAM usage on the device, updates the device firmware, then publishes information about DHCP clients and system information to the MQTT server at 192.168.1.100. The MQTT server IP is configurable.

```
"""
MQTT client example:
- Reporting some device metrics from rcurl
- Reporting DHCP clients
- Firmware update feature (simple implementation, read TODO in cmd_fwupdate)
"""

import sys
import time
import paho.mqtt.client as mqtt
import json
from cli import rcurl, config
from http import HTTPStatus
import urllib.request
import tempfile
```

```
import os
from digidevice import cli

POLL_TIME = 60

def cmd_reboot(params):
    print("Rebooting unit...")
    try:
        cli.execute("reboot", 10)
    except:
        print("Failed to run 'reboot' command")
        return HTTPStatus.INTERNAL_SERVER_ERROR

    return HTTPStatus.OK

def cmd_fwupdate(params):
    try:
        fw_url = params["url"]
    except:
        print("Firmware file URI not passed")
        return HTTPStatus.BAD_REQUEST

    print("Request to update firmware with URI: {}".format(fw_url))

    try:
        fd, fname = tempfile.mkstemp()
        os.close(fd)
        try:
            urllib.request.urlretrieve(fw_url, fname)
        except:
            print("Failed to download FW file from URI {}".format(fw_url))
            return HTTPStatus.NOT_FOUND

        try:
            ret = cli.execute("system firmware update file " + fname, 60)
        except:
            print("Failed to run firmware update command")
            return HTTPStatus.INTERNAL_SERVER_ERROR

        if not "Firmware update completed" in ret:
            print("Failed to update firmware")
            return HTTPStatus.INTERNAL_SERVER_ERROR
    finally:
        os.remove(fname)

    print("Firmware update finished")

    return HTTPStatus.OK

CMD_HANDLERS = {
    "reboot": cmd_reboot,
    "fw-update": cmd_fwupdate
}


def send_cmd_reply(client, cmd_path, rid, cmd, status):
    if not status or not rid:
        return

    if cmd_path.startswith(PREFIX_CMD):
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
        path = cmd_path[len(PREFIX_CMD):]
    else:
        print("Invalid command path {}, cannot send reply".format(cmd_path))
        return

    reply = {
        "cmd": cmd,
        "status": status
    }

    client.publish(PREFIX_RSP + path + "/" + cid, json.dumps(reply, separators=
(',',':')))

def on_connect(client, userdata, flags, rc):
    print("Connected to MQTT server")
    client.subscribe(PREFIX_CMD + "/system")

def on_message(client, userdata, msg):
    """ Supporting only a single topic for now, no need for filters
    Expects the following message format:
    {
        "cid": "<client-id>",
        "cmd": "<command>",
        "params": {
            <optional_parameters>
        }
    }

    Supported commands:
    - "fw-update"
        params:
            - "url": "<firmware_file_URL>"
    - "reboot"
        params:
    """

    try:
        m = json.loads(msg.payload)
        cid = m["cid"]
        cmd = m["cmd"]
        try:
            payload = m["params"]
        except:
            payload = None
    except:
        print("Invalid command format: {}".format(msg.payload))
        if not cid:
            # Return if client-ID not passed
            return None
        send_cmd_reply(client, msg.topic, cid, cmd, HTTPStatus.BAD_REQUEST)

    try:
        status = CMD_HANDLERS[cmd](payload)
    except:
        print("Invalid command: {}".format(cmd))
        status = HTTPStatus.NOT_IMPLEMENTED

    send_cmd_reply(client, msg.topic, cid, cmd, status)
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
def publish_dhcp_leases():
    leases = []
    try:
        with open('/etc/config/dhcp.leases', 'r') as f:
            for line in f:
                elems = line.split()
                if len(elems) != 5:
                    continue
                leases.append({"mac": elems[1], "ip": elems[2], "host": elems
[3]})
        if leases:
            client.publish(PREFIX_EVENT + "/leases", json.dumps(leases,
separators=(',',':')))
    except:
        print("Failed to open DHCP leases file")

def publish_system():
    avg1, avg5, avg15 = run1.get("system.load_avg").split(', ')
    ram_used = run1.get("system.ram.pct")
    disk_opt = run1.get("system.disk./opt.pct")
    disk_config = run1.get["system.disk./etc/config.pct"]

    msg = json.dumps({
        "load_avg": {
            "info": avg1,
            "data": avg5,
            "alarm": avg15
        },
        "disk_usage": {
            "/opt": disk_opt,
            "/etc/config": disk_config,
            "ram": ram_used
        }
    })

    client.publish(PREFIX_EVENT + "/system", json.dumps(msg))

run1.start()
serial = run1.get("system.serial")

PREFIX = "router/" + serial
PREFIX_EVENT = "event/" + PREFIX
PREFIX_CMD = "cmd/" + PREFIX
PREFIX_RSP = "rsp/" + PREFIX

client = mqtt.Client()
client.on_connect = on_connect
client.on_message = on_message

try:
    client.connect("192.168.1.100", 1883, 60)
    client.loop_start()
except:
    print("Failed to connect to MQTT server")
    sys.exit(1)

while True:
    publish_dhcp_leases()
    publish_system()
    time.sleep(POLL_TIME)
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Set up the Connect EZ 4 WS to automatically run your applications

This section contains the following topics:

- Configure scripts to run automatically
- Show script information
- Stop a script that is currently running

Configure scripts to run automatically

You can configure a script or a python application to run automatically when the system restarts, at specific intervals, or at a specified time. By default, scripts execute in a "sandbox," which restricts access to the file system and available commands that can be used by the script.

Required configuration items

- Upload or create the script. The script must be uploaded to /etc/config/scripts or a subdirectory.
- Enable the script.
- Select whether the script should run:
  - When the device boots.
  - At a specified time.
  - At a specified interval.
  - During system maintenance.

Additional configuration items

- If the script is a Python application, include the full path to the script.
- A label used to identify the script.
- The action to take if the script finishes. The actions that can be taken are:
  - None.
  - Restart the script.
  - Reboot the device.
- Whether to write the script output and errors to the system log.
- If the script is set to run at a specified interval, whether another instance of the script should be run at the specified interval if the previous instance is still running.
- The memory available to be used by the script.
- Whether the script should run one time only.

Task one: Upload the application


Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Applications Set up the Connect EZ 4 WS to automatically run your applications

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **System**. Under **Administration**, click **File System**.



The **File System** page appears.



2. Highlight the **scripts** directory and click to open the directory.
3. Click (upload).
4. Browse to the location of the script on your local machine. Select the file and click **Open** to upload the file.

The uploaded file is uploaded to the */etc/config/scripts* directory.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, use the scp command to upload the Python application script to the Connect EZ 4 WS device.

```
> scp host hostname-or-ip user username remote remote-path local local-
path on local
```

   where:

   - *hostname-or-ip* is the hostname or IP address of the remote host.
   - *username* is the name of the user on the remote host.
   - *remote-path* is the path and filename of the file on the remote host that will be copied to the Connect EZ 4 WS device.
   - *local-path* is the location on the Connect EZ 4 WS device where the copied file will be placed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

For example:

To upload a script from a remote host with an IP address of 192.168.4.1 to the /etc/config/scripts directory on the Connect EZ 4 WS device, issue the following command:

```
> scp boot 192.168.4.1 user admin resource /home/admin/bin/test.py local
/etc/config/scripts/ to local
admin@192.168.4.1's password: adminpwd
test.py                                   100%   3098     11.3KB/s   00:00
>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Note You can also create scripts by using the **vi** command when logged in with shell access.

Task two: Configure the application to run automatically

Note This feature does not provide syntax or error checking. Certain commands can render the device inoperable. Use with care.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:
   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:
   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.


   

   The **Configuration** window is displayed.
3. Click **System** > **Scheduled tasks** > **Custom scripts**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. For **Add Script**, click **+**.

The script configuration window is displayed.



Custom scripts are enabled by default. To disable, toggle off **Enable** to toggle off.

5. (Optional) For **Label**, provide a label for the script.
6. For **Run mode**, select the mode that will be used to run the script. Available options are:
   - **On boot**: The script will run once each time the device boots.
     - If **On boot** is selected, select the action that will be taken when the script completes in **Boot action**. Available options are:
       - **None**: Action taken when the script exits.
       - **Restart script**: Runs the script repeatedly.
       - **Reboot**: The device will reboot when the script completes.
   - **Interval**: The script will start running at the specified interval, within 30 seconds after the configuration change is saved.
     - If **Interval** is selected, in **Interval**, type the interval.

       Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*w|d|h|m|s.

       For example, to set **Interval** to ten minutes, enter **10m** or **600s**.
     - Click to enable **Run single** to run only a single instance of the script at a time.

       If **Run single** is not enabled, a new instance of the script will be started at every interval, regardless of whether the script is still running from a previous interval.
   - **Set time**: Runs the script at a specified time of the day.
     - If **Set time** is selected, specify the time that the script should run in **Run time**, using the format *HH:MM*.
   - **During system maintenance**: The script will run during the system maintenance time window.
7. For **Commands**, type the commands that will execute the script.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- If a Python script is being used, include the full path to the Python script. For example:

```
python /etc/config/scripts/test.py
```

- If the script begins with #!, then the script will be invoked on the location specified by the path for the script command. Otherwise, the default shell will be used (equivalent to #!/bin/sh).

8. Script logging options:
   a. Click to enable **Log script output** to log the script's output to the system log.
   b. Click to enable **Log script errors** to log script errors to the system log.

   If neither option is selected, only the script's exit code is written to the system log.
9. For **Maximum memory**, enter the maximum amount of memory available to be used by the script and its subprocesses, using the format *number*[b|kb|mb|gb] (for example, 1mb).
10. **Sandbox** is enabled by default, which restricts access to the file system and available commands that can be used by the script. This option protects the script from accidentally destroying the system it is running on.
11. Click to enable **Once** to configure the script to run only once at the specified time.

    If **Once** is enabled, rebooting the device will cause the script to not run again. The only way to re-run the script is to:
    - Remove the script from the device and add it again.
    - Make a change to the script.
    - Uncheck **Once**.
12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a script:

```
(config)> add system schedule script end
(config system schedule script 0)>
```

   Scheduled scripts are enabled by default. To disable:

```
(config system schedule script 0)> enable false
(config system schedule script 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. (Optional) Provide a label for the script.

```
(config system schedule script 0)> label value
(config system schedule script 0)>
```

where **value** is any string. If spaces are used, enclose **value** within double quotes.

5. Set the mode that will be used to run the script.

```
(config system schedule script 0)> when mode
(config system schedule script 0)>
```

where **mode** is one of the following:

- **boot**: The script will run once each time the device boots.
  - If **boot** is selected, set the action that will be taken when the script completes.

    ```
    (config system schedule script 0)> exit_action action
    (config system schedule script 0)>
    ```

    where **action** is one of the following:
    - **none**: Action taken when the script exits.
    - **restart**: Runs the script repeatedly.
    - **reboot**: The device will reboot when the script completes.
- **interval**: The script will start running at the specified interval, within 30 seconds after the configuration change is saved. If **interval** is selected:
  - Set the interval.

    ```
    (config system schedule script 0)> on_interval value
    (config system schedule script 0)>
    ```

    where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number**w|d|h|m|s.

    For example, to set **on_interval** to ten minutes, enter either **10m** or **600s**:

    ```
    (config system schedule script 0)> on_interval 10m
    (config system schedule script 0)>
    ```
  - (Optional) Configure the script to run only a single instance at a time.

    ```
    (config system schedule script 0)> once true
    (config system schedule script 0)>
    ```

    If **once** is set to **false**, a new instance of the script will be started at every interval, regardless of whether the script is still running from a previous interval.
- **set time**: Runs the script at a specified time of the day.
  - If **set time** is set, set the time that the script should run, using the format HH:MM.

    ```
    (config system schedule script 0)> run_time HH:MM
    (config system schedule script 0)>
    ```
- **maintenance time**: The script will run during the system maintenance time window.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Set the commands that will execute the script:

```
(config system schedule script 0)> commands filename
(config system schedule script 0)>
```

where **filename** is the path and filename of the script, and any related command line information.

- If a Python script is being used, include the full path to the Python script and enclose in quotation marks. For example:

```
(config system schedule script 0)> commands python
"/etc/config/scripts/test.py"
(config system schedule script 0)>
```

- If the script begins with **#!**, then the script will be invoked in the location specified by the path for the script command. Otherwise, the default shell will be used (equivalent to **#!/bin/sh**).

7. Script logging options:
   - To log the script's output to the system log:

```
(config system schedule script 0)> syslog_stdout true
(config system schedule script 0)>
```

   - To log script errors to the system log:

```
(config system schedule script 0)> syslog_stderr true
(config system schedule script 0)>
```

If **syslog stdout** and **syslog stderr** are not enabled, only the script's exit code is written to the system log.

8. Set the maximum amount of memory available to be used by the script and its subprocesses:

```
(config system schedule script 0)> max_memory value
(config system schedule script 0)>
```

where **value** uses the syntax **number[b|kb|mb|gb]** (MB is the default).

9. To run the script only once at the specified time:

```
(config system schedule script 0)> once true
(config system schedule script 0)>
```

If **once** is enabled, rebooting the device will cause the script to run again. The only way to re-run the script is to:

- Remove the script from the device and add it again.
- Make a change to the script.
- Disable **once**.

10. **Sandbox** is enabled by default. This option protects the script from accidentally destroying the system it is running on.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config system schedule script 0)> sandbox true
(config system schedule script 0)>
```

11. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

12. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show script information

You can view status and statistics about location information from either the WebUI or the command line.

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. At the **Status** page, click **Scripts**.

   The **Scripts** page displays.



Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Use the show scripts command at the system prompt.

```
> show scripts

Index  Label      Enabled  Status  Run time
-----  ---------  -------  ------  --------
0      script1    true     active
1      script2    true     idle    01:08
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Stop a script that is currently running


You can stop a script that is currently running.

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. At the **Status** page, click **Scripts**.

   The **Scripts** page displays.



2. For scripts that are currently running, click **Stop Script** to stop the script.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Determine the name of scripts that are currently running:

```
> show scripts

Index  Label          Enabled  Status  Run time
-----  -------------  -------  ------  --------
0      script1        true     active
1      script2        true     idle    01:08
>
```

   Scripts that are currently running have the status of **active**.

3. Stop the appropriate script:

```
> system script stop script1
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Start an interactive Python session

Use the **python** command without specifying any parameters to start an interactive Python session. The Python session operates interactively using REPL (Read Evaluate Print Loop) to allow you to write Python code on the command line.

Note The Python interactive session is not available from the Admin CLI. You must access the device shell in order to run Python applications from the command line. See Authentication groups for information about configuring authentication groups that include shell access.

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, use the **python** command with no parameters to enter an interactive Python session:

```
# python
Python 3.10.1 (main, Mar 10 2022, 22:47:13) [GCC 11.2.0] on linux
Type "help", "copyright", "credits" or "license" for more information.
>>>
```

3. Type Python commands at the Python prompt. For example, to view help for the digidevice module, type:

```
>>> help("digidevice")
Help on package digidevice:

NAME
    digidevice - Digi device python extensions

DESCRIPTION
    This module includes various extensions that allow Python
    to interact with additional features offered by the device.
...
```

4. Use **Ctrl-D** to exit the Python session. You can also exit the session using **exit()** or **quit()**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Run a Python application at the shell prompt

Python applications can be run from a file at the shell prompt. The Python application will run until it completes, displaying output and prompting for additional user input if needed. To interrupt the application, enter CTRL-C.

Note Python applications cannot be run from the Admin CLI. You must access the device shell in order to run Python applications from the command line. See Authentication groups for information about configuring authentication groups that include shell access.

1. Upload the Python application to the Connect EZ 4 WS device.

Web

Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.

a. On the menu, click **System**. Under **Administration**, click **File System**.



The **File System** page appears.



b. Highlight the **scripts** directory and click to open the directory.

c. Click (upload).

d. Browse to the location of the script on your local machine. Select the file and click **Open** to upload the file.

The uploaded file is uploaded to the **/etc/config/scripts** directory.

Command line

a. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

b. At the command line, use the scp command to upload the Python application script to the Connect EZ 4 WS device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
# scp host hostname-or-ip user username remote remote-path local
local-path to local
```

where:

- **hostname-or-ip** is the hostname or IP address of the remote host.
- **username** is the name of the user on the remote host.
- **remote-path** is the path and filename of the file on the remote host that will be copied to the Connect EZ 4 WS device.
- **local-path** is the location on the Connect EZ 4 WS device where the copied file will be placed.

For example:

To upload a script from a remote host with an IP address of 192.168.4.1 to the /etc/config/scripts directory on the Connect EZ 4 WS device, issue the following command:

```
# scp host 192.168.4.1 user admin remote /home/admin/bin/test.py local
/etc/config/scripts/ to local
admin@192.168.4.1's password: adminpwd
test.py                       100%   30MB   11.1MB/s   00:02
#
```

c. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Note You can also create scripts by using the **vi** command when logged in with shell access.

2. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

3. Use the **python** command to run the Python application. In the following example, the Python application, **test.py**, takes 3 parameters: **123**, **ports** and **storage**.

```
# python /etc/config/scripts/test.py 123 ports storage
```

Configure scripts to run manually

You can configure an scripts to be manually run.

Required configuration items

- Upload or create the script.
- Enable the script.
- Set the script to run manually.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Additional configuration items

- A label used to identify the script.
- The arguments for the script.
- Whether to write the script output and errors to the system log.
- The memory available to be used by the script.
- Whether the script should run one time only.

Task one: Upload the application

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **System**. Under **Administration**, click **File System**.



The **File System** page appears.



2. Highlight the **scripts** directory and click 📂 to open the directory.
3. Click ⬆ (upload).
4. Browse to the location of the script on your local machine. Select the file and click **Open** to upload the file.

The uploaded file is uploaded to the **/etc/config/scripts** directory.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, use the scp command to upload the Python application script to the Connect EZ 4 WS device.

```
> scp boot hostname-or-ip user username remote remote-path local local-
path to local
```

where:

- hostname-or-ip is the hostname or IP address of the remote host.
- username is the name of the user on the remote host.
- remote-path is the path and filename of the file on the remote host that will be copied to the Connect EZ 4 WS device.
- local-path is the location on the Connect EZ 4 WS device where the copied file will be placed.

For example:

To upload a script from a remote host with an IP address of 192.168.4.1 to the /etc/config/scripts directory on the Connect EZ 4 WS device, issue the following command:

```
> scp boot 192.168.4.1 user admin remote /home/admin/bin/test.py local
/etc/config/scripts/ to local
admin@192.168.4.1's password: admin#pwd
test.py                                   100%   30MB    11.1MB/s   00:02
>
```

3. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Note You can also create scripts by using the **vi** command when logged in with shell access.

Task two: Configure the application to run automatically

Note This feature does not provide syntax or error checking. Certain commands can render the device inoperative. Use with care.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI.


a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **System** > **Scheduled tasks** > **Custom scripts**.
4. For **Add Script**, click **+**.

The script configuration window is displayed.



Custom scripts are enabled by default. To disable, toggle off **Enable** to toggle off.

5. (Optional) For **Label**, provide a label for the script.
6. For **Run mode**, select **Manual**.
7. For **Commands**, type the commands that will execute the script.
   - If a Python script is being used, include the full path to the Python script. For example:

     ```
     python /etc/config/scripts/test.py
     ```

   - If the script begins with **#!**, then the script will be invoked in the location specified by the path for the script command. Otherwise, the default shell will be used (equivalent to **#!/bin/sh**).
8. Script logging options.
   a. Click to enable **Log script output** to log the script's output to the system log.
   b. Click to enable **Log script errors** to log script errors to the system log.

   If neither option is selected, only the script's exit code is written to the system log.
9. For **Maximum memory**, enter the maximum amount of memory available to be used by the script and its subprocesses, using the format *number*[b|kb|mb|gb] (KB, MB, GB, etc.).

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

10. **Sandbox** is enabled by default, which restricts access to the file system and available commands that can be used by the script. This option protects the script from accidentally destroying the system it is running on.
11. Click to enable **Once** to configure the script to run only once at the specified time.

    If **Once** is enabled, rebooting the device will cause the script to not run again. The only way to re-run the script is to:

    - Remove the script from the device and add it again.
    - Make a change to the script.
    - Uncheck **Once**.
12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a script:

```
(config)> add system schedule script end
(config system schedule script 0)>
```

   Scheduled scripts are enabled by default. To disable:

```
(config system schedule script 0)> enable false
(config system schedule script 0)>
```

4. (Optional) Provide a label for the script.

```
(config system schedule script 0)> label value
(config system schedule script 0)>
```

   where **value** is any string. If spaces are used, enclose **value** within double quotes.
5. Set the run mode to manual:

```
(config system schedule script 0)> when manual
(config system schedule script 0)>
```

6. Set the commands that will execute the script:

```
(config system schedule script 0)> commands filename
(config system schedule script 0)>
```

   where **filename** is the path and filename of the script, and any related command line information.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- If a Python script is being used, include the full path to the Python script and enclose in quotation marks. For example:

```
(config system schedule script 0)> command python
"/etc/config/scripts/test.py"
(config system schedule script 0)>
```

- If the script begins with #!, then the script will be invoked at the location specified by the path for the script command. Otherwise, the default shell will be used (equivalent to #!/bin/sh).

7. Script logging options:
   - To log the script's output to the system log:

```
(config system schedule script 0)> syslog_stdout true
(config system schedule script 0)>
```

   - To log script errors to the system log:

```
(config system schedule script 0)> syslog_stderr true
(config system schedule script 0)>
```

   If **syslog_stdout** and **syslog_stderr** are not enabled, only the script's exit code is written to the system log.

8. Set the maximum amount of memory available to be used by the script and its subprocesses:

```
(config system schedule script 0)> max_memory value
(config system schedule script 0)>
```

   where *value* uses the syntax: *number*[b|kb|mb|gb] (KB|MB|GB|B|).

9. To run the script only once at the specified time:

```
(config system schedule script 0)> once true
(config system schedule script 0)>
```

   If **once** is enabled, rebooting the device will cause the script to run again. The only way to re-run the script is to:
   - Remove the script from the device and add it again.
   - Make a change to the script.
   - Disable **once**.

10. **Sandbox** is enabled by default. This option protects the script from accidentally destroying the system it is running on.

```
(config system schedule script 0)> sandbox true
(config system schedule script 0)>
```

11. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

12. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Start a manual script

You can start a script that is enabled and configured to have a run mode of **Manual**.

Web

Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.

1. At the **Status** page, click **Scripts**.

   The **Scripts** page displays.



2. For scripts that are enabled and configured to have a run mode of **Manual**, click **Start Script** to start the script.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Determine the name of scripts that are currently running:

```
> show scripts

Index  Label      Enabled  Status  Run time
-----  ---------  -------  ------  --------
0      script1    true     active
1      script2    true     idle    0d:0h
>
```

3. Start the script:

```
> system script start script1
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Python versions and corresponding DAL OS firmware versions

The table lists the Python versions where changes were made the to programming language and the corresponding DAL OS version to which those changes align.

Python version history	DAL OS version history
Python 3.12	DAL OS 24.12.153.128
Python 3.10.13	DAL OS 24.3.28.88
Python 3.8.15	DAL OS 21.11.85.83

To see the Python change log, go to https://docs.python.org/3/whatsnew/changelog.html.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

User authentication

This chapter contains the following topics:

Connect EZ 4 WS user authentication 608
User authentication methods 609
Authentication groups 610
Local users 611
Terminal Access Controller Access-Control System Plus (TACACS+) 612
Remote Authentication Dial-In User Service (RADIUS) 615
LDAP 617
Configure serial authentication 618
Disable shell access 619
Set the idle timeout for Connect EZ 4 WS users 620
Example user configuration 621

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Connect EZ 4 WS user authentication

User authentication on the Connect EZ 4 WS has the following features and default configuration:

Feature	Description	Default
Idle timeout	Determines how long a user session can be idle before the system automatically disconnects.	• 10 minutes
Allow shell	If disabled, prevents all authentication profiles access to the shell prompt for all authentication groups. This does not prevent access to the Admin CLI. Note If shell access is disabled, re-enabling it will erase the device's configuration and perform a factory reset.	• Enabled
Methods	Determines how users are authenticated for access: **local users**, TACACS+, or **RADIUS**.	• **local users**
Groups	Associates access permissions for a group. . You can modify the released groups and create additional groups as needed for your site. A user can be assigned to more than one group.	• **admin**. Provides the logged-in user with administrative and shell access. • **serial**. Provides the logged-in user with access to serial ports.
Users	Defines local users for the Connect EZ 4 WS.	• **admin**. Belongs to both the **admin** and **serial** groups.
TACACS+	Configures support for TACACS+ (Terminal Access Controller Access-Control System Plus) servers and users.	• Not configured
RADIUS	Configures support for RADIUS (Remote Authentication Dial-In User Service) servers and users.	• Not configured
LDAP	Configures support for LDAP (Lightweight Directory Access Protocol) servers and users.	• Not configured
Serial	Configures authentication for serial TCP and autoconnect services.	• Not configured

User authentication methods

Authentication methods determine how users of the Connect EZ 4 WS device are authenticated. Available authentication methods are:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

User authentication User authentication methods

- **Local users**: User are authenticated on the local device.
- **RADIUS**: Users authenticated by using a remote RADIUS server for authentication.
  See Remote Authentication Dial-In User Service (RADIUS) for information about configuring RADIUS authentication.
- **TACACS+**: Users authenticated by using a remote TACACS+ server for authentication.
  See Terminal Access Controller Access-Control System Plus (TACACS+) for information about configuring TACACS+ authentication.
- **LDAP**: Users authenticated by using a remote LDAP server for authentication.
  See LDAP for information about configuring LDAP authentication.

Digi Connect EZ 4 WS User Guide 608

Add a new authentication method

Required configuration items

- The types of authentication method to be used.

To add an authentication method:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in User Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.


   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Authentication** > **Methods**.
4. For **Add Method**, click **+**.



5. Select the appropriate authentication type for the new method from the **Method** drop-down.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note: Authentication methods are attempted in the order they are listed until the first successful authentication result is returned. See Rearrange the position of authentication methods for information about how to reorder the authentication methods.

6. Repeat these steps to add additional methods.
7. Click **Apply** to save the configuration and apply the change.

Command line

Authentication methods are attempted in the order they are listed until the first successful authentication result is returned. This procedure describes how to add methods to various places in the list.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add the new authentication method to the appropriate location in the list.
   - To determine the current list of authentication methods:
     a. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

        Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
     b. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

     c. Use the **show auth method** command to display the current authentication methods configuration:

```
(config)> show auth method
0 local
(config)>
```

   - To add the new authentication method to the beginning of the list, use the index value of **0** to indicate that it should be added as the first method:

```
(config)> add auth method 0 auth_type
(config)>
```

     where **auth_type** is one of **local**, **radius**, **tacacs+**, or **ldap**.
   - To add the new authentication method to the end of the list, use the index keyword **end**:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> add auth method end auth_type
(config)>
```

where **auth_type** is one of **local**, **radius**, **tacacs+**, or **ldap**.

- To add the new authentication in another location in the list, use an index value to indicate the appropriate position. For example:

```
(config)> add auth method 1 auth_type
(config)>
```

where **auth_type** is one of **local**, **radius**, **tacacs+**, or **ldap**.

- You can also use the **move** command to rearrange existing methods. See Rearrange the position of authentication methods for information about how to reorder the authentication methods.

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

Delete an authentication method

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The **Configuration** window is displayed.

3. Click **Authentication** > **Methods**.
4. Click the menu icon (...) next to the method and select **Delete**.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Use the **show auth method** command to determine the index number of the authentication method to be deleted.

```
[config]> show auth method
0 local
1 radius
2 tacacs+
[config]>
```

4. Delete the appropriate authentication method:

```
[config]> del auth method n
```

   Where n is index number of the authentication method to be deleted. For example, to delete the TACACS+ authentication method as displayed by the example **show** command, above:

```
[config]> del auth method 2
```

5. Save the configuration and apply the change.

```
[config]> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Rearrange the position of authentication methods

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Web

Authentication methods are reordered by changing the method type in the **Method** drop-down for each authentication method to match the appropriate order.

For example, the following configuration has **Local users** as the first method, and **RADIUS** as the second.

To reorder these so that **RADIUS** is first, and **Local users** is second:

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:


   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click to expand the first **Method**.
4. In the **Method** drop-down, select **RADIUS**.

5. Click to expand the second **Method**.
6. In the **Method** drop-down, select **Local users**.

7. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Use the **show** command to display current configuration:

```
[config]> show auth method
0 local
1 radius
[config]>
```

4. Use the **move** command to rearrange the methods:

```
[config]> move auth method 1 0
[config]>
```

5. Use the **show** command again to verify the change:

```
[config]> show auth method
0 radius
1 local
[config]>
```

6. Save the configuration and apply the change.

```
[config]> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Authentication groups

Authentication groups are used to assign access rights to Connect EZ 4 WS users. Three types of access rights can be assigned:

- **Admin access**. Users with Admin access can be configured to have either:
  - The ability to manage the Connect EZ 4 WS device by using the WebUI or the Admin CLI.
  - Read-only access to the WebUI and Admin CLI.
- **Shell access**. Users with Shell access have the ability to access the shell when logging into the Connect EZ 4 WS via ssh, telnet, or the serial console.

  Shell access is not available if the **Allow shell** parameter has been disabled. See Disable shell access for more information about the **Allow shell** parameter.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **Serial access**: Users with Serial access have the ability to log into the Connect EZ 4 WS device by using the serial console.

Preconfigured authentication groups

The Connect EZ 4 WS device has two preconfigured authentication groups:

- The **admin** group is configured by default to have full **Admin access**.
- The **serial** group is configured by default to have **Serial access**.

The preconfigured authentication groups cannot be deleted, but the access rights defined for the group are configurable.

This section contains the following topics:

Change the access rights for a predefined group 617
Add an authentication group 619
Delete an authentication group 623

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 616 / 927

Change the access rights for a predefined group

By default, two authentication groups are predefined: **admin** and **serial**. To change the access rights of the predefined groups:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Authentication** > **Groups**.
4. Click the authentication group to be changed, either **admin** or **serial**, to expand its configuration node.
5. Click the box next to the following options, as appropriate, to enable or disable access rights for each:
   - **Admin access**

     For groups assigned Admin access, you can also determine whether the **Access level** should be **Full access** or **Read-only access**.
     - **Full access** provides users of this group with the ability to manage the Connect EZ 4 WS device by using the WebUI or the Admin CLI.
     - **Read-only access** provides users of this group with read-only access to the WebUI and Admin CLI.

     The default is **Full access**.
   - **Serial access**
   - **Interactive shell access**

     Shell access is not available if the **Allow shell** parameter has been disabled. See Disable shell access for more information about the **Allow shell** parameter.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable or disable access rights for the group. For example:

   - Admin access:
     - To set the access level for Admin access of the **admin** group:

```
(config)> auth group admin acl admin level value
(config)>
```

       where *value* is either:

       - **full**: provides users of this group with the ability to manage the Connect EZ 4 WS device by using the WebUI or the Admin CLI.
       - **read-only**: provides users of this group with read-only access to the WebUI and Admin CLI.

       The default is **full**.

     - To disable Admin access for the **admin** group:

```
(config)> auth group admin acl admin enable false
(config)>
```

   - Shell access:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To enable Shell access for the **serial** group:

```
(config)> auth group serial acl shell enable true
(config)>
```

Shell access is not available if the **Allow shell** parameter has been disabled. See Disable shell access for more information about the **Allow shell** parameter.

- Serial access:
  - To enable Serial access for the **admin** group:

```
(config)> auth group admin acl serial enable true
(config)>
```

4. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Add an authentication group

Required configuration items

- The access rights to be assigned to users that are assigned to this group.

Additional configuration items

- Access rights to OpenVPN tunnels, and the tunnels to which they have access.
- Access rights to captive portals, and the portals to which they have access.
- Access rights to query the device for Nagios monitoring.

To add an authentication group:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your device.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Authentication** > **Groups**
4. For **Add**, type a name for the group and click **+**.



The group configuration window is displayed.



5. Click the following options, as appropriate, to enable or disable access rights for each:
   - **Admin access**

     For groups assigned Admin access, you can also determine whether the **Access level** should be **Full access** or **Read-only access**.

     Where value is either:
     - **Full access full**: provides users of this group with the ability to manage the Connect EZ 4 WS device by using the WebUI or the Admin CLI.
     - **Read-only access read-only**: provides users of this group with read-only access to the WebUI and Admin CLI.

     The default is **Full access full**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **Serial access**

6. (Optional) Configure OpenVPN access. See for further information.
7. (Optional) Configure captive portal access:
   a. Enable captive portal access rights for users of this group by checking the box next to **Captive portal access**.
   b. Click **Captive portals** to expand the **Captive portal** node.
   c. For **Add Captive portal**, click **+**.
   d. In the **Captive portal** dropdown, select a captive portal to which users of this group will have access.
   e. Click **+** again to add additional captive portals.
8. **Interactive shell access**:

   Shell access is not available if the **Allow shell** parameter has been disabled. See Disable shell access for more information about the **Allow shell** parameter.
9. (Optional) Enable users that belong to this group to query the device for Nagios monitoring by checking the box next to **Nagios access**.
10. (Optional) Enable users that belong to this group to access the Wi-Fi scanning service by checking the box next to **Wi-Fi scanner access**.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Use the **add auth group** command to add a new authentication. For example, to add a group named **test**:

```
(config)> add auth group test
(config auth group test)>
```

4. Enable access rights for the group:
   - Admin access:

```
(config auth group test)> act admin enable true
(config)>
```

   - Set the access level for Admin access:

```
(config)> auth group admin act admin level value
(config)>
```

   where *value* is either:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **full**: provides users of this group with the ability to manage the Connect EZ 4 WS device by using the WebUI or the Admin CLI.
- **read-only**: provides users of this group with read-only access to the WebUI and Admin CLI.

The default is **full**.

- Shell access:

```
(config auth group test)> acl shell enable true
(config)>
```

Shell access is not available if the **Allow shell** parameter has been disabled. See Disable shell access for more information about the **Allow shell** parameter.

- Serial access:

```
(config auth group test)> acl serial enable true
(config)>
```

5. (Optional) Configure captive portal access.
   a. Return to the config prompt by typing three periods (...):

```
(config auth group test)> ...
(config)>
```

   b. Enable captive portal access rights for users of this group:

```
(config)> auth group test acl portal enable true
(config)>
```

   c. Add a captive portal to which users of this group will have access:
      i. Determine available portals:

```
(config)> show firewall portal
portals
        auth none
        enable true
        http redirect
        no interface
        no message
        no redirect_url
        no terms
        timeout 300
        no title
(config)>
```

      ii. Add a captive portal:

```
(config)> add auth group test acl portal portals end portals
(config)>
```

6. (Optional) Configure Nagios monitoring:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> auth group test acl nagios enable true
(config)>
```

7. (Optional) Enable users that belong to this group to access the Wi-Fi scanning service:

```
(config)> auth group group test acl wifi_scanner enable true
(config)>
```

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete an authentication group

By default, the Connect EZ 4 WS device has two preconfigured authentication groups: **admin** and **serial**. These groups cannot be deleted.

To delete an authentication group that you have created:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Authentication** > **Groups**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Click the menu icon (...) next to the group to be deleted and select **Delete**.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> del auth group groupname
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local users

Local users are authenticated on the device without using an external authentication mechanism such as TACACS+ or RADIUS. Local user authentication is enabled by default, with one preconfigured default user.

Default user

At manufacturing time, each Connect EZ 4 WS device comes with a default user configured as follows:

- Username: **admin**.
- Password: The default password is displayed on the label on the bottom of the device.

> **Note** The default password is a unique password for the device, and is the most critical security feature for the device. If you need the device to factory defaults, you must log in using the default user and password, and you should immediately change the password to a custom password. Before deploying or mounting the Connect EZ 4 WS device, record the default password, so you have the information available when you need it, even if you cannot physically access the label on the bottom of the device.

The default **admin** user is preconfigured with both Admin and Serial access. You can configure the **admin** user account to fit with the needs of your environment.

This section contains the following topics:

Change a local user's password 626
Configure a local user 626
Delete a local user 626

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Change a local user's password

Note When updating the password for the local user, you will be prompted to enter the current password before applying the configuration update.

To change a user's password:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your device.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Authentication** > **Users**.
4. Click the username to expand the user's configuration mode.
5. For **Password**, enter the new password. The password must be at least eight characters long and must contain at least one uppercase letter, one lowercase letter, one number, and one special character.

   For the **admin** user, the password field can be left blank.

   - If the password field for the **admin** user is left blank, the **admin** user's password will be the default password printed on the device's label.
   - If the **admin** user's password has been changed from the default and the configuration saved, if you then clear the password field for the **admin** user, this will result in the device device's configuration being erased and reset to the default configuration.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



You can also change the password for the active user by clicking the user name in the menu bar.



The active user must have full Admin access rights to be able to change the password.

6. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> auth user username password pwd
```

   Where:

   - **username** is the name of the user.
   - **pwd** is the new password for the user. The password must be at least eight characters long and must contain at least one uppercase letter, one lowercase letter, one number, and one special character.

4. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

Configure a local user

Required configuration items

- A username.
- A password. The password must be at least eight characters long and must contain at least one uppercase letter, one lowercase letter, one number, and one special character. For security reasons, passwords are stored in hash form. There is no way to get or display passwords in clear-text form, although prior to saving the configuration, the password can be shown by clicking **Reveal**.
- The authentication group or groups from which the user will inherit access rights. See Authentication groups for information about configuring groups.

Additional configuration items

- An alias for the user. Because the username cannot contain any special characters, such as hyphens (-) or periods (.), an alias allows the user to log in using a name that contains special characters.
- The number of unsuccessful login attempts before the user is locked out of the system.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- The amount of time that the user is locked out of the system after the specified number of unsuccessful login attempts.
- An optional public ssh key, to authenticate the user when using passwordless SSH login.
- Two-factor authentication information for user login over SSH, telnet, and the serial console.
  - The verification type for two-factor authentication: Either time-based or counter-based.
  - The security key.
  - Whether to allow passcode reuse (time-based verification only).
  - The passcode refresh interval (time-based verification only).
  - The valid code window size.
  - The login limit.
  - The login limit period.
  - One-time use eight-digit emergency scratch codes.

To configure a local user:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.


   The **Configuration** window is displayed.
3. Click **Authentication** > **Users**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. In **Add User**, type a name for the user and click **+**.



The user configuration window is displayed.



The user is enabled by default. To disable, toggle off **Enable**.

5. (Optional) For **Username alias**, type an alias for the user.

   Because the name used to create the user and cannot contain special characters such as hyphens (-) or periods (.), an alias allows the user to log in using a name that contains special characters. For security purposes, if two users have the same alias, the alias will be disabled.

6. Enter a password for the user. The password must be at least eight characters long and must contain at least one uppercase letter, one lowercase letter, one number, and one special character.

7. Click to expand **Login failure lockout**.

   The login failure lockout feature is enabled by default. To disable, toggle off **Enable**.

   a. For **Lockout tries**, type the number of unsuccessful login attempts before the user is locked out of the device. The default is **5**.

   b. For **Lockout duration**, type the amount of time that the user is locked out after the number of unsuccessful login attempts defined in **Lockout tries**.

      Allowed values are any number of minutes, or seconds, and take the format **number[m|s]**. For example, to set **Lockout duration** to ten minutes, enter **10m** or **600s**.

      The minimum value is 1 second, and the maximum is 15 minutes. The default is 15 minutes.


8. Add groups for the user.

   Groups define user access rights. See Authentication groups for information about configuring groups.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Click to expand **Groups**.

b. For **Add Group**, click **+**.



c. For **Group**, select an appropriate group.



Note: Every user must be configured with at least one group. You can add multiple groups to a user by clicking **Add** again and selecting the next group.

ii. (Optional) Add SSH keys for the user to use passwordless SSH login.

a. Click **SSH keys**.

b. In **Add SSH key**, paste or type a public encryption key that this user can use for passwordless SSH login and click **+**.

iii. (Optional) Configure two-factor authentication for SSH, telnet, and serial console login.

a. Click **Two-factor authentication**.

b. Check **Enable** to enable two-factor authentication for this user.

c. Select the **Verification type**:

- **Time-based (TOTP)**: Time-based One-time Password (TOTP) authentication uses the current time to generate a one-time password.
- **Counter-based (HOTP)**: HMAC-based One-time Password (HOTP) uses a counter to validate a one-time password.

d. Generate a **Secret key**:

i. Click ... next to the field label and select **Generate secret key**.

ii. Copy the secret key for use with an application or mobile device to generate passcodes.

e. For time-based verification only, select **Disallow code reuse** to prevent a code from being used more than once during the time that it is valid.

f. For time-based verification only, in **Code refresh interval**, type the amount of time that a code will remain valid.

Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*w|d|h|m|s. For example, to set **Code refresh interval** to ten minutes, enter **10m** or **600s**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

g. In **Valid code window size**, type the allowed number of concurrently valid codes. In cases where TOTP is being used, increasing the **Valid code window size** may be necessary when the clocks used by the server and client are not synchronized.

h. For **Login limit**, type the number of times that the user is allowed to attempt to log in during the **Login limit period**. Set **Login limit** to 0 to allow an unlimited number of login attempts during the **Login limit period**.

i. For **Login limit period**, type the amount of time that the user is allowed to attempt to log in.

Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*(w|d|h|m|s). For example, to set **Login limit period** to ten minutes, enter **10m** or **600s**.

j. Scratch codes are emergency codes that may be used once, at any time. To add a scratch code:

i. Click **Scratch codes**.

ii. For **Add Code**, click **+**.

iii. For **Code**, enter the scratch code. The code must be eight digits, with a minimum of 10000000.

iv. Click **+** again to add additional scratch codes.

11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Add a user. For example, to create a user named **new_user**:

```
(config)> add auth user new_user
(config auth user new_user)>
```

The user is enabled by default. To disable the user, type:

```
(config auth user new_user)> enable false
(config auth user new_user)>
```

4. (Optional) Create a username alias for the user.

Because the name to create the user cannot contain special characters such as hyphens (-) or periods (.), an alias allows the user to log in using a name that contains special characters. For security purposes, if two users have the same alias, the alias will be disabled.

```
(config auth user new_user)> username username_alias
(config auth user new_user)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Set the user's password. The password must be at least eight characters long and must contain at least one uppercase letter, one lowercase letter, one number, and one special character.

```
(config auth user new_user)> password pwd
(config auth user new_user)>
```

6. Configure login failure lockout settings:

The login failure lockout feature is enabled by default. To disable:

```
(config auth user new_user)> lockout enable false
(config auth user new_user)>
```

a. Set the number of unsuccessful login attempts before the user is locked out of the device.

where **value** is any integer. The minimum value is 1, and the default value is **3**.

b. Set the amount of time that the user is locked out after the number of unsuccessful login attempts defined in **lockout tries**.

```
(config auth user new_user)> lockout duration value
(config auth user new_user)>
```

where **value** is any number of minutes, or seconds, and takes the format **number[m|s]**. For example, to set **duration** to ten minutes, enter either **10m** or **600s**:

```
(config auth user new_user)> lockout duration 10m
(config auth user new_user)>
```

The minimum value is 1 second, and the maximum is 15 minutes. The default is 15 minutes.

7. Add groups for the user.

Groups define user access rights. See Authentication groups for information about configuring groups.

a. Add a group to the user. For example, to add the admin group to the user:

```
(config auth user new_user)> add group end admin
(config auth user new_user)>
```

Note Every user must be configured with at least one group.

b. (Optional) Add additional groups by repeating the add group command:

```
(config auth user new_user)> add group end serial
(config auth user new_user)>
```

To remove a group from a user:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library
TS-TL-DGI-010
we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 633 / 927

a. Use the **show** command to determine the index number of the group to be deleted:

```
(config auth user new_user) show group
0 admin
1 serial
(config auth user new_user)
```

b. Type the following:

```
(config auth user new_user)> del group n
(config auth user new_user)>
```

Where n is index number of the authentication method to be deleted. For example, to delete the serial group as displayed by the example **show** command, above:

```
(config auth user new_user)> del group 1
(config auth user new_user)>
```

8. (Optional) Add SSH keys for the user to use passwordless SSH login:

a. Change to the user's ssh_key node:

```
(config auth user new_user)> ssh_key
(config auth user new_user ssh_key)>
```

b. Add the key by using the ssh_key command and pasting or typing a public encryption key that this user can use for passwordless SSH login:

```
(config auth user new_user ssh_key)> ssh_key key
(config auth user new_user ssh_key)>
```

9. (Optional) Configure two-factor authentication for SSH, telnet, and serial console login:

a. Change to the user's two-factor authentication node:

```
(config auth user new_user)> 2fa
(config auth user new_user 2fa)>
```

b. Enable two-factor authentication for this user:

```
(config auth user new_user 2fa)> enable true
(config auth user new_user 2fa)>
```

c. Configure the verification type. Allowed values are:

- **totp**: Time-based One-time Password (TOTP) authentication uses the current time to generate a one-time password.
- **hotp**: HMAC-based One-time Password (HOTP) uses a counter to validate a one-time password.

The default value is **totp**:

```
(config auth user new_user 2fa)> type totp
(config auth user new_user 2fa)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

d. Add a secret key.

```
(config auth user new_user 2fa)> secret key
(config auth user new_user 2fa)>
```

This key should be used by an application or mobile device to generate passcodes.

e. For time-based verification only, enable **disallow reuse** to prevent a code from being used more than once during the time that it is valid.

```
(config auth user new_user 2fa)> disallow_reuse true
(config auth user new_user 2fa)>
```

f. For time-based verification only, configure the code refresh interval. This is the amount of time that a code will remain valid.

```
(config auth user new_user 2fa)> refresh_interval value
(config auth user new_user 2fa)>
```

where *value* is any number of weeks, days, hours, minutes, or seconds, and takes the format *number*[w|d|h|m|s].

For example, to set **refresh interval** to ten minutes, enter either **10m** or **600s**.

```
(config auth user name 2fa)> refresh_interval 600s
(config auth user name 2fa)>
```

The default is **30s**.

g. Configure the valid code window size. This represents the allowed number of concurrently valid codes. In cases where TOTP is being used, increasing the valid code window size may be necessary when the clocks used by the server and client are not synchronized.

```
(config auth user new_user 2fa)> window_size 3
(config auth user new_user 2fa)>
```

h. Configure the login limit. This represents the number of times that the user is allowed to attempt to log in during the Login limit period. Set to 0 to allow an unlimited number of login attempts during the Login limit period.

```
(config auth user new_user 2fa)> login_limit 3
(config auth user new_user 2fa)>
```

i. Configure the login limit period. This is the amount of time that the user is allowed to attempt to log in.

```
(config auth user new_user 2fa)> login_limit_period value
(config auth user new_user 2fa)>
```

where *value* is any number of weeks, days, hours, minutes, or seconds, and takes the format *number*[w|d|h|m|s].

For example, to set **login limit period** to ten minutes, enter either **10m** or **600s**.

```
(config auth user name 2fa)> login_lifetime 1440
(config auth user name 2fa)>
```

The default is 30s.

j. Scratch codes are emergency codes that may be used once at any time. To add a scratch code:

i. Change to the user's scratch code node:

```
(config auth user new_user 2fa)> scratch_code
(config auth user new_user 2fa scratch_code)>
```

ii. Add a scratch code:

```
(config auth user new_user 2fa scratch_code)> add end code
(config auth user new_user 2fa scratch_code)>
```

Where code is an digit number, with a minimum of 10000000.

iii. To add additional scratch codes, use the **add end code** command again.

iii. Save the configuration and apply the change.

```
(config auth user new 2fa scratch_code)> save
Configuration saved.
>
```

ii. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete a local user

To delete a user from your Connect EZ 4 WS:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your device.

b. Click the **Device ID**.

c. Click **Settings**.

d. Click to expand **Config**.

Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Authentication** > **Users**.
4. Click the menu icon (...) next to the name of the user to be deleted and select **Delete**.

5. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> del auth user username
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Terminal Access Controller Access-Control System Plus (TACACS+)

Your Connect EZ 4 WS device supports Terminal Access Controller Access-Control System Plus (TACACS+), a networking protocol that provides centralized authentication and authorization management for users who connect to the device. With TACACS+ support, the Connect EZ 4 WS device acts as a TACACS+ client, which sends user credentials and connection parameters to a TACACS+ server over TCP. The TACACS+ server then authenticates the TACACS+ client requests and sends back a response message to the device.

When you are using TACACS+ authentication, you can have both local users and TACACS+ users able to log in to the device. To use TACACS+ authentication, you must set up a TACACS+ server that is accessible by the Connect EZ 4 WS device prior to configuration. The process of setting up a TACACS+ server varies by the server environment.

This section contains the following topics:

TACACS+ user configuration 640
TACACS+ server failover and fallback to local authentication 641
Configure your Connect EZ 4 WS device to use a TACACS+ server 641

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 639 / 927

TACACS+ user configuration

When configured to use TACACS+ support, the Connect EZ 4 WS device uses a remote TACACS+ server for user authentication (password verification) and authorization (assigning the access level of the user). Additional TACACS+ servers can be configured as backup servers for user authentication.

This section outlines how to configure a TACACS+ server to be used for user authentication on your Connect EZ 4 WS device.

Example TACACS+ configuration

With TACACS+, users are defined in the server configuration file. On Ubuntu, the default location and filename for the server configuration file is **/etc/tacacs+/tac_plus.conf**.

Note TACACS+ configuration, including filenames and locations, may vary depending on your platform and installation. This example assumes a Ubuntu installation.

To define users:

1. Open the TACACS+ server configuration file in a text editor. For example:

```
$ sudo gedit /etc/tacacs+/tac_plus.conf
```

2. Add users to the file using the following format. This example will create two users, one with admin and serial access, and one with only serial access.

```
user = user1 {
        name = "User1 for Connect EZ 4 WS"
        pap = cleartext password1
        service = system {
          groupname = admin,serial
        }
}
user = user2 {
        name = "User2 for Connect EZ 4 WS"
        pap = cleartext password2
        service = system {
          groupname = serial
        }
}
```

The **groupname** attribute is optional. If used, the value must correspond to authentication groups configured on your Connect EZ 4 WS. Alternatively, if the user is also configured as a local user on the Connect EZ 4 WS device and the LDAP server authenticates the user but does not return any groups, the local configuration determines the list of groups. See Authentication groups for more information about authentication groups. The **groupname** attribute can contain one group or multiple groups in a comma-separated list.

3. Save and close the file.
4. Verify that your changes did not introduce any syntax errors:

```
$ sudo tac_plus -C /etc/tacacs+/tac_plus.conf -P
```

If successful, this command will echo the configuration file to standard out. If the command encounters any syntax errors, a message similar to this will display:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Error: Unrecognized token on line 1
```

5. Restart the TACACS+ server.

```
$ sudo /etc/init.d/tacacs_plus restart
```

TACACS+ server failover and fallback to local authentication

In addition to the primary TACACS+ server, you can also configure your Connect EZ 4 WS device to use backup TACACS+ servers. Backup TACACS+ servers are used for authentication requests when the primary TACACS+ server is unreachable.

Falling back to local authentication

With user authentication methods, you can configure your Connect EZ 4 WS device to use multiple types of authentication. For example, you can configure both TACACS+ authentication and local authentication, so that local authentication can be used as a fallback mechanism if the primary and backup TACACS+ servers are unavailable. Additionally, users who are configured locally but are not configured on the TACACS+ server are still able to log into the device. Authentication methods are attempted in the order they are listed until the first successful authentication result is returned. Therefore if you want to ensure that users are authenticated first through the TACACS+ server, and only authenticated locally if the TACACS+ server is unavailable or if the user is not defined on the TACACS+ server, then you should list the TACACS+ authentication method prior to the Local users authentication method.

See User authentication methods for more information about authentication methods.

If the TACACS+ servers are unavailable and the Connect EZ 4 WS device falls back to local authentication, only users defined locally on the device are able to log in. TACACS+ users cannot log in until the TACACS+ servers are brought back online.

Configure your Connect EZ 4 WS device to use a TACACS+ server

This section describes how to configure a Connect EZ 4 WS device to use a TACACS+ server for authentication and authorization.

Required configuration items

- Define the TACACS+ server IP address or domain name.
- Define the TACACS+ server shared secret.
- The group attribute configured in the TACACS+ server configuration.
- The service field configured in the TACACS+ server configuration.
- Add TACACS+ as an authentication method for your Connect EZ 4 WS device.

Additional configuration items

- Whether other user authentication methods should be used in addition to the TACACS+ server, or if the TACACS+ server should be considered the authoritative login method.
- Enable command authorization, so that the device will communicate with the TACACS+ server to determine if the user is authorized to execute a specific command.
- Enable command accounting, so that the device will communicate with the TACACS+ server to log commands that the user executes.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- The TACACS+ server port. It is configured to 49 by default.
- Add additional TACACS+ servers in case the first TACACS+ server is unavailable.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your device.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Authentication** > **TACACS+** > **Servers**.
4. Add TACACS+ servers:

   a. For **Add server**, click **+**.

   b. For **Hostname**, type the hostname or IP address of the TACACS+ server.
   c. (Optional) Change the default **Port** setting to the appropriate port. Normally this should be left at the default setting of port 49.
   d. For **Secret**, type the TACACS+ server's shared secret. This is configured in the key parameter of the TACACS+ server's tac_plus.conf file, for example:

```
key = testing123
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note: DAL authentication does not support the use of the # character in the key (e.g., DAL#123&). If included, the server will be unable to decipher the request.

a. (Optional) Click **+** again to add additional TACACS+ servers.

5. (Optional) Enable **Authoritative** to prevent other authentication methods from being attempted if TACACS+ login fails.
6. (Optional) For **Group attribute**, type the name of the attribute used in the TACACS+ server's configuration to identify the Connect EZ 4 WS authentication group or groups that the user is a member of. For example, in TACACS+ user configuration, the group attribute in the sample tac_plus.conf file is **groupname**, which is also the default setting in the Connect EZ 4 WS configuration.
7. (Optional) For **Service**, type the value of the **service** attribute in the the TACACS+ server's configuration. For example, in TACACS+ user configuration, the value of the **service** attribute in the sample tac_plus.conf file is **system**, which is also the default setting in the Connect EZ 4 WS configuration.
8. (Optional) Enable **Command authorization**, which instructs the device to communicate with the TACACS+ server to determine if the user is authorized to execute a specific command. Only the first configured TACACS+ server will be used for command authorization.
9. (Optional) Enable **Command accounting**, which instructs the device to communicate with the TACACS+ server to log commands that the user executes. Only the first configured TACACS+ server will be used for command accounting.
10. Add TACACS+ to the authentication methods:
    a. Click **Authentication** > **Methods**.
    b. For **Add method**, click **+**.

    c. Select **TACACS+** for the new method from the **Method** drop-down.

Authentication methods are attempted in the order they are listed until an authentication response, either pass or fail, is received. If **Authoritative** is enabled (see above), non-authoritative methods are not attempted. See Rearrange the position of authentication methods for information about rearranging the position of the methods in the list.

11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. (Optional) Prevent other authentication methods from being used if TACACS+ authentication fails. Other authentication methods will only be used if the TACACS+ server is unavailable.

```
(config)> auth tacacs+ authoritative true
(config)>
```

4. (Optional) Configure the group_attribute. This is the name of the attribute used in the TACACS+ server's configuration to identify the Connect EZ 4 WS authentication group or groups that the user is a member of. For example, in TACACS+ user configuration, the group attribute in the sample tac_plus.conf file is **groupname**, which is also the default setting for the group_attribute in the Connect EZ 4 WS configuration.

```
(config)> auth tacacs+ group_attribute attribute-name
(config)>
```

5. (Optional) Configure the type of service. This is the value of the **service** attribute in the the TACACS+ server's configuration. For example, in TACACS+ user configuration, the value of the **service** attribute in the sample tac_plus.conf file is **ppp**, which is also the default setting in the Connect EZ 4 WS configuration.

```
(config)> auth tacacs+ service service-name
(config)>
```

6. (Optional) Enable command authorization, which instructs the device to communicate with the TACACS+ server to determine if the user is authorized to execute a specific command. Only the first configured TACACS+ server will be used for command authorization.

```
(config)> auth tacacs+ command_authorization true
(config)>
```

7. (Optional) Enable command accounting, which instructs the device to communicate with the TACACS+ server to log commands that the user executes. Only the first configured TACACS+ server will be used for command accounting.

```
(config)> auth tacacs+ command_accounting true
(config)>
```

8. Add a TACACS+ server:

   a. Add the server:

```
(config)> add auth tacacs+ server end
(config auth tacacs+ server 2)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Enter the TACACS+ server's IP address or hostname.

```
(config auth tacacs+ server 1)> hostname hostname|ip-address
(config auth tacacs+ server 1)>
```

c. (Optional) Change the default port setting to the appropriate port.

```
(config auth tacacs+ server 1)> port port
(config auth tacacs+ server 1)>
```

d. (Optional) Repeat the above steps to add additional TACACS+ servers.

ii. Add TACACS+ to the authentication methods. Authentication methods are attempted in the order they are listed until the first successful authentication result is returned. This example will add TACACS+ to the end of the list. See User authentication methods for information about adding methods to the beginning or middle of the list.

```
(config)> add auth method end tacacs+
(config)>
```

iii. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

iv. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Remote Authentication Dial-In User Service (RADIUS)

Your Connect EZ 4 WS device supports Remote Authentication Dial-In User Service (RADIUS), a networking protocol that provides centralized authentication and authorization management for users who connect to the device. With RADIUS support, the Connect EZ 4 WS device acts as a RADIUS client, which sends user credentials and connection parameters to a RADIUS server over UDP. The RADIUS server then authenticates the RADIUS client requests and sends back a response message to the device.

When you are using RADIUS authentication, you can have both local users and RADIUS users able to log in to the device. To use RADIUS authentication, you must set up a RADIUS server that is accessible by the Connect EZ 4 WS device prior to configuration. The process of setting up a RADIUS server varies by the server environment. An example of a RADIUS server is FreeRADIUS.

This section contains the following topics:

RADIUS user configuration 647
RADIUS server failover and fallback to local configuration 647
Configure your Connect EZ 4 WS device to use a RADIUS server 648

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

RADIUS user configuration

When configured to use RADIUS support, the Connect EZ 4 WS device uses a remote RADIUS server for user authentication (password verification) and authorization (assigning the access level of the user). Additional RADIUS servers can be configured as backup servers for user authentication.

This section outlines how to configure a RADIUS server to be used for user authentication on your Connect EZ 4 WS device.

Example FreeRADIUS configuration

With FreeRADIUS, users are defined in the **users** file in your FreeRADIUS installation. To define users:

1. Open the FreeRadius user file in a text editor. For example:

```
$ sudo gedit /etc/freeradius/3.0/users
```

2. Add users to the file using the following format:

```
user1 Cleartext-Password := "user1"
        Digi-FTP-Group-Names := "admin"

user2 Cleartext-Password := "user2"
        Digi-FTP-Group-Names := "serial"
```

The **Digi-FTP-Group-Names** attribute is optional. If used, the value must correspond to authentication groups configured on your Connect EZ 4 WS. Alternatively, if the user is also configured as a local user on the Connect EZ 4 WS device and the RADIUS server authenticates the user but does not return any groups, the local configuration determines the list of groups. See Authentication groups for more information about authentication groups.

The **Digi-FTP-Group-Names** attribute can contain one group or multiple groups in a comma-separated list.

3. Save and close the file.
4. Verify that your changes did not introduce any syntax errors:

```
$ sudo freeradius -CX
```

This should return a message that completes similar to:

```
...
Configuration appears to be OK
```

5. Restart the FreeRADIUS server:

```
$ sudo /etc/init.d/freeradius restart
```

RADIUS server failover and failback to local configuration

In addition to the primary RADIUS server, you can also configure your Connect EZ 4 WS device to use backup RADIUS servers. Backup RADIUS servers are used for authentication requests when the primary RADIUS server is unavailable.

Failing back to local authentication

With user authentication methods, you can configure your Connect EZ 4 WS device to use multiple types of authentication. For example, you can configure both RADIUS authentication and local

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

authentication, so that local authentication can be used as a fallback mechanism if the primary and backup RADIUS servers are unavailable. Additionally, users who are configured locally but are not configured on the RADIUS server are still able to log into the device. Authentication methods are attempted in the order they are listed until the first successful authentication result is returned. Therefore if you want to ensure that users are authenticated first through the RADIUS server, and only authenticated locally if the RADIUS server is unavailable or if the user is not defined on the RADIUS server, then you should list the RADIUS authentication method prior to the Local users authentication method.

See User authentication methods for more information about authentication methods.

If the RADIUS servers are unavailable and the Connect EZ 4 WS device fall back to local authentication, only users defined locally on the device are able to log in. RADIUS users cannot log in until the RADIUS servers are brought back online.

Configure your Connect EZ 4 WS device to use a RADIUS server

This section describes how to configure a Connect EZ 4 WS device to use a RADIUS server for authentication and authorization.

Required configuration items

- Define the RADIUS server IP address or domain name.
- Define the RADIUS server shared secret.
- Add RADIUS as an authentication method for your Connect EZ 4 WS device.

Additional configuration items

- Whether other user authentication methods should be used in addition to the RADIUS server, or if the RADIUS server should be considered the authoritative login method.
- The RADIUS server port. It is configured to 1812 by default.
- Add additional RADIUS servers in case the first RADIUS server is unavailable.
- The server NAS ID. If left blank, the default value is used:
  - If you are access the Connect EZ 4 WS device by using the WebUI, the default value is for NAS ID is **httpd**.
  - If you are access the Connect EZ 4 WS device by using ssh, the default value is **sshd**.
- Time in seconds before the request to the server times out. The default is 3 seconds and the maximum possible value is 60 seconds.
- Enable additional debug messages from the RADIUS client.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Click **Settings**.

d. Click to expand **Config**.


Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Authentication** > **RADIUS** > **Servers**.
4. Add RADIUS servers:
   a. For **Add server**, click **+**.




   b. For **Hostname**, type the hostname or IP address of the RADIUS server.
   c. (Optional) Change the default **Port** setting to the appropriate port. Normally this should be left at the default setting of port 1812.
   d. For **Secret**, type the RADIUS server's shared secret. This is configured in the secret parameter of the RADIUS server's client.conf file, for example:

```
secret=testing123
```

   e. For **Timeout**, type or select the amount of time in seconds to wait for the RADIUS server to respond. Allowed value is any integer from 3 to 60. The default value is 3.
   f. (Optional) Click **+** again to add additional RADIUS servers.
5. (Optional) Enable **Authoritative** to prevent other authentication methods from being attempted if RADIUS login fails.
6. (Optional) Click **RADIUS debug** to enable additional debug messages from the RADIUS client.
7. (Optional) For **NAS ID**, type the unique identifier for this network access server (NAS). You can use the fully-qualified domain name of the NAS or any arbitrary string. If not set, the default value is used:
   - If you are accessing the Connect EZ 4 WS device by using the Web UI, the default value is for NAS ID is **httpd**.
   - If you are accessing the Connect EZ 4 WS device by using ssh, the default value is **sshd**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Add RADIUS to the authentication methods.
   a. Click **Authentication** > **Methods**.
   b. For **Add method**, click **+**.



   c. Select **RADIUS** for the new method from the **Method** drop-down.

Authentication methods are attempted in the order they are listed until an authentication response, either pass or fail, is received. If **Authoritative** is enabled (see above), non-authoritative methods are not attempted. See Rearrange the position of authentication methods for information about rearranging the position of the methods in the list.

9. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. (Optional) Prevent other authentication methods from being used if RADIUS authentication fails. Other authentication methods will only be used if the RADIUS server is unavailable.

```
(config)> auth radius authoritative true
(config)>
```

4. (Optional) Enable debug messages from the RADIUS client.

```
(config)> auth radius debug true
(config)>
```

5. (Optional) Configure the NAS ID. This is a unique identifier for this network access server (NAS). You can use the fully-qualified domain name of the NAS or any arbitrary string. If not set, the default value is used:
   - If you are accessing the Connect EZ 4 WS device by using the WebUI, the default value is for NAS ID is **httpd**.
   - If you are accessing the Connect EZ 4 WS device by using ssh, the default value is **sshd**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> auth radius nas_id tz
(config)>
```

6. Add a RADIUS server:
   a. Add the server:

```
(config)> add auth radius server end
(config auth radius server 0)>
```

   b. Enter the RADIUS server's IP address or hostname:

```
(config auth radius server 0)> hostname hostname|ip-address
(config auth radius server 0)>
```

   c. (Optional) Change the default port setting to the appropriate port:

```
(config auth radius server 0)> port port
(config auth radius server 0)>
```

   d. Configure the amount of time in seconds to wait for the RADIUS server to respond. Allowed value is any integer from 3 to 60. The default value is 3.

```
(config auth radius server 0)> timeout value
(config auth radius server 0)>
```

   e. (Optional) Repeat the above steps to add additional RADIUS servers.
7. Add RADIUS to the authentication methods. Authentication methods are attempted in the order they are listed until the first successful authentication result is returned. This example will add RADIUS to the end of the list. See User authentication methods for information about adding methods to the beginning or middle of the list.

```
(config)> add auth method end radius
(config)>
```

8. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

LDAP

Your Connect EZ 4 WS device supports LDAP (Lightweight Directory Access Protocol), a protocol used for directory information services over an IP network. LDAP can be used with your Connect EZ 4 WS device for centralized authentication and authorization management for users who connect to the device. With LDAP support, the Connect EZ 4 WS device acts as an LDAP client, which sends user credentials and connection parameters to an LDAP server. The LDAP server then authenticates the LDAP client request and sends back a response message to the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

User authentication LDAP

When you are using LDAP authentication, you can have both local users and LDAP users able to log in to the device. To use LDAP authentication, you must set up a LDAP server that is accessible by the Connect EZ 4 WS device prior to configuration. The process of setting up a LDAP server varies by the server environment.

This section contains the following topics:

LDAP user configuration 653
LDAP server failover and fallback to local configuration 654
Configure your Connect EZ 4 WS device to use an LDAP server 654

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

LDAP user configuration

When configured to use LDAP support, the Connect EZ 4 WS device uses a remote LDAP server for user authentication (password verification) and authorization (assigning the access level of the user). Additional LDAP servers can be configured as backup servers for user authentication.

This section outlines how to configure a LDAP server to be used for user authentication on your Connect EZ 4 WS device.

There are several different implementations of LDAP, including Microsoft Active Directory. This section uses OpenLDAP as an example configuration. Other implementations of LDAP will have different configuration methods.

Example OpenLDAP configuration

With OpenLDAP, users can be configured in a text file using the LDAP Data Interchange Format (LDIF). In this case, we will be using a file called **add_user.ldif**.

1. Create the **add_user.ldif** file in a text editor. For example:

```
$ gedit ./add_user.ldif
```

2. Add users to the file using the following format:

```
dn: uid=john,dc=example,dc=com
objectClass: inetOrgPerson
cn: John Smith
sn: Smith
uid: john
userPassword: password
ou: admin serial
```

   - The value of **uid** and **userPassword** must correspond to the username and password used to log into the Connect EZ 4 WS device.
   - The **ou** attribute is optional. If used, the value must correspond to authentication groups configured on your Connect EZ 4 WS. Alternatively, if the user is also configured as a local user on the Connect EZ 4 WS device and the LDAP server authenticates the user but does not return any groups, the local configuration determines the list of groups. See Authentication groups for more information about authentication groups.

   Other attributes may be required by the user's objectClass. Any objectClass may be used as long as allows the **uid**, **userPassword**, and **ou** attributes.
3. Save and close the file.
4. Add the user to the OpenLDAP server:

```
$ ldapadd -x -W "ldap:///" -D "cn=admin,dc=example,dc=com" -W -f add_
user.ldif
adding new entry "uid=john,dc=example,dc=com"
```

5. Verify that the user has been added by performing an LDAP search:

```
$ ldapsearch -x -LLL -W "ldap:///" -b 'dc=example,dc=com'
uid=john
dn: uid=john,dc=example,dc=com
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
objectClass: inetOrgPerson
cn: John Smith
sn: Smith
uid: john
sn: admin serial
```

LDAP server failover and failback to local configuration

In addition to the primary LDAP server, you can also configure your Connect EZ 4 WS device to use backup LDAP servers. Backup LDAP servers are used for authentication requests when the primary LDAP server is unavailable.

Failing back to local authentication

With user authentication methods, you can configure your Connect EZ 4 WS device to use multiple types of authentication. For example, you can configure both LDAP authentication and local authentication, so that local authentication can be used as a fallback mechanism if the primary and backup LDAP servers are unavailable. Additionally, users who are configured locally but are not configured on the LDAP server are still able to log into the device. Authentication methods are attempted in the order they are listed until the final successful authentication result is returned. Therefore if you want to ensure that users are authenticated first through the LDAP server, and only authenticated locally if the LDAP server is unavailable or if the user is not defined on the LDAP server, then you should list the LDAP authentication method prior to the Local users authentication method.

See User authentication methods for more information about authentication methods.

If the LDAP servers are unavailable and the Connect EZ 4 WS device fails back to local authentication, only users defined locally on the device are able to log in. LDAP users cannot log in until the LDAP servers are brought back online.

Configure your Connect EZ 4 WS device to use an LDAP server

This section describes how to configure a Connect EZ 4 WS device to use an LDAP server for authentication and authorization.

Required configuration items

- Define the LDAP server IP address or domain name.
- Add LDAP as an authentication method for your Connect EZ 4 WS device.

Additional configuration items

- Whether other user authentication methods should be used in addition to the LDAP server, or if the LDAP server should be considered the authoritative login method.
- The LDAP server port. It is configured to 389 by default.
- Whether to use Transport Layer Security (TLS) when communicating with the LDAP server.
- The distinguished name (DN) and password used to communicate with the server.
- The distinguished name used to search to user base.
- The group attribute.
- The number of seconds to wait to receive a message from the server.
- Add additional LDAP servers to ones the first LDAP server is unavailable.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.


   The **Configuration** window is displayed.
3. Click **Authentication** > **LDAP** > **Servers**.
4. Add LDAP servers.
   a. For **Add server**, click **+**.

   b. For **Hostname**, type the hostname or IP address of the LDAP server.
   c. (Optional) Change the default **Port** setting to the appropriate port. Normally this should be left at the default setting of port 389 for non-TLS and 636 for TLS.
   d. (Optional) Click **+** again to add additional LDAP servers.
5. (Optional) Enable **Authoritative** to prevent other authentication methods from being attempted if LDAP login fails.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. For **TLS connection**, select the type of TLS connection used by the server:
   - **Disable TLS**: Uses a non-secure TCP connection on the LDAP standard port, 389.
   - **Enable TLS**: Uses an SSL/TLS encrypted connection on port 636.
   - **Start TLS**: Makes a non-secure TCP connection to the LDAP server on port 389, then sends a request to upgrade the connection to a secure TLS connection. This is the preferred method for LDAP.
7. If **Enable TLS** or **Start TLS** are selected for **TLS connection**:
   - Leave **Verify server certificate** at the default setting of enabled to verify the server certificate with a known Certificate Authority.
   - Disable **Verify server certificate** if the server is using a self-signed certificate.
8. (Optional) For **Server login**, type a distinguished name (DN) that is used to bind to the LDAP server and search for users, for example **cn=user,dc=example,dc=com**. Leave this field blank if the server allows anonymous connections.
9. (Optional) For **Server password**, type the password used to log into the LDAP server. Leave this field blank if the server allows anonymous connections.
10. For **User search base**, type the distinguished name (DN) on the server to search for users. This can be the root of the directory tree (for example, **dc=example,dc=com**) or a sub-tree (for example, **ou=People,dc=example,dc=com**).
11. For **Login attribute**, enter the user attribute containing the login of the authenticated user. For example, in the LDAP user configuration, the login attribute is **uid**. If this attribute is not set, the user will be denied access.
12. (Optional) For **Group attribute**, type the name of the user attribute that contains the list of Connect EZ 4 WS authentication groups that the authenticated user has access to. See LDAP user configuration for further information about the group attribute.
13. For **Timeout**, type or select the amount of time in seconds to wait for the LDAP server to respond. Allowed value is between 3 and 60 seconds.
14. Add LDAP to the authentication methods:
    a. Click **Authentication** > **Methods**.
    b. For **Add method**, click **+**.



    c. Select **LDAP** for the new method from the **Method** drop-down.

Authentication methods are attempted in the order they are listed until an authentication response, either pass or fail, is received. If **Authoritative** is enabled (see above), non-authoritative methods are not attempted. See Rearrange the position of authentication methods for information about rearranging the position of the methods in the list.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

15. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. (Optional) Prevent other authentication methods from being used if LDAP authentication fails. Other authentication methods will only be used if the LDAP server is unavailable.

```
(config)> auth ldap authoritative true
(config)>
```

4. Set the type of TLS connection used by the LDAP server:

```
(config)> auth ldap tls value
(config)>
```

   where **value** is one of:

   - **off**: Uses a non-secure TCP connection on the LDAP standard port, 389.
   - **on**: Uses an SSL/TLS-encrypted connection on port 636.
   - **start_tls**: Makes a non-secure TCP connection to the LDAP server on port 389, then sends a request to upgrade the connection to a secure TLS connection. This is the preferred method for LDAP.

   The default is **off**.

5. If **tls** is set to **on** or **start_tls**, configure whether to verify the server certificate:

```
(config)> auth ldap verify_server_cert value
(config)>
```

   where **value** is either:

   - **true**: Verifies the server certificate with a known Certificate Authority.
   - **false**: Does not verify the certificate. Use this option if the server is using a self-signed certificate.

   The default is **true**.

6. Set the distinguished name (DN) that is used to bind to the LDAP server and search for users. Leave this option unset if the server allows anonymous connections.

```
(config)> auth ldap bind_dn dn_value
(config)>
```

   For example:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> auth ldap bind_dn cn=user,dc=example,dc=com
(config)>
```

7. Set the password used to log into the LDAP server. Leave this option unset if the server allows anonymous connections.

```
(config)> auth ldap bind_password password
(config)>
```

8. Set the distinguished name (DN) on the server to search for users. This can be the root of the directory tree (for example, **dc=example,dc=com**) or a sub-tree (for example, **ou=People,dc=example,dc=com**).

```
(config)> auth ldap base_dn value
(config)>
```

9. Set the login attribute.

```
(config)> auth ldap login_attribute value
(config)>
```

where value is the user attribute containing the login of the authenticated user. For example, in the LDAP user configuration, the login attribute is **uid**. If this attribute is not set, the user will be denied access.

10. (Optional) Set the name of the user attribute that contains the list of Connect EZ 4 WS authentication groups that the authenticated user has access to. See LDAP user configuration for further information about the group attribute.

```
(config)> auth ldap group_attribute value
(config)>
```

For example:

```
(config)> auth ldap group_attribute ou
(config)>
```

11. Configure the amount of time in seconds to wait for the LDAP server to respond.

```
(config)> auth ldap timeout value
(config)>
```

where value is any integer from 3 to 60. The default value is 3.

12. Add an LDAP server:
    a. Add the server:

```
(config)> add auth ldap server mhd
(config auth ldap server 0)>
```

    b. Enter the LDAP server's IP address or hostname:

```
(config auth ldap server 0)> hostname hostname|ip-address
(config auth ldap server 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. (Optional) Change the default port setting to the appropriate port:

```
(config auth ldap server 0)> port port
(config auth ldap server 0)>
```

d. (Optional) Repeat the above steps to add additional LDAP servers.

13. Add LDAP to the authentication methods. Authentication methods are attempted in the order they are listed until the first successful authentication result is returned. This example will add LDAP to the end of the list. See User authentication methods for information about adding methods to the beginning or middle of the list.

```
(config)> add auth method end ldap
(config)>
```

14. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

15. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure serial authentication

This section describes how to configure authentication for serial access.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

b. Click the **Device ID**.

c. Click **Settings**.

d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Authentication** > **Serial**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. (Optional) For **TLS identity certificate**, paste a TLS certificate and private key in PEM format. If empty, the certificate for the web administration service is used. See Configure the web administration service for more information.
5. For **Peer authentication**, select the method used to verify the certificates of a remote peer.
6. **Include standard CAs** is enabled by default. This allows peers with certificates that have been signed by standard Certificate Authorities (CAs) to authenticate.
7. Click to expand **Custom certificate authorities** to add the public certificates of custom CAs.
   a. For **Add CA certificate**, type the name of a custom CA and click **+**.
   b. Paste the public certificate for the custom CA in PEM format.
   c. Repeat for additional custom CA certificates.
8. Click to expand **Peer certificates** to add the public certificates of trusted peers.
   a. For **Add Peer certificate**, type the name of a trusted peer and click **+**.
   b. Paste the public certificate for the trusted peer in PEM format.
   c. Repeat for additional trusted peer certificates.
9. Enable **telnet Login**, which requires a user to login via the telnet connection before accessing a port.
10. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. (Optional) Paste a TLS certificate and private key in PEM format:

```
(config)> auth serial tlsentity "cert-and-private-key"
(config)>
```

4. Set the method used to verify the certificate of a remote peer:

```
(config)> auth serial verify value
(config)>
```

   where **value** is either:
   - **ca**: Uses certificate authorities (CAs) to verify.
   - **peer**: Uses the remote peer's public certificate to verify.
5. By default, peers with certificates that have been signed by standard Certificate Authorities (CAs) are allowed to authenticate. To disable:

```
(config)> auth serial ca_standard false
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Add the public certificate for a custom certificate authority:

```
(config)> add auth serial ca_certs CA-cert-name "cert-and-private-key"
(config)>
```

where:

- **CA-cert-name** is the name of the certificate for the custom certificate authority.
- **cert-and-private-key** is the certificate and private key for the custom certificate authority.

Repeat for additional custom certificate authorities.

7. Require a user to login via the telnet connection before accessing a port:

```
(config)> auth serial telnet_login
(config)>
```

1. Save the configuration and apply the change:

```
(config)> save
Configuration saved.
>
```

2. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Disable shell access

To prohibit access to the shell prompt for all authentication groups, disable the **Allow shell** parameter. This does not prevent access to the Admin CLI.

Note If shell access is disabled, re-enabling it will erase the device's configuration and perform a factory reset.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

b. Click the **Device ID**.

c. Click **Settings**.

d. Click to expand **Config**.

Local Web UI:


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Authentication**.
4. Click to disable **Allow shell**.



Note If shell access is disabled, re-enabling it will erase the device's configuration and perform a factory reset.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Set the **allow_shell** parameter to **false**:

```
(config)> auth allow_shell false
```

Note If shell access is disabled, re-enabling it will erase the device's configuration and perform a factory reset.

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Set the idle timeout for Connect EZ 4 WS users

To configure the amount of time that the user's active session can be inactive before it is automatically disconnected, set the **Idle timeout** parameter.

By default, the Idle timeout is set to 15 minutes.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your device.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Authentication**.
4. For **Idle timeout**, enter the amount of time that the active session can be idle before the user is automatically logged out.

   Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

   For example, to set **Idle timeout** to ten minutes, enter **10m** or **600s**.

5. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. At the config prompt, type:

```
[config]> auth idle_timeout value
```

   where *value* is any number of weeks, days, hours, minutes, or seconds, and takes the format **number(w|d|h|m|s)**.
   For example, to set **idle timeout** to ten minutes, enter either **10m** or **600s**:

```
[config]> auth idle_timeout 10m
[config]>
```

4. Save the configuration and apply the change:

```
[config]> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Example user configuration

Example 1: Administrator user with local authentication

Goal: To create a user with administrator rights who is authenticated locally on the device.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.


   The **Configuration** window is displayed.
3. Click **Authentication** > **Users**.
4. In **Add User:** enter a name for the user and click **+**.



The user configuration window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

User authentication Example user configuration



5. Enter a Password for the user.
6. Assign the user to the admin group:
   a. Click Groups.
   b. For Add Group, click +.
   c. For Group, select the admin group.
   d. Verify that the admin group has full administrator rights:
      i. Click Authentication > Groups.
      ii. Click admin.
      iii. Verify that the admin group has Admin access enabled. If not, click Admin access to enable.
      iv. Verify that Access level is set to Full access. If not, select Full access.
   e. Verify that Local users is one of the configured authentication methods:
      i. Click Authentication > Methods.
      ii. Verify that Local users is one of the methods listed in the list. If not:
         i. For Add Method, click +.
         ii. For Method, select Local users.
7. Click Apply to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click Actions > Open Console, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an Access selection menu. Type admin to access the Admin CLI.
2. At the command line, type config to enter configuration mode:

```
> config
(config)>
```

3. Verify that the admin group has full administrator rights:

```
(config)> show auth group admin acl
admin
        enable true
        level full
...
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

If **admin** > **enable** is set to false:

```
(config)> auth group admin acl admin enable true
(config)>
```

If **admin** > **level** is set to read-only:

```
(config)> auth group admin acl admin level full
(config)>
```

4. Verify that **local** is one of the configured authentication methods.

```
(config)> show auth method
0 local
(config)>
```

If **local** is not listed:

```
(config)> add auth method end local
(config)>
```

5. Create the user. In this example, the user is being created with the username **admnuser**.

```
(config)> add auth user admnuser
(config auth user admnuser)>
```

6. Assign a password to the user.

```
(config auth user admnuser)> password pwd
(config auth user admnuser)>
```

7. Assign the user to the **admin** group.

```
(config auth user admnuser)> add group end admin
(config auth user admnuser)>
```

8. Save the configuration and apply the changes.

```
(config auth user admnuser)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Example 2: RADIUS, TACACS+, and local authentication for one user

Goal: To create a user with administrator rights who is authenticated by using all three authentication methods.

In this example, when the user attempts to log in to the Connect EZ 4 WS device, user authentication will occur in the following order:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

User authentication Example user configuration

1. The user is authenticated by the RADIUS server. If the RADIUS server is unavailable,
2. The user is authenticated by the TACACS+ server. If both the RADIUS and TACACS+ servers are unavailable,
3. The user is authenticated by the Connect EZ 4 WS device using local authentication.

This example uses a FreeRadius 3.0 server running on ubuntu, and a TACACS+ server running on ubuntu. Server configuration may vary depending on the platforms or types of servers used in your environment.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Web

1. Configure a user on the RADIUS server:
   a. On the ubuntu machine hosting the FreeRadius server, open the **/etc/freeradius/3.0/users** file:

   ```
   $ sudo gedit /etc/freeradius/3.0/users
   ```

   b. Add a RADIUS user to the **users** file:

   ```
   admin1 Cleartext-Password := "password1"
          Unix-FTP-Group-Names := "admin"
   ```

   In this example:
   - The user's username is **admin1**.
   - The user's password is **password1**.
   - The authentication group on the Connect EZ 4 WS device, **admin**, is identified in the **Unix-FTP-Group-Names** parameter.

   c. Save and close the **users** file.
2. Configure a user on the TACACS+ server:
   a. On the ubuntu machine hosting the TACACS+ server, open the **/etc/tacacs+/tac_plus.conf** file:

   ```
   $ sudo gedit /etc/tacacs+/tac_plus.conf
   ```

   b. Add a TACACS+ user to the **tac_plus.conf** file:

   ```
   user = admin1 {
         name ="Admin1 for TX64"
         pap = cleartext password1
         service = system {
                  groupname = admin
                  }
         }
   }
   ```

   In this example:
   - The user's username is **admin1**.
   - The user's password is **password1**.
   - The authentication group on the Connect EZ 4 WS device, **admin**, is identified in the **groupname** parameter.

   c. Save and close the **tac_plus.conf** file.
3. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
4. Access the device configuration.

Remote Manager

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.


Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.




The **Configuration** window is displayed.

5. Configure the authentication methods:
   a. Click **Authentication** > **Methods**.
   b. For **Method**, select **RADIUS**.
   c. For **Add Method**, click **+** to add a new method.
   d. For the new method, select **LDAP/3rd**.
   e. Click **+** to add another new method.
   f. For the new method, select **Local users**.



6. Create the local user:
   a. Click **Authentication** > **Users**.
   b. In **Add User:**, type **admin1** and click **+**.




   c. For **password**, type **password1**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


d. Assign the user to the **admin** group:

i. Click **Groups**.

ii. For **Add Group**, click **+**.



iii. For **Group**, select the **admin** group.



e. Verify that the **admin** group has full administrator rights:

i. Click **Authentication** > **Groups**.

ii. Click **admin**.

iii. Verify that the admin group has **Admin access** enabled. If not, click **Admin access** to enable.

iv. Verify that **Access level** is set to **full access**. If not, select **full access**.

f. Click **Apply** to save the configuration and apply the change.

Command line

1. Configure a user on the RADIUS server:

a. On the ubuntu machine hosting the FreeRadius server, open the **/etc/freeradius/3.0/users** file:

```
$ sudo gedit /etc/freeradius/3.0/users
```

b. Add a RADIUS user to the **users** file:

```
admin1  Cleartext-Password := "password1"
        Digi-FTP-Group-Names := "admin"
```

In this example:

- The user's username is **admin1**.
- The user's password is **password1**.
- The authentication group on the Connect EZ 4 WS device, **admin**, is identified in the **Digi-FTP-Group-Names** parameter.

c. Save and close the **users** file.

2. Configure a user on the TACACS+ server:

a. On the ubuntu machine hosting the TACACS+ server, open the **/etc/tacacs+/tac_plus.conf** file:

```
$ sudo gedit /etc/tacacs+/tac_plus.conf
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Add a TACACS+ user to the **tac_plus.conf** file:

```
user = admin1 {
        name = "Admin1 for TXG4"
        pap = cleartext password1
        service = system {
                groupname = admin
                }
        }
}
```

In this example:

- The user's username is **admin1**.
- The user's password is **password1**.
- The authentication group on the Connect EZ 4 WS device, **admin**, is identified in the **groupname** parameter.

c. Save and close the **tac_plus.conf** file.

3. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

4. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

5. Configure the authentication methods:

a. Determine the current authentication method configuration:

```
(config)> show auth method
0 local
(config)>
```

This output indicates that on this example system, only local authentication is configured.

b. Add RADIUS authentication to the beginning of the list:

```
(config)> add auth method 0 radius
(config)>
```

c. Add TACACS+ authentication second place in the list:

```
(config)> add auth method 1 tacacs+(config)>
```

d. Verify that authentication will occur in the correct order:

```
(config)> show auth method
0 radius
1 tacacs+
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
} local
(config)>
```

6. Verify that the **admin** group has full administrative rights.

```
(config)> show auth group admin acl
admin
        enable true
        level full
...
(config)>
```

If **admin > enable** is set to false:

```
(config)> auth group admin acl admin enable true
(config)>
```

If **admin > level** is set to read-only:

```
(config)> auth group admin acl admin level full
(config)>
```

7. Configure the local user.
   a. Create a local user with the username **admin1**.

```
(config)> add auth user admin1
(config auth user admin1)>
```

   b. Assign a password to the user.

```
(config auth user admin1)> password password1
(config auth user admin1)>
```

   c. Assign the user to the **admin** group.

```
(config auth user admin1)> add group end admin
(config auth user admin1)>
```

8. Save the configuration and apply the changes.

```
(config auth user admin1)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firewall

This chapter contains the following topics:

Firewall configuration 675
Port forwarding rules 680
Packet filtering 687
Configure custom firewall rules 694
Configure captive portals 707
Web filtering 709

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firewall configuration

Firewall configuration includes the following configuration options:

- **Zones**: A zone is a firewall access group to which network interfaces can be added. You then use zones to configure packet filtering and access control rules for interfaces that are included in the zone. Preconfigured zones include:
  - **Any**: Matches any network interface, even if they are not assigned to this zone.
  - **Loopback**: Zone for interfaces that are used for communication between processes running on the device.
  - **Internal**: Used for interfaces connected to trusted networks. By default, the firewall will allow most access from this zone.
  - **External**: Used for interfaces to connect to untrusted zones, such as the internet. This zone has Network Address Translation (NAT) enabled by default. By default, the firewall will block most access from this zone.
  - **Edge**: Used for interfaces connected to trusted networks, where the device is a client on the edge of the network rather than a router or gateway.
  - **Setup**: Used for interfaces involved in the initial setup of the device. By default, the firewall will only allow this zone to access administration services.
  - **IPsec**: The default zone for IPsec tunnels.
  - **Dynamic routes**: Used for routes learned using routing services.
- **Port forwarding**: A list of rules that allow network connections to the Connect EZ 4 WS to be forwarded to other servers by translating the destination address.
- **Packet filtering**: A list of packet filtering rules that determine whether to accept or reject network connections that are forwarded through the Connect EZ 4 WS.
- **Custom rules**: A script that is run to install advanced firewall rules beyond the scope/capabilities of the standard device configuration.
- **Quality Of Service**: Quality of Service (QOS) options for bandwidth allocation and policy-based traffic shaping and prioritizing.

Create a custom firewall zone

In addition to the preconfigured zones, you can create your custom zones that can be used to configure packet filtering and access control list's for network interfaces.

To create a zone:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Click **Settings**.

d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Firewall** > **Zones**.

4. In **Add Zone**, enter a name for the zone and click **+**.

The firewall configuration window is displayed.

5. (Optional) If traffic on this zone will be forwarded from a private network to the internet, enable Network Address Translation (NAT).

6. Click **Apply** to save the configuration and apply the change.

See Configure the firewall zone for a network interface for information about how to configure network interfaces to use a zone.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights. Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add the new zone. For example, to add a zone named **my_zone**:

```
(config)> add firewall zone my_zone
(config firewall zone my_zone)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. (Optional) Enable Network Address Translation (NAT):

```
(config firewall zone my_zone)> src_nat true
(config firewall zone my_zone)>
```

5. Save the configuration and apply the change:

```
(config firewall zone my_zone)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

See Configure the firewall zone for a network interface for information about how to configure network interfaces to use a zone.

Configure the firewall zone for a network interface

Firewall zones allow you to group network interfaces for the purpose of packet filtering and access control. There are several preconfigured firewall zones, and you can create custom zones as well. The firewall zone that a network interface uses is selected during interface configuration.

This example procedure uses an existing network interface named **br/2** and changes the firewall zone from the default zone, **Internal**, to **External**.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Interfaces** > **br/2**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

4. For **Zone**, select **External**.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> network interface eth1 zone my_zone
(config)>
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete a custom firewall zone

You cannot delete preconfigured firewall zones. To delete a custom firewall zone:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Firewall** > **Zones**.
4. Click the menu icon (...) next to the appropriate custom firewall zone and select **Delete**.

5. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Use the **del** command to delete a custom firewall rule. For example:

```
(config)> del firewall zone my_zone
```

4. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Port forwarding rules

Most computers are protected by a firewall that prevents users on a public network from accessing servers on the private network. To allow a computer on the Internet to connect to a specific server on a private network, set up one or more port forwarding rules. Port forwarding rules provide mapping instructions that direct incoming traffic to the proper device on a LAN.

Configure port forwarding

Required configuration items

- The network interface for the rule.

  Network connections will only be forwarded if their destination address matches the IP address of the selected network interface.
- The public-facing port number that network connections must use for their traffic to be forwarded.
- The IP address of the server to which traffic should be forwarded.
- The port or range of ports to which traffic should be forwarded.

Additional configuration items

- A label for the port forwarding rule.
- The IP version (either IPv4 or IPv6) that incoming network connections must match.
- The protocol that incoming network connections must match.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- A white list of devices, based on either IP addresses or firewall zones, that are authorized to leverage this forwarding rule.

To configure a port forwarding rule:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Firewall** > **Port forwarding**.
4. For **Add port forward**, click **+**.

   The port forwarding rule configuration window is displayed.

   Port forwarding rules are enabled by default. To disable, toggle off **Enable**.
5. (Optional) Type a **Label** that will be used to identify the rule.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. For **Interface**, select the network interface for the rule.

   Network connections will only be forwarded if their destination address matches the IP address of the selected network interface.

7. For **IP version**, select either **IPv4** or **IPv6**.

   Network connections will only be forwarded if they match the selected IP version.

8. For **Protocol**, select the type of internet protocol.

   Network connections will only be forwarded if they match the selected protocol.

9. For **Incoming port(s)**, type the public-facing port number that network connections must use for their traffic to be forwarded.

10. For **To Address**, type the IP address of the server to which traffic should be forwarded.

11. For **Destination Port(s)**, type the port number, comma-separated list of port numbers, or range of port numbers on the server to which traffic should be forwarded. For example, to forward traffic to ports one, three, and five through ten, enter: **1, 3, 5-10**.

12. (Optional) Click **Access control list** to create a white list of devices that are authorized to leverage this forwarding rule, based on either the IP address or firewall zone.

    - To white list IP addresses:
      a. Click **Addresses**.
      b. For **Add Address**, enter an IP address and click **+**.
      c. Repeat for each additional IP address that should be white listed.
    - To specify firewall zones for white listing:
      a. Click **Zones**.
      b. For **Add zone**, click **+**.
      c. For **Zone**, select the appropriate zone.
      d. Repeat for each additional zone.

13. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. At the config prompt, type:

```
(config)> add firewall port end
(config firewall port 6)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Port forwarding rules are enabled by default. To disable the rule:

```
(config firewall dnat 0)> enable false
(config firewall dnat 0)>
```

4. Set the network interface for the rule:

```
(config firewall dnat 0)> interface
(config firewall dnat 0)>
```

Network connections will only be forwarded if their destination address matches the IP address of this network interface.

a. Use the `?` to determine available interfaces:

b. Set the interface. For example:

```
(config firewall dnat 0)> interface wan1
(config firewall dnat 0)>
```

5. Set the IP version. Allowed values are **ipv4** and **ipv6**. The default is **ipv4**:

```
(config firewall dnat 0)> ip_version ipv6
(config firewall dnat 0)>
```

6. Set the public-facing port number that network connections must use for their traffic to be forwarded:

```
(config firewall dnat 0)> port port
(config firewall dnat 0)>
```

7. Set the type of internet protocol:

```
(config firewall dnat 0)> protocol value
(config firewall dnat 0)>
```

Network connections will only be forwarded if they match the selected protocol. Allowed values are **custom**, **tcp**, **tcpudp** or **upd**. The default is **tcp**.

8. Set the IP address of the server to which traffic should be forwarded:

- For IPv4 addresses:

```
(config firewall dnat 0)> to_address ip-address
(config firewall dnat 0)>
```

- For IPv6 addresses:

```
(config firewall dnat 0)> to_address6 ip-address
(config firewall dnat 0)>
```

9. Set the public-facing port number(s) that network connections must use for their traffic to be forwarded:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firewall Port forwarding rules

```
(config firewall zone 0)> no_port value
(config firewall zone 0)>
```

where value is the port number, comma-separated list of port numbers, or range of port numbers on the server to which traffic should be forwarded. For example, to forward traffic to ports one, three, and five through ten, enter **1, 3, 5-10**.

iii. (Optional) To create a white list of devices that are authorized to leverage this forwarding rule, based on either the IP address or firewall zone, change to the acl mode:

```
(config firewall zone 0)> acl
(config firewall zone 0 acl)>
```

- To white list an IP address:
  - For IPv4 addresses:

    ```
    (config firewall zone 0 acl)> add address end ip-address
    (config firewall zone 0 acl)>
    ```

  - For IPv6 addresses:

    ```
    (config firewall zone 0 acl)> add address6 end ip-address
    (config firewall zone 0 acl)>
    ```

  Repeat for each appropriate IP address.
- To specify the firewall zone for white listing:

  ```
  (config firewall zone 0 acl)> add zone end zone
  ```

  Repeat for each appropriate zone.

  To view a list of available zones:

  ```
  (config firewall zone 0 acl)> ..  .. .. zone ?

  Zones: A list of groups of network interfaces that can be referred
  to by packet filtering rules
  and access control lists.

   Additional Configuration
  ------------------------------------------------------------------
  ------------

    any
    dynamic_routes
    edge
    external
    internal
    ipsec
    loopback
    setup

  (config firewall zone 0 acl)>
  ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

11. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

12. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete a port forwarding rule

To delete a port forwarding rule:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Firewall > Port forwarding**.
4. Click the menu icon (...) next to the appropriate port forwarding rule and select **Delete**.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Determine the index number of the port forwarding rule you want to delete:

```
(config)> show firewall snat
0
        acl
                no address
                no zone
        enable true
        interface
        ip_version ipv4
        label IPv4 port forwarding rule
        port 10000
        protocol tcp
        to_address 10.10.10.10
        to_port 10001

1
        acl
                no address6
                no zone
        enable false
        interface
        ip_version ipv6
        label IPv6 port forwarding rule
        port 10002
        protocol tcp
        to_address6 2001:4830:bb83:bb11:9a1f:5000:4b53:c1da
        to_port 10003
(config)>
```

4. To delete the rule, use the index number with the **del** command. For example:

```
(config)> del firewall snat 1
```

5. Save the configuration and apply the change:

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Packet filtering

By default, one preconfigured packet filtering rule, **Allow all outgoing traffic**, is enabled and monitors traffic going to and from the Connect EZ 4 WS device. The predefined settings are intended to block unauthorized inbound traffic while providing an unrestricted flow of outgoing data. You can modify the default packet filtering rule and create additional rules to define how the device accepts or rejects traffic that is forwarded through the device.

Configure packet filtering

Required configuration items

- The action that the packet filtering rule will perform, either **Accept**, **Reject**, or **Drop**.
- The source firewall zone. Packets originating from interfaces on this zone will be monitored by this rule.
- The destination firewall zone. Packets destined for interfaces on this zone will be accepted, rejected, or dropped by this rule.

Additional configuration requirements

- A label for the rule.
- The IP version to be matched, either **IPv4**, **IPv6** or **Any**.
- The protocol to be matched, one of:
  - ICI'
  - UDI'
  - ICMI'
  - ICMI'6
  - Any

To configure a packet filtering rule:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Firewall** > **Packet filtering**.
   - To create a new packet filtering rule, for **Add packet filter**, click **+**.

   - To edit the default packet filtering rule or another existing packet filtering rule, click to expand the rule.

The packet filtering rule configuration window is displayed.

Packet filters are enabled by default. To disable, toggle off **Enable**.

4. (Optional) Type a **Label** that will be used to identify the rule.
5. For **Action**, select one of:
   - **Accept**: Allows matching network connections.
   - **Reject**: Blocks matching network connections, and sends an ICMP error if appropriate.
   - **Drop**: Blocks matching network connections, and does not send a reply.
6. Select the **IP version**.
7. Select the **Protocol**.
8. For **Source zone**, select the firewall zone that will be monitored by this rule for incoming connections from network interfaces that are a member of this zone.

   See Firewall configuration for more information about firewall zones.
9. For **Destination zone**, select the firewall zone. Packets destined for network interfaces that are members of this zone will either be accepted, rejected or dropped by this rule.

   See Firewall configuration for more information about firewall zones.
10. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

   To edit the default packet filtering rule or another existing packet filtering rule:

   a. Determine the index number of the appropriate packet filtering rule:

```
(config)> show firewall filter
0
    action accept
    ext_zone any
    enable true
    ip_version any
    label Allow all outgoing traffic
    protocol any
    src_zone firewall
1
    action drop
    ext_zone internal
    enable true
    ip_version any
    label myFilter
    protocol any
    src_zone external
(config)>
```

   b. Select the appropriate rule by using its index number:

```
(config)> firewall filter 1
(config firewall filter 1)>
```

   To create a new packet filtering rule:

```
(config)> add firewall filter end
(config firewall filter 2)>
```

   Packet filtering rules are enabled by default. To disable the rule:

```
(config firewall filter 2)> enable false
(config firewall filter 2)>
```

3. (Optional) Set the label for the rule.

```
(config firewall filter 2)> label "My filter rule"
(config firewall filter 2)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Set the action to be performed by the filter rule.

```
(config firewall filter 1)> action value
(config firewall filter 1)>
```

where value is one of:

- **accept**: Allows matching network connections.
- **reject**: Blocks matching network connections, and sends an ICMP error if appropriate.
- **drop**: Blocks matching network connections, and does not send a reply.

5. Set the firewall zone that will be monitored by this rule for incoming connections from network interfaces that are a member of this zone.

See firewall configuration for more information about firewall zones.

```
(config firewall filter 1)> src_zone my_zone
(config firewall filter 1)>
```

6. Set the destination firewall zone. Packets destined for network interfaces that are members of this zone will either be accepted, rejected or dropped by this rule.

See firewall configuration for more information about firewall zones.

```
(config firewall filter 1)> dst_zone my_zone
(config firewall filter 1)>
```

7. Set the IP version.

```
(config firewall filter 1)> ip_version value
(config firewall filter 1)>
```

where value is one of:

- **any**
- **ipv4**
- **ipv6**
- The default is **any**.

8. Set the protocol.

```
(config firewall filter 1)> protocol value
(config firewall filter 1)>
```

where value is one of:

- **any**
- **icmp**
- **icmpv6**
- **tcp**
- **udp**

The default is **any**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

ii. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

iii. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Enable or disable a packet filtering rule

To enable or disable a packet filtering rule.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.


   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Firewall > Packet filtering**.
4. Click the appropriate packet filtering rule.
5. Click **Enable** to toggle the rule between enabled and disabled.

   
6. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Determine the index number of the appropriate port forwarding rule.

```
(config)> show firewall filter
1
    action accept
    dst_zone any
    enable true
    ip_version any
    label Allow all outgoing traffic
    protocol any
    src_zone internal
2
    action drop
    dst_zone internal
    enable true
    ip_version any
    label My packet filter
    protocol any
    src_zone external
(config)>
```

4. To enable a packet filtering rule, use the index number with the **enable true** command. For example:

```
(config)> firewall filter 1 enable true
```

5. To disable a packet filtering rule, use the index number with the **enable false** command. For example:

```
(config)> firewall filter 1 enable false
```

6. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete a packet filtering rule

To delete a packet filtering rule:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Firewall** > **Packet filtering**.
4. Click the menu icon (...) next to the appropriate packet filtering rule and select **Delete**.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

   ```
   > config
   (config)>
   ```
3. Determine the index number of the packet filtering rule you want to delete:

   ```
   (config)> show firewall filter
   0
       action accept
   ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
    dst_zone any
    enable true
    ip_version any
    label Allow all outgoing traffic
    protocol any
    src_zone internal
1
    action drop
    dst_zone internal
    enable true
    ip_version any
    label My packet filter
    protocol any
    src_zone external
[config]>
```

4. To delete the rule, use the index number with the **del** command. For example:

```
[config]> del firewall filter 1
```

5. Save the configuration and apply the change.

```
[config]> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

Configure custom firewall rules

Custom firewall rules consist of a script of shell commands that can be used to install firewall rules, ipsets, and other system configuration. These commands are run whenever system configuration changes occur that might cause changes to the firewall.

To configure custom firewall rules:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Firewall** > **Custom rules**.

4. **Enable** the custom rules.
5. (Optional) Enable **Override** to override all preconfigured firewall behavior and rely solely on the custom firewall rules.
6. For **Rules**, type the shell command that will execute the custom firewall rules script.
7. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable custom firewall rules:

```
(config)> firewall custom enable true
(config)>
```

4. (Optional) Instruct the device to override all preconfigured firewall behavior and rely solely on the custom firewall rules:

```
(config)> firewall custom override true
(config)>
```

5. Set the shell command that will execute the custom firewall rules script:

```
(config)> firewall custom rules "shell-command"
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Firewall Configure custom firewall rules

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an Access selection menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure captive portals

Captive portals are commonly used on public-access networks to require users to login or accept terms and conditions before accessing the Internet.

To configure captive portals:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Firewall** > **Captive portals**.
4. For **Add captive portal:**, enter a name for the portal and click **+**.

   The captive portal configuration window is displayed.

   The captive portal is enabled by default. To disable, toggle off **Enable**.
5. For **Interface**, select the network interface for the portal.

   Traffic received on this interface's network device will not be forwarded unless the client has been granted access.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. For **Session timeout**, type the amount of time that a user session remains valid. After the session times out, the user will be required to log in again.

   Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

   For example, to set **Session timeout** to ten minutes, enter **10m** or **600s**.

7. For **Portal HTTP access**, configure whether the portal can be accessed over an insecure connection.
   - **Allow**: Allows access to the portal page over an insecure connection (HTTP port 80).
   - **Redirect to HTTPS**: Automatically redirects the request to a secure connection (HTTPS port 443).
   - **Disallow**: Does not allow access over an insecure connection (HTTP port 80).

   Note: this setting does not affect access to HTTP port 80 after the client has been granted access to the portal.

8. For **Authorization**, select the method that will be used to authorize the user:
   - **None**: Users are not required to enter any information to access the portal.
   - **User login**: Users are required to authenticate with an account on this device. Users must be part of a user group that allows access to this portal.
   - **Collect user information**: Users are required to complete a form to continue. The form fields may be customized.
9. (Optional) For **Title**, enter the title of the portal page that the user will see when accessing the portal.
10. (Optional) For **Message**, enter a message that will appear on the portal page.
11. (Optional) For **Terms and Conditions**, enter the terms and conditions that will appear on the portal page. Users will be required to agree to the terms and conditions before being granted access to the portal.
12. (Optional) For **Redirect to URL**, enter the URL to which the user will be directed when granted access to the portal. If left blank, the user will be directed to the domain of the URL in the original access request.
13. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. To create an active portal called **portal1**:

```
(config)> add firewall portal portal1
(config firewall portal portal1)>
```

Captive portals are enabled by default. To disable the portal:

```
(config firewall portal portal1)> enable false
(config firewall portal portal1)>
```

4. Set the network interface for the portal. Traffic received on this interface's network device will not be forwarded unless the client has been granted access.
   a. Use the `?` to determine available interfaces.
   b. Set the interface. For example:

```
(config firewall portal portal1)> interface /network/interface/eth1
(config firewall portal portal1)>
```

5. Set the amount of time that a user session remains valid. After the session times out, the user will be required to log in again.

```
(config firewall portal portal1)> timeout value
(config firewall portal portal1)>
```

where *value* is any number of weeks, days, hours, minutes, or seconds, and takes the format **number(w|d|h|m|s)**.

For example, to set **Session timeout** to ten minutes, enter either **10m** or **600s**:

```
(config firewall portal portal1)> timeout 10m
(config firewall portal portal1)>
```

6. Configure whether the portal can be accessed over an insecure connection.

```
(config firewall portal portal1)> http value
(config firewall portal portal1)>
```

where *value* is one of:

- **allow**: Allows access to the portal page over an insecure connection (HTTP, port 80).
- **redirect**: Automatically redirects the request to a secure connection (HTTPS, port 443).
- **disallow**: Does not allow access over an insecure connection (HTTP, port 80).

Note: This setting does not affect access to HTTP port 80 after the client has been granted access to the portal.

7. Set the method that will be used to authorize the user:

```
(config firewall portal portal1)> auth value
(config firewall portal portal1)>
```

where *value* is one of:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **none**: Users are not required to enter any information to access the portal.
- **login**: Users are required to authenticate with an account on this device. Users must be part of a user group that allows access to this portal.
- **info**: Users are required to complete a form to continue. The form fields may be customized.

8. (Optional) Set the title of the portal page that the user will see when accessing the portal.

```
(config firewall portal portal1)> title "Corporate portal"
(config firewall portal portal1)>
```

9. (Optional) Set a message that will appear on the portal page.

```
(config firewall portal portal1)> message "Welcome to the corporate web
portal"
(config firewall portal portal1)>
```

10. (Optional) Set the terms and conditions that will appear on the portal page. Users will be required to agree to the terms and conditions before being granted access to the portal.

```
(config firewall portal portal1)> terms "Accept the terms and conditions
of this portal"
(config firewall portal portal1)>
```

11. (Optional) Set the URL to which the user will be directed when granted access to the portal. If left blank, the user will be directed to the domain of the URL in the original access request.

```
(config firewall portal portal1)> url https://myportal.com
(config firewall portal portal1)>
```

12. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

13. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Delete captive portals

To delete captive portals:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Firewall > Captive portals**.
4. Click the down caret (▾) next to the appropriate captive portal and select **Delete**.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. To delete a captive portal, use the **del** command. For example:

```
(config)> del firewall portal portal1
```

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Web filtering

Web filtering allows you to control access to services that can be accessed through the Connect EZ 4 WS device by forwarding all Domain Name System (DNS) traffic to a web filtering service. This allows the network security administrator to configure a set of policies with the web filtering service that are applied to all routing devices with web filtering enabled. For example, a policy may allow or deny access to a specific service or type of service such as social media, gaming, and so on.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Your Connect EZ 4 WS device supports two methods for configuring web filtering:

- Cisco Umbrella (formally known as OpenDNS)
- Manual DNS server entry

Configure web filtering with Cisco Umbrella

Required configuration items

- Enable web filtering.
- A Cisco Umbrella account.

  See https://umbrella.cisco.com for information about how to create a Cisco Umbrella account. A 14 day trial account is available.
- A customer-specific API token.

Task one: Generate a Cisco Umbrella API token

1. Log into the Cisco Umbrella Dashboard (https://dashboard.umbrella.com).
2. On the menu, select **Admin** > **API Keys**.

   The **API Keys** page displays.
3. Click **+** (**Create**).
4. Select **Legacy Network Devices**.
5. Click **Create**.
6. Copy the token.

Task two: Configure web filtering

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Firewall > Web filtering service**.

4. Click **Enable web filtering** to enable.
5. For **Web filtering service**, select **Cisco Umbrella**.
6. Paste the **API token** that was generated in Task one: Generate a Cisco Umbrella API token.
7. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable web filtering:

```
(config)> firewall web-filter enable true
(config)>
```

4. Set the web filter service type to **umbrella**:

```
(config)> firewall web-filter service umbrella
(config)>
```

5. Set **umbrella_token** to the API token generated in Task one: Generate a Cisco Umbrella API token:

```
(config)> firewall web-filter umbrella_token token
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Clear the Cisco Umbrella device ID

If the Cisco Umbrella device ID being used by your Connect EZ 4 WS is invalid, you can clear the device ID.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the Admin CLI prompt, use the `rm` command to delete the **web-filter-id** file, and confirm the deletion:

```
> rm /etc/config/web-filter-id
rm: remove '/etc/config/web-filter-id'? yes
>
```

3. Restart the web filtering service:

```
> config firewall web-filter enable false
> config firewall web-filter enable true
>
```

Configure web filtering with manual DNS servers

Required configuration items

- Enable web filtering.
- The IP address of one or more DNS servers. Cisco provides two open DNS servers for web filtering:
  - 208.67.222.222
  - 208.67.220.220

  Note These two IP addresses do not work with the OpenDNS option. See https://www.opendns.com/setupguide/ for more information about using Cisco DNS servers for web filtering.

To configure web filtering with manual DNS servers:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Firewall** > **Web filtering service**.

4. Click **Enable web filtering** to enable.
5. For **Web filtering service**, select **Manual**.
6. Click to expand **Servers**.
7. Click **+** to add a server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. For **IP address**, enter the IP address of the DNS server.

9. (Optional) Repeat for additional DNS servers.
10. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable web filtering:

```
(config)> firewall web-filter enable true
(config)>
```

4. Set the web filter service type to **manual**:

```
(config)> firewall web-filter service manual
(config)>
```

5. Add a DNS server:

```
(config)> add firewall web-filter server end
(config firewall web-filter server 0)>
```

6. Set the DNS server's IP address:

```
(config firewall web-filter server 0)> ip ip_address
(config firewall web-filter server 0)>
```

7. (Optional) Repeat for additional DNS servers.

   For example, to configure manual web filtering using Cisco's open DNS servers:

   a. Enable web filtering:

```
(config)> firewall web-filter enable true
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Set the web filter service type to **manual**:

```
(config)> firewall web-filter service manual
(config)>
```

c. Add the first DNS server:

i. Add the server:

```
(config)> add firewall web-filter server end
(config firewall web-filter server 0)>
```

ii. Set the server's IP address:

```
(config firewall web-filter server 0)> ip 208.67.222.220
(config firewall web-filter server 0)>
```

d. Add the second DNS server:

i. Move back one node in the configuration tree:

```
(config firewall web-filter server 0)> ..
(config firewall web-filter server)>
```

ii. Add the server:

```
(config firewall web-filter server)> add end
(config firewall web-filter server 1)>
```

iii. Set the server's IP address:

```
(config firewall web-filter server 1)> ip 208.67.220.220
(config firewall web-filter server 0)>
```

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Verify your web filtering configuration

If your web filtering implementation has the service set to Cisco Umbrella, or if it is configured to use manual DNS servers and uses the Cisco open DNS servers, you can verify the web filtering implementation by using the Cisco test site www.internetbadguys.com.

To verify the implementation:

Web

This procedure assumes you have already configured web filtering to use either Cisco Umbrella or the Cisco open DNS servers.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- See Configure web filtering with Cisco Umbrella for information about configuring web filtering with Cisco Umbrella.
- See Configure web filtering with manual DNS servers for information about configuring web filtering to use Cisco open DNS servers.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:
   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:
   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Disable web filtering:
   a. Click **Firewall** > **Web filtering service**.
   b. Click **Enable web filtering** to disable.

   c. Click **Apply** to save the configuration and apply the change.
4. From a new tab in your browser, attempt to connect to the Cisco test URL http://www.internetbadguys.com.

   The connection should be successful.
5. Return to the Connect EZ 4 WS Web UI and enable web filtering:
   a. Click **Firewall** > **Web filtering service**.
   b. Click **Enable web filtering** to enable.
   c. Click **Apply** to save the configuration and apply the change.
6. From your browser, attempt to connect to http://www.internetbadguys.com again.

   The connection attempt should fail with the message, "This site is blocked due to a phishing threat."

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

This procedure assumes you have already configured web filtering to use either Cisco Umbrella or the Cisco open DNS servers.

- See Configure web filtering with Cisco Umbrella for information about configuring web filtering with Cisco Umbrella.
- See Configure web filtering with manual DNS servers for information about configuring web filtering to use Cisco open DNS servers.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Disable web filtering:

```
> config firewall web-filter enable false
>
```

3. Attempt to connect to the Cisco test URL http://www.internetbadguys.com by using either a web browser or the **curl** command from a Linux shell:

```
$ curl -I http://www.internetbadguys.com
HTTP/1.1 200 OK
Server: Apache
Content-Type: text/html; charset=UTF-8
Accept-Ranges: bytes
Date: Thu, Jan 11, 2024 12:18:08
X-Varnish: 420139746
Age: 0
Via: 1.1 varnish
Connection: keep-alive

$
```

You should receive an "HTTP/1.1 200 OK" message, as highlighted above.

4. Return to the Admin CLI and enable web filtering:

```
> config firewall web-filter enable true
>
```

5. Attempt to connect to http://www.internetbadguys.com again:

```
$ curl -I www.internetbadguys.com
HTTP/1.1 403 Forbidden
Server: openresty/1.9.7.3
Date: Thu, Jan 11, 2024 12:18:08
Content-Type: text/html
Connection: keep-alive

$
```

You should receive an "HTTP/1.1 403 Forbidden" message, as highlighted above.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Show web filter service information

To view information about the web filter service:

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights. Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, use the show web-filter command to view information about the web-filter service.

```
> show web-filter

Enabled     : true
Service     : umbrella
Device ID   : 0864b1c0ffe1de7aa

>
```

If the device is configured to use Cisco Umbrella for web filtering, a device ID is displayed. The device ID is a unique ID assigned to the device by Cisco Umbrella. If there is a problem with the device ID, you can clear the ID. See Clear the Cisco Umbrella device ID for instructions.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Containers

The Connect EZ 4 WS device includes support for LXC Linux containers. LXC containers are a lightweight, operating system level method of virtualization that allows you to run one or more isolated Linux instances on a the same host using the host's Linux kernel.

Note Container support must be enabled in Digi Remote Manager. Contact your Digi sales representative for information.

This chapter contains the following topics:

Use Digi Remote Manager to deploy and run containers 712
Upload a new LXC container 715
Configure a container 717
Starting and stopping the container 722
View the status of containers 723
Schedule a script to run in the container 724
Create a custom container 727

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use Digi Remote Manager to deploy and run containers

Note Container support must be enabled in Digi Remote Manager. Contact your Digi sales representative for information.

1. In Remote Manager, create a Configuration template. See the Remote Manager User Guide for instructions.
   a. For the **Settings** step:
      - Click **Import from device** and import settings from an appropriate device.
      - Configure a script to run the container:
        i. Click **System**.
        ii. Click **Scheduled tasks** > **Custom scripts**.
        iii. Click + to add a custom script.
        iv. Click the **Label** checkbox and type an identifiable label for the script, for example, **StartContainerScript**.
        v. To ensure that the script is always running:
           i. Click the **Run mode** checkbox and select **Interval**.
           ii. Click the **Interval** checkbox and enter a very short interval (for example, one minute).
           iii. Click the **Run angle** checkbox, and toggle on to enable.

           This will configure the device to regularly check if the script is running, but only run it if it is currently not running.
        vi. For **Commands**, type the command to run the script. The command will vary depending on how you want to run the script, and what application you want to run inside the script. For example, to run the ping command inside a container, the command would be:

        ```
        lxc container_name /bin/ping -c 30 1.1.1.1
        ```

        
   b. For the **Containers** step:
      i. Click + to add a container to the configuration.

      If no containers have been uploaded, or if Click ⬆ to upload a container file.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Containers Use Digi Remote Manager to deploy and run containers



i. Click **Browse** and select the container file.

ii. Type the **Name** of the container.

The **Name** entered here must be the same name as the container .tgz file. This is absolutely necessary, otherwise the container file will not be properly configured on the local devices.

iii. (Optional) Include a version number for the container.

iv. (Optional) Select the **Device Type** and **Firmware Version** that applies to the container.

If set, these options will limit the container to only be included in Configuration templates that match the specified device type and firmware version. If these are left blank, the container can be included in any Configuration template.

v. Click **Upload**.

vi. Repeat to upload additional containers.

ii. Select one or more containers to add to the configuration.

iii. Click **Done**.

iv. Click **Save**.

v. Click **Continue**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. For the **Automation** step:

i. Click to toggle on **Enable Scanning**.

ii. Click to toggle on **Remediate**.

2. Run a manual configuration scan to apply the container and configuration settings to all applicable devices.

3. Verify that the container is running on a device.

- To verify by using device metrics:

a. From the Remote Manager main menu, click **Management** > **Devices**.

b. Click the **Device ID** to open the device's **Details** page.

c. Click **Metrics**.

d. Information about configured containers is located under the **Container Details** heading.




- To verify by using the **Data streams** page:

a. From the Remote Manager main menu, click **Management** > **Data Streams**.

b. Locate the container's data stream:

i. Click to search using advanced filtering.

ii. Click in the search text box and select **Device ID** from the menu.



iii. Type the device ID and press the Enter key.

iv. Click in the search text box again and select **Stream ID** from the menu.

v. Type container and press the Enter key.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

vi. Click the **Stream ID** to view container status.



- To verify by using the **show containers** command on the local device:
  a. From the Remote Manager main menu, click **Management** > **Devices**.
  b. Select the device.
  c. From the **Actions** menu, select **Open Console**.
  d. At the prompt, type **show containers**.



Use an automation to start the container

You can also use an automation to start a container:

1. Follow the steps in the previous procedure, except:
   - For **Run mode**, select **Manual**.
   - Do not set **Interval** or **Run angle**.
2. Create an automation that uses a Command Line Interface step.

   For the **Command Line Message**, use the system script start command, using the label provided for the script in the previous procedure:


```
system script start StartContainerScript
```



Once the automation has been created, you can:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Run the automation manually.
- Include the automation in a Configuration template as a post-remediation or post-scan step.
  When creating or editing a Configuration template, at the **Automation** page:
  1. For **Post Remediation Options**, click **Run Automation** and select the automation.
  2. For **On Successful Scan Options**, click **Run Automation** and select the automation.
- Include a trigger for the automation.
  When creating or editing an automation, at the **Triggers** page:
  1. Click to enable **Triggered** to configure the automation to be triggered, either on a schedule or by device activity.
     a. To configure the script to be run on a schedule:
        i. Click to enable **By Schedule**.
        ii. Click **Start time**.
        iii. From the calendar provided, select the date and time that the script should be started for the first time.
        iv. By default, the script will run only once. Click to enable **Repeat** to configure the script to run on a regular basis.



        v. Type or select the number of times, and select the time period.
        vi. (Optional) Click **Until** to select a date and time when the automation schedule will stop repeating.
     b. To configure the automation to be triggered by device activity, click to enable one or more of the following:
        - **Run when a device enters the target scope**
        - **Run when a device in the target scope enters a maintenance window**
        - **Run when a device in the target scope leaves debug mode**

        Target scope refers to a device that either:
        - Is a member of a group that was selected on the **Target** page.
        - Has a tag that was selected on the **Target** page.
        - Is one of the devices included on the **Target** page.

Upload a new LXC container

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. From the main menu, click **Status**. Under **Services**, click **Containers**.
2. Click **Upload New Container**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. From your local file system, select the container file in *.lxc format.
   You can download a simple example container file, test_no.lxc, from the Digi website.
4. **Create Configuration** is selected by default. This will create a configuration on the device for the container when it is installed. If deselected, you will need to create the configuration manually.
5. Click **Apply**.
6. If **Create Configuration** was deselected when the container was created, click 🔧 to go to the container configuration.



See Configure a container for further information about configuring the container.

Configure a container

Required configuration items

- The following configuration options are completed automatically if **Create Configuration** was selected when the container was created. See Upload a new LXC container for details.
  - Name of the container.
  - Enable the container.
  - Whether or not the container should use the device's system libraries.
- Determine whether or not the device should including virtual networking capabilities.

Additional configuration items

- If virtual networking is enabled:
  - The bridge to be used to provide network connectivity.
  - A static IP address for the container.
  - The network gateway.
- Serial port on the device that the container will have access to.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Click the **Device ID**.
c. Click **Settings**.
d. Click to expand **Config**.

Local Web UI:


a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **System** > **Containers**.
4. For **Add Container**, type the name of the container and click **+**.

The Container configuration window is displayed.



New containers are enabled by default. To disable, toggle off **Enable**.

5. **Close boot system libraries** is enabled by default. This allows the container to use the device's system libraries.
6. Enable **Virtual Network** if the container should have network access.
   a. Select a **Network Bridge Device** that will provide access to the container.
   b. (Optional) Enter a static **IP Address** and netmask for the container. This must be a valid IP address for the bridge, or, if left blank, a DHCP server can assign the container an IP address.
   c. (Optional) For **Gateway**, type the IP address of the network gateway.
7. Enable **Start on boot** to configure the container to start when the system boots.
   a. For **Restart timeout**, set the amount of time to wait before restarting the container, if the container ever stops. The default timeout of **0** means that if the container stops, it will not be restarted.

      Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*(w|d|h|m|s).

      For example, to set **Restart timeout** to ten minutes, enter **10m** or **600s**.
8. (Optional) Type any **Optional parameters** for the container. Parameters are in the format accepted by the lxc utility.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

9. (Optional) Type a **Working directory** to configure an initial working directory for the container. The directory is an absolute path within the container and must begin with "/". The default is /.
10. (Optional) Click to expand **Mounted directories** to configure system directories that will be mounted inside the container. Any mounted directories need to be accessible to a non-privileged user.
    a. For **Add Directory**, click +.
    b. For **Directory**, type the pathname of the directory to be mounted. The leading slash should be removed, so for example to mount the /opt directory, type **opt**.
11. (Optional) Click to expand **Serial ports** to assign serial ports that the container will have access to.
    a. For **Add Port**, click +.
    b. For **Port**, select the serial port.
12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Create a new container:

```
(config)> add system container name
(config system container name)>
```

   where **name** is the

   New access points are enabled by default.
4. New containers are enabled by default. To disable

```
(config system container name)> enable false
(config system container name)>
```

5. By default, the container will use the device's system libraries. To disable

```
(config system container name)> sal false
(config system container name)>
```

6. If the device will use virtual networking
   a. Enable virtual networking

```
(config system container name)> network true
(config system container name)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Set the network bridge device that will be used to provide network access.

i. Use the ? to determine the available bridges:

```
(config system container name)> bridge ?

Network Bridge Device: Containers require a bridge to access the
network. Choose
which bridge to connect the container to.
Format:
  hotspot_bridge
  lan1
Current value:

(config system container name)>
```

ii. Set the bridge:

```
(config system container name)> bridge lan1
(config system container name)>
```

c. (Optional) Set the IP address and netmask for the container:

```
(config system container name)> address IP_address/netmask
(config system container name)>
```

d. (Optional) Set the IP address of the network gateway:

```
(config system container name)> gateway IP_address
(config system container name)>
```

7. To configure the container to start when the device boots:

```
(config system container name)> start_on_boot true
(config system container name)>
```

8. Set the amount of time to wait before restarting the container, if the container ever stops:

```
(config system container name)> restart_timeout value
(config system container name)>
```

where *value* is any number of weeks, days, hours, minutes, or seconds, and takes the format *number*w|d|h|m|s.

For example, to set **restart timeout** to ten minutes, enter either **10m** or **600s**:

```
(config system container name)> restart_timeout 600s
(config system container name)>
```

The default timeout of **0** means that if the container stops, it will not be restarted.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Type any optional parameters for the container:

```
(config system container name)> args parameters
(config system container name)>
```

Parameters are in the format accepted by the lxc utility.

9. (Optional) Set an initial working directory for the container:

```
(config system container name)> workdir /value
(config system container name)>
```

The directory is an absolute path within the container and must begin with "/". The default is /.

10. (Optional) Set any system directories that should be mounted inside the container. Any mounted directories need to be accessible to a non-privileged user.
    a. Add a system directory to be mounted:

```
(config system container name)> system_dirs directory
(config system container name)>
```

    where directory is the pathname of the directory to be mounted. The leading slash should be removed, so for example to mount the /opt directory, type opt.
    b. Repeat for additional directories.
11. For **Add Directory**, click **+**.
    a. For **Directory**, type the pathname of the directory to be mounted. The leading slash should be removed, so for example to mount the /opt directory, type opt.
12. (Optional) Assign serial ports that the container will have access to:
    a. Determine available serial ports:

```
(config system container name)> .. serial

Serial

 Additional Configuration
 ------------------------------------------------------------------------
 ------------
 port1                    Port 1
 ...

(config system container name)>
```

    b. Add the port:

```
(config system container name)> add ports end port1
(config system container name)>
```

13. Save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network wireless client new_client)> save
Configuration saved.
>
```

14. Type **exit** to exit the Admin CLI.

    Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Starting and stopping the container

Container commands are not available from the Admin CLI. See Authentication groups for information about configuring authentication groups that include shell access.

Note Container support must be enabled in Digi Remote Manager. Contact your Digi sales representative for information.

Starting the container

There are two methods to start containers:

- Non-persistent: Changes made to the container file system will be lost when the container is stopped.
- Persistent: Changes made to the container file system when not Serial when the container is stopped.

Starting a container in non-persistent mode

To start the container in non-persistent mode:

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.

2. At the shell prompt, type:

   ```
   # lxc container_name
   lxc #
   ```

   where **container_name** is the name of the container as configured on the device. For example:

   ```
   # lxc test_lxc
   lxc #
   ```

This will start the container by using "bash -l, which runs the shell and loads the shell profile. The default shell profile includes an lxc # prompt.

Starting a container in persistent mode

To start the container in persistent mode, include the **-p** option at the command line. For example:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.
2. At the shell prompt, type:

```
# lxc root_lxc -p
lxc #
```

This will start the container by using **/bin/sh -l**, which runs the shell and loads the shell profile. The default shell profile includes an **lxc #** prompt.

Starting a container by including an executable

You can supply an executable to run when you start the container, along with any parameters. If you don't supply a parameter, the default behavior is to run the executable by using **/bin/sh -l**, which runs the shell and loads the shell profile. This is useful when you use the **Clone OAL** option when uploading the container, which includes the device's system libraries. In this case, the command without any additional parameters will use the device's shell. See Upload a new LXC container for more information.

Stopping the container

1. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions** > **Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **shell** to access the device shell.
2. At the lxc shell prompt, type:

```
lxc # exit
#
```

View the status of containers

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. From the main menu, click **Status**. Under **Services**, click **Containers**.

The **Containers** status page displays.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



Command line

Show status of all containers

Use the show containers command with no additional arguments to show the status of all containers on the system.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the prompt, type:

```
> show containers

Container   Configured  Enabled  State
----------  ----------  -------  ----------
mytest1     True        enabled  STOPPED
test_lxc    True        enabled  RUNNING PID 10127
>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Show status of a specific container

Use the show containers container name command to show the status of the specified container.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the prompt, type:

```
> show containers container test_lxc

Container   Configured  Enabled  State
----------  ----------  -------  ----------
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
zacn_1ac    True        enabled  RUNNING PID 10317
>
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Schedule a script to run in the container

This simple example will:

1. Start the container in non-persistent mode.
2. Execute a ping command every ten seconds from inside the container.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **System** > **Scheduled tasks** > **Custom scripts**.
4. For **Add Script**, click **+**.

The script configuration window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Containers Schedule a script to run in the container

5. (Optional) For **Label**, type **container_script**.
6. For **Run mode**, select **Interval**.
7. For **Interval**, type **10s**.
8. For **Commands**, type the following:

```
lxc container_name /bin/ping -c 1 IP_address
```

For example:

```
lxc test_lxc /bin/ping -c 1 192.168.1.146
```

9. Click to disable **Sandbox**. Sandbox restrictions are not necessary when a container is used.
10. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a script:

```
(config)> add system schedule script end
(config system schedule script 0)>
```

4. Provide a label for the script, for example:

```
(config system schedule script 0)> label test_lxc
(config system schedule script 0)>
```

5. Set the mode to interval:

```
(config system schedule script 0)> when interval
(config system schedule script 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

6. Set the interval to ten seconds:

```
(config system schedule script 0)> on_interval 10s
(config system schedule script 0)>
```

7. Set the commands that will execute the script:

```
(config system schedule script 0)> commands "%sc script_name /bin/ping -c
1 IP_address"
(config system schedule script 0)>
```

For example:

```
(config system schedule script 0)> commands "%sc test_%sc /bin/ping -c 1
192.168.1.145"
(config system schedule script 0)>
```

8. Disable the **sandbox**. Sandbox restrictions are not necessary when a container is used:

```
(config system schedule script 0)> sandbox false
(config system schedule script 0)>
```

9. Save the configuration and apply the changes:

```
(config)> save
Configuration saved.
>
```

10. Type **exit** to exit the Admin CLI:
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Create a custom container

This example creates a simple custom container that contains a python script in the /etc directory. In this example, we will use a simple container file named test_tsc.tgz. You can download test_tsc.tgz from the Digi website.

At the command line of a Linux host, we will: unpack the file, add a simple python script, and create a new container file that includes the python script.

Create the custom container file

1. At the command line of a Linux host, unpack the test_tsc.tgz file:

```
$ tar -xfv test_tsc.tgz
rootfs/
rootfs/usr/
rootfs/etc/
rootfs/etc/group
rootfs/etc/profile
rootfs/etc/passwd
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
rootfs/tmp/
$
```

2. Change to the rootfs/etc directory:

```
$ cd rootfs/etc
$
```

3. Create a file named test.py with the following contents:

```
print("Hello world.\n")
```

4. Change directories to leave the container file structure:

```
$ cd ../..
```

5. Change user and group permissions on all files in the container file structure:

```
$ sudo chown -R 160320 rootfs
$ sudo chgrp -R 160320 rootfs
```

6. Tar and zip the directory structure to create a new container file:

```
$ sudo tar -czvf python_loc.tgz rootfs
```

If using macOS, include the --disable-copyfile option with the command:

```
$ sudo tar --disable-copyfile -czvf python_loc.tgz rootfs
```

Test the custom container file

1. Add the new container to your Connect EZ 4 WS device:

   Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

   a. From the main menu, click **Status**. Under **Services**, click **Containers**.

   b. Click **Upload New Container**.

   c. From your local file system, select the container file.

   You can download a simple example container file, test_loc.tgz, from the Digi website.

   d. **Create Configuration** is selected by default. This will create a configuration on the device for the container when it is installed. If deselected, you will need to create the configuration manually.

   e. Click **Apply**.

2. Select a device in Remote Manager that is configured to allow shell access to the admin user, and click **Actions > Open Console**. Alternatively, log into the Connect EZ 4 WS local command line as a user with shell access.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **shell** to access the device shell.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Containers Create a custom container

3. At the shell prompt, type:

```
# lxc python_lxc
lxc #
```

4. Execute the python command:

```
lxc # python /etc/test.py
Hello world.
lxc #
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

System administration

This chapter contains the following topics:

Review device status 731
Configure system information 732
Update the system firmware 734
External storage 736
Reboot your Connect EZ 4 WS device 738
Device reset 740
Locate the device by using the Find Me feature 741
Enable FIPS mode 742
Configuration files 743
Schedule system maintenance tasks 746
Disable device encryption 748
Configure the speed of your Ethernet ports 749
Watchdog service 751
Configure the Watchdog service 751
View Watchdog metrics 755

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Review device status

You can review the system of your device from either the **Status** page of the Web interface, or from the command line.

Web

To display system information:

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **Status**.
   A secondary menu appears, along with a status panel.
2. On the secondary menu, click to display the details panel for the status you want to view.

Command line

To display system information, use the show system command.

- Show basic system information:
  1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
     Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
  2. Enter **show system** at the prompt:

```
> show system

  Model                  : Digi Connect EZ 4 WS
  Serial Number          : Connect EZ 4 WSxxxxxxxxyyyyyy
  SKU                    : Connect EZ 4 WS
  Hostname               : Connect EZ 4 WS
  MAC Address            : DF:DD:E2:AE:21:18

  Hardware Version       : 10001047-01 1P
  Firmware Version       : 25.5
  Alt. Firmware Version  : 25.5
  Alt. Firmware Build Date : Fri, Jan 12, 2024 12:10:00
  Bootloader Version     : 10.7.13.0-13f9326e8ed

  Current Time           : Thu, Jan 11, 2024 12:10:00 +0000
  CPU                    : 1.4%
  Uptime                 : 0 days, 6 hours, 31 minutes, 57 seconds
(Utility)
  Temperature            : 46C
  Location               :
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Contact                 :

>
```

- Show more detailed system information:
  1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights. Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
  2. Enter **show system verbose** at the prompt:

```
> show system verbose

  Model                       : Digi Connect EZ 4 WS
  Serial Number               : Connect EZ 4 WSxxxxxxxxyyyyxx
  SKU                         : Connect EZ 4 WS
  Hostname                    : Connect EZ 4 WS
  MAC Address                 : DF:DB:F2:AC:11:18

  Hardware version            : 32000147-01 1F
  Firmware version            : 25.5
  Alt. Firmware version       : 25.5
  Alt. Firmware Build Date    : Fri, Jan 12, 2024 12:10:00
  Bootloader Version          : 19.7.33.0-1SP03Gm4mt
  Schema Version              : 715

  Timezone                    : UTC
  Current Time                : Thu, Jan 11, 2024 12:10:00 +0000
  CPU                         : 1.4%
  Uptime                      : 5 days, 6 hours, 21 minutes, 57 seconds
(5+21117s)
  Load Average                : 0.01, 0.03, 0.03
  RAM Usage                   : 119.11MB/1878.84MB(6%)
  Temperature                 : 46C
  Location                    :
  Contact                     :
  Disk
  ----
  Disk /etc/config Usage      : 16.42MB/454.37MB(3%)
  Disk /var/log_ext Usage     : 6.18MB/14.86MB(1%)
  Disk /opt Usage             : 211.72MB/418.33MB(50%)
  Disk /tmp Usage             : 0.00MB/128.0MB(0%)
  Disk /var Usage             : 0.01MB/32.0MB(1%)

>
```

Configure system information

You can configure information related to your Connect EZ 4 WS device, such as providing a name and location for the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configuration items

- A name for the device.
- The name of a contact for the device.
- The location of the device.
- A description of the device.
- A banner that will be displayed when users access terminal services on the device.

To enter system information:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **System**.
4. For **Name**, type a name for the device. This name will appear in log messages and at the command prompt.
5. For **Contact**, type the name of a contact for the device.
6. For **Location**, type the location of the device.
7. For **Banner**, type a banner message that will be displayed when users log into terminal services on the device.
8. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode.

```
> config
[config]>
```

3. Set a name for the device. This name will appear in log messages and at the command prompt.

```
[config]> system name 192.168.3.1
192.168.3.1[config]>
```

4. Set the contact for the device.

```
192.168.3.1[config]> system contact "Jane User"
192.168.3.1[config]>
```

5. Set the location for the device.

```
192.168.3.1[config]> system location "5350 Executive Blvd., Suite 100, Naples, FL"
192.168.3.1[config]>
```

6. Set the banner for the device. This is displayed when users access terminal services on the device.

```
192.168.3.1[config]> system banner "Welcome to the Digi Connect EZ 4 WS."
192.168.3.1[config]>
```

7. Save the configuration and apply the changes.

```
192.168.3.1[config]> save
Configuration saved.
192.168.3.1>
```

8. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Update the system firmware

The Connect EZ 4 WS operating system firmware images consist of a single file with the following naming convention:

platform-version.bin

For example, **Connect ez 4 WS-25.2.54.xxx**

Manage firmware updates using Digi Remote Manager

If you have a network of many devices, you can use Digi Remote Manager **Profiles** to manage firmware updates. Profiles ensure all your devices are running the correct firmware version and that

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

all newly installed devices are updated to that same version. For more information, see the **Profiles** section of the Digi Remote Manager User Guide.

Python and DAL OS firmware updates

Make sure to check the Python version you are using and that it is compatible with the DAL OS firmware version to which you want to upgrade. You may need to update any Python scripts you have so they are compatible with the Python running on the DAL OS firmware version you choose. See Python versions and corresponding DAL OS firmware versions.

Certificate management for firmware images

The system firmware files are signed to ensure that only Digi-approved firmware load onto the device. The Connect EZ 4 WS device validates the system firmware image as part of the update process and only successfully updates if the system firmware image can be authenticated.

Downgrading

Downgrading to an earlier release of the firmware may result in the device configuration being erased.

Downgrading from firmware version 22.2.9.x

Beginning with firmware version 22.2.9.x, the Connect EZ 4 WS device uses certificate-based communication for enhanced security when connecting to Digi Remote Manager. If you downgrade your firmware from version 22.2.9.x to version 21.11.x or previous, your device will no longer be able to communicate with Remote Manager.

To remedy this issue, select the device in Remote Manager and select **Actions > Reset Device Certificate**.

Update firmware from a local file

Web

1. Download the Connect EZ 4 WS operating system firmware from the Digi Support FTP site to your local machine.
   Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the main menu, click **System**. Under **Administration**, click **Firmware Update**.



3. Click **Choose file**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Browse to the location of the firmware on your local file system and select the file.
5. Click **Update firmware**.

Command line

1. Download the Connect EZ 4 WS operating system firmware from the Digi Support Portal to your local machine.
2. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
3. Load the firmware image onto the device. We recommend using the /tmp directory.

```
> scp host hostname-or-ip user username remote remote-path local local-
path to local
```

   where:
   - **hostname-or-ip** is the host name or IP address of the remote host.
   - **username** is the name of the user on the remote host.
   - **remote-path** is the path and filename of the file on the remote host that will be copied to the Connect EZ 4 WS device.
   - **local-path** is the location on the Connect EZ 4 WS device where the copied file will be placed.

   For example:

```
> scp host 192.168.4.1 user admin remote /home/admin/bin/Connect EZ 4 WS-
35.5.bin local /tmp/ to local
admin@192.168.4.1's password: adminpwd
Connect EZ 4 WS-35.5.bin                    100%   32MB   12.1MB/s   00:03
>
```

4. Verify that the firmware file has been successfully uploaded to the device.

```
> ls /tmp
-rw-r--r--    1 root     root      37511320 May 16 20:10 Connect EZ 4 WS-
35.5.bin
-rw-r--r--    1 root     root          2588 May 16 10:44 blank.json
...
>
```

5. Update the firmware by entering the system firmware update command, specifying the path and file name to the firmware file.

```
> system firmware update file /tmp/Connect EZ 4 WS-35.5.bin
35511K
netflash: got "/tmp/Connect EZ 4 WS-35.5.bin", length=37511320
netflash: authentication successful
netflash: programming FLASH device /dev/flash/image
35511K 100%
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Firmware update completed, reboot device
>
```

6. Reboot the device to run the new firmware image using the reboot command.

```
> reboot
Rebooting system
>
```

7. Once the device has rebooted, log into the Connect EZ 4 WS's command line as a user with Admin access and verify the running firmware version by entering the show system command.

```
> show system

  Hostname                : Connect EZ 4 WS
  FW Version              : 25.3
  MAC                     : 0040FF000139
  Model                   : Digi Connect EZ 4 WS
  Current Time            : Thu, Jan 11, 2024 12:16:58 +0000
  Uptime                  : 42 seconds (42s)

>
```

Dual boot behavior

By default, the Connect EZ 4 WS device stores two copies of firmware in two flash memory banks:

- The current firmware version that is used to boot the device.
- A copy of the firmware that was in use prior to your most recent firmware update.

When the device reboots, it will attempt to use the current firmware version. If the current firmware version fails to load after three consecutive attempts, it is marked as invalid and the device will use the previous firmware version stored in the alternate memory bank.

If the device consistently loses power during the boot process, this may result in the current firmware being marked as invalid and the device downgrading to a previous version of the firmware. As a result of this behavior, you can use the following procedure to guarantee that the same firmware is stored in both memory banks.

Web


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **System**. Under **Administration**, click **Firmware Update**.



2. Click **Duplicate firmware**.



3. Click **Duplicate Firmware**.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Duplicate the firmware:

```
> system duplicate-firmware
>
```

External storage

You can configure different methods of external storage for system and serial logs from the **External Storage** page.

Configure external storage on a network server

You can configure the external storage on a network server.

1. Log into the WebUI as a user with Admin access.
2. From the main menu, click **System**.
3. Click **External Storage**.
4. Expand the **NFS Filesystem** section. Information about the NFS share displays.
   - **Mount Path**: /opt/exfmfs

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Specify the server name and server path.
   a. In the **Server Name** field, enter the hostname or IP address of the network server.
   b. In the **Server Path** field, enter the NFS share that can be used for storage.
   c. Click **Apply**.
6. Enable the automount feature. When enabled, the NFS share is automatically mounted when the Connect EZ 4 WS is powered on or if it is rebooted.
   a. Click **Enable**.
   b. Click **Apply**. Additional fields display.
7. Review the space available, the amount of space currently used and the corresponding percentage displays in the **Used Size** field.
   (Optional) You can choose to generate a system log event when a specified percentage of the share is used.
   a. In the **Monitor** field, enter the threshold percentage. When this threshold is met, an **External Storage** system log event is generated. For information about system log event categories, see Configure options for the event and system logs.
   b. If a system log event is generated, you can choose email a notification or send it to an SNMP trap. See Configure an email notification for a system event and Configure an SNMP trap for a system event.
   c. Click **Apply**.

Configure log location

You can configure the location to which system and serial logs are stored.

1. Log into the WebUI as a user with Admin access.
2. From the main menu, click **System**.
3. Click **External Storage**.
4. Expand the **Logging Location** section.
5. From the **Store Logs to** list box, select an option.
   - **RAM**. The system and serial logs are stored in volatile memory. Log contents are not retained across a reboot.
   - **SD Card**. The system and serial logs are stored on the SD card. When this option is selected, the **Log Path** field displays. The log path defaults to the mount path for the SD card, but can be changed.
   - **NFS**. The system and serial logs are stored on a network server. When this option is selected, the **Log Path** field displays. The log path defaults to the mount path for the network server, but can be changed.
6. Click **Apply**.

Reboot your Connect EZ 4 WS device

You can reboot the Connect EZ 4 WS device immediately or schedule a reboot for a specific time every day.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note You may want to save your configuration settings to a file before rebooting. See Save configuration to a file.

Reboot your device immediately

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. From the main menu, click **System**.
3. Click **Reboot**.



4. Click **Reboot** to confirm that you want to reboot the device.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the prompt, type:

```
> reboot
```

Schedule reboots of your device

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration.

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Select **System** > **Scheduled tasks**.
4. For **Reboot time**, enter the time of the day that the device should reboot, using the format *HH:MM*. The device will reboot at this time every day.

   If **Reboot time** is set, but the device is unable to synchronize its time with an NTP server, the device will reboot after it has been up for 24 hours. See System time synchronization for information about configuring NTP servers. If **Reboot window** is set, the reboot will occur during a random time within the reboot window.
5. For **Reboot window**, enter the maximum random delay that will be added to **Reboot Time**.

   Allowed values are any number of hours, minutes, or seconds, and take the format *number* [*h*|*m*|*s*].

   For example, to set **parameter name** to ten minutes, enter **10m** or **600s**.
   The default is **10m**, and the maximum allowed time is **24h**.
6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode.

```
> config
(config)>
```

3. Set the reboot time:

```
(config)> system schedule reboot_time time
(config)>
```

where *time* is the time of the day that the device should reboot, using the format *HH:MM*. For example, this will the device to reboot at two in the morning every day.

```
(config)> system schedule reboot_time 02:00
(config)>
```

If **reboot time** is set, but the device is unable to synchronize its time with an NTP server, the device will reboot after it has been up for 24 hours. See System time synchronization for information about configuring NTP servers. If **reboot window** is set, the reboot will occur during a random time within the reboot window.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library

TS-TL-DGI-010

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 741 / 927

4. Set the maximum random delay that will be added to **reboot time**.

```
(config)> system schedule reboot_window value
(config)>
```

where *value* is any number of hours, minutes, or seconds, and takes the format *number [h|m|s]*.
For example, to set **reboot window** to ten minutes, enter either *10m* or *600s*.

```
(config)> system schedule reboot_window 600s
(config)>
```

5. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Device reset

A device reset is the process of restoring a device to a designated state. The state to which the device is restored depends on the **mode** triggered, which include *Config Reset*, *Keep Known Working APN*, and *Factory Reset*. There are several methods by which you can trigger each mode, including RESET button, Web UI, and/or CLI.

See the Compare device reset modes for a description of the modes, the actions that will occur when one is triggered, and the methods available to trigger a specific mode.


Things to know

- If installing DAL OS feature firmware version 25.5, the default behavior for the RESET button does not change. If you want to configure the device reset behavior to use a certain mode every time a reset is triggered, see Configure device reset behavior.
- Performing any of the reset modes resets the unique admin password you may have set back to the factory-assigned default password. This password can be found on the product label on the bottom of the device or on the extra product label sticker that came with your device. Log in to the device after the reset is complete to change the factory-assigned default password to your unique password, if needed.
- Performing a **Factory Reset** on a device, if the device is running DAL OS firmware version 22.2.9.x or newer, deletes all client-side certificates, including certificate(s) used for Digi Remote Manager communication. If you are re-using the device, you will need to Reset the device's client-side certificate.

Compare device reset modes

Use this table to compare the device reset modes available to you, as well as the methods you can use to trigger each one and the actions that will occur.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



Use to restore	Behavior for Digi Connect EZ and older	Behavior for Digi Connect EZ 4 and newer	Scenarios	Actions: Delete all custom configuration settings	Actions: Delete user files	Actions: Delete user private and public encryption keys	Actions: Delete user private keys	Actions: Delete certificates	Actions: Delete user-configured and known-working AT files	Actions: Reset to cellular module manufacturer's default configuration settings
Config Reset	Default behavior • By default, this button operates in the same way as the Factory Default button.	This is the default behavior, unless the device has been configured to behave in which case that becomes the default behavior. Note If you change the	• Restores module manufacturer's default configuration settings. Deletes user files, event/system logs, and user-configured/non-working AT file. • Generated keys and certificates remain.	Yes[1]	Yes	Yes	No	No	Yes	No


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

System administration Device reset




원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

System administration Device reset



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

System administration Device reset



Digi Connect EZ 4 WS User Guide 748

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


System administration Device reset



Digi Connect EZ 4 WS User Guide 747

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


System administration Device reset



Digi Connect EZ 4 WS User Guide 748

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

System administration Device reset



1

Triggering any of the reset modes reverts the unique password you may have set back to the factory-assigned default password. The default admin password can be found on the product label on the bottom of the device or on the extra product label sticker that came with your device. Log in to the device after the reset is complete to change the factory-assigned default password to your unique password.

2

Examples of user files that would be deleted include *.pfconf application scripts, custom script files, LXC containers, and user-created folders and data.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3
The DAL OS pre-configured default APNs remain. To see a list of these APNs, access the file system of your device and find the `serviceproviders-local.txt` and `serviceproviders.txt` files.

4
This action only occurs if the device reset behavior is set to **Factory Reset**.

5
If you plan to trigger either the **Config Reset** mode or **Keep Known Working APNs** mode, but you want the device to reboot and use custom default settings, see Configure your device to use custom default settings after a device reset before starting the device reset.

6
This mode is available in DAL OS feature firmware version 25.6 or newer firmware.

7
If the device is running DAL OS firmware version 22.2.9.x or newer, performing a **Factory Reset** will delete all client-side certificates, including certificate(s) used for Digi Remote Manager communication. If you are re-using the device, you will need to Reset the device's client-side certificate in Digi Remote Manager.

Configure device reset behavior

This procedure is applicable for DAL OS feature release 25.6 and newer.

Before you begin

- Review the Device reset topic to familiarize yourself with this concept.
- Configuring this setting overrides the default WAN button behavior.
- This configuration defines what mode a device reset will trigger. **If you change the default behavior, then this mode will be triggered regardless of the method used (WAN button, Web UI, or CLI).** For example, if you change the device reset behavior to use the **Factory Reset** mode, then any method you use to reset a device will trigger that mode.
- To make sure the mode you choose will result in the actions you expect, see the Device reset modes comparison table to compare the modes available to you, as well as the actions that will occur when that mode is triggered.

Web UI steps

To configure the device reset behavior:

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Local Web UI

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Settings** > **System**.
4. Click to expand the **Reset Behavior** configuration.
5. In the **Press Action** setting, select the mode you want triggered when a device reset occurs.
6. Click **Save**.

From now on, a device reset will trigger the mode you chose.

CLI steps

To configure the device reset behavior:

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, type or copy the following command and add the desired parameter:

```
config system press_button <value>
```

with <value> being the **config_reset**, **factory_reset**, or **keep_known_apps** parameter.

4. On the keyboard, press **Return**.

From now on, a device reset will trigger the mode you chose.

5. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure your device to use custom default settings after a device reset

You can configure your device to use the custom default settings specified in a `.bin` file after triggering a **Config Reset** or a **Keep Known-Working API** device reset.

Tip: Actions will not use the custom default settings specified in a bin file if you trigger a **Factory Reset**. This does not work because the `.bin` file is deleted as part of that process.

Required configuration items

- Custom factory-default configuration (`.bin`) file, if not already available

Web


1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. Configure your Connect EZ 4 WS device to match the desired custom factory default settings. For example, you may want to configure the device to use a custom APN or a particular network configuration, so that when you reset the device to factory defaults, it will automatically have your required network configuration.
3. On the main menu, click **System**. Under **Configuration**, click **Configuration Maintenance**.



The **Configuration Maintenance** window is displayed.



4. In the **Configuration backup** section, click **SAVE**.



Do not set a **Passphrase** for the configuration backup. The file will be downloaded using your browser's standard download process.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. After the configuration backup file has been downloaded, rename the file to **custom-default-config.bin**.
6. Upload the file to the device:
   a. From the main menu, select **System > Filesystem**.
   b. Under **Default device configuration**, click ⬆.



   c. Select the file from your local file system.
7. Reboot your device.

   The device will reboot using the custom factory default settings specified in the bin file.

Note After configuring a device to use custom factory default settings, wait five minutes after rebooting to defaults before powering off the device or triggering a device reset.

If you do not wait five minutes after rebooting the device to use the custom factory default.bin file, the reset process will delete the file and the device will use the standard factory default settings.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. The table below lists the available commands.

[illegible]	[illegible]
`system custom-default-config file [file name]`	Set the file you specify as the custom factory default configuration file (custom-default-config.bin). The SHA file is also created. Where **filename** is the name of the file created using the **system backup** command.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

`system custom-default-config current`	Save the current configuration as a `custom-default-config.bin` file. The SHA file is also created.
`system custom-default-config remove`	Remove the `custom-default-config.bin` and SHA files.

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Note After configuring a device to use custom factory default settings, wait five minutes after rebooting to defaults before powering off the device or triggering a device reset.
If you do not wait five minutes after rebooting the device to use the custom factory defaults in the `bin` file, the reset process will delete the file and the device will use the standard factory default settings.

Trigger a Config Reset using the RESET button

Note This procedure tells you how to trigger the **Config Reset** mode using the RESET button by pressing it once, which is the default behavior for this button. You can change the reset behavior, which then becomes the default behavior. The mode chosen will determine what type of reset occurs (**Config Reset**, **Keep Known-Working APNs** or **Factory Reset**) so if you need to trigger a **Config Reset**, make sure to check if the reset behavior has been configured first and what mode it is set to use.

1. Locate the RESET button on the device.
2. Using a pinhole tool, ..
   The device reboots automatically.
   - All custom settings, user files, event/system logs and user-configured known-working APNs are deleted.
   - Generated keys and certificates remain.

   The device will connect to the network and to Digi Remote Manager via the Ethernet connection using a pre-configured default APN.
3. (Optional) Reset the unique **admin** password, if needed.

   Tip Triggering a **Config reset** resets the unique **admin** password you may have configured back to the factory-assigned default **admin** password. If you are trying to log in to the device locally after the **Config reset** is complete, you will have to use the factory-assigned default **admin** password, which is located on the product label sticker on the bottom of the device or the extra product label sticker. To configure a unique **admin** password, see to Change the factory-assigned administrator password for a device to a unique password.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Trigger a Config Reset in the device Web UI

Note The reset behavior, if configured, will determine what type of reset occurs (**Config Reset**, **Keep Known-Working APIs**, or **Factory Reset**) so if you need to trigger a **Config Reset**, make sure to check if the reset behavior has been configured first and what mode it is set to use. You may need to change the mode before continuing.

1. In the main menu, click **System**.
2. Click **Configuration Maintenance**.
3. On the **Configuration Maintenance** page that displays, in the **Erase configuration** section, click **Erase**.

   The device reboots automatically.
   - All custom settings, user files, event/system logs, and user-configured known-working APIs are deleted.
   - Generated keys and certificates remain.

   The device will connect to the network and to Digi Remote Manager via its Ethernet connection using a pre-configured default API.
4. (Optional) Reset the unique **admin** password, if needed.

Tip Triggering a **Config reset** resets the unique **admin** password you may have configured back to the factory-assigned default **admin** password. If you are trying to log in to the device locally after the **Config reset** is complete, you will have to use the factory-assigned default **admin** password, which is located on the product label sticker on the bottom of the device or the extra product label sticker. To configure a unique **admin** password, see to Change the factory-assigned administrator password for a device for a unique password.



Trigger a Config Reset using the CLI

You can trigger a **Config Reset** using two different commands: `system factory-erase` or `revert`.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- `system factory-erase`: Revert all of the configuration settings.

  Note The reset behavior, if configured, will determine what type of erase occurs (**Config Reset**, **Keep Known-Working APIs**, or **Factory Reset**).

- `revert`: Revert certain sections of the configuration settings depending on where in the configuration hierarchy the command is executed and whether the optional `path` parameter is used.

Revert all configuration changes to the default settings using the system factory-erase command

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the CLI prompt, type `system factory-erase`.

   A confirmation message appears.
3. Type **yes** to confirm that you want all configuration settings reverted to the default configuration settings.
4. On the keyboard, press **Enter**.

   The device automatically reboots to perform the **Config Reset**.

   Note The reset behavior, if configured, will determine what type of erase occurs (**Config Reset**, **Keep Known-Working APIs**, or **Factory Reset**).

Revert all configuration changes to the default settings using the revert command

CAUTION! The `revert` command returns all changes to the default configuration, not just unsaved changes.

Tip After executing this command, you must save the configuration changes by using the `save` command. You can also discard the configuration changes by using the `cancel` command.

To discard all configuration changes and revert to default settings, use the `revert` command at the config prompt without the optional `path` parameter.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

   ```
   > config
   (config)>
   ```

3. At the config prompt, enter `revert`:

   ```
   (config)> revert
   (config)>
   ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Set the password for the admin user prior to saving the changes.

```
(config)> auth user admin password pwd
(config)>
```

5. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Revert a subset of configuration changes to the default setting using the revert command

CAUTION! The `revert` command returns all changes to the default configuration, not just unsaved changes.

Tip After executing this command, you must save the configuration changes by using the **save** command. You can also discard the configuration changes by using the **cancel** command.

There are two methods to revert a subset of configuration changes to the default settings.

- Enter the **revert** command with the **path** parameter. For example, to revert all changes to the authentication methods configuration:
  1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

     Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
  2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

  3. Enter the **revert** command with the **path** set to `auth method`:

```
(config)> revert auth method
(config)>
```

  4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

  5. Type **exit** to exit the Admin CLI.

     Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Move to the location in the configuration and enter the **revert** command without the **path** parameter. For example:
  1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

     Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
  2. At the command line, type **config** to enter configuration mode:

     ```
     > config
     (config)>
     ```
  3. Change to the auth method node:

     ```
     (config)> auth method
     (config auth method)>
     ```
  4. Enter the **revert** command:

     ```
     (config auth method)> revert
     (config auth method)>
     ```
  5. Save the configuration and apply the change:

     ```
     (config auth method)> save
     Configuration saved.
     >
     ```
  6. Type **exit** to exit the Admin CLI.

     Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.
- You can also use a combination of both the previous two methods:
  1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

     Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
  2. At the command line, type **config** to enter configuration mode:

     ```
     > config
     (config)>
     ```
  3. Change to the **auth** node:

     ```
     (config)> auth
     (config auth)>
     ```
  4. Enter the **revert** command with the **path** set to **method**:

     ```
     (config auth)> revert method
     (config auth)>
     ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. Save the configuration and apply the change.

```
(config auth)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Trigger a Factory Reset using the RESET button

Note This procedure tells you how to trigger the **Factory Reset** mode using the RESET button by pressing it twice, which is the default behavior for this button. The reset behavior, if configured, will determine what type of erase occurs (**Config Reset**, **Keep Known-Working APNs** or **Factory Reset**) so if you need to trigger a **Factory Reset**, make sure to check if the reset behavior has been configured first, and what mode it is set to use. You may need to change the mode before continuing.

1. Locate the RESET button on the device.
2. Trigger a **Config Reset**. Using a pinhole tool,

   The device reboots automatically.

   - All custom settings, user files, event/system logs, and user-configured known-working APNs are deleted. Generated keys and certificates remain.
   - The device connects to the network and to Digi Remote Manager via its Ethernet connection using a pre-configured default APN.
3. Trigger a **Factory Reset**. Within 5 minutes of the first button press, using a pinhole tool,

   The device reboots automatically for a second time.

   - All custom settings, user files, event/system logs, generated keys, certificates, and user-configured known-working APNs are deleted.
   - The device connects to the network and to Digi Remote Manager again via its Ethernet connection using a pre-configured default APN.

   The **Factory Reset** is complete. The device is ready to be decommissioned or can be reused as needed.

   If re-using the device, refer to the Connect EZ 4 WS Quick start guide which will walk you through the essentials steps you need to deploy it again.

Tip Triggering a **Factory Reset** resets the unique **admin** password you may have configured back to the factory-assigned default **admin** password. If you are trying to log in to the device locally after the **Factory reset** is complete, you will have to use the factory-assigned default **admin** password, which is located on the product label sticker on the bottom of the device or the extra product label sticker. To configure a unique **admin** password, see to Change the factory-assigned administrative password for a device to a unique password.

Tip If re-using the device, it will still be registered in Digi Remote Manager but it's certificate would now be invalid. You will need to manually reset the certification in Digi Remote Manager. See Reset the device's client-side certificate in the *Digi Remote Manager* user guide. You can now configure the device according to your network requirements.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Locate the device by using the Find Me feature

Use the **Find Me** feature to cause LEDs on the device to blink, which can help you to identify the specific device. For the Connect EZ 4 WS, the User LED blinks.

To use this feature:

Web

1. Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.
2. On the menu, click **System**. Under **Administration**, click **Find Me**.

   A notification message appears, noting that the LED is flashing on the device. Click the **x** in the message to close it.



3. On the menu, click **System** again. A blue circle next to **Find Me** is blinking, indicating that the **Find Me** feature is active.
4. To deactivate the **Find Me** feature, click **System** and click **Find Me** again.

   A notification message appears, noting that the LED is no longer flashing on the device. Click the **x** in the message to close it.



Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. To activate the **Find Me** feature, at the prompt, type the following at the command prompt:

```
> system find-me on
>
```

3. To deactivate the **Find Me** feature, type the following at the command prompt:

```
> system find-me off
>
```

4. To determine the status of the **Find Me** feature, type the following at the command prompt:

```
> system find-me status
off
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Enable RPS mode

You can enable your device to be Federal Information Processing Standard (FIPS) 140-2 compliant. With FIPS 140-2 compliance, only FIPS 140-2 cipher and MAC algorithms are available. As a result, features like aircel, ssh, and openvpn are limited in what they can use. For example, in FIPS mode ssh will only offer and negotiate AES based ciphers.

When the FIPS setting is changed, the device will reboot automatically. Disabling FIPS after it has been enabled will cause the current configuration to be erased.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Expand **System**.



4. Click to enable **FIPS**.
5. Click **Apply** to save the configuration and apply the change. The the device will reboot automatically.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Enable FIPS:

```
(config)> system fips true
$
```

3. Save the change. The the device will reboot automatically.

```
(config)> save
$
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configuration files

The Connect EZ 4 WS configuration file, /etc/config/acms.json, contains all configuration changes that have been made to the device. It does not contain the complete device configuration, it only contains changes to the default configuration. Both the default configuration and the changes contained in the acms.json file are applied when the device reboots.

Save configuration changes

When you make changes to the Connect EZ 4 WS configuration, the changes are not automatically saved. You must explicitly save configuration changes, which also applies the changes. If you do not save configuration changes, the system discards the changes.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Make any necessary configuration changes.
4. Click **Apply** to save the configuration and apply the changes.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the command line, type **config** to enter configuration mode.

```
> config
[config]>
```

3. Make any necessary configuration changes.
4. Save the configuration and apply the changes.

```
[config]> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Save configuration to a file

You can save your Connect EZ 4 WS device's configuration to a file and use this file to restore the configuration, either to the same device or to similar devices.

Web


This procedure creates a binary archive file containing the device's configuration, certificates and keys, and other information.

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **System**. Under **Configuration**, click **Configuration Maintenance**.



The **Configuration Maintenance** window is displayed.



2. In the **Configuration backup** section:
   a. (Optional) To encrypt the configuration using a passphrase, for **Passphrase (save/restore)**, enter the passphrase.
   b. Click **SAVE**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

The file will be downloaded using your browser's standard download process.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Enter the following:

```
> system backup path [passphrase passphrase] type type
```

   where:

   - **path** is the location on the Connect EZ 4 WS's filesystem where the configuration backup file should be saved.
   - **passphrase** (optional) is a passphrase used to encrypt the configuration backup.
   - **type** is the type of backup, either:
     - **archive**: Creates a binary archive file containing the device's configuration, certificates and keys, and other information.
     - **cli-config**: Creates a text file containing only the configuration changes.

   For example:

```
> system backup /etc/config/scripts/ type archive
```

3. (Optional) Use **scp** to copy the file from your device to another host.

```
> scp host hostname-or-ip user username remote remote-path local local-
path to remote
```

   where:

   - **hostname-or-ip** is the hostname or IP address of the remote host.
   - **username** is the name of the user on the remote host.
   - **remote-path** is the location on the remote host where the file will be copied.
   - **local-path** is the path and filename on the Connect EZ 4 WS device.

   For example:

```
> scp host 192.168.4.1 user admin remote /home/admin/bin/ local
/etc/config/backup-archive-0040FF600120-19.01.17-19.01.17.bin to remote
```

Restore the device configuration

You can restore a configuration file to your Connect EZ 4 WS device by using a backup from the device, or a backup from a similar device.

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **System**. Under **Configuration**, click **Configuration Maintenance**.



The **Configuration Maintenance** window is displayed.



2. In the **Configuration Restore** section:
   a. If a passphrase was used to create the configuration backup, for **Passphrase (save/restore)**, enter the passphrase.
   b. Under **Configuration Restore**, click **Choose File**.
   c. Browse to the system firmware file location on your local computer and select the file.
   d. Click **RESTORE**.
3. Click **CONFIRM**.

The configuration will be restored and the device will be rebooted.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. If the configuration backup is on a remote host, use **scp** to copy the file from the host to your device.

```
> scp host hostname-or-ip user username remote remote-path local local-path to local
```

where:

- **hostname-or-ip** is the hostname or IP address of the remote host.
- **username** is the name of the user on the remote host.
- **remote-path** is the path and filename of the file on the remote host that will be copied to the Connect EZ 4 WS device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- local-path is the location on the Connect EZ 4 WS device where the copied file will be placed.

For example:

```
> scp boot 192.168.4.1 user admin remote /home/admin/bin/backup-archive-
00407F000138-35.5-10.33.42.bin local /opt to local
```

3. Enter the following:

```
> system restore filepath [passphrase passphrase]
```

where

- filepath is the file path and filename of the configuration backup file on the Connect EZ 4 WS's filesystem (local-path in the previous step).
- passphrase (optional) is the passphrase to restore the configuration backup, if a passphrase was used when the backup was created.

For example:

```
> system restore /opt/backup-archive-00407F000138-35.5
10.33.42.bin
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Schedule system maintenance tasks

You can configure tasks to be run during a specified maintenance window. When the device is within the maintenance window, firmware updates and Digi Remote Manager configuration checks will be performed.

You can also schedule custom scripts to run during the maintenance window. See Configure scripts to run automatically for more information.

Required configuration items

- Events that trigger the maintenance window to begin.
- Whether all configured triggers, or only one of the triggers, must be met.
- The tasks to be performed. Options are:
  - Firmware updates
  - Digi Remote Manager configuration check
- Whether the device will check for updates to the device firmware.
- The frequency (daily, weekly, or monthly) that checks for firmware updates will run.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:


   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



   The **Configuration** window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click **System** > **Scheduled tasks** > **System maintenance**.



4. Click to expand **Maintenance window triggers**.
5. Click **+** to add a maintenance window trigger.



6. For **Maintenance window trigger type**, select one of the following:
   - **Check if interface is up**, for **Test Interface**, select the interface.
   - **Time period for maintenance window**.
     a. Click to expand **Maintenance window**.
     b. For **Start time**, type the time of day that the maintenance window should start, using the syntax *HH:MM*. If **Start time** is not set, maintenance tasks are not scheduled and will not be run.

        The behavior of **Start time** varies depending on the setting of **Duration window**, which is configured in the next step:
        - If **Duration window** is set to **Immediately**, all scheduled tasks will begin at the exact time specified in **Start time**.
        - If **Duration window** is set to **24 hours**, **Start time** is effectively obsolete and the maintenance tasks will be scheduled to run at any time. Setting **Duration window** to **24 hours** can potentially overstress the device and should be used with caution.
        - If **Duration window** is set to any value other than to **Immediately** or **24 hours**, the maintenance tasks will run at a random time during the time allotted for the duration window.
        - If **Duration window** is set to one or more hours, the minutes field in **Start time** is ignored and the duration window will begin at the beginning of the specified hour.

     c. For **Duration window**, select the amount of time that the maintenance tasks will be run. If **Immediately** is selected, all scheduled tasks will begin at the exact time specified in **Start time**.
     d. For **Frequency**, select whether the maintenance window will be started every day, or once per week.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- If **Check if Python Out-of-Service** is set, the maintenance window will only start if the Python Out-of-Service is set. See Use Python to set the maintenance window for further information.

f. If **Central Management** is disabled, click **Device firmware update** to instruct the system to look for any updated device firmware during the maintenance window. If updated firmware is found, it will then be installed. This option is only available if **Central Management** is disabled; see Central management for more information.

g. (Optional) Configure automated checking for device firmware updates:

i. Click to expand **Firmware update check**.

ii. **Device firmware update check** is enabled by default. This enables the automated checking for device firmware updates.

iii. For **Frequency**, select how often automated checking for device firmware should take place. Allowed values are **Daily**, **Weekly**, and **Monthly**. The default is **Daily**.

h. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Configure a system maintenance trigger:

   a. Add a trigger:

```
(config)> add system schedule maintenance trigger end
(config)>
```

   b. Set the type of trigger:

```
(config add system schedule maintenance trigger)> type value
(config)>
```

   where *value* is one of:

   - **interface up**: If **interface up** is set:

     i. Set the interface:

```
(config add system schedule maintenance trigger)> interface
value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

ii. i. Use the ?to determine available interfaces.

ii. Set the interface. For example:

```
(config system schedule maintenance trigger 0)# interface
/network/interface/eth0
(config system schedule maintenance trigger 0)#
```

- **out of service**: The maintenance window will only start if the Python Out-of-Service is set. See Use Python to set the maintenance window for further information.
- **time**: Configure a time period for the maintenance window:
  1. Configure the time of day that the maintenance window should start, using the syntax *HH:MM*. If the start time is not set, maintenance tasks are not scheduled and will not be run.

     ```
     (config system schedule maintenance trigger 0)# time from
     HH:MM
     (config system schedule maintenance trigger 0)#
     ```

     The behavior of the start time varies depending on the setting of the duration length, which is configured in the next step:
     - If the duration length is set to **0**, all scheduled tasks will begin at the exact time specified in the start time.
     - If the duration length is set to **24 hours**, the start time is effectively obsolete and the maintenance tasks will be scheduled to run at any time. Setting the duration length to **24 hours** can potentially overstress the device and should be used with caution.
     - If the duration length is set to any value other than to **0** or **24 hours**, the maintenance tasks will run at a random time during the time allotted for the duration window.
     - If the duration length is set to one or more hours, the minutes field in the start time is ignored and the duration window will begin at the beginning of the specified hour.
  2. Configure the duration length (the amount of time that the maintenance tasks will be run). If **0** is used, all scheduled tasks will begin at the start time, defined in the previous step.

     ```
     (config system schedule maintenance trigger 0)# length num
     (config system schedule maintenance trigger 0)#
     ```

     where *num* is any whole number between **0** and **24**.
  3. Configure the frequency that the maintenance tasks should be run:

     ```
     (config system schedule maintenance trigger 0)# frequency
     value
     (config system schedule maintenance trigger 0)#
     ```

     where *value* is either **daily** or **weekly**. **Daily** is the default.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

4. If **Central Management** is disabled, configure the device to look for any updated device firmware during the maintenance window. If updated firmware is found, it will then be installed. The device will look for updated firmware both on the local device and over the network.

   This option is only available if **Central Management** is disabled; see [illegible] for more information.

   ```
   (config)> system schedule maintenance device_fw_update true
   (config)>
   ```

5. (Optional) Configure automated checking for device firmware updates:

   a. **Device firmware update check** is enabled by default. This enables to automated checking for device firmware updates. To disable:

      ```
      (config)> system schedule maintenance firmware_update_check device
      false
      (config)>
      ```

   b. Set how often automated checking for device firmware should take place:

      ```
      (config)> system schedule maintenance frequency value
      (config)>
      ```

      where **value** is either **daily**, **weekly**, or **monthly**. **daily** is the default.

6. Save the configuration and apply the changes.

   ```
   (config)> save
   Configuration saved.
   >
   ```

7. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

8. (Optional) Configure automated checking for device firmware updates:

   a. **Device firmware update check** is enabled by default. This enables to automated checking for device firmware updates. To disable:

      ```
      (config)> system schedule maintenance firmware_update_check device
      false
      (config)>
      ```

   b. Set how often automated checking for device firmware should take place:

      ```
      (config)> system schedule maintenance frequency value
      (config)>
      ```

      where **value** is either **daily**, **weekly**, or **monthly**. **daily** is the default.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025

㈜테솔 · www.tessol.com TS-TL-DGI-010 772 / 927

TS-TL-DGI-010

8. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

9. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Disable device encryption

You can disable the cryptography on your Connect EZ 4 WS device. This can be used to ship unused devices from overseas without needing export licenses from the country from which the device is being shipped.

When device encryption is disabled, the following occurs.

- The device is reset to the default configuration and rebooted.
- After the reboot:
  - Access to the device via the WebUI and SSH are disabled.
  - All Internet connectivity is disabled. Connectivity to central management software is also disabled.
  - All IP routes and addresses are disabled except for the default 192.168.210.1/24 network on the local LAN Ethernet port. DHCP server is also disabled.

    The device can only be accessed by using telnet from a local machine connecting to the 192.168.210.1/24 network.

Disabling device encryption is not available in the WebUI. It can only be performed from the Admin CLI.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Disable encryption with the following command:

```
> system disable-cryptography
>
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Re-enable cryptography after it has been disabled.

To re-enable cryptography:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Configure your PC network to connect to the 192.168.210 subnet. For example, on a Windows PC:
   a. Select the **Properties** of the relevant network connection on the Windows PC.



   b. Click the **Internet Protocol Version 4 (TCP/IPv4)** parameter.
   c. Click **Properties**. The **Internet Protocol Version 4 (TCP/IPv4) Properties** dialog appears.
   d. Configure with the following details:
      - **IP address** for PC: 192.168.210.2
      - **Subnet**: 255.255.255.0

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Gateway: 192.168.210.1



2. Connect the PC's Ethernet port to the ETH1 Ethernet port on your Connect EZ 4 WS device.
3. Open a telnet session and connect to the Connect EZ 4 WS device at the IP address of 192.168.210.1.
4. Log into the device:
   - Username: **admin**
   - Password: The default unique password for your device is printed on the device label.
5. At the shell prompt, type:

```
# rm /etc/config/.nocrypt
# flatfsd -i
```

This will re-enable encryption and leave the device at its factory default setting.

Configure the speed of your Ethernet ports

You can configure the speed of your Connect EZ 4 WS device's Ethernet ports.

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Network** > **Device**.
4. Click to expand the Ethernet port to be configured.
5. For **Speed**, select the appropriate speed for the Ethernet port, or select **Auto** to automatically detect the speed. The default is **Auto**.
6. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

   ```
   > config
   (config)>
   ```

3. At the config prompt, type:

   ```
   (config)> network device eth_port value
   ```

   where:

   - **eth_port** is the name of the Ethernet port (for example, **eth1**).
   - **value** is one of:
     - **10**—Sets the speed to 10 Mbps.
     - **100**—Sets the speed to 100 Mbps.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- 1000—Sets the speed to 1 Gbps. Available only for devices with Gigabit Ethernet ports.

  auto—Configures the device to automatically determine the best speed for the Ethernet port.

The default is **auto**.

4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Watchdog service

The Watchdog service can monitor the operation of your device, test the system for problems, and automatically restart that device if it detects a fault or failure. You can also see metrics for the Watchdog service and performance results of the tests performed.

When the Watchdog service has been enabled, the service name and green check mark displays in the dashboard.

Configure the Watchdog service

To configure the Watchdog service on your Connect EZ 4 WS:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



   The **Configuration** window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click **System** > **Advanced Watchdog**.
4. The watchdog is disabled by default. To enable, click to toggle off **Disable**.
5. For **Watchdog test interval**, type the amount of time between running system tests.
   Allowed values are any number of days, hours, minutes, or seconds, and take the format **number(d|h|m|s)**.
   For example, to set **Watchdog test interval** to ten minutes, enter **10m** or **600s**.
   The maximum is two days (**2d**), and the default is five minutes (**5m**).
6. Type or select the **Number of test failures before a reboot**.
7. Configure the tests that the watchdog will perform:
   a. Click to expand **Fault detection tests**.
   b. Click to expand **Memory usage**.
      i. The memory check is enabled by default. To disable, click the **Enable memory check** toggle.
      ii. For **RAM usage threshold to trigger a warning**, type or select the percentage of RAM usage that will trigger a warning. The minimum value is **50** percent, the maximum is **100** percent. The default is **90** percent.
      iii. Type or select the **Percentage of system memory used before triggering a reboot**. The minimum value is **50** percent, the maximum is **100** percent. The default is **95** percent.
      iv. To log memory usage with every watchdog memory usage test, click to enable **Log memory usage every interval**.
   c. Click to expand **Interface tests**.
      i. Click the **Enable interface(s) down check** toggle to enable. The system periodically checks the interfaces you configure here and, after the specified amount of time, reboots them.
      ii. Click to expand **Check interface(s)**.
      iii. Click **+** to add a new interface.
      iv. For **Interface**, choose the interface you want to test.
8. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. The watchdog is enabled by default. To disable:

```
(config)> system watchdog enable false
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

4. Set the amount of time between running system tests:

```
(config)> system watchdog interval value
(config)>
```

where *value* is any number of days, hours, minutes, or seconds, and takes the format *number* *d|h|m|s*.

For example, to set **interval** to ten minutes, enter either **10m** or **600s**:

```
(config)> system watchdog interval 600s
(config)>
```

The maximum is two days (**2d**), and the default is five minutes (**5m**).

5. Set the number of test failures before the system reboots:

```
(config)> system watchdog max_failures int
(config)>
```

6. Configure the tests that the watchdog will perform:

   a. The memory check is enabled by default. To disable:

   ```
   (config)> system watchdog tests memory enable false
   (config)>
   ```

   b. Set the percentage of RAM usage that will trigger a warning:

   ```
   (config)> system watchdog tests memory max_memory_warning int
   (config)>
   ```

   The minimum value is **50** percent, the maximum is **100** percent. The default is **90** percent.

   c. Set the percentage of RAM usage that will trigger a reboot of the device:

   ```
   (config)> system watchdog tests memory max_memory_critical int
   (config)>
   ```

   The minimum value is **50** percent, the maximum is **100** percent. The default is **95** percent.

   d. To log memory usage with every watchdog memory usage test, enable **log memory**:

   ```
   (config)> system watchdog tests memory log_memory true
   (config)>
   ```

   e. To have the interface(s) checked and rebooted after the specified amount of time:

   ```
   (config)> system watchdog tests interfaces interfaces add [value]
   (config)>
   ```

   with *value* being the name of the interface.

7. Save the configuration and apply the changes:

```
(config)> save
Configuration saved.
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

View Watchdog metrics

To view metrics for the Watchdog service and the tests performed:

Web

In the local Web UI of your Connect EC 4 WS:

1. Log in to the local Web UI of your device as a user with full Admin access rights.
2. To access the Watchdog Service page:

   From the Dashboard of the device:

   a. In the **Services** card, you can see the operational status of the Watchdog service.



   b. Click **Watchdog** to view metrics.



   From the menu:

   Click **Status** > **Services** > **Watchdog** to see the page.

In Digi Remote Manager, to view the test failures:

a. Click **Devices**, and select a device from the list.

b. Click **Metrics**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Click to expand **Sys Details**.

d. Click **Sys Watchdog Failures**.



A new window opens and displays a chart showing the test failures and when they occurred.

Command line

To view the results of the Watchdog tests:

1. Access the Command Line Interface for your Connect EZ, from either the local web UI as an administrator with full access rights or from Digi Remote Manager.
2. At the prompt, type:

```
show watchdog
```

   All tests that were performed, as well as their status are listed.
3. Type **exit** to exit the CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Monitoring

This chapter contains the following topics:

Configure the monitoring of a device's internet connection 783
intelliflow 785
Configure NetFlow / IPFIX 787

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure the monitoring of a device's internet connection

Monitor the bandwidth and performance of the overall internet connection of a device over time. Ping tests and speed tests will be performed at configurable intervals. The data is reported to Digi Remote Manager. You can view the metrics on the device dashboard. This setting is **not enabled by default**.

Note You do not have the option to select an interface. This monitoring reports metrics on the connection that is active at the time.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Monitoring** > **Performance Quality**.
4. To **Enable** performance quality monitoring, click the toggle.
5. (Optional) To enable speed tests, click the **Use speedtest** toggle.

   Speed tests are run once per hour if enabled and are independent of the ping test interval.
6. To configure ping tests:
   a. For **Test Interval**, select how often the ping test should occur.
   b. For **Ping Host**, type the IP address of the host to use. (The default is blank).
   c. For **Ping Count**, type the number of pings to send for statistics collection. (default is 10).
   d. For **Ping Preload Count**, type the number of pings to send for the pre-load (default is 3). This wakes up the network so it is ready to perform the testing.
7. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. To **enable** performance quality monitoring:

```
(config monitoring perf_quality) enable true
```

4. (Optional) To enable speed tests:

```
(config monitoring perf-quality) speedtest true
```

   Speed tests are run once per hour if enabled and are independent of the ping test interval.
5. To configure ping tests:
   a. To set how often the ping test should occur:

```
(config monitoring perf-quality) interval [value]
```

      with **value** being 10min, 20min, 5min.
   b. Add the number of pings for statistics collection:

```
(config monitoring perf_quality) ping_count [value].
```

      with **value** being the number of pings. The default value is **10**.
   c. Add the ping host:

```
(config monitoring perf_quality) ping_host [value]
```

      with **value** being the IP address of the resolver you'd like to use. The default is blank.
   d. For **Ping Preload Count**, type the number of pings to send for the pre-load (default is 3). This wakes up the network so it is ready to perform the testing.

```
(config monitoring perf_quality) ping_preload_count [value].
```

      with **value** being the number of pings to send for the preload to wake up the network so it is ready to perform the testing. The default is **3**.
6. Save the configuration and apply the changes.

```
(config network wireless client new_client)> save
Configuration saved.
>
```

7. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

intelliFlow

Digi intelliFlow is a reporting and graphical presentation tool for visualizing your network's data usage and network traffic information.

intelliFlow can be enabled on Digi Remote Manager to provide a full analysis of all Digi devices on your network. Contact your Digi sales representative for information about enabling intelliFlow on Remote Manager.



intelliFlow is also available on the local device for device-specific visualization of network use. To use intelliFlow on the local device, you must have access to the local WebUI. Once you enable intelliFlow, the **Status > intelliFlow** option is available in the main menu. By default, intelliFlow is disabled on the local device.

On the local device, intelliFlow provides charts on the following information:

- System utilization
- Top data usage by host
- Top data usage by server
- Top data usage by service
- Host data usage over time

intelliFlow charts are dynamic; at any point, you can click inside the chart to drill down to view more granular information, and menu options allow you to change various aspects of the information being displayed.

This section contains the following topics:

Enable intelliFlow 786
Configure service types 787
Configure domain name groups 788
Use intelliFlow to display average CPU and RAM usage 789
Use intelliFlow to display top data usage information 794
Use intelliFlow to display data usage by host over time 798

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Enable IntelliFlow

Required configuration items

- Enable IntelliFlow.

Additional configuration items

- The firewall zone for internal clients being monitored by IntelliFlow.

To enable IntelliFlow:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.


   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Monitoring** > **IntelliFlow**.

   The IntelliFlow configuration window is displayed.

   
4. Click **Enable IntelliFlow**.
5. For **Zone**, select the firewall zone. Internal clients that are being monitored by IntelliFlow should be present on the specified zone.
6. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable IntelliFlow:

```
(config)> monitoring intelliflow enable true
```

4. Set the firewall zone. Internal clients that are being monitored by IntelliFlow should be present on the specified zone.
   a. Determine available zones:

```
(config)> monitoring intelliflow zone ?

Zone: The firewall zone which is assigned to the network interface(s)
that
intelliflow will see as internal clients.  intelliflow relies on an
internal to
external relationship, where the internal clients are present on the
zone specified.
Format:
  any
  dynamic_routes
  edge
  external
  internal
  ipsec
  loopback
  setup
Default value: internal
Current value: internal

(config)>
```

   b. Set the zone to be used by IntelliFlow:

```
(config)> monitoring intelliflow zone my_zone
```

5. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

6. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure service types

The service type is used to categorize several ports under one service. For example, port numbers 80, 443, and 8080 are included in the **Web** service type.

There are several predefined service types:

- Web: Ports 80, 443, and 8080.
- FTP: Ports 20, 21, 989, and 990.
- SSH: Port 22.
- Telnet: Ports 23 and 992.
- Mail: Ports 25, 110, 143, 220, 993 and 995.
- DNS: Port 53.
- IRC: Ports 194 and 994.
- RDP/C: Ports 873.

You can add and remove ports from the predefined service port types, and you can also define your own service types. For example, to define a service type called "MyService" using ports 8000 and 8001:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Monitoring** > **intelliFlow**.
4. Click to expand **Ports**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

5. At the bottom of the list of ports, click **+** to add a port.

6. **Label** is optional.
7. For **Port number**, type **8888**.
8. For **Service name**, type **MyService**.



9. Click **+** to add another port.
10. For **Port number**, type **9001**.
11. For **Service name**, type **MyService**.
12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Add a port:

```
(config)> add monitoring intelliflow ports end
(config monitoring intelliflow ports 24)>
```

4. Set the port number:

```
(config monitoring intelliflow ports 24)> port 8888
(config monitoring intelliflow ports 24)>
```

5. Set the service type:

```
(config monitoring intelliflow ports 24)> service MyService
(config monitoring intelliflow ports 24)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

8. Add another port:

```
(config monitoring intelliflow ports 20)> add ... end
(config monitoring intelliflow ports 21)>
```

7. Set the port number:

```
(config monitoring intelliflow ports 21)> port 9881
(config monitoring intelliflow ports 21)>
```

8. Set the service type:

```
(config monitoring intelliflow ports 21)> service MyService
(config monitoring intelliflow ports 21)>
```

9. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

10. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure domain name groups

Domain name groups are used to categorize serveral domains names in one group. For example, digi.com and devicecloud.com could be grouped together in an intelliflow group called Digi.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

Remote Manager:

a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

b. Click the **Device ID**.

c. Click **Settings**.

d. Click to expand **Config**.

Local Web UI:

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The **Configuration** window is displayed.

3. Click **Monitoring** > **intelliFlow** > **Groups**.
4. Click **+** to add a domain.



5. **Label** is optional.
6. For **Domain name**, type **digi.com**.
7. For **Group**, type **Digi**.
8. Click **+** to add another part.
9. For **Domain name**, type **devicecloud.com**.
10. For **Group**, type **Digi**.
11. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Add a group:

```
[config]> add monitoring intelliflow groups end
[config monitoring intelliflow groups 1]>
```

4. Set the domain name:

```
[config monitoring intelliflow groups 1]> domain digi.com
[config monitoring intelliflow groups 1]>
```

5. Set the group name:

```
[config monitoring intelliflow groups 1]> group Digi
[config monitoring intelliflow groups 1]>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

6. Add another port:

```
(config monitoring intelliflow groups 1)> add ... end
(config monitoring intelliflow groups 2)>
```

7. Set the port number:

```
(config monitoring intelliflow groups 2)> domain devicecloud.com
(config monitoring intelliflow groups 2)>
```

8. Set the service type:

```
(config monitoring intelliflow groups 2)> group 24gt
(config monitoring intelliflow groups 2)>
```

9. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

10. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use intelliFlow to display average CPU and RAM usage

This procedure is only available from the WebUI.


To display display average CPU and RAM usage:

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. If you have not already done so, enable intelliFlow. See Enable intelliFlow.
2. From the menu, click **Status** > **intelliFlow**.


The System Utilization chart is displayed:



- Display more granular information:
  1. Click and drag over an area in the chart to zoom into that area and provide more granular information.




2. Release to display the selected portion of the chart.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click **Reset zoom** to return to the original display.



- Change the time period displayed by the chart.

  By default, the **System utilization** chart displays the average CPU and RAM usage over the last minute. You can change this to display the average CPU and RAM usage:

  - Over the last hour.
  - Over the last day.
  - Over the last 30 days.
  - Over the last 180 days.

  1. Click the menu icon (☰).
  2. Select the time period to be displayed.



- Save or print the chart.

  1. Click the menu icon (☰).
  2. To save the chart to your local filesystem, select **Export to PNG**.
  3. To print the chart, select **Print chart**.

Use intelliFlow to display top data usage information

With intelliFlow, you can display top data usage information based on the following:

- Top data usage by host.
- Top data usage by server.
- Top data usage by service.

To generate a top data usage chart:


Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. If you have not already done so, enable intelliFlow. See Enable intelliFlow.
2. From the menu, click **Status** > **intelliFlow**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.


3. Display a data usage chart:
   - To display the **Top Data Usage by Host** chart, click **Top Data Usage by Host**.




   - To display the **Top Data Usage by Server** chart, click **Top Data Usage by Server**.



   - To display the **Top Data Usage by Service** chart, click **Top Data Usage by Service**.



4. Change the type of chart that is used to display the data.
   a. Click the menu icon (☰).
   b. Select the type of chart.



5. Change the number of top users displayed.
   You can display the top five, top ten, or top twenty data users.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. Click the menu icon (☰).
b. Select the number of top users to display/sort.



8. Save or print the chart.
   a. Click the menu icon (☰).
   b. To save the chart to your local filesystem, select **Export to PNG**.
   c. To print the chart, select **Print chart**.

Use intelliFlow to display data usage by host over time

To generate a chart displaying a host's data usage over time:

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. If you have not already done so, enable intelliFlow. See Enable intelliFlow.
2. From the menu, click **Status** > **intelliFlow**.
3. Click **Host Data Usage Over Time**.



- Display more granular information:
  a. Click and drag over an area in the chart to zoom into that area and provide more granular information.




원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

b. Release to display the selected portion of the chart.



c. Click **Reset zoom** to return to the original display.



- Save or print the chart.
  a. Click the menu icon (☰).
  b. To save the chart to your local filesystem, select **Export to PNG**.
  c. To print the chart, select **Print chart**.

Configure NetFlow Probe

NetFlow probe is used to probe network traffic on the Connect EZ 4 WS device and export statistics to NetFlow collectors.

Required configuration items

- Enable NetFlow.
- The IP address of a NetFlow collector.

Additional configuration items

- The NetFlow version.
- Enable flow sampling and select the flow sampling technique.
- The number of flows from which the flow sampler can sample.
- The number of seconds that a flow is inactive before it is exported to the NetFlow collectors.
- The number of seconds that a flow is active before it is exported to the NetFlow collectors.
- The maximum number of simultaneous flows.
- A label for the NetFlow collector.
- The port of the NetFlow collector.
- Additional NetFlow collectors.

To probe network traffic and export statistics to NetFlow collectors:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **Monitoring** > **NetFlow probe**.

   
4. **Enable** NetFlow probe.
5. **Protocol version**: Select the **Protocol version**. Available options are:
   - **NetFlow v5**—Supports IPv4 only.
   - **NetFlow v9**—Supports IPv4 and IPv6.
   - **NetFlow v10 (IPFIX)**—Supports both IPv4 and IPv6 and includes IP Flow Information Export (IPFIX).

   The default is **NetFlow v10 (IPFIX)**.
6. Enable **Flow sampler** by selecting a sampling technique. Flow sampling can reduce flow processing and transmission overhead by providing a representative subset of all flows. Available options are:
   - **None**—No flow sampling method is used. Each flow is accounted.
   - **Deterministic**—Selects every nth flow, where n is the value of **Flow sampler population**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **Random**—Randomly selects one out of every *n* flows, where *n* is the value of **Flow sampler population**.
- **Hash**—Randomly selects one out of every *n* flows using the hash of the flow key, where *n* is the value of **Flow sampler population**.

7. For **Flow sampler population**, if you selected a flow sampler, enter the number of flows for the sampler. Allowed value is any number between 2 and 16383. The default is 100.
8. For **Inactive timeout**, type the the number of seconds that a flow can be inactive before sent to a collector. Allowed value is any number between 1 and 15. The default is 15.
9. For **Active timeout**, type the number of seconds that a flow can be active before sent to a collector. Allowed value is any number between 1 and 3600. The default is 1800.
10. For **Maximum flows**, type the maximum number of flows to probe simultaneously. Allowed value is any number between 8 and 2000000. The default is 2000000.
11. Add collectors:
    a. Click to expand **Collectors**.
    b. For **Add Collector**, click **+**.
    c. (Optional) Type a **Label** for the collector.
    d. For **Address**, type the IP address of the collector.
    e. (Optional) For **Port**, enter the port number used by the collector. The default is 2055.

    Repeat to add additional collectors.
12. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Enable NetFlow:

```
(config)> monitoring netflow enable true
(config)>
```

4. Set the protocol version:

```
(config)> monitoring netflow protocol version
                                          (config)>
```

   where **version** is one of:
   - **v5**—NetFlow v5 supports IPv4 only.
   - **v9**—NetFlow v9 supports IPv4 and IPv6.
   - **v10**—NetFlow v10 (IPFIX) supports both IPv4 and IPv6 and includes IP Flow Information Export (IPFIX).

The default is 4118.

1. Enable flow sampling by selecting a sampling technique. Flow sampling can reduce flow processing and transmission overhead by providing a representative subset of all flows.

```
(config)> monitoring netflow sampler type
(config)>
```

where type is one of:

- **none**—No flow sampling method is used. Each flow is accounted.
- **deterministic**—Selects every nth flow, where n is the value of the flow sample population.
- **random**—Randomly selects one out of every n flows, where n is the value of the flow sample population.
- **hash**—Randomly selects one out of every n flows using the hash of the flow key, where n is the value of the flow sample population.

5. If you are using a flow sampler, set the number of flows for the sampler.

```
(config)> monitoring netflow sampler_population value
(config)>
```

where value is any number between 2 and 16383. The default is 100.

6. Set the number of seconds that a flow can be inactive before sent to a collector.

```
(config)> monitoring netflow inactive_timeout value
(config)>
```

where value is any is any number between 1 and 15. The default is 15.

7. Set the number of seconds that a flow can be active before sent to a collector.

```
(config)> monitoring netflow active_timeout value
(config)>
```

where value is any is any number between 1 and 1800. The default is 1800.

8. Set the maximum number of flows to probe simultaneously.

```
(config)> monitoring netflow max_flows value
(config)>
```

where value is any is any number between 0 and 2000000. The default is 2000000.

9. Add collectors.
   a. Add a collector.

```
(config)> add monitoring netflow collector end
(config monitoring netflow collector 0)>
```

   b. Set the IP address of the collector.

```
(config monitoring netflow collector 0)> address ip_address
(config monitoring netflow collector 0)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. (Optional) Set the port used by the collector:

```
(config monitoring netflow collector 0)> port port
(config monitoring netflow collector 0)>
```

d. (Optional) Set a label for the collector:

```
(config monitoring netflow collector 0)> label "This is a collector."
(config monitoring netflow collector 0)>
```

Repeat to add additional collectors.

11. Save the configuration and apply the change.

```
(config monitoring netflow collector 0)> save
Configuration saved.
>
```

11. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Central management

This chapter contains the following topics:

Digi Remote Manager support 803
Certificate-based enhanced security 803
Configure your device for Digi Remote Manager support 803
Reach Digi Remote Manager on a private network 814
Log in to Digi Remote Manager 815
Use Digi Remote Manager to view and manage your device 817
Add a device to Remote Manager 817
Configure multiple Connect EZ 4 WS devices by using Digi Remote Manager configurations 819
View Digi Remote Manager connection status 820
Learn more 821

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Digi Remote Manager support

Digi Remote Manager is a hosted remote configuration and management system that allows you to remotely manage a large number of devices. Remote Manager includes a web-based interface that you can use to perform device operations, such as viewing and changing device configurations and performing firmware updates. Remote Manager servers also provide a data storage facility. The Digi Remote Manager is the default cloud-based management system, and is enabled by default.

To use Remote Manager, you must set up a Remote Manager account. To set up a Remote Manager account and learn more about Digi Remote Manager, go to http://www.digi.com/products/cloud/digi-remote-manager.

To learn more about Remote Manager features and functions, see the Digi Remote Manager User Guide.

Certificate-based enhanced security

Beginning with firmware version 22.2.0.x, the default URL for the device's Remote Manager connection is edp12.devicecloud.com. This URL is required to utilize the client-side certificate support. Prior to release 22.2.0.x, the default URL was my.devicecloud.com.

- If your Digi device is configured to use a non-default URL to connect to Remote Manager, updating the firmware will not change your configuration. However, if you erase the device's configuration, the Remote Manager URL will change to the default of edp12.devicecloud.com.
- If you perform a factory reset by pressing the **RESET** twice, the client-side certificate will be erased and you must use the Remote Manager interface to reset the certificate. Select the device in Remote Manager and select **Actions > Reset Device Certificate**.
- The certificate that is provided to the client by Remote Manager is signed by a specific certificate authority, and the device is expecting that same certificate authority. If your IT infrastructure uses its own certificate-based authentication, this might cause the device to interpret the certificate provided by Remote Manager as being from an incorrect certificate authority. If this is the case, you need to include an exception to allow edp12.devicecloud.com to authenticate using its own certificate.

The new URL of edp12.devicecloud.com is for device communication only. Use https://remotemanager.digi.com for user interaction with remote manager.

Firewall issues

To utilize the certificate-based security, you may need to open a port through your firewall for egress connectivity to edp12.devicecloud.com. TCP port 3199 is used for communication with Remote Manager.

Configure your device for Digi Remote Manager support

By default, your Connect EZ 4 WS device is configured to use for central management.

Additional configuration options

These additional configuration settings are not typically configured, but you can set them as needed:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Disable the Digi Remote Manager connection if it is not required. You can also configure an alternative cloud-based central management application.
- Change the reconnection timer.
- The non-cellular keepalive timeout.
- The keepalive count before the Remote Manager connection is dropped.
- SMS support.
- HTTP proxy server support.

To configure your device's Digi Remote Manager support:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



   The **Configuration** window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click **Central management**.
   The Central management configuration window is displayed.



   Digi Remote Manager support is enabled by default. To disable, toggle off **Enable central management**.
4. For **Service**, select **Digi Remote Manager**.
5. (Optional) For **Management server**, type the URL for the central management server.
   The default varies depending on firmware versions:
   - Firmware version 22.2.9.x and newer, the default is the adp12.devicecloud.com. This server is for device-connectivity only, and uses enhanced security through certificate-based communication. See Digi Remote Manager support for further information.
   - Firmware prior to version 22.2.9.x, the default is the Digi Remote Manager server, https://remotemanager.digi.com.
6. (Optional) For **Management port**, type the destination port for the remote cloud services connection. The default is **3199**.
7. **Firmware server** should normally be left at the default location.
8. (Optional) For **Speedtest server**, type the name or IP address of the server to use to test the speed of the device's internet connection(s).
9. (Optional) For **Retry interval**, type the amount of time that the Connect EZ 4 WS device should wait before reattempting to connect to remote cloud services after being disconnected. The default is 30 seconds.
   Allowed values are any number of hours, minutes, or seconds, and take the format *number* [*h*|*m*|*s*].
   For example, to set **Retry interval** to ten minutes, enter **10m** or **600s**.
10. (Optional) For **Keep-alive interval**, type the amount of time that the Connect EZ 4 WS device should wait between sending keep-alive messages to remote cloud services when using a non-cellular interface. The default is 60 seconds.
    Allowed values are any number of hours, minutes, or seconds, and take the format *number* [*h*|*m*|*s*].
    For example, to set **Keep-alive interval** to ten minutes, enter **10m** or **600s**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Note The **Cellular keep-alive interval** is not used by the Connect EZ 4 WS. Any entry is ignored.

11. (Optional) For **Allowed keep-alive misses**, type the number of allowed keep-alive misses. The default is **3**.
12. **Enable watchdog** is used to monitor the connection to Digi Remote Manager. If the connection is down, you can configure the device to restart the connection, or to reboot. The watchdog is enabled by default. To configure the Watchdog service and view metrics, see Watchdog service.
13. If **Enable watchdog** is enabled:
    a. (Optional) For **Restart timeout**, type the amount of time to wait before restarting the connection to the remote cloud services, once the connection is down.
    Allowed values are any number of hours, minutes, or seconds, and take the format **number[h|m|s]**.
    For example, to set **Restart timeout** to ten minutes, enter **10m** or **600s**.
    The minimum value is 30 minutes and the maximum is 48 hours. If not set, this option is disabled. The default is 30 minutes.
    b. (Optional) For **Reboot timeout**, type the amount of time to wait before rebooting the device, once the connection to the remote cloud services is down. By default, this option is not set, which means that the option is disabled.
    Allowed values are any number of hours, minutes, or seconds, and take the format **number[h|m|s]**.
    For example, to set **Reboot timeout** to ten minutes, enter **10m** or **600s**.
    The minimum value is 30 minutes and the maximum is 48 hours. If not set, this option is disabled. The default is disabled.
14. (Optional) Enable **Locally authenticate CLI** to require a login and password to authenticate the user from the remote cloud services CLI. If disabled, no login prompt will be presented and the user will be logged in as **admin**. The default is disabled.
15. (Optional) Configure the Connect EZ 4 WS device to communicate with remote cloud services by using SMS:
    a. Click to expand **Short message service**.
    b. **Enable** SMS messaging.
    c. For **Destination phone number**, type the phone number for the remote cloud services.
        - Within the US: **12025550370**
        - International: **447537431797**
    d. (Optional) Type the **Service identifier**.
16. (Optional) Configure the Connect EZ 4 WS device to communicate with remote cloud services via one of two methods: PinPoint or Proxy server.
If using the PinPoint method, refer to the following:
If using the Proxy server method:
    a. Click to expand **HTTP Proxy**.
    b. **Enable** the use of an HTTP proxy server.
    c. For **Server**, type the hostname of the HTTP proxy server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

d. For **Port**, type or select the port number on the HTTP proxy server that the device should connect to. The default is **2128**.

17. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Digi Remote Manager support is enabled by default. To disable Remote Manager support:

```
(config)> cloud enable false
(config)>
```

4. (Optional) Set the URL for the central management server.

```
(config)> cloud drm drm_url url
(config)>
```

   The default varies depending on firmware versions:

   - Firmware version 22.2.6.x and newer, the default is the edp12.devicecloud.com. This server is for device-connectivity only, and uses enhanced security through certificate-based communication. See Digi Remote Manager support for further information.
   - Firmware prior to version 22.2.6.x, the default is the Digi Remote Manager server, https://remotemanager.digi.com.

5. (Optional) Set the amount of time that the Connect EZ 4 WS device should wait before reattempting to connect to the remote cloud services after being disconnected. The minimum value is ten seconds. The default is 30 seconds.

```
(config)> cloud drm retry_interval value
```

   where **value** is any number of hours, minutes, or seconds, and takes the format **number [h|m|s]**.

   For example, to set **the retry interval** to ten minutes, enter either **10m** or **600s**:

```
(config)> cloud drm retry_interval 600s
(config)>
```

6. (Optional) Set the amount of time that the Connect EZ 4 WS device should wait between sending keep-alive messages to the Digi Remote Manager when using a non-cellular interface. Allowed values are from 30 seconds to two hours. The default is 60 seconds.

```
(config)> cloud drm keep_alive value
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

where value is any number of hours, minutes, or seconds, and takes the format *number* [h|m|s].

For example, to set **the keep-alive interval** to ten minutes, enter either 10m or 600s:

```
(config)> cloud dre keep_alive 600s
(config)>
```

Note The **Cellular keep-alive interval** is not used by the Connect EZ 4 WS. Any entry is ignored.

7. Set the number of allowed keep-alive misses. Allowed values are any integer between 2 and 64. The default is 3:

```
(config)> cloud dre keep_alive_misses integer
(config)>
```

8. The **watchdog** is used to monitor the connection to remote cloud services. If the connection is down, you can configure the device to restart the connection, or to reboot. The watchdog is enabled by default. To disable:

```
(config)> cloud dre watchdog false
(config)>
```

9. If **watchdog** is enabled:
   a. (Optional) Set the amount of time to wait before restarting the connection to the remote cloud services, once the connection is down.

      where *value* is any number of hours, minutes, or seconds, and takes the format *number* [h|m|s].

      For example, to set **restart timeout** to ten minutes, enter either 10m or 600s:

      ```
      (config)> cloud dre restart_timeout 600s
      (config)>
      ```

      The minimum value is 30 minutes and the maximum is 48 hours. If not set, this option is disabled. The default is 30 minutes.
   b. (Optional) Set the amount of time to wait before rebooting the device, once the connection to the remote cloud services is down. By default, this option is not set, which means that the option is disabled.

      where *value* is any number of hours, minutes, or seconds, and takes the format *number* [h|m|s].

      For example, to set **reboot timeout** to ten minutes, enter either 10m or 600s:

      ```
      (config)> cloud dre reboot_timeout 600s
      (config)>
      ```

      The minimum value is 30 minutes and the maximum is 48 hours. If not set, this option is disabled. The default is disabled.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

10. **firmware url** should normally be left at the default location. To change:

```
(config)> cloud drm firmware_url url
(config)>
```

11. (Optional) Set the hostname or IP address of the speedtest server. The default is speedtest.accns.com:

```
(config)> cloud drm speedtest_server name
(config)>
```

12. (Optional) Determine whether to require a login and password to authenticate the user from the remote cloud services GUI:

```
(config)> cloud drm cli_local_auth true
(config)>
```

If set to **false**, no login prompt will be presented and the user will be logged in as **admin**. The default is **false**.

13. (Optional) Configure the Connect EZ 4 WS device to communicate with remote cloud services by using SMS:
    a. **Enable** SMS messaging:

```
(config)> cloud drm sms enable true
(config)>
```

    b. Set the phone number for Digi Remote Manager:

```
(config)> cloud drm sms destination value
(config)>
```

    where **value** is either:
    - Within the US: **12062823370**
    - International: **447537431737**

    c. (Optional) Set the service identifier:

```
(config)> cloud drm sms service_id id
(config)>
```

14. (Optional) Configure the Connect EZ 4 WS device to communicate with remote cloud services by using an HTTP proxy server:
    a. **Enable** the use of an HTTP proxy server:

```
(config)> cloud drm proxy enable true
(config)>
```

    b. Set the hostname of the proxy server:

```
(config)> cloud drm proxy host hostname
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. (Optional) Set the port number on the proxy server that the device should connect to. The default is 2138:

```
(config)> cloud dns proxy port integer
(config)>
```

15. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

16. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Collect device health data and set the sample interval

You can enable or disable the collection of device health data to upload to Digi Remote Manager, and configure the interval between health sample uploads. By default, device health data upload is enabled, and the health sample interval is set to 60 minutes. Each time a device connects to Digi Remote Manager after the device boots (or reboots), the device immediately uploads all health metrics.

To avoid a situation where several devices are uploading health metrics information to Remote Manager at the same time, the Connect EZ 4 WS device includes a preconfigured randomization of two minutes for uploading metrics. For example, if **Health sample interval** is set to five minutes, the metrics will be uploaded to Remote Manager at a random time between five and seven minutes.

To disable the collection of device health data or enable it if it has been disabled, or to change the health sample interval:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



The **Configuration** window is displayed.

3. Click **Monitoring** > **Device Health**.

4. (Optional) Click to expand **Data point tuning**.
Data point tuning options allow to you configure what data are uploaded to the Digi Remote Manager. All options are enabled by default.
5. **Only report changed values to Digi Remote Manager** is enabled by default.
When enabled:
   - The device only reports device health metrics that have changed. Health metrics were last uploaded. This is useful to reduce the bandwidth used to report health metrics.
   - All metrics are uploaded once every hour.

   When disabled, all metrics are uploaded every **Health sample interval**.
6. Device health data upload is enabled by default. To disable, toggle off **Enable Device Health samples upload**.
7. For **Health sample interval**, select the interval between health sample uploads.
8. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. Device health data upload is enabled by default. To enable or disable:
   - To enable:

```
(config)> monitoring devicehealth enable true
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To disable:

```
(config)> monitoring devicehealth enable false
(config)>
```

4. The interval between health sample uploads is set to 60 minutes by default. To change:

```
(config)> monitoring devicehealth interval value
(config)>
```

where *value* is one of 1, 5, 15, 30, or 60, and represents the number of minutes between uploads of health sample data.

5. By default, the device will only report health metrics values to Digi Remote Manager that have changed health metrics were last uploaded. This is useful to reduce the bandwidth used to report health metrics. This is useful to reduce the bandwidth used to report health metrics. Even if enabled, all metrics are uploaded once every hour.

   To disable:

```
(config)> monitoring devicehealth only_send_deltas false
(config)>
```

   When disabled, all metrics are uploaded every **Health sample interval**.

6. (Optional) Tuning parameters allow to you configure what data are uploaded to the Digi Remote Manager. By default, all tuning parameters are enabled.

   To view a list of all available tuning parameters, use the **show** command:

```
(config)> show monitoring devicehealth tuning
all
    eth
        rx
            bytes
                enable true
        tx
            bytes
                enable true
    serial
        rx
            bytes
                enable true
        tx
            bytes
                enable true
...                                          (config)>
```

   To disable a tuning parameter, set its value to false. For example, to turn off all reporting for the serial port:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> monitoring devicehealth rusting all serial rx bytes enabled
false
(config)> monitoring devicehealth rusting all serial tx bytes enabled
false
(config)>
```

7. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Event log upload to Digi Remote Manager

Your device is automatically configured to upload the event log to Digi Remote Manager. These logs are uploaded every 60 minutes.

Change the upload interval

To change how often the event logs are uploaded to Digi Remote Manager:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:


   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.



   The **Configuration** window is displayed.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click **Monitoring** > **Device event logs**.



4. For **Device event log upload interval**, change the interval between health sample uploads. The default is **60 minutes**.
5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4-WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. The interval between event log uploads is set to 60 minutes by default. To change:

```
(config)> monitoring events interval value
(config)>
```

   where *value* is one of 1, 5, 15, 30, or 60, and represents the number of minutes between uploads of health sample data.
4. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

5. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Reach Digi Remote Manager on a private network

If your company has a private network and you have devices that need to reach Digi Remote Manager, there are several methods available.

- **Pinhole**: a communication port on your network not protected by the firewall which allows the application on the device to reach Digi Remote Manager.
- **Proxy server**: a dedicated software system equipped with its own IP address that runs on your network and acts as an intermediary between the device and Digi Remote Manager.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **VPN tunnel**: a virtual private network that offers a secure, encrypted connection between a device and the internet.

Pinhole method

Using the pinhole method requires your network administrator to remove the firewall connection on a communication port. For more information, see Firewall concerns for outbound EDP connections to Digi Remote Manager.

Proxy server method

The device is capable of connecting through an HTTP proxy, such as Squid, but it is up to the network administrator to decide which HTTP proxy type to use.

To enable a proxy server and enter the server and port in Digi Remote Manager, see step 17 in Configure your device for Digi Remote Manager support.

Tip: To see instructions for setting up Squid and then configuring a device (not DAL) to reach Digi Remote Manager, see the Digi Quick Note, Connecting to Digi Remote Manager through Web Proxy. Though this Quick Note references older technology and device types, it may provide a network administrator with concrete examples from which they can draw correlations to newer technology and devices.

VPN Tunnel method

Configuring a VPN tunnel to communicate with Digi Remote Manager is a two-step process. One step is done by your organization's network administrator and the other by Digi Support.

Step 1: Set up the VPN tunnel

Your organization's network administrator needs to set up a VPN tunnel on your network, which will be used to communicate with Digi Remote Manager through the Digi cloud service.

Step 2: Contact Digi Support.

Digi Support configures the Digi cloud service to allow your VPN to communicate with Digi Remote Manager. Contact Digi Support at https://www.digi.com/contactus.

Log in to Digi Remote Manager

To log in to Remote Manager:

1. In a web browser, go to remotemanager.digi.com.
2. Type your username.
3. Click **Continue**.
4. Type your password.
5. Click **Login**.

   If you used the same browser tab/window to log in again, you will see the page you were on in your previous session. If you opened a new browser tab/window to log in, you will see the default Feed: Dashboard page.

Tip: If you cannot remember your password, go to remotemanager.digi.com, type your username and then click **Forgot username?** You will be asked to provide your email address associated with

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

your user account. If you are not sure that you have a user account, talk with your Remote Manager administrator.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use Digi Remote Manager to view and manage your device

To view and manage your devices:

1. If you have not already done so, connect to your Digi Remote Manager account.
2. From the menu, click **Devices** to display a list of your devices.
3. Use the Filter bar to locate the device you want to manage. For example, to search by type of device:
   a. Click the Advanced Search button ( ).
   b. Click in the filter bar.



   c. Type the type of device (for example, Connect EZ 4 WS).

Add a device to Remote Manager

There are several options for adding a device to Remote Manager.

- **Quick Start process.** Use this process to both install a device and then add it to Remote Manager. See the Connect EZ 4 WS Quick Start Guide.
- **Device label information.** Use the information on the device label (e.g., Device ID, MAC address, Password) to add a new device to Remote Manager. See Add a device to Remote Manager using information from the label.
- **Digi Remote Manager credentials.** Use your Remote Manager credentials to add a device to Remote Manager when you do not have the device password. See Add a device to Remote Manager using your Remote Manager login credentials.

Add a device to Remote Manager using information from the label

Tip If you do not have access to the device label, you can add the device using your Remote Manager login credentials. See Add a device to Remote Manager using your Remote Manager login credentials.

1. If you have not already done so, connect to your Digi Remote Manager account.
2. From the menu, click **Devices** to display a list of your devices.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Click **Add**.



4. Type the Device ID, MAC Address, or IMEI.
5. For **Device Default Password**, enter the default password on the printed label packaged with your device. The same default password is also shown on the label affixed to the bottom of the device.
6. (Optional) Complete the other fields.
7. Click **Add Device**.
   Remote Manager adds the Connect EZ 4 WS device to your account and it appears in the **Device Management** view.

Add a device to Remote Manager using your Remote Manager login credentials

If you want to add a device to Remote Manager, and you do not have its password, you can add it using your Remote Manager login credentials.


To add a device using your Remote Manager credentials:

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
2. On the dashboard, in **Digi Remote Manager** status pane, click **Register device in new account**.



3. The **Register Device in New Account** page displays.



4. For **Digi Remote Manager Username**, type your Remote Manager username.
5. For **Digi Remote Manager Password**, type your Remote Manager password.
6. For **Digi Remote Manager Group (optional)**, type the group to which the device will be added, if needed.
7. Click **Register**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 818 / 927

TS-TL-DGI-010

The device is added to Remote Manager.

Command line

1. Log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
2. Register a device.

```
(config)> register [group STRING] password STRING username STRING
```

where:

- group: group to add device in Digi Remote Manager.
- password: Digi Remote Manager password (required).
- username: Digi Remote Manager username (required).

1. Click **Apply** to save the configuration and apply the change.
2. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure multiple Connect EZ 4 WS devices by using Digi Remote Manager configurations

Digi recommends you take advantage of Remote Manager configurations to manage multiple Connect EZ 4 WS devices. A Remote Manager configuration is a named set of device firmware, settings, and file system options. You use the configuration to automatically update multiple devices and to periodically scan devices to check for compliance with the configuration. See the Digi Remote Manager User Guide for more information about Remote Manager configurations.

Typically, if you want to provision multiple Connect EZ 4 WS routers:

1. Using the Connect EZ 4 WS local WebUI, configure one Connect EZ 4 WS router to use as the model configuration for all subsequent Connect EZ 4 WSs you need to manage.
2. Register the configured Connect EZ 4 WS device in your Remote Manager account.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

3. In Remote Manager, create a configuration:
   a. From the Dashboard, select Configurations.



   b. Click **Create**.



   c. Enter a **Name** and an optional **Description** for the configuration, and select the **Groups**, **Device Types**, and **Firmware Version**.
   d. Click **Save and continue**.
   e. Click **Import from device** and select the device configured above.
   f. Click **Import**.
   g. At the **Settings** page, configure any desired configuration overrides and click **Continue**.
   h. At the **File System** page, make any desired changes to the files that were imported from the device and click **Continue**.
   i. At the **Automations** page, click **Enable Scanning**, make any other desired changes, and click **Save**.

Digi Remote Manager provides multiple methods for applying configurations to registered devices. You can also include site-specific settings with a profile to override settings on a device-by-device basis.

View Digi Remote Manager connection status

To view the current Digi Remote Manager connection status from the local device:

Web

1. Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.
   The dashboard includes a Digi Remote Manager status panel.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Central management Learn more

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **admin** to access the Admin CLI.

2. Use the show cloud command to view the status of your device's connection to Remote Manager:

```
> show cloud

Device Cloud Status
-------------------

Status     : Connected
Server     : etsli.devicecloud.com Device ID : 00000000-00000000-00C1FF-
FFA8B7>
```

1. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

Learn more

To learn more about Digi Remote Manager features and functions, see the Digi Remote Manager User Guide.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

File system

This chapter contains the following topics:

The Connect EZ 4 WS local file system 823
Display directory contents 826
Create a directory 834
Display file contents 835
Copy a file or directory 838
Move or rename a file or directory 839
Delete a file or directory 841
Upload and download files 843

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The Connect EZ 4 WS local file system

The Connect EZ 4 WS local file system has approximately 150 MB of space available for storing files, such as Python programs, alternative configuration files and firmware versions, and release files. The writable directories within the file system are:

- /tmp
- /opt
- /etc/config

Files stored in the /tmp directory do not persist across reboots. Therefore, /tmp is a good location to upload temporary files, such as files used for firmware updates. Files stored in /opt and /etc/config do persist across reboots, but are deleted if a factory reset of the system is performed. See Device reset for more information.

Display directory contents

To display directory contents by using the WebUI or the Admin CLI:

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **System**. Under **Administration**, click **File System**.



The **File System** page appears.



2. Highlight a directory and click to open the directory and view the files in the directory.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the Admin CLI prompt, type **ls** */path/dir_name*. For example, to display the contents of the **/etc/config** directory:

```
> ls /etc/config
-rw-r-----    1 root     root           866 Nov 30 20:12 access.json
drw---------    2 root     root           160 Sep 23 04:02 analyzer
drwxr-xr-x    3 root     root           224 Sep 23 04:02 cc_acl
-rw-r-----    1 root     root            47 Sep 23 04:02 dhcp.leases
...
>
```

3. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Create a directory

Command line

This procedure is not available through the WebUI. To make a new directory, use the *mkdir* command, specifying the name of the directory.

For example:

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the Admin CLI prompt, type **mkdir** */path/dir_name*. For example, to create a directory named **temp** in **/etc/config**:

```
> mkdir /etc/config/temp
>
```

3. Verify that the directory was created:

```
> ls /etc/config
...
-rw-r-----    1 root     root          1435 Aug 12 21:36 ssl.crt
-rw---------    1 root     root          3365 Aug 12 21:36 ssl.pem
-rw-r-----    1 root     root            18 Aug  5 02:41 start
drwxr-xr-x    2 root     root           160 Aug 25 17:49 temp
>
```

4. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Display file contents

This procedure is not available through the WebUI. To display the contents of a file by using the Admin CLI, , use the more command, specifying the name of the directory.

For example:

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, type **more /path/filename**. For example, to view the contents of the file **accosjson** in **/etc/config**:

```
> more /etc/config/acosx.json
{
    "auth":
        "user": {
            "admin": {
                "password":
"$1$a$VBkXkIoiuuud/nn3XXT.$gnGewriyenhkQdbaFxanGswAgnVJe"
            }
        }
    },
    "schema": {
        "version": "461"
    }
}
>
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Copy a file or directory

This procedure is not available through the WebUI. To copy a file or directory by using the Admin CLI, use the cp command, specifying the existing path and filename followed by the path and filename of the new file, or specifying the existing path and directory name followed by the path and directory name of the new directory.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

2. At the Admin CLI prompt, type **cp /path/filename1 dir_name1 /path/filename2 dir_name2**. For example:
   - To copy the file **/etc/config/access.json** to a file named **backup_cfg.json** in a directory named **/etc/config/test**, enter the following:

```
> cp /etc/config/access.json /etc/config/test/backup_cfg.json
>
```

   - To copy a directory named **/etc/config/test** to **/opt**:

```
> cp /etc/config/test/ /opt/
>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Move or rename a file or directory

This procedure is not available through the WebUI. To move or rename a file or directory by using the Admin CLI, use the **mv** command.

Command line

To rename a file named **test.py** in **/etc/config/scripts** to **final.py**:

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, type:

```
> mv /etc/config/scripts/test.py /etc/config/scripts/final.py
>
```

3. Type **exit** to exit the Admin CLI.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

To move **test.py** from **/etc/config/scripts** to **/opt**:

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, type:

```
> mv /etc/config/scripts/test.py /opt/
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.


Delete a file or directory

To delete a file or directory by using the WebUI or the Admin CLI:

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **System**. Under **Administration**, click **File System**.



The **File System** page appears.



2. Highlight the directory containing the file to be deleted and click 📂 to open the directory.
3. Highlight the file to be deleted and click 🗑.
4. Click **OK** to confirm.

Command line

To delete a file named **test.py** in **/etc/config/scripts**:

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the Admin CLI prompt, type:

```
> rm /etc/config/scripts/test.py
rm: remove '/etc/config/scripts/test.py'? yes
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

To delete a directory named **temp** from **/opt**:

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the Admin CLI prompt, type:

```
> rm /opt/temp/
rm: descend into directory '/opt/temp'? yes
rm: remove directory '/opt/temp'? yes
>
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Upload and download files

You can download and upload files by using the WebUI or from the command line by using the scp Secure Copy command, or by using a utility such as SSH File Transfer Protocol (SFTP) or an SFTP application like FileZilla.

Upload and download files by using the WebUI

Upload files

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **System**. Under **Administration**, click **File System**.



The **File System** page appears.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.




2. Highlight the directory to which the file will be uploaded and click to open the directory.
3. Click (upload).
4. Browse to the location of the file on your local machine. Select the file and click **Open** to upload the file.

Download files

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **System**. Under **Administration**, click **File System**.



The **File System** page appears.



2. Highlight the directory to which the file will be uploaded and click to open the directory.
3. Highlight the appropriate file and click (download).

Upload and download files by using the Secure Copy command

Copy a file from a remote host to the Connect EZ 4 WS device

To copy a file from a remote host to the Connect EZ 4 WS device, use the scp command as follows:

```
# scp host hostname-or-ip user username remote remote-path local local-path to local
```

where is:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- *hostname-or-ip* is the hostname or IP address of the remote host.
- *username* is the name of the user on the remote host.
- *remote-path* is the path and filename of the file on the remote host that will be copied to the Connect EZ 4 WS device.
- *local-path* is the location on the Connect EZ 4 WS device where the copied file will be placed.

For example:

To copy firmware from a remote host with an IP address of 192.168.4.1 to the /etc/config directory on the Connect EZ 4 WS device, issue the following command:

```
> scp host 192.168.4.1 user admin remote /home/admin/bin/Connect EZ 4 WS-
35.5.bin local /etc/config/scripts to local
admin@192.168.4.1's password: adminpwd
Connect EZ 4 WS-35.5.bin                    100%   30MB    11.1MB/s    00:03
>
```

Transfer a file from the Connect EZ 4 WS device to a remote host

To copy a file from the Connect EZ 4 WS device to a remote host, use the *scp* command as follows:

```
> scp host hostname-or-ip user username remote remote-path local local-path to
remote
```

where:

- *hostname-or-ip* is the hostname or IP address of the remote host.
- *username* is the name of the user on the remote host.
- *remote-path* is the location on the remote host where the file will be copied.
- *local-path* is the path and filename on the Connect EZ 4 WS device.

For example:

To copy a support report from the Connect EZ 4 WS device to a remote host at the IP address of 192.168.4.1:

1. Use the **system support-report** command to generate the report.

```
> system support-report path /var/log/
Saving support report to /var/log/support-report-00408D133336-24-01-13-
12:10:00.bin
Support report saved.
>
```

2. Use the **scp** command to transfer the report to a remote host.

```
> scp host 192.168.4.1 user admin remote /home/admin/temp/ local
/var/log/support-report-00:40:8D:13:33:36-24-01-13-12:10:00.bin to remote
admin@192.168.4.1's password: adminpwd
support-report-00408D133336-24-01-13-12:10:00.bin
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Upload and download files using SFTP

Transfer a file from a remote host to the Connect EZ 4 WS device

This example uploads firmware from a remote host to the Connect EZ 4 WS device with an IP address of **192.168.2.1**, using the username **ahmed**:

```
$ sftp ahmed@192.168.2.1
Password:
Connected to 192.168.2.1.
sftp> put Connect EZ 4 WS-20.5
Uploading Connect EZ 4 WS-20.5 to Connect EZ 4 WS-20.5
Connect EZ 4 WS-20.5
          100%  24M   828.4KB/s   00:00
sftp> exit
$
```

Transfer a file from the Connect EZ 4 WS device to a remote host

This example downloads a file named **test.py** from the Connect EZ device at the IP address of **192.168.2.1** with a username of **ahmed** to the local directory on the remote host:

```
$ sftp ahmed@192.168.2.1
Password:
Connected to 192.168.2.1.
sftp> get test.py
Fetching test.py to test.py
test.py
    100%  154     0.3KB/s   00:00
sftp> exit
$
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Diagnostics

This chapter contains the following topics:

Perform a speed test
Generate a support report
View system and event logs
Configure syslog servers
Configure options for the event and system logs
Configure an email notification for a system event
Configure an SNMP trap for a system event
Analyze network traffic
Use the ping command to troubleshoot network connections
Use the traceroute command to diagnose IP routing problems

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Perform a speedtest

To perform a speedtest:

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Use the **iperf** command to generate the report:

   ```
   > iperf host
   ```

   where **host** is the hostname or IP address of a specified host. For example:

   ```
   > iperf speedtest.accns.com
   Tx (upload) average: 50.1110 Mbps
   Tx latency: 31.45 ms
   Rx (download) average: 44.7166 Mbps
   Rx latency: 30.65 ms
   >
   ```
3. To output the result in json format, use the **output** parameter:

   ```
   > iperf host output json
   {"tx_avg": "51.5510", "tx_avg_units": "Mbps", "tx_latency": "31.0", "tx_latency_units": "ms", "rx_avg": "39.5770", "rx_avg_units": "Mbps", "rx_latency": "34.16", "rx_latency_units": "ms" }
   >
   ```
4. To change the size of the speedtest packet, use the **size** parameter:

   ```
   > iperf host size 1m
   ```
5. By default, the speedtest uses **nuttcp** for the mode. To change this setting from nuttcp to **iperf**, use the **mode** parameter:

   ```
   > iperf host mode iperf
   ```
6. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Generate a support report

To generate and download a support report:

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **System**. Under **Administration**, click **Support Report**.



2. Click to generate and download the support report.



Attach the support report to any support requests.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Use the **system support-report** command to generate the report.

```
> system support-report path /var/log/
Saving support report to: /var/log/support-report-00408D113C3C-24-61-12-
12:16:09.bin
Support report saved.
>
```

3. Use the **scp** command to transfer the report to a remote host.

```
> scp host 192.168.4.1 user admin remote /home/admin/temp/ local
/var/log/support-report-00:40:8D:12:3C:3C-24-61-12-12:16:09.bin to remote
admin@192.168.4.1's password: adminpwd
support-report-00408D113C3C-24-61-12-12:16:09.bin
>
```

4. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

See Support report overview for an overview of what is contained in the support report.

Support report overview

Generating a Support Report

Support reports provide a snapshot of a device's current settings and connection statuses at the time of the report's generation. The relevant log files are packaged into a .bin file that can be downloaded from the local (web) UI. For more information about generating support reports, see Generate a support report.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Diagnostics Generate a support report

Note Information logged on the device will be erased when the device is powered off or rebooted to avoid unnecessary wear to the flash memory. See Configure options for the event and system logs for more information on how to enable persistent system logs.

Use /--tgz or any other file-archiving utility to extract a support report. Its contents are organized into the following directories:

/etc

Directory	Filename	Notes
/etc/	version	Active firmware version

/opt

Information stored here persists between reboots and system resets.

Directory	Filename	Notes
/opt/log/	messages	With persistent system logs enabled, syslog info will be stored in the /opt directory which isn't erased after reboots or system resets

/tmp

Output from a series of diagnostic queries is stored in a randomly generated sub-directory within /tmp. When combing through these logs, pay particular attention to config_dump-public (to verify local device settings).

Directory	Filename	Notes
/tmp/d*		*# is generated at random
	arp -nv	The tables of IP-address to MAC-address translations used by the address resolution protocol (ARP)
	ebtables -nvv -L	The tables of Ethernet packet filter rules in the Linux kernel
	cat /proc/meminfo	A breakdown of memory utilization at the time when the support report was generated
	config_dump-public	The device's current settings, scrubbed of passwords and preshared keys
	conntrack -L	A list of all currently tracked connections through the system
	conntrack -S	A summary of currently tracked connections
	date	Local system time. If the device isn't online when the support report is generated, the date will be based on the date/month/year that the firmware running

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Diagnostics Generate a support report

Directory	Filename	Notes
		on the device was created (e.g. 18.4.54.41 was created 2018-07-05)
	df -h	A report of the file system disk space usage
	event_list	A list of events leveraged for syslog messages
	fw_printenv	The entire environment for the bootloader U-Boot
	ip_addr_list	IP addresses listed per interface
	ip_route_list	Default routing information per interface
	ip6tables -nvx -L	A list of IPV6 routing tables
	ip6tables -nvx -L -t mangle	Firewall table used when handling mangled/fragmented IPV6 packets
	ip6tables -nvx -L -t nat	Firewall table used to direct NAT'd traffic
	iptables -nvx -L	A list of IPv4 firewall tables
	iptables -nvx -L -t mangle	Firewall table used when handling mangled/fragmented IPv4 packets
	iptables -nvx -L -t nat	Firewall table used to direct NAT'd traffic
	ls -RthA etc/config	An index of items in /etc/config (and its sub-directories)
	ls -RthA opt	An index of items in /opt (and its sub-directories)
	ls -RthA tmp	An index of items in /tmp (and its sub-directories)
	ls -RthA var	An index of items in /var (and its sub-directories)
	netstat -i	Interface statistics for transmitted/ received packets
	netstat -nw	List of both listening and non-listening network sockets on the device
	ps -l	A snapshot of the current processes running at the time of generating the report
	rundb -pjson	Storage for active/ engaged system variables
	ubus-dump	A log of ubus calls for network devices and interfaces
	uptime	The device's uptime at the time of generating the report, along with CPU load averages for the past 1, 5, and 15 minutes

/var/log

The running system log is stored to "messages" until reaching a set line count (1,000 lines by default). Once this limit is exceeded, that file is renamed to "messages.0" and a new running log is written to the now-empty "messages" log.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Diagnostics Generate a support report

Directory	Filename	Notes
/var/log	messages	Current syslog information
	messages.0	Rollover syslog information

/var/run

This directory can be disregarded for most troubleshooting/ diagnostic purposes.

Directory	Filename	Notes
/var/run	all files	Runtime settings for the device – referenced in the syslog data gathered in /tmp (see above)

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

View system and event logs


See Configure options for the event and system logs for information about configuring the information displayed in event and system logs.

View System Logs

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the main menu, click **System** > **Logs**.



The system log displays.



2. Limit the display in the system log by using the **Find** search tool.




3. Use filters to configure the types of information displayed in the system logs.



원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. Click to download the system log.



Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Use the show log command at the Admin CLI prompt:

```
> show log

Timestamp          Message
-------------------  ------------------------------------------------------------
-----
Nov 16 21:54:34  Connect EZ 4 WS netifd: Interface 'interface_wan' is
setting up now
Nov 16 21:54:36  Connect EZ 4 WS firewall[611]: reloading status
...:
>
```

3. (Optional) Use the **show log number** *num* command to limit the number of lines that are displayed. For example, to limit the log to the most recent ten lines:

```
> show log number 10

Timestamp          Message
-------------------  ------------------------------------------------------------
-----
Nov 16 21:54:34  Connect EZ 4 WS netifd: Interface 'interface_wan' is
setting up now
Nov 16 21:54:36  Connect EZ 4 WS firewall[611]: reloading status
...:
>
```

4. (Optional) Use the **show log filter value** command to limit the number of lines that are displayed. Allowed values are **critical**, **warning**, **info**, and **debug**. For example, to limit the event list to only info messages:

```
> show log filter info

Timestamp          Type     Category  Message
-------------------  -------- --------  ------------------------------------------
-----
Nov 16 22:08:36  Info     user
name:admin-service:11-state:opened-remote:192.168.1.2
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Nov 15 22:04:35  info    user
name=admin-service-ctl-state=closed-remote=192.168.1.2
...
#
```

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

View Event Logs

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.


1. On the main menu, click **System** > **Logs**.



2. Click ▾ **System Logs** to collapse the system logs viewer, or scroll down to **Events**.
3. Click ▸ **Events** to expand the event viewer.



4. Limit the display in the event log by using the **Find** search tool.



5. Click 📥 to download the event log.



Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Use the show event command at the Admin CLI prompt:

```
> show event

Timestamp          Type     Category  Message
-------------------- -------- --------- ------------------------------------------------
------
Nov 16 21:42:37  status  stat
/ntf:ethi-type:ethernet-rx:11332435-tx:3618713
Nov 16 21:42:35  status  system    local_time:Thu, 08 Aug 2019 21:42:35
+0000-uptime:2 hours, 0 minutes, 46 seconds
...
>
```

3. (Optional) Use the **show event number** *num* command to limit the number of lines that are displayed. For example, to limit the event list to the most recent ten lines:

```
> show event number 10

Timestamp          Type     Category  Message
-------------------- -------- --------- ------------------------------------------------
------
Nov 16 21:42:37  status  stat
/ntf:ethi-type:ethernet-rx:11332435-tx:3618713
Nov 16 21:42:35  status  system    local_time:Thu, 08 Aug 2019 21:42:35
+0000-uptime:2 hours, 0 minutes, 46 seconds
...
>
```

4. (Optional) Use the **show event table value** command to limit the number of lines that are displayed. Allowed values are **error**, **info**, and **status**. For example, to limit the event list to only info messages:

```
> show event table info

Timestamp          Type     Category  Message
-------------------- -------- --------- ------------------------------------------------
------
Nov 16 22:01:16  info    user
name:admin-service:cli-state:opened-remote:192.168.1.3
Nov 16 22:01:20  info    user
name:admin-service:cli-state:closed-remote:192.168.1.3
...
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Diagnostics View system and event logs

5. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Configure syslog servers

You can configure remote syslog servers for storing event and system logs.

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.
   b. Click the **Device ID**.
   c. Click **Settings**.
   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **System** > **Log**.

4. Add and configure a remote syslog server:
   a. Click to expand **Server list**.
   b. For **Add Server**, click **+**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The log server configuration window is displayed.



Log servers are enabled by default. To disable, toggle off **Enable**.

c. Type the host name or IP address of the **Server**.

d. Select the event categories that will be sent to the server. By default, all event categories are enabled. You can disable logging for error, informational, and status event categories by clicking to toggle off the category.

e. For **Syslog egress port**, type the port number to use for the syslog server. The default is **514**.

f. For **Protocol**, select the IP protocol to use for communication with the syslog server. Available options are **TCP** and **UDP**. The default is **UDP**.

5. Click **Apply** to save the configuration and apply the change.

Command line

1. Select the device in Remote Manager and click **Actions > Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. (Optional) To configure remote syslog servers:

   a. Add a remote server:

```
(config)> add system log remote end
(config system log remote 0)>
```

   b. Enable the server:

```
(config system log remote 0)> enable true
(config system log remote 0)>
```

   c. Set the host name or IP address of the server:

```
(config system log remote 0)> server hostname
(config system log remote 0)>
```

   d. The event categories that will be sent to the server are automatically enabled when the server is enabled.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- To disable informational event messages:

```
[config system log remote 0]> info false
[config system log remote 0]>
```

- To disable status event messages:

```
[config system log remote 0]> status false
[config system log remote 0]>
```

- To disable informational event messages:

```
[config system log remote 0]> error false
[config system log remote 0]>
```

4. Set the port number to use for the syslog server:

```
[config system log remote 0]> port value
[config system log remote 0]>
```

where *value* is any integer between 1 and 65535. The default is 514.

5. Set the IP protocol to use for communication with the syslog server:

```
[config system log remote 0]> protocol value
[config system log remote 0]>
```

where *value* is either tcp or udp. The default is udp.

6. Save the configuration and apply the changes.

```
[config]> save
Configuration saved.
>
```

7. Type exit to exit the Admin CLI.

Depending on your device configuration, you may be presented with an Access selection menu. Type quit to disconnect from the device.

Configure options for the event and system logs

The default configuration for event and system logging is:

- The heartbeat interval, which determines the amount of time to wait before sending a heartbeat event if no other events have been sent, is set to 30 minutes.
- All event categories are enabled.

To change or disable the heartbeat interval, or to disable event categories, and to perform other log configuration:

Web

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.

   The **Configuration** window is displayed.
3. Click **System** > **Log**.



4. (Optional) To change the **Heartbeat interval** from the default of 30 minutes, type a new value. The heartbeat interval determines the amount of time to wait before sending a heartbeat event if no other events have been sent.

   Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format **number(w|d|h|m|s)**.

   For example, to set **Heartbeat interval** to ten minutes, enter **10m** or **600s**.

   To disable the **Heartbeat interval**, enter **0s**.
5. (Optional) To disable event categories, or to enable them if they have been disabled:

   a. Click to expand **Event Categories**.

   b. Click an event category to expand.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

c. Depending on the event category, you can enable or disable different types of events.

- **Enable error events**: Enable to generate an event whenever an error occurs.
- **Enable status events**: Enable to generate periodic reports of the current status. These events are generated at specific time intervals, rather than when changes occur, and are only sent if a change has occurred since the previous report. Status events may also be generated in response to remote control commands.
- **Status interval**: The minimum time interval between periodic status events. The limitation does not apply to events generated in response to remote control commands. Set this field to blank to only send events generated in response to remote control commands.

  Syntax: number[w|d|h|m|s]

  Default: 30m (30 minutes)

  This field works with the **Enable status events** option.
- **Enable informational events**: Enable to generate an event whenever a significant change occurs.
- **Enable email notifications**: Enable to email a system log event notification to a specified email address. The email address must also be specified before a notification can be sent. To configure, see Configure an email notification for a system event.
- **Enable SNMP traps**: Enable to save system log event information to an SNMP trap. At least one SNMP destination must be defined before event information can be saved. To configure, see Configure an SNMP trap for a system event.

6. (Optional) See Configure syslog servers for information about configuring remote syslog servers to which log messages will be sent.
7. (Optional) To change the system log settings from the defaults, type in a new value.
   - **System log rotation size**: Specify the maximum size (measured in kilobytes) the system log file can reach before log rotation. When the specified size is reached, the system log rotates.

     Default is **200** kb. Minimum is **10** kb.
   - **System log rotation count**: Specify the number of system log files to keep.

     Default is **5**. Minimum is 1, maximum is **20**.
8. Enable **Preserve system logs** to save the current session's system log after a reboot.

   By default, the Connect EZ 4 WS device erases system logs each time the device is powered off or rebooted.

   Note You should only enable **Preserve system logs** temporarily to debug issues. Once you are finished debugging, immediately disable **Preserve system logs** to avoid unnecessary wear to the flash memory.
9. (Optional) Configure **Email notifications** to send an email notification of a system event. See Configure an email notification for a system event.
10. (Optional) Configure **SNMP traps** destinations for a Connect EZ 4 WS to save system event information. See Configure an SNMP trap for a system event.
11. Click **Apply** to save the configuration and apply the change.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. (Optional) To change the heartbeat interval from the default of 30 minutes, set a new value. The heartbeat interval determines the amount of time to wait before sending a heartbeat event if no other events have been sent.

```
(config)> system log heartbeat_interval value
(config)>
```

   where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number[w|d|h|m|s]**.

   For example, to set **the heartbeat interval** to ten minutes, enter either **10m** or **600s**:

```
(config)> system log heartbeat_interval 600s
(config)>
```

   To disable the heartbeat interval, set the value to **0s**.

4. Enable preserve system logs functionality to save the current session's system log after a reboot. By default, the Connect EZ 4 WS device erases system logs each time the device is powered off or rebooted.

   Note You should only enable **Preserve system logs** temporarily to debug issues. Once you are finished debugging, immediately disable **Preserve system logs** to avoid unnecessary wear to the flash memory.

```
(config)> system log persistent true
(config)>
```

5. (Optional) To disable event categories, or to enable them if they have been disabled:

   a. Use the question mark (**?**) to determine available event categories:

```
(config)> system log event ?

Event categories: Settings to enable individual event categories.

  Additional Configuration

  ------------------------------------------------------------------------

  arping                    ARP ping
  config                    Configuration
  dhcpserver                DHCP server
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
firmware                  Firmware
location                  Location
netcon                    Active recovery
network                   Network interfaces
openvpn                   OpenVPN
portal                    Captive portal
remote                    Remote control
restart                   Restart
serial                    Serial
sms                       SMS commands
speed                     Speed
stat                      Network statistics
user                      User
watchdog                  Watchdog
wifi                      Wi-Fi
wol                       Wake-On-LAN

(config)> system log event
```

b. Depending on the event category, you can enable or disable informational events, status events, and error events. Some categories also allow you to set the status interval, which is the time interval between periodic status events. For example, to configure DHCP server logging:

i. Use the question mark (?) to determine what events are available for DHCP server logging configuration:

```
(config)> system log event dhcpserver ?
...
DHCP server: Settings for DHCP server events. Informational events
are generated
when a lease is obtained or released. Status events report the
current list of
leases.

  Parameters                Current Value
  ------------------------------------------------------------
  info                      true          Enable informational
events
  status                    true          Enable status events
  status_interval           30m           Status interval

(config)> system log event dhcpserver
```

ii. To disable informational messages for the DHCP server:

```
(config)> system log event dhcpserver info false
(config)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

iii. To change the status interval:

```
(config)> system log event dhcpserver status_interval value
(config)>
```

Where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number**w|d|h|m|s.

For example, to set the **status interval** to ten minutes, enter either **10m** or **600s**:

```
(config)> system log event dhcpserver status_interval 10m
(config)>
```

6. (Optional) See Configure syslog servers for information about configuring remote syslog servers to which log messages will be sent.
7. Save the configuration and apply the changes.

```
(config)> save
Configuration saved.
>
```

8. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Configure an email notification for a system event

You can configure the Connect EZ4 WS to send an email notification of a system event.

Step 1: Configure the SMTP server that is used to send email notifications when a system log event occurs by enabling the **Email notifications** system log feature.

Step 2: Review the system log event categories and select the type of information that you want to save to the system log: errors, informational events, or status events, depending on the event category. To ensure the notification is sent, enable the **Enable email notification** option for the event category.

1. Log in to the web UI.
2. Click **System** > **Device Configuration**. The **Configuration** page displays.
3. Expand **System** > **Log**.
4. Expand **Email notifications**.
5. Click **Enable**. The slider is blue when enabled.
   a. From the **Server type** list box, select the mail host used to connect and authenticate with the SMTP server.
   b. In the **SMTP server name** field, enter the host name or IP address of the SMTP server.
   c. In the **SMTP server port** field, enter the TCP port of the SMTP server.
   d. In the **Server user name** field, enter the server login name.
   e. In the **Server password** field, enter the server password.
   f. In the **Email from address** field, enter the email address that should be placed in the **From** field on an email.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

g. In the **Email to address** field, enter the email address that should be placed in the **To** field on an email.

h. In the **Email subject** field, enter the text for the subject line of the email.

6. Click **Apply** to save the configuration and apply the change.

7. Review the system log event categories and select the type of information that you want to save to the system log and enable the **Enable email notification** option. To configure these options, see Configure options for the event and system logs.

Configure an SNMP trap for a system event

You can configure an SNMP trap destination for a Connect EZ 4 WS to save system event information.

Step 1: Configure an SNMP trap by enabling the **SNMP traps** system log feature.

Step 2: Review the system log event categories and select the type of information that you want to save to the system log and the SNMP trap: errors, informational events, or status events, depending on the event category. To ensure the log information is saved to an SNMP trap, enable the **Enable SNMP traps** option for the event category.

1. Log in to the web UI.
2. Click **System > Device Configuration**. The **Configuration** page displays.
3. Expand **System > Log**.
4. Expand **SNMP traps**.
5. Click **Enable**. The slider is blue when enabled.
6. Add a destination.
   a. Click **Add Destination**.
   b. In the **Host Name** field, enter the host name or IP address of the SNMP destination.
   c. In the **Port** field, enter the UDP port of the SNMP destination. The default is **162**.
   d. In the **Community name** field, enter the SNMP destination community name. The default is **public**.
   e. Repeat this process to add an additional destination, if needed.
7. Click **Apply** to save the configuration and apply the change.
8. Review the system log event categories and select the type of information that you want to save to the system log and enable the **Enable SNMP traps** option. To configure these options, see Configure options for the event and system logs.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Analyze network traffic

The Connect EZ 4 WS device includes a network analyzer tool that captures data traffic on any interface and decodes the captured data traffic for diagnostics. You can capture data traffic on multiple interfaces at the same time and define capture filters to reduce the captured data. You can capture up to 10 MB of data traffic in two 5 MB files per interface.

To perform a more detailed analysis, you can download the captured data traffic from the device and view it using a third-party application.

Note Data traffic is captured to RAM and the captured data is lost when the device reboots unless you save the data to a file. See Save captured data traffic to a file.

This section contains the following topics:

Configure packet capture for the network analyzer 853
Example filters for capturing data traffic 853
Capture packets from the command line 853
Stop capturing packets 854
Show captured traffic data 855
Save captured data traffic to a file 856
Download captured data to your PC 857
Clear captured data 858

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 852 / 927

Configure packet capture for the network analyzer

To use the network analyzer, you must create one or more packet capture configurations.

Required configuration items

- The interface used by this packet capture configuration.

Additional configuration items

- The filter expression for this packet capture configuration.
- Schedule the analyzer to run based on a specified event or at a particular time:
  - The events or time that will trigger the analyzer to run, using this capture configuration.
  - The amount of time that the analyzer session will run.
  - The frequency with which captured events will be saved.

To configure a packet capture configuration:

Web

1. Log into Digi Remote Manager, or log into the local Web UI as a user with full Admin access rights.
2. Access the device configuration:

   Remote Manager:

   a. Locate your device as described in Use Digi Remote Manager to view and manage your devices.

   b. Click the **Device ID**.

   c. Click **Settings**.

   d. Click to expand **Config**.

   Local Web UI:

   a. On the menu, click **System**. Under **Configuration**, click **Device Configuration**.


   

   The **Configuration** window is displayed.
3. Click **Network** > **Analyzer**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

4. For **Add Capture settings**, type a name for the capture filter and click **+**.

The new capture filter configuration is displayed.



5. (Optional) Add a filter type.
   a. Click to expand **Filter**.

You can select from preconfigured filters to determine which types of packets to capture or ignore, or you can create your own Berkeley packet filter expression.

   b. To create a filter that either captures or ignores packets from a particular IP address or network:
      i. Click to expand **Filter IP address or networks**.
      ii. Click **+** to add an IP address/network.



      iii. For **IP address or network**, type the IPv4 or IPv6 address (and optional netmask).
      iv. For **Source or destination IP address**, select whether the filter should apply to packets when the IP address/network is the source, the destination, or both.
      v. Click **Ignore this IP address or network** if the filter should ignore packets from this IP address/network. By default, is option is disabled, which means that the filter will capture packets from this IP address/network.
      vi. Click **+** to add additional IP address/network filters.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. To create a filter that either captures or ignores packets that use a particular IP protocol:
   i. Click to expand **Filter IP protocols**.
   ii. Click + to add an IP protocol.
   iii. For **IP protocol to capture or ignore**, select the protocol. If **Other protocol** is selected, type the number of the protocol.
   iv. Click **Ignore this protocol** if the filter should ignore packets that use this protocol. By default, is option is disabled, which means that the filter will capture packets that use this protocol.
   v. Click + to add additional IP protocols filters.
d. To create a filter that either captures or ignores packets from a particular port:
   i. Click to expand **Filter TCP/UDP port**.
   ii. Click + to add a TCP /UDP port.
   iii. For **IP TCP/UDP port to capture or ignore**, type the number of the port to be captured or ignored.
   iv. For **TCP or UDP port**, select the type of transport protocol.
   v. For **Source or destination TCP/UDP port**, select whether the filter should apply to packets when the port is the source, the destination, or both.
   vi. Click **Ignore this TCP/UDP port** if the filter should ignore packets that use this port. By default, is option is disabled, which means that the filter will capture packets that use this port.
   vii. Click + to add additional port filters.
e. To create a filter that either captures or ignores packets from one or more specified MAC addresses:
   i. Click to expand **Filter Ethernet MAC addresses**.
   ii. Click + to add a MAC address.
   iii. For **Ethernet MAC address**, type the MAC address to be captured or ingored.
   iv. For **Source or destination Ethernet MAC address**, select whether the filter should apply to packets when the Ethernet MAC address is the source, the destination, or both.
   v. Click **Ignore this MAC address** if the filter should ignore packets that use this port. By default, is option is disabled, which means that the filter will capture packets that use this port.
   vi. Click + to add additional MAC address filters.
f. To create a filter that either captures or ignores packets from one or more VLANs:
   i. Click to expand **Filter VLANs**.
   ii. Click + to add a VLAN.
   iii. For **the VLAN to capture or ignore**, type the number of the VLAN.
   iv. Click **Ignore this VLAN** if the filter should ignore packets that use this port. By default, is option is disabled, which means that the filter will capture packets that use this port.
   v. Click + to add additional VLAN filters.


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

g. For **Berkeley packet filter expression**, type a filter using Berkeley Packet Filter (BPF) syntax. See Example filters for capturing data traffic for examples of filters using BPF syntax.

6. Add one or more interface to the capture filter:

a. Click to expand **Device**.

b. Click **+** to add an interface to the capture setting instance.



c. For **Device**, select an interface.

d. Repeat to add additional interfaces to the capture filter.

7. (Optional) For **Berkeley packet filter expression**, type a filter using Berkeley Packet Filter (BPF) syntax. See Example filters for capturing data traffic for examples of filters using BPF syntax.

8. (Optional) Schedule the analyzer to run, using the capture filter, based on a specified event or at a particular time.

a. For **Run mode**, select the mode that will be used to run the capture filter. Available options are:

- **On boot**: The capture filter will run once each time the device boots.
- **Interval**: The capture filter will start running at the specified interval, within 30 seconds after the configuration change is saved.
  - If **Interval** is selected, in **Interval**, type the interval.

    Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*w|d|h|m|s.

    For example, to set **Interval** to ten minutes, enter **10m** or **600s**.
- **Set time**: Runs the capture filter at a specified time of the day.
  - If **Set time** is selected, specify the time that the capture filter should run in **Run time**, using the format *HH:MM*.
- **During system maintenance**: The capture filter will run during the system maintenance time window.

b. **Enable** the capture filter schedule.

c. For **Duration**, type the amount of time that the scheduled analyzer session will run.

Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*w|d|h|m|s.

For example, to set **Duration** to ten minutes, enter **10m** or **600s**.

d. For **Save interval**, type the frequency with which captured events will be saved.

Allowed values are any number of weeks, days, hours, minutes, or seconds, and take the format *number*w|d|h|m|s.

For example, to set **Save interval** to ten minutes, enter **10m** or **600s**.

9. Click **Apply** to save the configuration and apply the change.

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
[config]>
```

3. Add a new capture filter:

```
[config]> add network analyzer name
[config network analyzer name]>
```

4. Add an interface to the capture filter:

```
[config network analyzer name]> add device eni device
[config network analyzer name]>
```

   Determine available devices and the proper syntax.

   To determine available devices and proper syntax, use the space bar autocomplete feature:

```
[config network analyzer name]> add device eni <space>
[config network analyzer name]> add interface wwi [network]
```

   Repeat to add additional interfaces.

5. (Optional) Set a filter for the capture filter:

   a. To create a filter that either captures or ignores packets from a particular IP address or network:

      i. Add a new IP address/network filter:

```
[config network analyzer name]> add filter address end
[config network analyzer name filter address 0]>
```

      ii. Set the IPv4 or IPv6 address (and optional netmask):

```
[config network analyzer name filter address 0]> address ip_
address[/network]
[config network analyzer name filter address 0]>
```

      iii. Set whether the filter should apply to packets when the IP address/network is the source, the destination, or both:

```
[config network analyzer name filter address 0]> match value
[config network analyzer name filter address 0]>
```

      where *value* is one of:

      - **source**: The filter will apply to packets when the IP address/network is the source.
      - **destination**: The filter will apply to packets when the IP address/network is the destination.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **either**: The filter will apply to packets when the IP address/network is either the source or the destination.

iv. (Optional) Set the filter should ignore packets from this IP address/network.

```
(config network analyzer name) filter address 0)> ignore true
(config network analyzer name) filter address 0)>
```

By default, to option is set to **false**, which means that the filter will capture packets from this IP address/network.

v. Repeat these steps to add additional IP address filters.

b. To create a filter that either captures or ignores packets that use a particular IP protocol:

i. Add a new IP protocol filter:

```
(config network analyzer name)> add filter protocol end
(config network analyzer name) filter protocol 0)>
```

ii. Use the ?to determine available protocols and the appropriate format:

```
(config network analyzer name) filter protocol 0)> protocol ?

IP protocol to capture or ignore: IP protocol to capture or
ignore.
Format:
  ah
  esp
  gre
  icmp
  icmpv6
  igmp
  ospf
  other
  tcp
  udp
  vrrp
Current value:

(config network analyzer name) filter protocol 0)>
```

iii. Set the protocol:

```
(config network analyzer name) filter protocol 0)> protocol value
(config network analyzer name) filter protocol 0)>
```

iv. If other is set for the protocol, set the number of the protocol:

```
(config network analyzer name) filter protocol 0)> protocol_other
value
(config network analyzer name) filter protocol 0)>
```

Where value is an integer between 1 and 255 and represents the the number of the protocol.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

v. (Optional) Set the filter should ignore packets from this protocol:

```
[config network analyzer name filter protocol 0]> ignore true
[config network analyzer name filter protocol 0]>
```

By default, ignore is set to **false**, which means that the filter will capture packets from this protocol.

vi. Repeat these steps to add additional protocol filters.

c. To create a filter that either captures or ignores packets from a particular port:

i. Add a new port filter:

```
[config network analyzer name]> add filter port end
[config network analyzer name filter port 0]>
```

ii. Set the transport protocol that should be filtered for the port:

```
[config network analyzer name filter port 0]> protocol value
[config network analyzer name filter port 0]>
```

where *value* is one of **tcp**, **udp**, or **either**. The default is either.

iii. Set whether the filter should apply to packets when the port is the source, the destination, or both:

```
[config network analyzer name filter port 0]> match value
[config network analyzer name filter port 0]>
```

where *value* is one of:

- **source**: The filter will apply to packets when the port is the source.
- **destination**: The filter will apply to packets when the port is the destination.
- **either**: The filter will apply to packets when the port is either the source or the destination.

iv. (Optional) Set the filter should ignore packets from this port:

```
[config network analyzer name filter port 0]> ignore true
[config network analyzer name filter port 0]>
```

By default, ignore is set to **false**, which means that the filter will capture packets from this port.

v. Repeat these steps to add additional port filters.

d. To create a filter that either captures or ignores packets from one or more specified MAC addresses:

i. Add a new MAC address filter:

```
[config network analyzer name]> add filter mac_address end
[config network analyzer name filter mac_address 0]>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 859 / 927

TESSOL Technical Library
TS-TL-DGI-010

ii. Set the MAC address that should be be captured or ignored:

```
(config network analyzer name filter mac_address 0)> address value
(config network analyzer name filter mac_address 0)>
```

Where value is the MAC address to be filtered, using colon-hexadecimal notation with lower case, for example, 00:aa:f1:bb:22:cc.

iii. Set whether the filter should apply to packets when the MAC address is the source, the destination, or both:

```
(config network analyzer name filter mac_address 0)> match value
(config network analyzer name filter mac_address 0)>
```

Where value is one of:

- **source**: The filter will apply to packets when the MAC address is the source.
- **destination**: The filter will apply to packets when the MAC address is the destination.
- **either**: The filter will apply to packets when the MAC address is either the source or the destination.

iv. (Optional) Set the filter should ignore packets from this port:

```
(config network analyzer name filter mac_address 0)> ignore true
(config network analyzer name filter mac_address 0)>
```

By default, ignore option is set to **false**, which means that the filter will capture packets from this MAC address.

v. Repeat these steps to add additional MAC addresses.

e. To create a filter that either captures or ignores packets from one or more specified VLANs:

i. Add a new VLAN filter:

```
(config network analyzer name)> add filter vlan end
(config network analyzer name filter vlan 0)>
```

ii. Set the VLAN that should be be captured or ignored:

```
(config network analyzer name filter vlan 0)> vlan value
(config network analyzer name filter vlan 0)>
```

Where value is number or the VLAN.

iii. (Optional) Set the filter should ignore packets from this VLAN:

```
(config network analyzer name filter vlan 0)> ignore true
(config network analyzer name filter vlan  0)>
```

By default, ignore option is set to **false**, which means that the filter will capture packets from this MAC address.

iv. Repeat these steps to add additional VLANs.

f. To create a filter using Berkeley Packet Filter (BPF) syntax:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config network analyzer name)> filter custom value
(config network analyzer name)>
```

where **value** is a filter using Berkeley Packet Filter (BPF) syntax. Values that contain spaces must be enclosed in double quotes (").

See Example filters for capturing data traffic for examples of filters using BPF syntax.

6. (Optional) Schedule the analyzer to run, using this capture filter, based on a specified event or at a particular time.

   a. Enable scheduling for this capture filter:

   ```
   (config network analyzer name)> schedule enable true
   (config network analyzer name)>
   ```

   b. Set the mode that will be used to run the capture filter:

   ```
   (config network analyzer name)> when mode
   (config network analyzer name)>
   ```

   where **mode** is one of the following:

   - **boot**: The script will run once each time the device boots.
   - **interval**: The script will start running at the specified interval, within 30 seconds after the configuration change is saved. If **interval** is selected, set the interval:

     ```
     (config add network analyzer name)> on_interval value
     (config add network analyzer name)>
     ```

     where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number**w|d|h|m|s.

     For example, to set **on_interval** to ten minutes, enter either **10m** or **600s**:

     ```
     (config network analyzer name)> on_interval 600s
     (config network analyzer name)>
     ```

   - **set_time**: Runs the script at a specified time of the day. If **set_time** is set, set the time that the script should run, using the format *HH:MM*:

     ```
     (config network analyzer name)> run_time HH:MM
     (config network analyzer name)>
     ```

   - **maintenance_time**: The script will run during the system maintenance time window.

   c. Set the amount of time that the scheduled analyzer session will run:

   ```
   (config network analyzer name)> duration value
   (config network analyzer name)>
   ```

   where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number**w|d|h|m|s.

   For example, to set **duration** to ten minutes, enter either **10m** or **600s**:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate. ㈜테솔 · www.tessol.com TS-TL-DGI-010 861 / 927
KOLAS 국제공인교정기관 · ISO/IEC 17025

TESSOL Technical Library
TS-TL-DGI-010

```
(config network analyzer name)> save_interval 60m
(config network analyzer name)>
```

d. Set the frequency with which captured events will be saved.

```
(config network analyzer name)> save_interval value
(config network analyzer name)>
```

where **value** is any number of weeks, days, hours, minutes, or seconds, and takes the format **number(w|d|h|m|s)**.

For example, to set **save interval** to ten minutes, enter either **10m** or **600s**.

```
(config network analyzer name)> save_interval 10m
(config network analyzer name)>
```

f. Save the configuration and apply the change.

```
(config)> save
Configuration saved.
>
```

g. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Example filters for capturing data traffic

The following are examples of filters using Berkeley Packet Filter (BPF) syntax for capturing several types of network data. See https://tshark.com/capture/bpf.html for detailed information about BPF syntax.

Example IPv4 capture filters

- Capture traffic to and from IP host 192.168.1.1:

```
ip host 192.168.1.1
```

- Capture traffic from IP host 192.168.1.1:

```
ip src host 192.168.1.1
```

- Capture traffic to IP host 192.168.1.1:

```
ip dst host 192.168.1.1
```

- Capture traffic for a particular IP protocol:

```
ip proto protocol
```

where *protocol* is a number in the range of 1 to 255 or one of the following keywords: **icmp**, **icmp6**, **igmp**, **pim**, **ah**, **esp**, **vrrp**, **udp**, or **tcp**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 862 / 927

TESSOL Technical Library
TS-TL-DGI-010

- Capture traffic to and from a TCP port 80:

```
ip proto tcp and port 80
```

- Capture traffic to UDP port 53:

```
ip proto udp and dst port 53
```

- Capture traffic from UDP port 53:

```
ip proto udp and src port 53
```

- Capture to and from IP host 10.0.0.1 but filter out ports 22 and 80:

```
ip host 10.0.0.1 and not (port 22 or port 80)
```

Example Ethernet capture filters

- Capture Ethernet packets to and from a host with a MAC address of 00:40:D0:13:35:36:

```
ether host 00:40:D0:13:35:36
```

- Capture Ethernet packets from host 00:40:D0:13:35:36:

```
ether src 00:40:D0:13:35:36
```

- Capture Ethernet packets to host 00:40:D0:13:35:36:

```
ether dst 00:40:D0:13:35:36
```

Capture packets from the command line

You can start packet capture at the command line with the analyzer start command. Alternatively, you can schedule the network analyzer to run based on a specified event or at a particular time. See Configure packet capture for the network analyzer for information about scheduling packet capturing.

Additional analyzer commands allow you to:

- Stop capturing packets.
- Save captured data traffic to a file.
- Clear captured data.

Required configuration items

- A configured packet capture. See Configure packet capture for the network analyzer for packet capture configuration information.

To start packet capture from the command line:

Command line

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Type the following at the Admin CLI prompt:

```
> analyzer start name capture_filter
>
```

where **capture_filter** is the name of a packet capture configuration. See Configure packet capture for the network analyzer for more information.

To determine available packet capture configurations, use the '?

```
> analyzer start name ?

name: Name of the capture filter to use.
Format:
  test_capture
  capture_ping

> analyzer start name
```

You can capture up to 10 MB of data traffic in two 5 MB files per interface.

Note Data traffic is captured to RAM and the captured data is lost when the device reboots unless you save the data to a file. See Save captured data traffic to a file.

Stop capturing packets

You can stop packet capture at the command line with the analyzer stop command.

To stop packet capture from the command line:

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Type the following at the Admin CLI prompt:

```
> analyzer stop name capture_filter
>
```

where **capture_filter** is the name of a packet capture configuration. See Configure packet capture for the network analyzer for more information.

To determine available packet capture configurations, use the '?

```
> analyzer stop name ?
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
name: Name of the capture filter to use.
Format:
  test_capture
  capture_ping

> analyzer stop name
```

Show captured traffic data

To view captured data traffic, use the show analyzer command. The command output show the following information for each packet:

- The packet number.
- The timestamp for when the packet was captured.
- The length of the packet and the amount of data captured.
- Whether the packet was sent or received by the device.
- The interface on which the packet was sent or received.
- A hexadecimal dump of the packet of up to 256 bytes.
- Decoded information of the packet.

To show captured data traffic:

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Type the following at the Admin CLI prompt:

```
> show analyzer name capture_filter

Packet 1 : Sept-19-2022 12:18:08.267582, Length 68 bytes (Captured Length
68 bytes)

Received on Interface eth1

      00 40 ff 00 61 28 54 b5  80 11 b5 71 00 00 40 00   .@.. .. .
.(.A...E.
      00 34 1c 1c 40 00 80 06  14 bc 0a 0a 4a 82 0a 0a   .:.@... ....J..
      4a 46 c0 ae 00 16 a4 4c  ff 1f ae 1f d0 12 50 10   JW.....M
.F....PP.
      00 02 c7 46 00 00 02 04  05 b4 04 02               ...G.... ....

    Ethernet Header
      Destination MAC Addr : 00:40:00:61:28:35:36
      Source MAC Addr      : fb:02:53:05:11:1f
      Ethernet Type        : IP (0x0800)
    IP Header
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
    IP Version          : 4
    Header Length       : 20 bytes
    TpS                 : 0x00
    Total Length        : 40 bytes
    ID                  : 10678 (0x2936)
    Flags               : Do not fragment
    Fragment Offset     : 0 (0x0000)
    TTL                 : 128 (0x80)
    Protocol            : TCP (6)
    Checksum            : 0x149c
    Source IP Address   : 10.10.74.138
    Dest. IP Address    : 10.10.74.72
  TCP Header
    Source Port         : 22534
    Destination Port    : 23
    Sequence Number     : 2702443999
    Ack Number          : 3002004333
    Data Offset         : 5
    Flags               : ACK
    Window              : 2050
    Checksum            : 0xc744
    Urgent Pointer      : 0
  TCP Data
    00 00 00 00 00 00                                ......
```

```
>
```

where capture_filter is the name of a packet capture configuration. See Configure packet capture for the network analyzer for more information.

To determine available packet capture configurations, use the ?

```
> show analyzer name ?

name: Name of the capture filter to use.
Format:
  test_capture
  capture_ping

> show analyzer name
```

Save captured data traffic to a file

Data traffic is captured to RAM and when the device reboots, the data is lost. To retain the captured data, first save the data to a file and then upload the file to a PC.

To save captured traffic data to a file, use the analyzer save command.

Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. Type the following at the Admin CLI prompt:

```
> analyzer save filename filename path path
>
```

where:

- **filename** is the name of the file that the captured data will be saved to.

  Determine filenames already in use

  Use the tab autocomplete feature to determine filenames that are currently in use.

```
> analyzer save name <tab>
test1_analyzer_capture     test2_analyzer_capture
> analyzer save name
```

- **path** is the path and filename to save captured traffic to. If a relative path is provided, /etc/config/analyzer will be used as the root directory for the path and file.

To transfer the file to your PC, see Download captured data to your PC.

Download captured data to your PC

After saving captured data to a file (see Save captured data traffic to a file), you can download the file from the WebUI or from the command line by using the scp (secure copy file) command.

Web

Log into the Connect EZ 4 WS WebUI as a user with full Admin access rights.

1. On the menu, click **System**. Under **Administration**, click **File System**.



The **File System** page appears.



2. Highlight the **analyzer** directory and click 📂 to open the directory.
3. Select the saved analyzer report you want to download and click 📥 (download).

CLI Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Type **scp** to use the Secure Copy program to copy the file to your PC.

```
> scp host hostname-or-ip user username remote remote-path local local-
path to remote
```

where:

- **hostname-or-ip** is the hostname or IP address of the remote host.
- **username** is the name of the user on the remote host.
- **remote-path** is the location on the remote host where the file will be copied.
- **local-path** is the path and filename on the Connect EZ 4 WS device.

For example:

To download the traffic saved in the file **/etc/config/analyzer/eth0.pcpng** to a PC with the IP **192.168.210.2**, for a user named **maria**, in the **/home/maria** directory:

```
> scp host 192.168.210.2 user maria remote /home/maria local
/etc/config/analyzer/eth0.pcpng to remote

maria@192.168.210.2's password:
eth0.pcpng                                    100%   1168 611.3KB/s
00:00
```

Clear captured data

To clear captured data traffic in RAM, use the analyzer clear command.

CLI Command line

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. Type the following at the Admin CLI prompt:

```
> analyzer clear name capture_filter
>
```

where **capture_filter** is the name of a packet capture configuration. See Configure packet capture for the network analyzer for more information.

To determine available packet capture configurations, use the ?

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.



Diagnostics Analyze network traffic

```
> show user clear name ?

name: Name of the capture filter to use.
Formats:
  test_capture
  capture_prbs

> show user clear name
```

Note: You can remove data traffic saved to a file using the rm command.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use the ping command to troubleshoot network connections

Use the ping command troubleshoot connectivity problems.

Ping to check Internet connection

To check your internet connection:

1. Select the device in Remote Manager and click **Actions** > **Open Console** or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, type the ping command followed by the host name or IP address of the server to be pinged:

```
> ping 8.8.8.8
PING 8.8.8.8 (8.8.8.8) 56(84) bytes of data.
64 bytes from 8.8.8.8: icmp_seq=1 ttl=54 time=11.1 ms
64 bytes from 8.8.8.8: icmp_seq=2 ttl=54 time=10.8 ms
64 bytes from 8.8.8.8: icmp_seq=3 ttl=54 time=10.7 ms
...
>
```

3. Type **exit** to exit the Admin CLI.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **quit** to disconnect from the device.

Stop ping commands

To stop pings when the number of pings to send (the **count** parameter) has been set to a high value, enter **Ctrl^C**.

Use the traceroute command to diagnose IP routing problems

Use the **traceroute** command to diagnose IP routing problems. This command traces the route to a remote IP host and displays results. The **traceroute** command differs from ping in that traceroute shows where the route fails, while ping simply returns a single error on failure.

See the traceroute command description for command syntax and examples. The **traceroute** command has several parameters. Only **host** is required.

- **host**: The IP address of the destination host.
- **bypass**: Send directly to a host on an attached network.
- **debug**: Enable socket level debugging.
- **dontfragment**: Do not fragment probe packets.
- **first**: ttl: Specifies with what TTL to start. (Default: 1)
- **gateway**: Route the packet through a specified gateway.
- **icmp**: Use ICMP ECHO for probes.
- **interface**: Specifies the interface.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- **qdscheckcsums**: Calculate ip checksums.
- **max ttl**: Specifies the maximum number of hops. (Default: 30)
- **nomap**: Do not map IP addresses to host names.
- **squeries**: Sets the number of probe packets per hop. (Default: 3)
- **packetlen**: Total size of the probing packet. (Default: -1)
- **pausemsecs**: Minimal time interval between probes (Default: 0)
- **port**: Specifies the destination port. (Default: -1)
- **src addr**: Chooses an alternative source address.
- **tos**: Set Type of Service. (Default: -1)
- **verbose**: Verbose output.
- **waittime**: Max wait for a response to a probe. (Default: 5)

Example

This example shows using **traceroute** to verify that the Connect EZ device can route to host **8.8.8.8** (www.google.com) through the default gateway. The command output shows that **15** routing hops were required to reach the host.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device's configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
2. At the Admin CLI prompt, use the **traceroute** command to view IP routing information.

```
> traceroute 8.8.8.8
traceroute to 8.8.8.8 (8.8.8.8), 30 hops max, 52 byte packets
 1  192.168.8.1 (192.168.8.1)  0 ms  0 ms  0 ms
 2  10.10.10.10 (10.10.10.10)  4 ms  2 ms  2 ms
 3  * 10.10.8.33 (10.10.8.33)  1 ms  1 ms
 4  96.34.84.22 (96.34.84.22)  1 ms  1 ms  1 ms
 5  96.34.81.198 (96.34.81.198)  3 ms  3 ms  3 ms
 6  * * *
 7  96.34.3.12 (96.34.3.12)  11 ms  11 ms  11 ms
 8  * * *
 9  8.8.8.8 (8.8.8.8)  11 ms  11 ms  11 ms
>
```

By entering a **whois** command on a Unix device, the output shows that the route is as follows:

1. **192/8**: The local network of the Connect EZ 4 WS device.
2. **192.168.8.1**: The local network gateway to the Internet.
3. **96/8**: Charter Communications, the network provider.
4. **216/8**: Google Inc.

Stop the traceroute process

To stop the traceroute process, enter **Ctrl-C**.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line interface

This chapter contains the following topics:

Access the command line interface 873
Log in to the command line interface 873
Exit the command line interface 874
Execute a command from the web interface 874
Display help for commands and parameters 875
Auto-complete commands and parameters 877
Available commands 878
Use the scp command 879
Display status and statistics using the show command 880
Device configuration using the command line interface 903
Execute configuration commands at the root Admin CLI prompt 903
Configuration mode 904
Command line reference 906

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Access the command line interface

You can access the Connect EZ 4 WS command line interface using an SSH connection, a telnet connection, or a serial connection. You can use an open-source terminal software, such as PuTTY or TeraTerm, to access the device through one of these mechanisms.

You can also access the command line interface in the WebUI by using the **Terminal**, or the Digi Remote Manager by using the **Console**.

To access the command line, your device must be configured to allow access, and you must log in as a user who has been configured for the appropriate access.

For further information about configuring access to these services, see:

- Serial: Serial port
- WebUI: Configure the web administration service
- SSH: Configure SSH access
- Telnet: Configure telnet access

Log in to the command line interface

Command line

1. Connect to the Connect EZ 4 WS device by using a serial connection, SSH or telnet, or the **Terminal** in the WebUI or the **Console** in the Digi Remote Manager. See Access the command line interface for more information.
   - For serial connections, the default configuration is:
     - 9600 baud rate
     - 8 data bits
     - no parity
     - 1 stop bit
     - no flow control
   - For SSH and telnet connections, the Setup IP address of the device is 192.168.2.1 on the **LAN** port.
2. At the login prompt, enter the username and password of a user with Admin access.

```
Login: admin
Password: ***********
```

   The default username is **admin**. The default unique password for your device is printed on the device label.
3. Depending on the device configuration, you may be presented with another menu, for example:

```
Access selection menu:

        a: Admin CLI
        q: Quit
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Select access or quit [admin] :
```

Type **a** or **admin** to access the Connect EZ 4 WS command line.

You will now be connected to the Admin CLI:

```
Connecting now...
 Press Tab to autocomplete commands
 Press '?' for a list of commands and details
 Type 'help' for details on navigating the CLI
 Type 'exit' to disconnect from the Admin CLI

>
```

See Command line interface for detailed instructions on using the command line interface.

Exit the command line interface

Command line

1. At the command prompt, type **exit**.

```
> exit
```

2. Depending on the device configuration, you may be presented with another menu, for example:

```
Access selection menu:

        a: Admin CLI
        q: Quit

Select access or quit [admin] :
```

Type **q** or **quit** to exit.

Execute a command from the web interface

Log into the Connect EZ 4 WS Web UI as a user with full Admin access rights.

1. At the main menu, click **Terminal**. The device console appears.

```
Connect EZ 4 WS login:
```

2. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.
   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.
   The Admin CLI prompt appears.

```
>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Display help for commands and parameters

The help command

When executed from the root command prompt, **help** displays information about autocomplete operations, how to move the cursor on the Connect EZ 4 WS command line, and other keyboard shortcuts.

```
> help

Commands
--------

?               Show commands help
<Tab>           Tab completion, displays all valid commands to complete command,
                if only one command is possible, it is used
<Space>         Like tab except shortest prefix is used if command is valid
<Enter>         Enter an input. If quitting then a new line is created instead. If
                the input is invalid then characters will be deleted until a
                prefix for a valid command is found.
Ctrl + A        Move cursor to start of line
Ctrl + E        Move cursor to end of line
Ctrl + W        Delete word under cursor until start of line or [\",", ,\,/,.]
Ctrl + X        If the current input is invalid then characters will be deleted
                until a prefix for a valid command is found.
Ctrl + left     Jump cursor left until start of line or [\",", ,\,/,.]
Ctrl + right    Jump cursor right until start of line or [\",", ,\,/,.]

>
```

The question mark (?) command

When executed from the root command prompt, **?** displays available commands.

```
> ?

Commands
--------

config          View and modify the configuration
exit            Exit the CLI
analyser        Analyser commands.
cp              Copy a file or directory.
grep            Grep a file.
help            Show CLI editing and navigation commands.
ls              List a directory.
mkdir           Create a directory.

more            View a file.
mv              Move a file or directory.
ping            Ping a host.
reboot          Reboot the system.
rm              Remove a file or directory.
scp             Copy a file or directory over SSH.
show            Show instance statistics.
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
system      System commands.
tail        Tail a file.
traceroute  Print the route packets trace to network host.
.

>
```

Display help for individual commands

When included with a command name, both **?** and **help** provide further information about the command. For example:

1. To display further information about the **show** command, type either **show ?** or **show help**:

```
> show ?

Commands
--------

arp             Show ARP tables.
cloud           Show drm statistics.
config          Show config deltas.
containers      Show container statistics.
dhcp-lease      Show DHCP leases.
dns             Show DNS servers.
event           Show event list.
ipsec           Show IPsec statistics.
l2tp            Show L2TP statistics.
l2tppath        Show L2TPv3 ethernet statistics.
location        Show location information.
log             Show syslog.
manufacture     Show manufacturer information.
modbus-gateway  Show modbus gateway status & statistics.
nemo            Show NEMO statistics.
network         Show network interface statistics.
ntp             Show NTP information.
openvpn         Show OpenVPN statistics.
route           Show IP routing information.
scep-client     Show SCEP client statistics.
serial          Show serial statistics.

system          Show system statistics.
version         Show firmware version.
wifi            Show Wi-Fi statistics.

> show
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Use the Tab key or the space bar to display abbreviated help

When executed from the root command prompt, pressing the **tab** key or the space bar displays an abbreviated list of available commands.

Similar behavior is available with any command name.

```
> config network interface <space>
..                ...                 setup ip          setup interface ip
loopback
> config network interface
```

Auto-complete commands and parameters

When entering a command and parameter, press the **tab** key to cause the command line interface to auto-complete as much of the command and parameter as possible. Typing the space bar has similar behavior. If multiple commands are available that will match the entered text, auto-complete is not performed and the available commands are displayed instead.

Auto-complete applies to these command elements only:

- Command names. For example, typing **net<Tab>** auto-completes the command as **network**.
- Parameter names. For example:
  - **ping hostname int<tab>** auto-completes the parameter as **interface**.
  - **system bk<tab>** auto-completes the parameter as **backup**.
- Parameter values, where the value is one of an enumeration or on/off type. For example:

```
(config)> serial port1 enable tr<Tab>
```

auto-completes to

```
(config)> serial port1 enable true
```

Auto-complete does not function for:

- Parameter values that are string types.
- Integer values.
- File names.
- Select parameters passed to commands that perform an action.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Available commands

The following commands are available from the Admin CLI prompt.

Command	Description
config	Used to view and modify the configuration. See Device configuration using the command line interface for more information about using the **config** command.
exit	Exits the CLI.
analyser	Analyser commands.
cat	View a file.
clear	Commands to clear the device's status or systems.
container	Create, delete, or interact with a container.
cp	Copies a file or directory.
grep	Grep a file.
help	Displays: • CLI editing and navigation commands, when executed from the root of the Admin CLI prompt. • Available commands, syntax diagram, and parameter information, when executed in conjunction with another command. See Display help for commands and parameters for information about the **help** command.
ls	Lists the contents of a directory.
mkdir	Creates a directory.
monitoring	Monitoring commands.
more	Displays the contents of a file.
mv	Moves a file or directory.
ping	Pings a remote host using Internet Control Message Protocol (ICMP) Echo Request messages.
poweroff	Powers off the system.
reboot	Reboots the Connect EZ 4 WS device.
rm	Removes a file.
scp	Uses the secure copy protocol (SCP) to transfer files between the Connect EZ 4 WS device and a remote host.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command	Description
	See Use the scp command for information about using the **scp** command.
show	Displays information about the device and the device's configuration. See Display status and statistics using the show command for more information about the show command.
ssert	Perform a speedtest.
ssh	SSH login to a remote server.
system	Issues commands related to system functionality.
tail	Tail a file.
telnet	Telnet login to a remote server.
traceroute	Sends and tracks route packets to a destination host.

Note For commands that operate on the Connect EZ 4 WS's file system, such as the **cp**, **ls**, and **mkdir** commands, see File system for information about the file system, including how to copy, move and delete files and directories.

Use the scp command

The **scp** command uses Secure Copy Protocol (SCP) to transfer files between the Connect EZ 4 WS device and a remote host.

Required configuration items

- The hostname or IP address of the remote host.
- The username and password of the user on the remote host.
- Whether the file is being copied to the Connect EZ 4 WS device from a remote host, or to the remote host from the Connect EZ 4 WS device.
  - If the file is being copied to the Connect EZ 4 WS device from a remote host:
    - The path and filename of the file on the remote host that will be copied to the Connect EZ 4 WS device.
    - The location on the Connect EZ 4 WS device where the file will be copied.
  - If the file is being copied to a remote host from the Connect EZ 4 WS device:
    - The path and filename of the file on the Connect EZ 4 WS device that will be copied to the remote host.
    - The location on the remote host where the file will be copied.

Copy a file from a remote host to the Connect EZ 4 WS device

To copy a file from a remote host to the Connect EZ 4 WS device, use the scp command as follows:

```
> scp host hostname-or-IP user username remote remote-path local local-path to local
```

where:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- hostname-or-ip is the hostname or IP address of the remote host.
- username is the name of the user on the remote host.
- remote-path is the path and filename of the file on the remote host that will be copied to the Connect EZ 4 WS device.
- local-path is the location on the Connect EZ 4 WS device where the copied file will be placed.

For example:

To copy firmware from a remote host with an IP address of 192.168.4.1 to the /etc/config directory on the Connect EZ 4 WS device, issue the following command:

```
> scp host 192.168.4.1 user admin remote /home/admin/bin/Connect EZ 4 WS-
20.5.bin local /etc/config/scripts to local
admin@192.168.4.1's password: adminpwd
Connect EZ 4 WS-20.5.bin                    100%   30MB    11.1MB/s    00:03
>
```

Transfer a file from the Connect EZ 4 WS device to a remote host

To copy a file from the Connect EZ 4 WS device to a remote host, use the scp command as follows:

```
> scp host hostname-or-ip user username remote remote-path local local-path to
remote
```

where:

- hostname-or-ip is the hostname or IP address of the remote host.
- username is the name of the user on the remote host.
- remote-path is the location on the remote host where the file will be copied.
- local-path is the path and filename on the Connect EZ 4 WS device.

For example:

To copy a support report from the Connect EZ 4 WS device to a remote host at the IP address of 192.168.4.1:

1. Use the **system support-report** command to generate the report.

```
> system support-report path /var/log/
Saving support report to /var/log/support-report-00408D133336-24-01-13-
12:10:00.bin
Support report saved.
>
```

2. Use the **scp** command to transfer the report to a remote host.

```
> scp host 192.168.4.1 user admin remote /home/admin/temp/ local
/var/log/support-report-00:40:8D:13:33:36-24-01-13-12:10:00.bin to remote
admin@192.168.4.1's password: adminpwd
support-report-00408D133336-24-01-13-12:10:00.bin
>
```

Display status and statistics using the show command

The Connect EZ 4 WS **show** command displays status and statistics for various features.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

For example:

show config

The show config command displays all the configuration settings for the device that have been changed from the default settings. This is particularly useful when troubleshooting the device.

```
> show config

auth tacacs+ service "login"
auth user admin password
"$2a$05$WT3Qhou37Ggsyrhpb8KhaeLPtmr.aGAHBcrlEa3jwOvGJIOWqrdOu"
add auth user test
add auth user test group end "admin"
add auth user test group end "serial"
auth user test password
"$2a$05$GdGrsLnLKBmrmGcZjlnL.orgbJJ8KnYeZoUVGTWlGPdtMaPZGW"
network interface lan ipv4 type "dhcp"
network interface lan zone "external"

schema version "440"

>
```

show system

The show system command displays system information and statistics for the device, including CPU usage.

```
> show system

  Model                    : Digi Connect EZ 4 WS
  Serial Number            : Connect EZ 4 WSxxxxxxxxyyyyyy
  SKU                      : Connect EZ 4 WS
  Hostname                 : Connect EZ 4 WS
  MAC Address              : DF:DD:E2:AE:31:1A

  Hardware Version         : 3000190C1-01 1P
  Firmware Version         : 25.6
  Alt. Firmware Version    : 25.3
  Alt. Firmware Build Date : Fri, Jan 12, 2024 12:12:08
  Bootloader Version       : 19.7.22.0-129938e4ed

  Current Time             : Thu, Jan 11, 2024 12:12:00 +0000
  CPU                      : 4.4%
  Uptime                   : 4 days, 8 hours, 21 minutes, 57 seconds (1441317s)
  Temperature              : 46C
  Location                 :
  Contact                  :

>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

show network

The show network command displays status and statistics for network interfaces.

```
> show network

Interface          Proto  Status   Address
-----------------  -----  -------  ------------------------------------
setupip            IPv4   up       192.168.210.1/24
setupip:6bclocalip IPv4   up       169.254.100.100/16
lan                IPv4   up       192.168.2.1
lan                IPv6   up       0:0:0:0:0:ffff:c0a8:201
loopback           IPv4   up       127.0.0.1/8

>
```

Device configuration using the command line interface

The **config** command allows for device configuration from the command line. All configuration tasks that can be performed by using the WebUI can also be performed by using the **config** command.

There are two ways to invoke the **config** command from the CLI:

- Execute the **config** command and parameters at the root prompt. See Execute configuration commands at the root Admin CLI prompt for more information.
- Enter configuration mode by executing the **config** command without any parameters. See Configuration mode for more information.

Execute configuration commands at the root Admin CLI prompt

You can execute the **config** command at the root Admin CLI prompt with any appropriate parameters. When the **config** command is used in this way, changes to the device's configuration are automatically saved when the command is executed.

For example, to disable the SSH service from the root prompt, enter the following command:

```
> config service ssh enable false
>
```

The Connect EZ 4 WS device's ssh service is now disabled.

Note When the **config** command is executed at the root prompt, certain configuration actions that are available in configuration mode cannot be performed. This includes validating configuration changes, canceling and reverting configuration changes, and performing actions on elements in lists. See Configuration mode for information about using configuration mode.

Display help for the config command from the root Admin CLI prompt

Display additional configuration commands, as well as available parameters and values, by entering the question mark (?) character after the **config** command.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line interface — Execute configuration commands at the root Admin CLI prompt

1. For example:

```
> config ?
```

Will display the following help information:

```
> config ?

Additional Configuration
------------------------------------------------------------------------------
..
application             Custom scripts
auth                    Authentication
cloud                   Central management
firewall                Firewall
monitoring              Monitoring
network                 Network
serial                  Serial
service                 Services
system                  System
vpn                     VPN

Run "config" with no arguments to enter the configuration editing mode.

> config
```

2. You can then display help for the additional configuration commands. For example, to display help for the **config service** command:

```
> config service ?
Services

Additional Configuration
------------------------------------------------------------------------------
..
dns                     DNS
mdns                    Service Discovery (mDNS)
multicast               Multicast
ntp                     NTP
remote_control          Remote control
snmp                    SNMP
ssh                     SSH
telnet                  Telnet
web_admin               Web administration

> config service
```

3. Next, display help for the **config service ssh** command:

```
> config service ssh ?

SSH: An SSH server for managing the device.
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
Parameters                  Current Value
-------------------------------------------------------------------------------
.
enable                      true            Enable
key                         [private]       Private key
port                        22              Port

Additional Configuration
-------------------------------------------------------------------------------
.
acl                         Access control list
mdns

> config service ssh
```

4. Lastly, display the allowed values and other information for the **enable** parameter:

```
> config service ssh enable ?

Enable: Enable the service.
Format: true, false, yes, no, 1, 0
Default value: true
Current value: true

> config service ssh enable
```

Configuration mode

Configuration mode allows you to perform multiple configuration tasks and validate the changes prior to saving them. You can cancel all changes without saving them at any time. Configuration changes do not take effect until the configuration is saved.

Enable configuration mode

To enable configuration mode, at the root prompt, enter the **config** command without any parameters:

```
> config
(config)>
```

When the command line is in configuration mode, the prompt will change to include **(config)**, to indicate that you are currently in configuration mode.

Enter configuration commands in configuration mode

There are two ways to enter configuration commands while in configuration mode:

- Enter the full command string from the config prompt.
  For example, to disable the ssh service by entering the full command string at the config prompt:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
(config)> service ssh enable false
(config)>
```

- Execute commands by moving through the configuration schema.

  For example, to disable the ssh service by moving through the configuration and then executing the **enable false** command:

  1. At the **config** prompt, enter **service** to move to the **service** node.

     ```
     (config)> service
     (config service)>
     ```

  2. Enter **ssh** to move to the **ssh** node.

     ```
     (config service)> ssh
     (config service ssh)>
     ```

  3. Enter **enable false** to disable the **ssh** service.

     ```
     (config service ssh)> enable false
     (config service ssh)>
     ```

  See Move within the configuration schema for more information about moving within the configuration.

Save changes and exit configuration mode

To save changes that you have made to the configuration while in configuration mode, use **save**. The save command automatically validates the configuration changes. The configuration will not be saved if it is not valid. Note that you can also validate configuration changes at any time while in configuration mode by using the **validate** command.

```
(config)> save
Configuration saved.
>
```

After using **save** to save changes to the configuration, you will automatically exit configuration mode. To return to configuration mode, type **config** again.

Exit configuration mode without saving changes

You can discard any unsaved configuration changes and exit configuration mode by using the **cancel** command.

```
(config)> cancel
>
```

After using **cancel** to discard unsaved changes to the configuration, you will automatically exit configuration mode.

Configuration actions

In configuration mode, configuration actions are available to perform tasks related to saving or canceling the configuration changes, and to manage items and elements in lists. The commands can be listed by entering a question mark (?) at the **config** prompt.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

The following actions are available:

Configuration mode action	Description
cancel	Discards unsaved configuration changes and exits configuration mode.
save	Saves configuration changes and exits configuration mode.
validate	Validates configuration changes.
revert	Reverts the configuration to default settings. See the revert command for more information.
show	Displays configuration settings.
add	Adds a named element, or an element in a list. See Manage elements in lists for information about using the **add** command with lists.
del	Deletes a named element, or an element in a list. See Manage elements in lists for information about using the **del** command with lists.
move	Moves elements in a list. See Manage elements in lists for information about using the **move** command with lists.

Display command line help in configuration mode

Display additional configuration commands, as well as available parameters and values, by entering the question mark (?) character at the **config** prompt. For example:

1. Enter ? at the **config** prompt:

```
(config)> ?
```

This will display the following help information:

```
(config)> ?

Additional Configuration

...

application             Custom scripts
auth                    Authentication
cloud                   Central management
firewall                Firewall
monitoring              Monitoring
network                 Network
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line interface Configuration mode

```
serial          Serial
service         Services
system          System
vpn             VPN

(config)#
```

2. You can then display help for the additional configuration commands. For example, to display help for the **config service** command, use one of the following methods:

   - At the **config** prompt, enter **service ?**:

     ```
     (config)# service ?
     ```

   - At the **config** prompt:

     a. Enter **service** to move to the **service** mode.

     ```
     (config)# service
     (config service)#
     ```

     b. Enter **?** to display help for the **service** mode.

     ```
     (config service)# ?
     ```

   Either of these methods will display the following information:

```
config# service ?

Services

  Additional Configuration

  dns                   DNS
  sdns                  Service Discovery (mDNS)
  multicast             Multicast
  ntp                   NTP
  remote_control        Remote control
  snmp                  SNMP
  ssh                   SSH
  telnet                Telnet
  web_admin             Web administration

(config)# service
```

3. Next, to display help for the **service ssh** command, use one of the following methods:

   - At the **config** prompt, enter **service ssh ?**:

     ```
     (config)# service ssh ?
     ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- At the **config** prompt:
  a. Enter **service** to move to the **service** node:

```
(config)> service
(config service)>
```

  b. Enter **ssh** to move to the **ssh** node:

```
(config service)> ssh
(config service ssh)>
```

  c. Enter **?** to display help for the **ssh** node:

```
(config service ssh)> ?
```

Either of these methods will display the following information:

```
(config)> service ssh ?

SSH: An SSH server for managing the device.

Parameters                Current Value
-------------------------------------------------------------------------------
--
enable                    true            Enable
key                       [private]       Private key
port                      22              Port

Additional Configuration
-------------------------------------------------------------------------------
--
acl                                       Access control list
exit

(config)> service ssh
```

4. Lastly, to display allowed values and other information for the **enable** parameter, use one of the following methods:
   - At the **config** prompt, enter **service ssh enable ?**

```
(config)> service ssh enable ?
```

   - At the **config** prompt:
     a. Enter **service** to move to the **service** node:

```
(config)> service
(config service)>
```

     b. Enter **ssh** to move to the **ssh** node:

```
(config service)> ssh
(config service ssh)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

c. Enter **enable ?** to display help for the **enable** parameter:

```
(config service ssh)> enable ?
(config service ssh)>
```

Either of these methods will display the following information:

```
(config)> service ssh enable ?

Enable: Enable the service,
Format: true, false, yes, no, 1, 0
Default value: true
Current value: true

(config)> service ssh enable
```

Move within the configuration schema

You can perform configuration tasks at the CLI by moving within the configuration.

- Move forward one node in the configuration by entering the name of an Additional Configuration option:
  1. At the **config** prompt, type **service** to move to the **service** node:

     ```
     (config)> service
     (config service)>
     ```

  2. Type **ssh** to move to the **ssh** node:

     ```
     (config service)> ssh
     (config service ssh)>
     ```

  3. Type **acl** to move to the **acl** node:

     ```
     (config service ssh)> acl
     (config service ssh acl)>
     ```

  4. Type **zone** to move to the **zone** node:

     ```
     (config service ssh acl)> zone
     (config service ssh acl zone)>
     ```

  You can also enter multiple nodes at once to move multiple steps in the configuration:

  ```
  (config)> service ssh acl zone
  (config service ssh acl zone)>
  ```

- Move backward one node in the configuration by entering two periods (..):

  ```
  (config service ssh acl zone)> ..
  (config service ssh acl)>
  ```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

You can also move back multiples nodes in the configuration by typing multiple sets of two periods:

```
(config service ssh acl zone)> .. .. ..
(config service)>
```

- Move to the root of the config prompt from anywhere within the configuration by entering three periods (...):

```
(config service ssh acl zone)> ...
(config)>
```

Manage elements in lists

While in configuration mode, you can use the **add**, **del**, and **move** action commands to manage elements in a list. When working with lists, these actions require an index number to identify the list item that will be acted on.

Add elements to a list

When used with parameters that contain lists of elements, the **add** command is used to add an element to the list.

For example, to add an authentication method:

1. Display current authentication method by using the **show** command:

```
(config)> show auth method
0 local
(config)>
```

2. Add an authentication method by using the **add index_item** command. For example:
   - To add the TACACS+ authentication method to the beginning of the list, use the index number **0**:

```
(config)> add auth method 0 tacacs+
(config)> show auth method
0 tacacs+
1 local
(config)>
```

   - To add the TACACS+ authentication method to the end of the list, use the **end** keyword:

```
(config)> add auth method end tacacs+
(config)> show auth method
0 local
1 tacacs+
(config)>
```

The end keyword

As demonstrated above, the **end** keyword is used to add an element to the end of a list. Additionally, the **end** keyword is used to add an element to a list that does not have any elements.

For example, to add an authentication group to a user that has just been created:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

1. Use the **show** command to verify that the user is not currently a member of any groups:

```
(config)> show auth user new-user group
(config)>
```

2. Use the **end** keyword to add the admin group to the user's configuration:

```
(config)> add auth user new-user group end admin
(config)>
```

3. Use the **show** command again to verify that the admin group has been added to the user's configuration:

```
(config)> show auth user new-user group
0 admin
(config)>
```

Delete elements from a list

When used with parameters that contains lists of elements, the **del** command is used to delete an element in the list.

For example, to delete an authentication method:

1. Use the **show** command to display current authentication method configuration:

```
(config)> show auth method
0 local
1 tacacs+
2 radius
(config)>
```

2. Delete one of the authentication methods by using the **del** *index_number* command. For example:
   a. To delete the local authentication method, use the index number **0**:

```
(config)> del auth method 0
(config)>
```

   b. Use the **show** command to verify that the local authentication method was removed:

```
(config)> show auth method
0 tacacs+
1 radius
(config)>
```

Move elements within a list

Use the **move** command to reorder elements in a list.

For example, to reorder the authentication methods:

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 891 / 927

TESSOL Technical Library
TS-TL-DGI-010

1. Use the **show** command to display current authentication method configuration:

```
(config)> show auth method
0 local
1 tacacs+
2 radius
(config)>
```

2. To configure the device to use TACACS+ authentication first to authenticate a user, use the **move** *index_number_1 index_number_2* command:

```
(config)> move auth method 1 0
(config)>
```

3. Use the **show** command again to verify the change:

```
(config)> show auth method
0 tacacs+
1 local
2 radius
(config)>
```

Enter strings in configuration commands

For string parameters, if the string value contains a space, the value must be enclosed in quotation marks. For example, to assign a descriptive name for the device using the **system** command, enter:

```
(config)> system description "Digi Connect EZ 4 WS"
```

Example: Create a new user by using the command line

In this example, you will use the Connect EZ 4 WS command line to create a new user, provide a password for the user, and assign the user to authentication groups.

1. Select the device in Remote Manager and click **Actions** > **Open Console**, or log into the Connect EZ 4 WS local command line as a user with full Admin access rights.

   Depending on your device configuration, you may be presented with an **Access selection menu**. Type **admin** to access the Admin CLI.

2. At the command line, type **config** to enter configuration mode:

```
> config
(config)>
```

3. At the config prompt, create a new user with the username **user1**:
   - Method one: Create a user at the root of the config prompt:

```
(config)> add auth user user1
(config auth user user1)>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Method two: Create a user by moving through the configuration

  a. At the config prompt, enter **auth** to move to the **auth** node:

  ```
  (config)> auth
  (config auth)>
  ```

  b. Enter **user** to move to the **user** node:

  ```
  (config auth)> user
  (config auth user)>
  ```

  c. Create a new user with the username **user1**:

  ```
  (config auth user)> add users
  (config auth user user1)>
  ```

4. Configure a password for the user:

```
(config auth user user1)> password pwd1
(config auth user user1)>
```

5. List available authentication groups:

```
(config auth user user1)> show .. .. group

admin
    acl
        admin
            enable true
        mgmt
            enable false
        openvpn
            enable false
            no tunnels
        portal
            enable false
            no portals
        serial
            enable false
            no ports
        shell
            enable false

serial
    acl
        admin
            enable true
        mgmt
            enable false
        openvpn
            enable false
            no tunnels
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

```
            portal
                enable false
                no portals
            serial
                enable true
                    ports
                        2 port1
            shell
                enable false
[config auth user user1]#
```

8. Add the user to the admin group:

```
[config auth user user1]# add group end admin
[config auth user user1]#
```

9. Save the configuration and apply the change.

```
[config auth user user1]# save
Configuration saved.
#
```

10. Type **exit** to exit the Admin CLI.

Depending on your device configuration, you may be presented with an **Access selection** menu. Type **quit** to disconnect from the device.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Command line reference

ain calibrate

Measure current value of analog input, and set it as zero offset.

Syntax

```
ain calibrate <name> <type> <setpoint>
```

Parameters

name: Name of the analog input.

type: Calibrate low or high-end of analog input range.

setpoint: Reference voltage/current connected on the analog input (in mV/uA). (Minimum: 0)

ain calibration-reset

Reset both voltage and current calibration of analog input.

Syntax

```
ain calibration-reset <name>
```

Parameters

name: Name of the analog input.

analyzer clear

Clears the traffic captured by the analyzer.

Syntax

```
analyzer clear <name>
```

Parameters

name: Name of the capture filter to use.

analyzer save

Saves the current captured traffic to a file.

Syntax

```
analyzer save <name> <path>
```

Parameters

name: Name of the capture filter to use.

path: The path and filename to save captured traffic to. If a relative path is provided, /etc/config/analyzer will be used as the root directory for the path and file.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

analyzer start

Start a capture session of packets on this device interface.

Syntax

```
analyzer start <name>
```

Parameters

name: Name of the capture filter to use.

analyzer stop

Stops the traffic capture session.

Syntax

```
analyzer stop <name>
```

Parameters

name: Name of the capture filter to use.

cat

View the contents of a file.

Syntax

```
cat <path>
```

Parameters

path: The file to view.

clear dhcp-lease ip-address

Clear the DHCP lease for the specified IP address.

Syntax

```
clear dhcp-lease ip-address <address>
```

Parameters

address: An IPv4 or IPv6 address.

clear dhcp-lease mac

Clear the DHCP lease for the specified MAC address.

Syntax

```
clear dhcp-lease mac ADDRESS
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Parameters

address: 12-digit, colon-delimited MAC address [00:11:22:AA:BB:CC]

cp

Copy a file or directory.

Syntax

```
cp <source> <destination> [force]
```

Parameters

source: The source file or directory to copy.
destination: The destination path to copy the source file or directory to.
force: Do not ask to overwrite the destination file if it exists.

dio state

Set digital I/O.

Syntax

```
dio state <name> <state>
```

Parameters

name: Name of the digital I/O.
state: State of the digital I/O.

grep

Grep the contents of a file.

Syntax

```
grep <match> <path>
```

Parameters

match: Output all lines in file matching string.
path: The file to grep.

help

Show CLI editing and navigation commands.

Syntax

```
help
```

Parameters

None.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

ls

List a directory.

Syntax

```
ls <path> [show-hidden]
```

Parameters

path: List files and directories under this path.

show-hidden: Show hidden files and directories. Hidden filenames begin with '.'.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

mkdir

Create a directory. Parent directories are created as needed.

Syntax

```
mkdir <path>
```

Parameters

path: The directory path to create.

monitoring metrics upload

Immediately upload current device health metrics. Functions as if a scheduled upload was triggered.

Syntax

```
monitoring metrics upload
```

Parameters

None

monitoring

Commands to clear the device's status or events.

monitoring metrics

Device metrics commands.

upload

Immediately upload current device health metrics. Functions as if a scheduled upload was triggered.

Parameters

None

monitoring metrics upload

Immediately upload current device health metrics. Functions as if a scheduled upload was triggered.

Syntax

```
monitoring metrics upload
```

Parameters

None

more

View a file.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Syntax

```
mkfs <path>
```

Parameters

path: The file to view.

mv

Move a file or directory.

Syntax

```
mv <source> <destination> [force]
```

Parameters

source: The source file or directory to move.

destination: The destination path to move the source file or directory to.

force: Do not ask to overwrite the destination file if it exists.

ping

Ping a host using ICMP echo.

Syntax

```
ping <host> [interface STRING] [source STRING] [ipv6] [size INTEGER] [count INTEGER] [broadcast]
```

Parameters

host: The name or address of the remote host to send ICMP ping requests to. If broadcast is enabled, can be the broadcast address.

interface: The network interface to send ping packets from when the host is reachable over a default route. If not specified, the system's primary default route will be used.

source: The ping command will send a packet with the source address set to the IP address of this interface, rather than the address of the interface the packet is sent from.

ipv6: If a hostname is defined as the value of the 'host' parameter, uses the host's IPV6 address.

size: The number of bytes sent in the ICMP ping request. (Minimum: 0, Default: 56)

count: The number of ICMP ping requests to send before terminating. (Minimum: 1, Default: 100)

broadcast: Enable broadcast ping functionality.

poweroff

Power off the system.

Syntax

```
poweroff
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Parameters

None

pyinstall

Pyinstall commands

Syntax

```
pyinstall <package>
```

Parameters

package: Path and filename of the package to install (.zip, .whl).

reboot

Reboot the system.

Parameters

None

rm

Remove a file or directory.

Syntax

```
rm <path> [force]
```

Parameters

path: The path to remove.

force: Force the file to be removed without asking.

scp

Copy a file or directory over SSH.

Syntax

```
scp <local> <remote> <host> <user> <to> [port <0-65535>] [legacy]
```

Parameters

local: The path and name of the file on the local device to copy to or from.

remote: The path and name of the file on the remote host to copy to or from.

host: The hostname or IP address of the remote host.

user: The username to use when connecting to the remote host.

to: Determines whether to copy the file from the local device to the remote host, or from the remote host to the local device.

port: The SSH port to use to connect to the remote host. (Minimum: 1, Maximum: 65535, Default: 22)

legacy: Use the original SCP protocol for file transfers instead of the SFTP protocol.

config directory: show command

Show a summary of changes made to the default configuration in a format that can be copied and pasted.

Note: The same information can be displayed using the show config command, but the display is not suitable for copying and pasting.

Syntax

```
> config
(config)> show
```

Parameters

None

show ain

Show analog input status.

Syntax

```
show ain [name <STRING>]
```

Parameters

name: Name of the analog input.

show analyzer

Show packets from a specified analyzer capture.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Syntax

```
show analyzer <name>
```

Parameters

name: Name of the capture filter to use.

show arp

Show ARP tables. If no IP version is specified IPv4 & IPv6 will be displayed.

Syntax

```
show arp [ipv4] [ipv6] [verbose]
```

Parameters

ipv4: Display IPv4 routes. If no IP version is specified IPv4 & IPv6 will be displayed.
ipv6: Display IPv6 routes. If no IP version is specified IPv4 & IPv6 will be displayed.
verbose: Display more information (less concise, more detail).

show bluetooth-scanner log

Show the Bluetooth scanner output log.

Syntax

```
show bluetooth-scanner log
```

Parameters

None

show bluetooth-scanner nearby

Show Bluetooth devices detected during the most recent update interval.

Syntax

```
show bluetooth-scanner nearby
```

Parameters

None

show bluetooth-scanner static-candidate

Show Bluetooth devices detected during the most recent observation period but not evaluated as static.

Syntax

```
show bluetooth-scanner static-candidate
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Parameters

None

show bluetooth-scanner static-confirmed

Show Bluetooth™ devices that have been evaluated as static.

Syntax

```
show bluetooth-scanner static-confirmed
```

Parameters

None

show cloud

Show cnn status & statistics.

Syntax

```
show cloud
```

Parameters

None

show config

Show a summary of changes made to the default configuration. The changes shown are not suitable for pasting into a CLI session.

Syntax

```
show config [cli_format]
```

Parameters

cli_format: Show the exact CLI commands required to configure the device from a default configuration. The changes shown are suitable for pasting into a CLI session, although individual output lines may be context sensitive and unable to be entered in isolation.

show containers

Show container status & statistics.

Syntax

```
show containers [container STRING]
```

Parameters

container: Display more details and config data for a specific container.

show dhcp-lease

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Show DHCP leases.

Syntax

```
show dhcp-lease [all] [verbose]
```

Parameters

all: Show all leases (active and inactive (not in /etc/config/dhcp "leases)).
verbose: Display more information (less concise, more detail).

show dio

Show digital I/O status.

Syntax

```
show dio [name STRING]
```

Parameters

name: Name of the digital I/O.

show dns

Show DNS servers and associated domains.

Syntax

```
show dns
```

Parameters

None

show eth

Show ethernet status & statistics.

Syntax

```
show eth [name STRING]
```

Parameters

name: Display more details and configuration data for a specific ethernet instance.

show event

Show event list (high level).

Syntax

```
show event [table <eventlevelcachinfo>] [number INTEGER]
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Parameters

table: Type of event log to be displayed (status, error, info).

number: Number of lines to retrieve from log. (Minimum: 1, Default: 20)

show hotspot

Show hotspot statistics.

Syntax

```
show hotspot [name STRING] [ip STRING]
```

Parameters

name: The configured instance name of the hotspot.

ip: IP address of a specific client, to limit the status display to only this client.

show ipsec

Show IPsec status & statistics.

Syntax

```
show ipsec [tunnel STRING] [all] [verbose]
```

Parameters

tunnel: Display more details and config data for a specific IPsec tunnel.

all: Display all tunnels including disabled tunnels.

verbose: Display status of one or all tunnels in plain text.

show l2tp lac

Show L2TP access concentrator status & statistics.

Syntax

```
show l2tp lac [name STRING]
```

Parameters

name: Display more details for a specific L2TP access concentrator.

show l2tp lns

Show L2TP network server status & statistics.

Syntax

```
show l2tp lns [name STRING]
```

Parameters

name: Display more details for a specific L2TP network server.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

show l2tpeth

Show L2TPv3 ethernet tunnel session status and statistics.

Syntax

```
show l2tpeth [name STRING]
```

Parameters

name: Display more details for a specific L2TPv3 ethernet tunnel session.

show location

Show location information.

Syntax

```
show location [geofence]
```

Parameters

geofence: Show geofence information.

show log

Show system log (raw level).

Syntax

```
show log [number <1-999>] [filter <critical|warning|info|debug>]
```

Parameters

number: Number of lines to retrieve from log. (Minimum: 1, Default: 20)

filter: Filters for types of log message displayed (critical, warning, info, debug). Note, filters from the number of messages retrieved not the whole log (this can be very time consuming). If you require more messages of the filtered type, increase the number of messages retrieved using 'number'.

show manufacture

Show manufacturer information.

Syntax

```
show manufacture [verbose]
```

Parameters

verbose: Display more information (see counters, more detail).

show modbus-gateway

Show modbus gateway status & statistics.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Syntax

```
show modbus gateway [verbose]
```

Parameters

verbose: Display more information (less concise, more detail).

show nemo

Show NEMO status and statistics.

Syntax

```
show nemo [name STRING]
```

Parameters

name: Display more details and configuration data for a specific NEMO instance.

show network

Show network interface status & statistics.

Syntax

```
show network [interface STRING] [all] [verbose]
```

Parameters

interface: Display more details and config data for a specific network interface.
all: Display all interfaces including disabled interfaces.
verbose: Display more information (less concise, more detail).

show ntp

Show NTP status & statistics.

Syntax

```
show ntp
```

Parameters

None

show openvpn client

Show OpenVPN client status & statistics.

Syntax

```
show openvpn client [name STRING] [all]
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Parameters

name: Display more details and config data for a specific OpenVPN client.

all: Display all clients including disabled clients.

show openvpn server

Show OpenVPN server status & statistics.

Syntax

```
show openvpn server [name STRING] [all]
```

Parameters

name: Display more details and config data for a specific OpenVPN server.

all: Display all servers including disabled servers.

show route

Show IP routing information.

Syntax

```
show route [ipv4] [ipv6] [verbose]
```

Parameters

ipv4: Display IPv4 routes.

ipv6: Display IPv6 routes.

verbose: Display more information (see counters, more detail).

show scep-client

Show SCEP client status and statistics.

Syntax

```
show scep-client [name STRING]
```

Parameters

name: Display more details and configuration data for a specific SCEP client instance.

show scripts

Show scheduled system scripts.

Syntax

```
show scripts
```

Parameters

None.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

show serial

Show serial status & statistics.

Syntax

```
show serial [port STRING]
```

Parameters

port: Display more details and config data for a specific serial port.

show system

Show system status & statistics.

Syntax

```
show system [verbose]
```

Parameters

verbose: Display more information (disk usage, etc).

show version

Show firmware version.

Syntax

```
show version [verbose]
```

Parameters

verbose: Display more information (build date).

show vrrp

Show VRRP status & statistics.

Syntax

```
show vrrp [name STRING] [all] [verbose]
```

Parameters

name: Display more details and config data for a specific VRRP instance.

all: Display all VRRP instances including disabled instances.

verbose: Display all VRRP status and statistics including disabled instances.

show web-filter

Show web filter status & statistics.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Syntax

```
show web-filter
```

Parameters

None

show wifi ap

Display details for Wi-Fi access points.

Syntax

```
show wifi ap [name STRING] [all]
```

Parameters

name: Display more details for a specific Wi-Fi access point.

all: Display all Wi-Fi access points including disabled Wi-Fi access points.

show wifi client

Display details for Wi-Fi client mode connections.

Syntax

```
show wifi client [name STRING] [all]
```

Parameters

name: Display more details for a specific Wi-Fi client mode connection.

all: Display all Wi-Fi clients including disabled Wi-Fi client mode connections.

show wifi-scanner

Show Wi-Fi scanner information.

wifi-scanner blocklist

Show transmitters that have been evaluated as static and not included in the output log.

Parameters

None

wifi-scanner candidates

Show transmitters detected during the most recent observation period but not evaluated as static.

Parameters

None

wifi-scanner log

Show output log for the last update interval.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Parameters

None

show wifi-scanner blocklist

Show transmitters that have been evaluated as static and not included in the output log.

Syntax

```
show wifi-scanner blocklist
```

Parameters

None

show wifi-scanner candidates

Show transmitters detected during the most recent observation period but not evaluated as static.

Syntax

```
show wifi-scanner candidates
```

Parameters

None

show wifi-scanner log

Show output log for the last update interval.

Syntax

```
show wifi-scanner log
```

Parameters

None

Iperf

Perform a speed test to a remote host using multiple or iperf. The system's primary default route will be used. The speed test will take approximately 30 seconds to complete.

Syntax

```
iperf <host> [size <bytes>] [mode <multiple|iperf>] [output <text|json>]
```

Parameters

host: The name or address of the remote speed test host/server.

size: The number of kilobytes sent in the speed test packets. (Minimum: 0, Default: 1000)

mode: The type of speed test protocol to run. (Default: multiple)

output: The format of output to display the speed test results as. (Default: text)

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

ssh

Use SSH protocol to log into a remote server.

Syntax

```
ssh <host> <user> [port INTEGER] [command STRING]
```

Parameters

host: The hostname or IP address of the remote host.

user: The username to use when connecting to the remote host.

port: The SSH port to use to connect to the remote host. (Minimum: 1, Maximum: 65535, Default: 22)

command: The command that will be automatically executed once the SSH session to the remote host is established.

system backup

Save the device's configuration to a file. Archives are full backups including generated SSH keys and dynamic DHCP lease information. Command backups are a list of CLI commands required to build the device's configuration.

Syntax

```
system backup [type <cli-config|archive>] [path STRING] [passphrase STRING]
```

Parameters

type: The type of backup file to create. Archives are full backups including generated SSH keys and dynamic DHCP lease information. CLI configuration backups are a list of CLI commands used to build the device's configuration. (Default: archive)

path: The file path to save the backup to. (Default: /var/tmp/)

passphrase: Encrypt the archive with a passphrase.

system cloud register

Register with Digi Remote Manager account.

Syntax

```
system cloud register <username> <password> [group STRING]
```

Parameters

username: Digi Remote Manager username.

password: Digi Remote Manager password.

group: Group to add device in Digi Remote Manager.

system custom-default-config current

Install the current configuration as a custom-default-config.tar file and generate the SHA file.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

TESSOL Technical Library TS-TL-DGI-010

Syntax

```
system custom-default-config current
```

Parameters

None

system custom-default-config file

Sets up a backup file as a custom-default-config.bin file and generates the SHA file.

Syntax

```
system custom-default-config file <path>
```

Parameters

path: Backup file to set up as a custom-default-config.bin file.

system custom-default-config remove

Removes the current custom-default-config.bin and SHA file.

Syntax

```
system custom-default-config remove
```

Parameters

None

system disable-cryptography

Erases the device's configuration and reboots into a limited mode with no cryptography available. The device's shell will be accessible over Telnet (port 23) at IP address 192.168.270.1. To return the device to normal operation, perform the configuration erase procedure with the device's CFG/Z button twice consecutively.

Syntax

```
system disable-cryptography
```

Parameters

None

system duplicate-firmware

Duplicates the running firmware to the alternate partition so that the device will always boot the same firmware version.

Syntax

```
system duplicate-firmware
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Parameters

None

system factory-erase

Erase the device to restore to factory defaults. All configuration and automatically generated keys will be erased.

Syntax

```
system factory-erase [force]
```

Parameters

force: Do not prompt for confirmation before erasing the configuration and rebooting the device.

system firmware update

Update the current firmware image. Upon reboot the new firmware will be run.

Syntax

```
system firmware update <file>
```

Parameters

file: Firmware filename and path.

system power ignition off_delay

Update the current ignition off delay without changing the configuration.

Syntax

```
system power ignition off_delay <off_delay>
```

Parameters

off_delay: Ignition power off delay. Format: number[time], Min: 10h, (Minimum: 1s, Maximum: 18h)

system restore

Restore the device's configuration from a backup archive or CLI commands file.

Syntax

```
system restore <path> [passphrase STRING]
```

Parameters

path: The path to the backup file.

passphrase: Decrypt the archive with a passphrase.

system script start

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Run a manual script. Scripts that are disabled, not a manual script, or already running can not be run.

Syntax

```
system script start <script>
```

Parameters

script: Script to start.

system script stop

Stop an active running script. Scripts scheduled to run again will still run again. (Disable a script to prevent it from running again.)

Syntax

```
system script stop <script>
```

Parameters

script: Script to stop.

system serial clear

Clears the serial log.

Syntax

```
system serial clear <port>
```

Parameters

port: Serial port.

system serial copy

Copy serial settings from a port to a list of ports.

Syntax

```
system serial copy <source> <destination> [all] [label] [base] [serial]
[session] [monitor] [service] [hangup] [autoconnect] [framing] [modem] [pos_
start] [usb] [mapping]
```

Parameters

source: The serial port to copy settings from.

destination: A list of serial ports to copy settings to. Example: 1-4,8-10 or all.

all: Copy all serial port settings.

label: Copy label setting.

base: Copy enable, mode, sharing, and signal settings.

serial: Copy baudrate, data bits, parity, stop bits, and flow control settings.

session: Copy escape, history, port sharing, and idle timeout settings.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

monitor: Copy signal change monitoring settings.
service: Copy SSH, TCP, and telnet service settings.
hangup: Copy hangup on signal loss settings.
autoconnect: Copy autoconnect settings.
framing: Copy data framing settings.
modem: Copy modem emulation settings.
ppp dialin: Copy PPP dial-in settings.
udp: Copy UDP serial settings.
logging: Copy logging settings.

system serial ipport

Set sequential IP port numbers for a service on a list of ports.

Syntax

```
system serial ipport <destination> <service> <base>
```

Parameters

destination: A list of serial ports to set IP port numbers. Example: 1-4,9-10 or all.
service: The service type to set IP port numbers.
base: Set service IP port numbers to base port + serial port number. (Minimum: 1, Maximum: 65535)

system serial restart

Delete and restart the serial log.

Syntax

```
system serial restart <port>
```

Parameters

port: Serial port.

system serial save

Saves the current serial log to a file.

Syntax

```
system serial save <port> <path>
```

Parameters

port: Serial port.
path: The path and filename to save captured traffic to. If a relative path is provided, /etc/config/serial will be used as the root directory for the path and file.

system serial show

Displays the serial log on the screen.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

we measure, we calibrate, we validate.
KOLAS 국제공인교정기관 · ISO/IEC 17025
㈜테솔 · www.tessol.com TS-TL-DGI-010 917 / 927
TESSOL Technical Library
TS-TL-DGI-010

Syntax

```
system serial show <port>
```

Parameters

port: Serial port.

system storage format

Format a device to the selected filesystem type.

Syntax

```
system storage format <device> <fstype>
```

Parameters

device: Storage device type.

fstype: Format to this filesystem type.

system storage mount

Mount a partition on the device.

Syntax

```
system storage mount <device> [partition INTEGER]
```

Parameters

device: Storage device type.

partition: The partition number to mount. (Minimum: 1, Default: 1)

system storage show

Display information about external devices.

Syntax

```
system storage show
```

Parameters

None.

system storage unmount

Unmount the device.

Syntax

```
system storage unmount <device>
```


원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Parameters

device: Storage device type.

system support-report

Save a support report to a file and include with support requests.

Syntax

```
system support-report [path STRING]
```

Parameters

path: The file path to save the support report to. (Default: /var/log/)

system time set

Set the local date and time using the timezone set in the system time timezone config setting.

Syntax

```
system time set <datetime>
```

Parameters

datetime: The date in year-month-day hour:minute:second format (e.g. "2021-09-28 12:24:48").

system time sync

Set the local time to the first enabled time source that returns valid time information.

Syntax

```
system time sync
```

Parameters

None

system time test

Test each enabled time source. This test will not affect the device's current local date and time.

Syntax

```
system time test
```

Parameters

None

tail

Tail a file to see its contents.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Syntax

```
tail <path> [timeout INTEGER] [filter STRING] [match STRING]
```

Parameters

path: The file to tail.

timeout: The amount of time in seconds to tail the file. (Default: 10)

filter: Only see output that contains this string.

match: Stop tail when this string is detected in output.

telnet

Use Telnet protocol to log into a remote server.

Syntax

```
telnet <host> [port INTEGER]
```

Parameters

host: The hostname or IP address of the remote host.

port: The telnet port to use to connect to the remote host. (Minimum: 1, Maximum: 65535, Default: 23)

traceroute

Print the route packets trace to network host.

Syntax

```
traceroute <host> [icmp] [gateway STRING] [interface STRING] [first_ttl
INTEGER] [max_ttl INTEGER] [port INTEGER] [nqueries INTEGER] [src_addr STRING]
[tos INTEGER] [waittime INTEGER] [pausemsecs INTEGER] [packetlen INTEGER]
[debug] [dontfragment] [bypass] [noroute]
```

Parameters

host: The host that we wish to trace the route packets for.

ipv6: If a hostname is defined as the value of the "host" parameter, use the host's IPV6 address.

gateway: Tells traceroute to add an IP source routing option to the outgoing packet that tells the network to route the packet through the specified gateway.

interface: Specifies the interface through which traceroute should send packets. By default, the interface is selected according to the routing table.

first_ttl: Specifies with what TTL to start. (Minimum: 1, Default: 1)

max_ttl: Specifies the maximum number of hops (max time-to-live value) traceroute will probe. (Minimum: 1, Default: 30)

port: Specifies the destination port base traceroute will use (the destination port number will be incremented by each probe). A value of -1 specifies that no specific port will be used. (Minimum: -1, Default: -1)

nqueries: Sets the number of probe packets per hop. A value of -1 indicates. (Minimum: 1, Default: 3)

src_addr: Chooses an alternative source address. Note that you must select the address of one of the interfaces. By default, the address of the outgoing interface is used.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

tos: For IPv4, set the Type of Service (ToS) and Precedence value. Useful values are 16 (low delay) and 8 (high throughput). Note that in order to use some TOS precedence values, you have to be super user. For IPv6, set the Traffic Control value. A value of -1 specifies that no value will be used. (Minimum: -1, Default: -1)

waittime: Determines how long to wait for a response to a probe. (Minimum: 1, Default: 5)

pausemsec: Minimal time interval between probes. (Minimum: 0, Default: 0)

packetlen: Total size of the probing packet. Default 60 bytes for IPv4 and 80 for Ipv6. A value of -1 specifies that the default value will be used. (Minimum: -1, Default: -1)

debug: Enable socket level debugging.

dontfragment: Do not fragment probe packets.

icmp: Use ICMP ECHO for probes.

nomap: Do not try to map IP addresses to host names when displaying them.

bypass: Bypass the normal routing tables and send directly to a host on an attached network.

vtysh

Opens the integrated shell for FRRouting (FRR). For more information on FRRouting and VTYSH, visit the FRRouting documentation at https://docs.frrouting.org/projects/dev-guide/en/latest/vtysh.html.

Syntax

vtysh [show STRING]

Parameters

show: Takes a `show` command input, returning the requested values.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Safety Information

For safe operation of the device, refer to the safety information in this guide.

Warnings, cautions, and notes

Where necessary, the documentation highlights any applicable warnings, cautions, or notes to help eliminate or avoid the risk of injury to individuals or damage to equipment. The following lists the levels of information:



CAUTION Indicates a hazard with a low level of risk, which, if not avoided, could result in minor to moderate injury or severe damage or malfunctioning of the equipment.



WARNING Indicates a hazard with a medium to high level of risk which, if not avoided, can result in death or serious injury.

Note Box indicates helpful information to assist the user, and to avoid the risk of damage to equipment described in this guide, and/or any other equipment or goods.

Important safety information

Smoke



WARNING In case of smoke disconnect device and discontinue use. To safely terminate operation of the Connect EZ 4 WS, disconnect the power cable and the Ethernet cable.

Avoid contact with electrical current



WARNING To avoid contact with an electrical current:

- Do not touch device if immersed in liquid.
- Do not touch device and discontinue use if enclosure is broken.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Never install electrical wiring during an electrical storm.
- Never install an Ethernet connection in wet locations unless that connector is specifically designed for wet locations.
- Use caution when installing or modifying lines.
- Use a screwdriver and other tools with insulated handles.
- Wear safety glasses or goggles.
- Do not place Ethernet wiring or connections in any conduit, outlet or junction box containing electrical wiring.
- As a best practice, mount the device server on a wall or place it on a tabletop away from high traffic areas. Keep cables out of reach and off the floor.
- Do not place power cable in walkways or anywhere it may receive heavy wear or be crushed, or where it may be a trip hazard.
- Only use screws included in the packaging.
- Do not connect, remove, or modify protectors or grounding wires; you must have a qualified service provider perform these tasks.
- Do not touch uninsulated Ethernet wiring if lightning is likely.
- External wiring: Any external communications wiring installed must be constructed to all relevant electrical codes. In the United States, follow the National Electrical Code, Article 800. Contact a licensed electrician for details.

Installation and configuration

WARNING! Verify correct installation and configuration.

- Position the Connect EZ 4 WS so that the power connector and power switch face up. Do not position the Connect EZ 4 WS within 15 centimeters (6 inches) of the equipment above it. Position the device so that it is easy to remove and reinsert the power mains cable and the Ethernet cable.
- Do not use a multiple socket-outlet or an extension cord to connect this device.
- Device provides a maximum of 1.5 KV of isolation power protection for Power over Ethernet. Installer must ensure connected devices provide additional isolation if required.
- The serial ports of the Connect EZ 4 WS shall only be connected to IEC61 Class 8a or 8b or IEC60 equipment.
- If using the Connect EZ 4 WS in a ME environment, connect only device items that have been specified as part of the ME system or specified as being compatible with the ME system.
- Do not use near any device that emits electromagnetic waves, such as large motors or electrosurgical equipment., or the data may be corrupted.
- Reciprocal interference may be caused during specific investigations or treatments. Do not use this equipment during diagnosis or treatment unless you have verified that no reciprocal interference is caused.
- Do not rely on this equipment as part of an alarm or alert system.
- Disconnect all devices from the device server before using diagnostic mode.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

- Install the device in secure networks with internal firewalls.
- Wi-Fi connections may be subject to unexpected interference and loss of signal.
- Check network configuration and serial connection mapping before using device for data transfer.

Connecting to IT networks

WARNING! Connecting to IT networks that include other equipment could result in previously unidentified risks to patients, operators, or third parties. The responsible organization shall identify, analyze, evaluate, and control these risks.

WARNING! Changes to the IT network could introduce new risks that require additional analysis. Changes to the IT network include:

- Network configuration changes
- Connecting additional items
- Disconnecting items
- Updating equipment including updates of firmware to the Connect EZ 4 WS
- Upgrading equipment

Security

CAUTION! Do not share or write down user names or passwords.

Magnetic fields

WARNING! Do not use this device in areas with high magnetic fields.

Equipment connections

WARNING! Do not connect the Ethernet cable to a serial port. Damage may occur to the serial pins, causing the device to malfunction.

CAUTION! This equipment should be connected only to other equipment compliant with IEC 60601 or IEC 62368.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Safety warnings

English



Operation of this equipment in a residential environment could cause radio interference.

Bulgarian–български



Работата с това оборудване в жилищна среда може да причини радиосмущения.

Croatian–Hrvatski



Rad ove opreme u stambenom okruženju mogao bi prouzročiti radio smetnje.

French–Français



L'utilisation de cet équipement dans un environnement résidentiel peut provoquer des interférences radio.

Greek–Ελληνικά



Η λειτουργία αυτού του εξοπλισμού σε οικιακό περιβάλλον μπορεί να προκαλέσει παρεμβολές ραδιοφώνου.

Hungarian–Magyar



A berendezés lakókörnyezetben történő működtetése rádiózavarokat okozhat.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Italian--Italiano



Il funzionamento di questa apparecchiatura in un ambiente residenziale potrebbe causare interferenze radio.

Latvian--Latvietis



Šīs iekārtas darbība dzīvojamā vidē var izraisīt radio traucējumus.

Lithuanian--Lietuvis



Naudojant šią įrangą gyvenamojoje aplinkoje, gali kilti radijo trukdžių.

Polish--Polskie



Praca tego sprzętu w środowisku mieszkalnym może powodować zakłócenia radiowe.

Portuguese--Português



A operação deste equipamento em um ambiente residencial pode causar interferência de rádio.

Slovak--Slovák



Prevádzka tohto zariadenia v obytnom prostredí by mohla spôsobiť rádiové rušenie.

Slovenian--Esloveno



Delovanje te opreme v stanovanjskem okolju lahko povzroči radijske motnje.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.

Spanish--Español



El funcionamiento de este equipo en un entorno residencial puede provocar interferencias de radio.

원문: Digi EZ04-WS00 사용설명서(영문) · 제조사 원문 자료입니다. 사양은 제조사 사정에 따라 변경될 수 있습니다.