## **DICKSON D115**

## **Specifications:**

**Range:**  $-58 \text{ to } +302^{\circ}\text{F} (-50 \text{ to } +150^{\circ}\text{C})$ 

Accuracy:  $\pm 2^{\circ}F$  ( $\pm 1^{\circ}C$ ) between -58 to  $\pm 392^{\circ}F$  (-50 to 200°C) otherwise, more then  $\pm 4^{\circ}F$  ( $\pm 2^{\circ}C$ )

Resolution: 0.1° between -19.9 to 199.9, otherwise 1°

Sample Rate: 1 second

**Battery:** 1 pc x 1.5 volt type LR44 or equivalent

Probe Size: 125 mm

Ambient Temperature:  $+14 \text{ to } +122^{\circ}\text{F} (-10 \text{ to } +50^{\circ}\text{C})$ 

## Manual:

- Automatic power off after 10 minutes
- Press "ON/OFF" button once to switch OFF the thermometer
- Press and hold "C/F" button about 4 seconds, then release, to change the temperature unit
- TO clear memory, press "ON.OFF" button once to switch OFF the thermometer
- Battery Replacement: Open the battery cover b swirling counter-clockwise, replace the battery, then close the battery cover tightly by swirling clockwise
- Note: not to be used inside an oven or microwave oven
  Probe cover should not be used to stir high temperature substances.

## **Ordering Information**

DescriptionOrder No.Digital ThermometerD115