

Titan S8-CAN Portable Data Acquisition Logger



PRODUCT USER GUIDE

To view the full MadgeTech product line, visit our website at **madgetech.com**.



TABLE OF CONTENTS2 Product Overview5 User Interface14 Logging Data17 Viewing Data19 Managing Data24 Device Settings27 SAE Parameters29 Specifications32 Index33 Need Help?





PRODUCT OVERVIEW



Device Overview

The Titan S8-CAN is compatible with diesel engines that use SAE J1939 CAN communication protocol. The Titan-CAN connects to the vehicle via the J1939 diagnostic port and has the ability to monitor/record up to 23 active SPNs (suspect parameter numbers). In addition to CAN measurements, this versatile logger measures and records temperature, current, voltage and pulse simultaneously and displays data in real-time. The Titan S8-CAN is compatible for use with many thermocouple, RTD or thermistor probes as well as a number of voltage output sensors, current switches, transmitters and transducers.

The Titan S8-CAN is helpful for allowing diesel technicians and fleet owners with preventative and predictive maintenance with their fleet of vehicles. It's touchscreen user interface allows for easy set up and configuration.

The Titan S8-CAN is a powerful, independent tool. Unlike other data loggers, the Titan S8-CAN delivers an all-in-one data collection and monitoring solution that does not require a PC or any downloaded software for operation.



Tabletop Kickstand •

Mounting Keyholes

• Power Button: To power on and power off the device, hold down the Power button for 3 seconds.

*If device doesn't power on after 3 seconds and the battery is charged, hold down the power button for 20 seconds to reset the system.

- Home Button: The Home button will return the user to the home screen (details on page 5).
- Input Ports: The Titan S8-CAN features 8 sensor channel inputs plus one alarm port and a ground (details on pages 3-4).
- LCD Touchscreen: 5 inch LCD capacitive touchscreen.
- USB Port: The Titan S8-CAN has a built-in USB port for connecting the CAN converter (details on page 4) and downloading data to a flash drive.
- Power Input: Charging port.

PRODUCT OVERVIEW



Device Orientation

The Titan S8-CAN display can rotate 180 degrees depending on the desired orientation of the device. This option is available from the Settings menu under the Display section. *Please note: Power restart required in order to apply screen rotation.*

Desktop Orientation

For handheld and tabletop use, the inputs will be on the top. Note port number as it relates to device orientation.



Wall Mount Orientation

For wall mount use the unit will be rotated so that the inputs will be on the bottom.



Tabletop Orientation

The Titan S8-CAN features a built in kickstand on the back of the device for use on flat surfaces.



Device Ports

The Titan S8-CAN features 10 ports. Please refer to the images above for the port number as it relates to device orientation.

Channels and Functions

- Ports 1 thru 8 are sensor input channels (Temperature, Current or Voltage)
- Port 9 serves as an alarm output
- Port 10 serves as a ground for the device

Frequency or Pulse Counter Can only be used on port 1

3-Wire and 4-Wire PT100 RTD Sensors Use ports 1-2, 3-4, 5-6, or 7-8

2-Wire PT100 RTD Sensors Can be used on ports 1-8

PRODUCT OVERVIEW



Powering, Charging and Downloading Data



CAN to Vehicle Connection





CAN Connections are made by connecting CAN converter to USB port. Diagnostic cable is then plugged into the 9-pin DIN connector and plugged into the vehicle.



Top Menu Bar

The top bar of the Titan S8-CAN Interface features status icons and useful information to refer to while using the device.

| | | | External Memory | CAN B Adapter De | | |
|--|-----------|---------------|--------------------|---------------------|-----------------------|----------|
| TITAN S8-CAN | MADGETECH | () | ₽₽ | | 4 🗖 | 03 06 PM |
| Logging Session Indicator | | Alarm Set | Inter | nal Memory | Batter | |
| Inactive Delayed Start Configured Actively Logging | | | | 97% Full 🕂 | Charging Indicator | |

Home Screen

Home Button

The Home screen will display the following options when the Home button is selected.

- **Channel Configuration:** Configure parameters and options for each channel.
- Real-Time: Quickly view Real-Time data for all active channels.
- **Start Logging:** Start logging using current settings. (Stop logging if device is actively logging.)
- **Current Session:** View data from the current logging session as graph, tabular or real-time.
- Data Storage: View, Copy, Delete and Add notes to logged sessions.
- System: Access device preferences and options.



External Memory

The External Memory icon is also a button for screen capture. Press the icon to save screen images to the attached USB drive. Images are saved in the pictures folder.



CAN

CAN Bus Adapter Detected

CAN Bus driver is opened and ready to receive Will turn from yellow to green once the Update button in the Channel Configuration Screen has been pressed.

AN CAN Bus adapter has been removed If the USB CAN Bus adapter is removed while data logging is active then data logging is automatically terminated and a popup alert message is displayed. In this case, the red CAN icon will flash for a couple of seconds before going blank.





First Time Use

Follow these steps when the device is powered on for the first time.



3


SELECT SCREEN ORIENTATION

For desktop use, inputs are facing upward. For wall mounted use, inputs are facing downward.



4

SET INITIAL DATE AND TIME Enter the local date and time and select **Next**.



2


SCREEN READY Wait for the device to initiate, you will see the MadgeTech logo when complete.



4

SET INITIAL TIME ZONE

Enter the local time zone to be used by the device and select **Next**. Available in version v4.7 or later.






When the device presents the Home screen it is ready to use.





Channel Configuration


When the Channel Configuration icon is selected, the device will display the screen shown below:



- Channel 1-8: Configures the type of channel input, units, engineering units (if applicable), alarms and user calibration adjustments. Channel 1 cannot be used for CAN.
- Channel 9-24: Channels 9-24 are for CAN measurements. Channels 2-24 can be programmed for Active or All SPNs.
- **Update:** Applies the current channel configuration to make the device ready to start logging or display real-time data.
- File: Loads previously saved channel configurations.
- **Save:** Saves the current channel configuration so it may be loaded and used later.
- Disable All: Clears the configuration of all channels, returning them to the default disabled status.
- Cancel: Cancels changes and then goes back to the Home screen.

Channel Setup

When the user selects a Channel, the device will display the Channel Setup screen with several options:



Select Channel Configuration

- Disable (Channel is not being used)
- RTD (RTD probe)
- TC (Thermocouple probe)
- Voltage
- Current
- Thermistor (Thermistor probe)
- Can Bus
- Pulse (Only available on channel 1)



Swipe Left for Channels 9-24




Measurement Setup

When the user selects a Measurement Parameter, the device will display the relevant options for that selection. The example below shows the SAE J1939 CAN Bus options:

| TITAN S8-CAN MADGETECH SPN 38 Fuel Level 2 | CAN CO 03 06 PM | Select the Measurement butt screen of relevant measureme | |
|--|--|---|---|
| SPN 51 Engine Throttle Position | SPN 90 Power Takeoff Oil Temp | For CAN, selecting the Measur a list of all or active SPNs. | ement button will bring up |
| SPN 52 Engine Intercooler Temp | SPN 91 Accelerator Position | | |
| SPN 80 Washer Fluid Level | Cancel | | |
| Back | Next | | |
| TITAN 58-CAN MADRIFECH | © TITAN SB-CAN MADRETECH € CAN © 03 06 PM Channel Configuration | TITAN SB-CAN MADETICH 💽 CAN 🗆 03 06 PM. Channel 2 Setup | TITAN SB-CAN МАЛАГТСН САН С 03 06 РМ Channel 2 Setup |
| Channel Configuration Rest-Time Start Logging | 1 Disabled Disabled Disabled | O Disadole RTD TC Voltage Current Th | Disable Image: Constant Disable RTD TC Voltage Current Thermister |
| | 5 6 7 8 Disabled Disabled Disabled | Measurement > Units > Add Alarm Supported SPNs: @ All _ Active | Supported SPNs: Vills Add Alarm |
| Current Session Data Storage System Select Channel Configuration | Update File Save Disable All Cancel Select Channel | Apply Cancel Select Measurement Parameter | Apply Cancel Select Measurement Type |

Measurement Units

When the user selects the Units button, the device will display a pop-up menu of the corresponding options for that selection. The example below shows the Temperature options:





Engineering Units

Engineering Units can be applied to any channel measuring Voltage, Frequency or Pulse to display readings in a user selected custom unit of measure.

| Gain | Offset | |
|---------------------|--------------|--|
| Value | Value | |
| Unit of Measurement | Abbreviation | |
| Descriptive | Symbolic | |
| | | |

- Gain: User selected gain value.
- Offset: User selected offset value.
- Unit of Measurement: Desired unit to be measured.
- Abbreviation: User defined abbreviation.
- Apply: Saves the settings.
- File: Retrieves a previously saved Engineering Unit setting.
- **Save:** Saves the Engineering Unit setting for future use.
- Wizard: Allows the user to set up units by entering the input and output values for low and high scale points. The unit will automatically calculate the gain and offset the from these values.
- **Cancel:** Cancels Engineering Unit configuration and returns the user to the Channel Configuration screen.





Select Measurement Units

Select Engineering Units

🖽 03 06 PM

Titan S8-CAN

USER INTERFACE

Setting Up Engineering Units

| eering Unit (V) | | | | Channel 1 Engineerin | ng Unit (V) | and the second | |
|-----------------|-------------------------|-----------------------|--------------------------|-----------------------------|---|---|---|
| Offset | | 7 | | Gain | Offset | 4 | |
| nent Abbrevia | | | | Unit of Measurement | Abbreviation | | |
| Symbolic | | 1 | | PRESSURE | PSI | | |
| File S | Save | Wizard | Cancel | Apply File | e Sav | Wizard | Cancel |
| | value Abbrevia Symbolic | Abbreviation Symbolic | Abbreviation Symbolic | Value Abbreviation Symbolic | Value Value Ment Abbreviation Symbolic PRESSURE | Value Value Nent Abbreviation Symbolic PRESSURE | Value value value Value Value Unit of Measurement Abbreviation PRESSURE PSI |

Enter the unit of measurement and abbreviation.

Click the **Wizard** button to launch the Engineering Unit Wizard.

to apply the changes to current logging session.

| TITAN S8-CAN Channel 1 Engine | MADGETECH eering Unit Wizard | 🚓 CAN 🗆 03 06 | Channel 1 Engineer | ing Unit (V) | CAN | 🗔 03 06 PM |
|---------------------------------------|---------------------------------|-----------------------------|--------------------------------|--|--------|------------|
| | Input (V) | Output (PSI) | Gain | Offset | X | |
| Low Scale Point: | Value | Value | 100 | 0 | | |
| High Scale Point: | Value | Value | Unit of Measuremen PRESSURE | t Abbreviation | | |
| | Apply | Cancel | Apply F | ile Save | Wizard | Cancel |
| Enter the low click Apply . | and high scale p | oint inputs and outputs and | U U | set are automaticall ering units to the cha | - | |





Keyboard Function

When the user taps in any text field within the interface, the keyboard will appear. The numeric keypad appears when the Gain and Offset fields are selected. The keyboard appears when Unit of Measurement and Abbreviation fields are selected.

To prevent the keyboard from obscuring content, the screen will always focus on the selected field and bring it into view. Once the text field is complete, the user can tap anywhere on the screen and the keyboard will disappear from view.


| TITAN S8-CA | AN MADGE | ГЕСН | ₽ | CAN | 🔲 03 06 PM |
|--------------|----------|------------|----|-----|------------|
| Gain | | Offset | | _ | |
| 62.5 | | -250 | | | |
| Unit of Meas | surement | Abbreviati | on | | |
| ppm | | ppm | | | |
| | 7 | 8 | 9 | × | |
| | 4 | 5 | 6 | • | |
| | 1 | 2 | 3 | | |
| | 0 | • | Ļ | | |

An external keyboard can also be used by plugging it into the USB port on the device.

| Q | w | Е | R | т | Υ | U | - | 0 | Р |
|---|------|---|---|---|---|---|---|---|---|
| A | S | D | F | G | н | J | к | L | |
| + | z | х | С | v | в | N | М | • | × |
| ? | 1234 | | | | | | | Ļ | |

Alarms

Users can create one alarm configuration per channel with up to two alarm values per channel (above and below threshold):



- Above: Indicates the high reading threshold at which above the alarm becomes active
- Below: Indicates the low reading threshold at which below the alarm becomes active.
- Enabled/Disabled: Tap the button to either enable or disable the text field to enter desired alarm value.
- Disable All: Clears the alarm settings.
- Apply: Applies the setting to the current channel.
- Cancel: Cancels changes and then returns the user to the Channel Configuration screen.



Select Channel Configuration


Select Channel






Factory Calibration

The Titan S8-CAN includes a complete Factory Calibration feature that provides users with the ability to adjust the calibration settings per channel and revert back to the factory settings at any time. *Note:* For best performance and accuracy, Factory Calibration should be performed by MadgeTech at least once every 12 months.



Channel Configuration Overview

An example of a completed channel configuration screen is shown below.:



Apply Channel Configuration

Once channels are configured as desired, the user must then select **Update** to use those settings.

A pop-up as shown to the right will confirm that settings have been applied.



- View Wiring Diagram: Shows how to properly wire the device.
- Green Channel: Enabled channel.
- Orange Channel: Disabled channel.
- Linked Channels / Gray Channels: 3 or 4 wire RTD sensor types can be selected for Channels 1, 3, 5 and 7. This sensor type will also occupy the next sequential channel and will be visually represented with a Link icon as seen between Channels 3 and 4 on the screen to the left.
- **Update:** Once the user has configured the channel settings, this button will apply the current settings to all channels.
- File: Loads previously saved configurations.
- **Save:** Saves the current Channel Configuration so it may be loaded and used in the future.
- **Disable All:** Clears the programmed channels to disable all.
- **Cancel:** Cancels user changes and then goes back to the Home screen.



Save Configuration Settings

Completed channel configurations can be saved for repeated use. The user can select **Save** from the channel configuration screen to select a name for the saved settings file and apply them.

Load Configuration Settings

Saved channel configurations can be easily loaded for repeated use. The user can select File from the channel configuration screen to choose from the list of previously saved settings files. **Note:** *Loading a saved settings file will replace the existing configuration.*

| TITAN S8-CAN MADGETECH | 순 CAN 🗔 03 06 PM | TITAN S8-CAN MADGETECH | 도 CAN 🗔 03 06 PM |
|-------------------------------------|--|---|--|
| Save Settings | | Channel Settings | |
| Name File Name | | Building02Pref | Created 08/09/2018 10:33 AM |
| The Name | | FilePrefVoltage02 | Created 08/09/2018 10:33 AM |
| | | TestAnalysis03 | Created 08/09/2018 10:32 AM |
| | | Voltage_Channel_2 | Created 08/09/2018 10:34 AM |
| Apply | Cancel | Load | Delete Cancel |
| | ITAN S&-CAN MADestream CAN CO 03 06 PM Unamel Configuration CAN CO 03 06 PM User Weing Column User Weing Column Consider by Clis Consider by Clis Co | TITAN SG-CAN MddsdTeor Image: Control of the state of | M TITAN 58-CAN MAGGETECH Channel Configuration Channel Configurati |
| Current Session Data Storage System | Update Disable All Cancel Select Save | Current Session Data Storage System | UI File Save Disable All Cancel Select File |

Wiring Diagram

From the channel configuration screen, the user can select the Wiring Diagram button to display the proper wiring of the unit based on the currently applied configuration. *Please note the position of channel 1 in regards to screen orientation.*




LOGGING DATA



Start Logging

When **Start Logging** is selected from the **Home** screen, the **Logging Configuration** screen will appear and the user will be prompted to name the data logging session. If the user has not already configured the channels, they will be prompted to configure prior to starting a logging session. The user will be able to configure start time, stop time, and reading rate in addition to naming the logging session.




- Session Name: Enter the desired name for the logging session. If no name is given, a unique default name will be assigned (i.e. Session 1).
- **Delayed Start:** To set a logging start time in the future, select delayed start. To start logging immediately, select the Start Logging button at the bottom of this screen.
- Automatic Stop: The user has the option of selecting an Automatic Stop time. If no time is selected, the user will use the Stop Logging button on the Home screen to manually stop the device.
- **Reading Rate:** The reading rate will default to 10 seconds or use the setting of the last session configuration.
- **Start Logging Data:** Begins logging data session. If delay start has been set, the logging session will begin on the selected date and time.
- **Cancel:** Cancels user configuration and returns back to the Home screen.

NOTE: Maximum number of readings per session is 1,000,000 or 5,000,000 (user selectable in System/File Format).

Delayed Start

Selecting **Delayed Start** will bring up the following configuration screen:




- **Day:** Using the up and down arrows, the user is able to adjust the day.
- Hour: Using the up and down arrows, the user is able to adjust the hour.
- **Minute:** Using the up and down arrows, the user is able to adjust the minute.
- **am/pm:** Using the up and down arrows, the user is able to select am or pm (12-hour clock only).
- **Apply:** Applies the start or stop time settings and returns the user back to the Logging Configuration screen.
- **Cancel:** Cancels the start time settings and returns the user to the Logging Configuration screen.

LOGGING DATA



Automatic Stop

Selecting Automatic Stop will bring up the following configuration screen:



- Day: Use the up and down arrows to adjust the day.
- Hour: Use the up and down arrows to adjust the hour.
- Minute: Use the up and down arrows to adjust the minute.
- **am/pm:** Use the up and down arrows to select am or pm (12 -hour clock only).
- **Apply:** Applies the start or stop time settings and returns the user back to the Logging Configuration screen.
- **Cancel:** Cancels the stop time settings and returns the user to the Logging Configuration screen.

Reading Rate

 TITAN S8-CAN MADGETECH 💶 03 06 PM ₽ CAN 4 Hz 1 Second 2 Seconds 5 Seconds 10 Seconds 15 Seconds 30 Seconds 1 Minute Apply Cancel TITAN S8-CAN Logging Configuration Session Example 1 p: 11:36 am, Aug 10 Select Start Logging Select Reading Rate

When the user selects **Reading Rate**, the following configuration screen will appear. Once the desired reading rate is selected, the user must select **Apply** to use that option, or **Cancel** to return to the previous screen. See **page 31** for available reading rates.

LOGGING DATA



Review Session Details and Start Logging

Once the user selects a Session Name, Start Time, Stop Time and Reading Rate, the screen will look similar as it does below. Once the settings are complete, the user will select **Start Logging** to begin **Logging Mode**. After selecting **Start Logging**, the user will be brought to the **Home** screen.


Device Memory Warning

After selecting **Start Logging**, if the internal memory of the device is 100% full, the user will be notified with a pop-up warning message and two options to choose from. This warning will also appear if the internal memory of the device reaches 100% capacity while actively logging.

| TITAN S8-CAN MADGETECH CAN CON 03 06 PM Logging Configuration | 🔵 TITAN S8-CAN MADGETECH 🚭 🧮 CAN 🗔 03 06 P |
|--|--|
| Session Name Session Example 1 | Device Memory Full The device memory is 100% full. Move or |
| | |
| Start Logging Cancel | |
| | • View Stored Sessions: Takes the user to the Data Storage screen to delete or remove stored data from the device. |
| | • Dismiss: Returns the user back to the Home screen and logging will not start. |

Stop Logging

To manually stop a logging session, the user will select the **Stop Logging** button from the **Home** screen. *Note:* Access the Home screen at any time by pressing the Home button.




VIEWING DATA



Real-Time Data

When **Real-Time** is selected from the **Home** screen, the device will display data from all enabled channels and update at the user selected reading rates. The Real-time view is also available from the Current Session menu when the device is actively logging.




03 06 PN **Configuration Warning**

Real-Time data is only available if the device channels are configured.

Current Session — Graph View

Select the Current Session button from the Home screen to view the recorded data in various formats, swipe the screen to the left or right to navigate. This view can only be used or seen while actively logging.



Graph View

- Use the drop down menus at the top to select which channels to view.
- Touch any point on the graph line to display more detailed information.
- Triggered alarm events will be visible within the graph.
- Start/Stop Button: Stop the current screen display to analyze the data. Restarts the screen to go back to real time display on the graph.

Swipe Options

- Swipe left at the top of the screen to go to the tabular data view.
- Swipe within the graph to scroll through the graph timeline.

Select Current Session

Swipe to Navigate


VIEWING DATA



Current Session – Tabular View

Select the **Current Session** button from the **Home** screen to view the recorded data in various formats, swipe the screen to the left or right to navigate. This view can only be used or seen while actively logging.

| Current Data R | cuangs | | | |
|----------------|-----------|-----------|-----------|-----------------|
| TIME | CH 1 (mV) | CH 2 (mA) | CH 3 (°C) | CH 4 (Occupied) |
| MINIMUM | 236.129 | 0.0001 | 26.57 | |
| MAXIMUM | 404.517 | 0.0003 | 26.70 | |
| AVERAGE | 283.006 | 0.0002 | 26.62 | |
| 10:39:58 AM | 282.513 | 0.0002 | 26.62 | |
| 10:39:59 AM | 282.520 | 0.0002 | 26.62 | |
| | 282.517 | 0.0002 | 26.60 | |
| 10:40:00 AM | | | | |



| | CH 2 SPN 100 | > CH 3 : | SPN 11 | _î> | |
|---------|--------------|----------|------------------|-----------------|----|
| psi | | | | mb. | |
| 81 | | | | 97 | |
| 79 | | | *F | 95 | |
| π | | 08:05 | 40 PM (2018 | 93 | 11 |
| 76 | | | | 91 | |
| 74 | | 00 | $\sim \sim \sim$ | <u>→ → → 90</u> | 11 |
| 73 0-0- | • • • • • | | ~~~~~ | | |
| 71 0-0- | 000 | | | 86 | |
| 69 | | | | 84 | |
| 68 | | | | 82 | |

Select Current Session

Swipe Left to View Tabular Data

for the current session.Readings that exceeded user selected thresholds/

• Displays the Minimum, Maximum and Average values

- Readings that exceeded user selected thresholds/ alarms are displayed as red.
- Scroll vertically to see data timeline in tabular format.
- View four channels at a time.
- Swipe left at the top of the screen to see additional active channels.
- Pressing on the Time heading will change it from Time to Number.

| urrent Data R | eadings | | | | |
|---------------|-----------|-------------|-----------|-----------------|---|
| TIME | CH 1 (mV) | CH 2 (mA) | CH 3 ("C) | CH 4 (Occupied) | |
| MINIMUM | 236.129 | 2001 | 26.57 | | |
| MAXIMUM | 404.517 | $ \subset $ | 26.70 | | |
| AVERAGE | 283.006 | | 26.62 | | |
| 10:39:58 AM | 282.513 | 0.0002 | 26.62 | | 1 |
| 10:39:59 AM | 282.520 | 0.0002 | 26.62 | | 1 |
| 10:40:00 AM | 282.517 | 0.0002 | 26.60 | | |
| 10:40:01 AM | 282.460 | 0.0001 | 26.60 | | |
| 10:40:02 AM | 282.529 | 0.0001 | 26.60 | | |

| TITAN S8-CAN | MADGETECH | - - | CAN | 💶 03 06 P |
|----------------|----------------------|-----------------|----------|-----------|
| Current Data I | Readings | — <u>\</u> | | |
| TIME | CH 5 (Disabled) | mb | CH 7 (V) | CH 8 ("C) |
| MINIMUM | | | 0.879 | 44.38 |
| MAXIMUM | | \sim | 1.735 | 44.38 |
| AVERAGE | | | 1.562 | 44.38 |
| 10:39:58 AM | | | 1.729 | 44.38 |
| 10:39:59 AM | | | 1.733 | 44.38 |
| 10:40:00 AM | | | 1.730 | 44.38 |
| 10:40:01 AM | | | 1.729 | 44.38 |
| 10:40:02 AM | | | 1.733 | 44.38 |

Swipe Vertically to Scroll Timeline

Swipe Left for Additional Active Channels

Additional Views

Swipe left and right to rotate through the various screens.

Graph View > Tabular Views > Real-Time View > Current Session Overview

Note: Use the swipe navigation of data views for both current and stored sessions.



Data Storage

Selecting the **Data Storage** icon will bring up the screen pictured below. Stored sessions are displayed in a scrollable list. Swipe vertically to browse the list. Session Information includes the name of the session, the start time and date of the session, and the number of readings. The options available on this screen include the following:

| TAN S8-CAN | MADGETECH | € ⁴ u | CAN | O 3 | 06 PN |
|-----------------|---|--|--|--|--|
| a Storage | INT | 99% EXT | 969 | 6 22 SES | SIONS |
| | NAME | STAI | RT TIME | READING | s |
| Session Two | | 2019-1 | 1-16 11:04 | 1,132 | |
| Session 22 | | 2019-1 | 1-16 10:37 | 252 | |
| Session 21 | | 2019-1 | 1-16 10:25 | 2,772 | |
| Session 19 | | 2019-1 | 1-16 10:20 | 17 | |
| Session 18 | | 2019-1 | 1-16 10:09 | 41 | |
| Session 17 | | 2019-1 | 1-16 09:54 | 3,496 | |
| Session 15 | | 2019-1 | 1-16 09:13 | 580 | |
| Session 14 | | 2019-1 | 1-16 09:06 | 1,480 | |
| | Delete All | Ejec | t USB | | |
| 3-CAN MADGETECH | - CAN 🗇 03 0 | | | | 03 06 22 SESSION |
| | | # | NAME | START TIME | READINGS |
| X | | 1 Session Two | | 2019-11-16 11:04 | 1,132 |
| | Session Two Session 22 Session 21 Session 19 Session 18 Session 17 Session 15 Session 14 | A Storage INT NAME Session Two Session 22 Session 21 Session 19 Session 18 Session 17 Session 15 Session 14 Delete All | A Storage INT 99% EXT NAME Session Two Session 22 2019-1 Session 21 2019-1 Session 19 2019-1 Session 19 2019-1 Session 18 2019-1 Session 18 2019-1 Session 14 2019-1 Session 15 2019-1 Session 14 2019-1 Session 15 2019-1 Session 16 2019-1 Session 17 2019-1 Session 17 2019-1 Session 18 2019-1 Session 19 | INT 99% EXT 96% NAME START TIME Session Two 2019-11-16 11:04 Session 22 2019-11-16 10:37 Session 21 2019-11-16 10:25 Session 19 2019-11-16 10:25 Session 19 2019-11-16 10:20 Session 19 2019-11-16 10:20 Session 18 2019-11-16 10:09 Session 17 2019-11-16 09:13 Session 15 2019-11-16 09:13 Session 14 2019-11-16 09:06 | INT 99% EXT 96% 22 SESS NAME START TIME READING Session Two 2019-11-16 11:04 1,132 Session 22 2019-11-16 10:37 252 Session 21 2019-11-16 10:25 2,772 Session 19 2019-11-16 10:25 2,772 Session 19 2019-11-16 10:20 17 Session 19 2019-11-16 10:20 17 Session 19 2019-11-16 00:94 3,496 Session 17 2019-11-16 09:13 580 Session 15 2019-11-16 09:13 580 Session 14 2019-11-16 09:06 1,480 |



- **INT:** Available percentage of internal memory remaining on the device.
- **EXT:** Available percentage of memory remaining on the external USB drive.
- Number of Sessions: The total number of stored sessions on the device.
- Session Information: Tap on any row to view session specific options.
- **Delete All:** Erases all stored sessions from the internal memory.
- **Eject USB:** Select this button prior to removing the external USB drive.

Storage Space

Every channel configured is considered a separate reading, so the number of readings divided by the number of channels gives you the readings per channel. Maximum number of readings per session is 1,000,000 or 5,000,000 user selectable in Device Settings.

| Thermocouple Channels: | Millivolt, Volt, RTD, Thermistor (NTC), Milliamp channels: | Frequency/Counter (Single Channel): |
|--|---|--|
| 1 Hz or slower — 62,000,000 to 150,000,000 readings (depends on number of configured channels) in 1,000,000 or 5,000,000 reading increments. | 1 Hz or slower — 93,000,000 to 164,000,000 readings (depends on number of configured channels) in 1,000,000 or 5,000,000 reading increments. | 1 Hz or slower — 93,000,000 readings in 1,000,000 or 5,000,000 reading increments. |
| • 4 Hz or faster — 80,000,000 to 150,000,000 readings (depends on number of configured channels) in 1,000,000 or 5,000,000 reading increments. | 4 Hz or faster — 150,000,000 to 173,000,000 readings (depends on number of configured channels) in 1,000,000 or 5,000,000 reading increments. | |



Saved Session Options

From the **Data Storage** screen, tap on any row in the list to select a specific session to view options. The **Session Options** screen features four actions the user can take on any stored session:



- **Copy:** Copies the stored session to an external USB drive. If no USB drive is plugged into the device, the Copy button will not display.
- View Data: Views the data of this session in tabular or graph view.
- View/Edit Note: Add notes or comments to the session. Also allows the user to change the Session name (v4.7 or later).
- **Delete:** Removes the stored session from the device.

Copy Stored Sessions

Select Data Storage

Sessions can be copied from the internal device memory to an external USB drive. When the **Copy** option is selected, the **Copy Stored Session** pop-up will appear to confirm the user's request.



Note: Data can be saved to external memory as .csv and/or .mtb file format (user selectable in System/File Format).

- **Copy Data:** The session is copied to the external USB drive.
- **Cancel:** Cancels the copy and takes the user back to the Options screen.





View Data Sessions

When the **View Data** option is selected, the user is presented with the **Tabular Data** view of that session. From this screen the user can swipe left and right to navigate other views of the recorded data from that session (see swipe navigation options on **page 18**).

| | adings | | | |
|-------------|----------|-----------|-----------------|----------------|
| TIME | CH 1 (V) | CH 2 (mA) | CH 3 (Disabled) | CH 4 (Disabled |
| MINIMUM | 0.198 | 0.0004 | | |
| MAXIMUM | 0.366 | 0.0007 | | |
| AVERAGE | 0.338 | 0.0005 | | |
| 02:50:41 PM | 0.342 | 0.0005 | | |
| 02:50:51 PM | 0.341 | 0.0005 | | |
| 02:51:01 PM | 0.341 | 0.0006 | | |
| 02:51:11 PM | 0.341 | 0.0005 | | |
| 02:51:21 PM | 0.340 | 0.0005 | | |

Playback mode is available in tabular Data form or in the graphing mode.

| TITAN 58-CAN MADGETECH | - | CAN 🖼 03 06 PM | Data Storage | | 99% EXT 1 | 03 06 PM 22 SESSIONS | TITAN S8-C | N MADGETECH | 4 | CAN 🗂 03 06 PM |
|------------------------|--------------|----------------|------------------------------|-------|--------------------------------------|---|---|-------------|-------------|----------------|
| | | | 1 | NAME | START TIME 2019-11-16 11-04 | READINGS | Session 2 | 3 | | |
| | | | 2 Session 2 | | 2019-11-16 10.37 2019-11-16 10.25 | 252 | the second se | | | |
| Channel Configuration | Real-Time | Start Logging | 4 Session 19 | | 2019-11-16 10:20 2019-11-16 10:09 | 17 | Copy | View Dat | a View/Edit | |
| N (| | \odot | 6 Session 17 7 Session 18 | | 2019-11-16 09:54 2019-11-16 09:13 | 3,496 580 | | | | |
| Current Session | Data Storage | System | 8 Session 14 | | 2019-11-16 09:06 | 1,480 | | | Cancel | |
| Select | : Data Sto | rage | | Selec | t a Session | | | Selec | t View Dat | ta |

View/Edit Note and Session Name

When the **View/Edit Note** option is selected, the user is presented with a text entry screen. Text entered here is stored as a note associated with a particular session. This can be accessed and edited by users as desired.

| AN S8-CAN MAD | GETECH •ਿੰ⇔ | CAN 🗔 0 | 3 06 PM | TAN S8-CAN MADGETECH | CAN |
|-------------------------|------------------------------|--------------------------------------|-----------------|----------------------|--------------------------------------|
| | | | | Edit Session Name | |
| Add Note for | Session Two | > | | Session Two | |
| Press here to sta | rt entering text. | | | | |
| And pross horo to | o stop entering text. | | | Apply | Cancel |
| And press here d | o stop entering text. | | | | |
| | | | | TAN 58-CAN MADGETECH | CAN |
| | | | Dat | a Storage | 99% EXT 99% |
| | | | | NAME | START TIME |
| | | | | sion 54 | 2018-08-09 10:39 |
| | | | | sion 52 sion 51 | 2018-08-05 14:51 2018-08-03 15:58 |
| | | | | sion 50 | 2018-07-31 18:10 |
| | | | | sion 49 | 2018-07-30 16:08 |
| | 0 | Cancel | Ses | sion 48 | 2018-07-27 18:40 |
| | Save | Cancel | Ses | sion 47 | 2018-07-26 18:45 |
| | | | Ses | sion 46 | 2018-07-25 18:33 |
| | | | | Delete All | Eject USB |
| CAN MADGETECH | CAN 💷 03 06 PM 🔵 TITAN S8-C/ | N MADGETECH - CAN | 💷 03 06 PM 🔍 TI | TAN 58-CAN MADGETECH | CAN |
| AREA AREAN | Data Storage | | 6% 22 SESSIONS | | |
| | | NAME START TIME | READINGS | Session 23 | |
| | | 2019-11-16 11:04 | 1,132 | | |
| | 2 Session | 2019-11-16 10:37 | 252 | | |
| Configuration Real-Time | Start Logging 3 Session 21 | 2019-11-16 10:25 | 2,772 | | |
| | 4 Session 19 | 2019-11-16 10:20 | 17 | | E |
| | 5 Session 18 6 Session 17 | 2019-11-16 10:09 2019-11-16 09:54 | 41 3,496 | Copy View Data | View/Edit |
| | 7 Session 17 | 2019-11-16 09:54 2019-11-16 09:13 | 580 | | |
| | 8 Session 14 | 2019-11-16 09:06 | 1,480 | _ | |
| nt Session Data Storage | System | | | | Cancel |
| | | Delete All Eject USB | | | |
| Select Data Stor | age | Select a Session | | Select Vi | ew/Edit Note |
| | arc | JEIELL & JESSIOII | | JEIECL VI | EVV/LUILING |

User also has the ability to change the Session name in this section (v4.7 or later).

Note Flag

🔲 03 06 PM

03 06 PM

🔲 03 06 PM

When a note has been added to a logging session, a notes icon appears in the list of sessions.


Delete a Note

To delete a note, edit to remove all text and click **Save**.




Delete Stored Session

When the **Delete** session option is selected, the user is presented with a pop-up screen confirming the request:



Delete All

If a user selects the **Delete All** option, they will be presented with a confirmation screen. Selecting **Cancel** will return the user to the **Data Storage** screen and the stored data will not be deleted.







Deleting Stored Data Confirmation


When Delete Data is selected a pop-up screen will display a progress bar and confirm when action is complete. After data is successfully removed the user will be returned to the Data Storage screen.

Warning: Deleting a session is a permanent action.



No Stored Sessions

Before first use or after all data has been deleted, the **Data Storage** screen on the device will resemble the screen shown below:




FFT User Capabilities

The Titan S8-CAN will automatically calculate FFT for users in real time providing exact frequencies to make post analysis data easily available for both vibrational and electrical applications.

To enable FFT go to **System** (Device Settings/Display). FFT is available to view in both current sessions and stored sessions. To view FFT in a current session, select the **Current Session** icon and select the desired channel to be viewed. From the upper left-hand corner, select the red FFT button to view the real-time FFT monitoring.

To view FFT in a stored session, select the **Data Storage** button from the home screen. From the **Data Storage** tab, select the desired stored session to be viewed. Select **View Data** from the options panel. Once the graph is visible, select the red FFT button to view FFT monitoring from a stored session. 2,048 data readings have to be recorded before FFT will plot.



TITAN S8-CAN MADGETECH ţ 03 06 PM CH 1 (V) Return 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 0.000 125.00 Hz 250.00 Hz 375.00 Hz 0.00 Hz 500.00 Hz

Select Data Storage

Select Stored Session to View

DEVICE SETTINGS



Device Settings

When the **System** button is selected from the **Home** screen, the user is presented with options, preferences and information as shown below. The **System** panel displays an overview of information specific to the device. Network settings appear in v5.0 or later.

| TITAN S8-CAN | MADGE | TECH 🚅 | CAN | 🗔 03:06 PM |
|-----------------|-------|----------------------|------|----------------|
| Device Settings | | Hardware Version | | D.4.0.A.4.0 |
| 🌣 System | | Software Version | K.6. | 02.C.1.0.A.4.2 |
| 🖹 File Format | > | | | |
| 🗎 Date & Time | > | Serial Number | | R34285 |
| 🔅 Display | > | Internal Memory Used | | 4.9 MB |
| 🏟 Alarms | > | Internal Memory Free | | 1,501.7 MB |
| 🔥 CAN Bus | > | Stored Sessions | | 9 |
| ? Help | > | | | |
| ථ Power | > | Factory Calibration | | 06/05/2020 |

- Hardware Version
- Software Version
- Serial Number
- Internal Memory Used and Available
- Number of Stored Sessions
- Factory Calibration Date




| Select System |
|---------------|
|---------------|

| TITAN S8-CAN | MADGE | :ТЕСН 🕂 САМ 🗔 03 07 РМ |
|-----------------|-------|----------------------------------|
| Device Settings | | USB Flash File Format |
| 🌣 System | > | ✓ CSV Spreadsheet |
| 🖹 File Format | | мтв |
| 菌 Date & Time | > | Both |
| 🔅 Display | > | Data Logging File Readings Limit |
| 🏟 Alarms | > | 🕑 1 Million |
| 🕂 CAN Bus | > | 5 Million |
| ? Help | > | |
| ථ Power | > | |

File Format

Data from the Titan S8-CAN can be saved to external memory in one of two formats.

- USB Flash File Format: .csv spreadsheet, .mtb file or both.
- Data Logging File Readings Limit: Choose between 1 million or 5 million file readings limit.




Date & Time

The **Date & Time** screen will display the current date and time as well as provide the user with 12-Hour or 24-Hour clock options and time zone settings. Except for time zone UTC and "International Date Line West", a selected time zone may automatically support Daylight Saving Time. Arizona does not support DST so "Disable DST" has to be checked and "Mountain Time (US & Canada)" selected when in Arizona.

DEVICE SETTINGS





TITAN S8-CAN MADGETECH • 03 08 PM **Device Settings External Alarm** 🏟 System > Always Mute Temporary Mute 🖹 File Format > **Contact Closure Contact Signal** 菌 Date & Time Pulse Normally Opened 🔅 Display > Normally Closed Latch 🈩 Alarms 👗 CAN Bus > ? Help Σ () Power

Display

The **Display** screen allows the user to adjust options for the touch-screen display including:

- Display Brightness: User adjustable screen brightness level.
- Graph background: Select white or black.
- Graph FFT: Select enable or disable.
- Display Backlight: User selectable timeout period.
- **Display Orientation:** Changing the display orientation requires a reboot of the device.

Alarms


The **Alarms** screen provides the user with two **Contact Closure** options for when an alarm is triggered.

- Always/Temporary Mute
- Contact Closure: Normally Open / Closed
- Contact Signal: Pulse / Latch
- Status: Shows if there are any alarms triggered.

CAN Bus

The CAN Bus screen allows the user to set up CAN Bus options.

- CAN Bus Speed: 250K / 500K
- J1939 Transmit: Disable / Enable
- Engine Number: One or Two
- SPN Faults List



DEVICE SETTINGS



| TITAN S8-CAN | Madge | ETECH 🔂 C | AN 🗔 03:08 PM |
|-----------------|-------|----------------------------|-----------------------------------|
| Device Settings | | A | |
| 🗘 System | > | | ETECH DATA LOGGERS |
| 🖹 File Format | > | Sales & General Inquiries: | (603) 456-2011 |
| 🗐 Date & Time | > | Toll Free: | (877) 671-2885 |
| 🔅 Display | > | Technical Support: | (603) 746-8202 |
| Alarms | > | Fax: | (603) 456-2012 |
| ÷ Alams | - | Website: | madgetech.com |
| 👗 CAN Bus | > | Mailing Address: | MadgeTech, Inc. |
| ? Help | | - | 6 Warner Road Warner, NH 03278 |
| ථ Power | > | Made in | USA |

| TITAN S8-CAN | MADGETECH | CAN | 🗔 03:09 PM |
|-----------------|-----------|---------------|------------|
| Device Settings | | | |
| 🗱 System | > | | |
| 🖹 File Format | > | Sleep | |
| 🗐 Date & Time | > | | |
| 🔅 Display | > | Power Off | |
| 🎓 Alarms | > | | |
| 👗 CAN Bus | > | Factory Reset | |
| ? Help | > | | |
| ථ Power | | | |

Help

Provides MadgeTech's contact information to the user.

Power

Provides sleep mode, power off via screen and factory reset.

Warning: Factory reset will restore the unit to Factory Settings. This will delete all saved sessions and configurations.

SAE PARAMETERS



SAE J1939 Parameters

The Titan S8-CAN supports 55 suspect parameter numbers (SPN).

| SPN | PARAMETER NAME | PGN Parameter Group No. | DESCRIPTION Per SAE J1939 Documentation | TITAN PARAMETER Displayed Name in Configuration | UNIT OF MEASURE Displayed in Titan S8-CAN |
|-----|---|--------------------------------------|---|---|---|
| 38 | Fuel Level 2 | 65276 | When Fuel Level 2 (SPN 38) is not used, Fuel Level 1 represents the total fuel in all fuel storage containers. When Fuel Level 2 is used, Fuel Level 1 represents the fuel level in the primary or left-side fuel storage container | Fuel Level 2 | 0-100%, Engineering Units |
| 51 | Engine Throttle Valve 1 Position | 65266 | The position of the valve used to regulate the supply of a fluid, usually air or fuel/air mixture, to an engine. 0% represents no supply and 100% is full supply. | Engine Throttle Position | 0-100%, Engineering Units |
| 52 | Engine Intercooler Temperature | 65262 | Temperature of liquid found in the intercooler located after the turbocharger. | Engine Intercooler Temp | °C, °F, K |
| 80 | Washer Fluid Level | 65276 | Ratio of volume of liquid to total container volume of fluid reservoir in windshield wash system. | Washer Fluid Level | 0-100%, Engineering Units |
| 84 | Wheel-Based Vehicle Speed | 65265 | Speed of the vehicle as calculated from wheel or tailshaft speed | Wheel-Based Speed | Kilometers per hour, miles per hour, knots |
| 90 | Power Takeoff Oil Temperature | 65264 | Temperature of lubricant in device used to transmit engine power to auxiliary equipment. | Power Takeoff Oil Temp | °C, °F, K |
| 91 | Accelerator Pedal Position 1 | 61443 | Accelerator Pedal Position 1 | Accelerator Position | 0-100%, Engineering Units |
| 92 | Engine Percent Load At Current Speed | 61443 | Engine Percent Load At Current Speed | Engine Percent Load | 0-100%, Engineering Units |
| 94 | Engine Fuel Delivery Pressure | 65263 | Gage pressure of fuel in system as delivered from supply pump to the injection pump. See also SPN 5578 for Fuel | Engine Fuel Pressure | PSI, megapascal, kilopascal, bar |
| 96 | Fuel Level 1 | 65276 | Ratio of volume of fuel to the total volume of fuel storage container. When Fuel Level 2 (SPN 38) is not used, Fuel Level 1 represents the total fuel in all fuel storage containers. | Fuel Level 1 | 0-100%, Engineering Units |
| 97 | Water In Fuel Indicator | 65279 | Signal which indicates the presence of water in the fuel | Water in Fuel Indicator | Numberic code |
| 98 | Engine Oil Level | 65263 | Ratio of current volume of engine sump oil to maximum required volume. | Engine Oil Level | 0-100%, Engineering Units |
| 100 | Engine Oil Pressure | 65263 | Gage pressure of oil in engine lubrication system as provided by oil pump. | Engine Oil Press | PSI, megapascal, kilopascal, bar |
| 101 | Engine Crankcase Pressure | 65263 | Gage pressure inside engine crankcase. | Engine Crankcase Press | PSI, megapascal, kilopascal, bar |
| 102 | Engine Intake Manifold #1 Pressure | 65270 | The gage pressure measurement of the air intake manifold. If there are multiple air pressure sensors in the intake stream, this is the last one in flow direction before entering the combustion chamber. This should be the pressure used to drive gauges and displays. | Intake Manifold Press | PSI, megapascal, kilopascal, bar |
| 103 | Engine Turbocharger 1 Speed | 65245 | Rotational velocity of rotor in the turbocharger. | Turbocharger Speed | PSI, megapascal, kilopascal, bar |
| 104 | Engine Turbocharger Lube Oil Pressure 1 | 65245 | Gage pressure of oil in turbocharger lubrication system. | Turbocharger Oil Press | PSI, megapascal, kilopascal, bar |
| 105 | Engine Intake Manifold 1 Temperature | 65270 | Temperature of pre-combustion air found in intake manifold of engine air supply system. | Intake Manifold Temp | °C, °F, K |
| 109 | Engine Coolant Pressure | 65263 | Gage pressure of liquid found in engine cooling system. | Engine Coolant Press | PSI, megapascal, kilopascal, bar |
| 110 | Engine Coolant Temperature | 65262 | Temperature of liquid found in engine cooling system. | Engine Coolant Temp | °C, °F, K |
| 111 | Engine Coolant Level | 65263 | Ratio of volume of liquid found in engine cooling system to total cooling system volume. Typical monitoring location is in the coolant expansion tank. | Engine Coolant Level | 0-100%, Engineering Units |
| 114 | Net Battery Current | 65271 | Net flow of electrical current into/out of the battery or batteries. | Net Battery Current | Amps |
| 115 | Alternator Current | 65271 | Measure of electrical current flow from the alternator. Alternator Current (High Range/Resolution) parameter SPN 1795 has a higher range and resolution of the same parameter. | Alternator Current | Amps |
| 116 | Brake Application Pressure | 65274 | Gage pressure of compressed air or fluid in vehicle braking system measured at the brake chamber when brake shoe (or pad) is placed against brake drum (or disc). | Brake Application Press | PSI, megapascal, kilopascal, bar |
| 117 | Brake Primary Pressure | 65274 | Gage pressure of air in the primary, or supply side, of the air brake system | Brake Primary Press | PSI, megapascal, kilopascal, bar |
| 118 | Brake Secondary Pressure | 65274 | Gage pressure of air in the secondary, or service side, of the air brake system | Brake Secondary Press | PSI, megapascal, kilopascal, bar |
| 124 | Transmission Oil Level 1 | 65272 | First instance of a transmission oil level indicator. Conveys the ratio of volume of transmission sump oil to recommended volume | Transmission Oil Level | 0-100%, Engineering Units |
| 127 | Transmission Oil Pressure | 65272 | Gage pressure of lubrication fluid in transmission, measured after pump | Transmission Oil Press | PSI, megapascal, kilopascal, bar |
| 157 | Engine Injector Metering Rail 1 Pressure | 65243 | The gage pressure of fuel in the primary, or first, metering rail as delivered from the supply pump to the injector metering intake. | Engine Injector 1 Press | PSI, megapascal, kilopascal, bar |

SAE PARAMETERS



SAE J1939 Parameters (cont'd)

The Titan S8-CAN supports 55 suspect parameter numbers (SPN).

| SPN | PARAMETER NAME | PGN Parameter Group No. | DESCRIPTION Per SAE J1939 Documentation | TITAN PARAMETER Displayed Name in Configuration | UNIT OF MEASURE Displayed in Titan S8-CAN |
|------|---|--------------------------------------|---|---|---|
| 158 | Keyswitch Battery Potential | 65271 | Battery potential measured at the input of the electronic control unit supplied through a keyswitch or similar switching device. | Battery Voltage (Combined with SPN 168) | Volts |
| 167 | Charging System Potential (Voltage) | 65271 | Electrical potential measured at the charging system output. The charging system may be any device charging the batteries. This includes alternators, generators, solid state charger and other charging devices. | Charging System | Volts |
| 168 | Battery Potential / Power Input 1 | 65271 | This parameter measures the first source of battery potential as measured at the input of the ECM/actuator etc. coming from one or more batteries, irrespective of the distance between the component and the battery. This SPN is also used when ECM's are interconnected in a series configuration, where the source of power is coming directly or indirectly from the same battery/batteries | Battery Voltage (Combined with SPN 158) | Volts |
| 173 | Engine Exhaust Gas Temperature | 65270 | Temperature of combustion byproducts leaving the engine. See SPNs 2433 and 2434 for engines with more than one exhaust gas temperature measurement | Exhaust Gas Temp | °C, °F, K |
| 174 | Engine Fuel Temperature 1 | 65262 | Temperature of fuel (or gas) passing through the first fuel control system. See SPN 3468 for the second control system | Engine Fuel Temp | °C, °F, K |
| 175 | Engine Oil Temperature 1 | 65262 | Temperature of the engine lubricant | Engine Oil Temp | °C, °F, K |
| 176 | Engine Turbocharger Oil Temperature | 65262 | Temperature of the turbocharger lubricant | Turbocharger Oil Temp | °C, °F, K |
| 177 | Transmission Oil Temperature 1 | 65272 | First instance of transmission lubricant temperature | Transmission Oil Temp | °C, °F, K |
| 183 | Engine Fuel Rate | 65266 | Amount of fuel consumed by engine per unit of time | Engine Fuel Rate | liters per hour, ounces per hour, quarts per hour, gallons per hour |
| 184 | Engine Instantaneous Fuel Economy | 65266 | Current fuel economy at current vehicle velocity | Instant Fuel Economy | kilometers per liter, miles per gallon |
| 185 | Engine Average Fuel Economy | 65266 | Average of instantaneous fuel economy for that segment of vehicle operation of interest | Average Fuel Economy | kilometers per liter, miles per gallon |
| 186 | Power Takeoff Speed | 65264 | Rotational velocity of device used to transmit engine power to auxiliary equipment. | Power Takeoff Speed | RPM |
| 190 | Engine Speed | 61444 | Actual engine speed which is calculated over a minimum crankshaft angle of 720 degrees divided by the number of cylinders. | Engine Speed | RPM |
| 245 | Total Vehicle Distance | 65248 | Accumulated distance traveled by vehicle during its operation. | Total Vehicle Distance | kilometers, miles, nautical miles |
| 246 | Total Vehicle Hours | 65255 | Accumulated time of operation of vehicle. | Total Vehicle Hours | Hours |
| 247 | Engine Total Hours of Operation | 65253 | Accumulated time of operation of engine. | Total Engine Hours | Hours |
| 248 | Total Power Takeoff Hours | 65255 | Accumulated time of operation of power takeoff device. | Total Power Takeoff Hrs | Hours |
| 917 | High Resolution Total Vehicle Distance | 65217 | Accumulated distance traveled by the vehicle during its operation | Hi-Res Total Distance | kilometers, miles, nautical miles |
| 1349 | Engine Injector Metering Rail 2 Pressure | 65243 | The gage pressure of fuel in the metering rail #2 as delivered from the supply pump to the injector metering intake. See Figure SPN16_A for fuel system related parameters. Although the figure does not show rail #2 it does show the relationship of rail pressure to other signals. | Engine Injector 2 Press | PSI, megapascal, kilopascal, bar |
| 1638 | Hydraulic Temperature | 65128 | Temperature of hydraulic fluid. | Hydraulic Temperature | °C, °F, K |
| 1761 | Aftertreatment 1 Diesel Exhaust Fluid Tank Level | 65110 | Ratio of volume of diesel exhaust fluid to the total volume of diesel exhaust fluid storage container | DEF Tank Level | 0-100%, Engineering Units |
| 2602 | Hydraulic Oil Level | 65128 | This parameter indicates the level of the hydraulic fluid in tank as a ratio of current volume to total tank volume. This parameter is intended for reporting the hydraulic fluid level in the system tank or reservoir. This hydraulic fluid is for the entire hydraulics system of a piece of equipment. | Hydraulic Oil Level | 0-100%, Engineering Units |
| 3031 | Aftertreatment 1 Diesel Exhaust Fluid Tank Temperature | 65110 | Temperature of the diesel exhaust fluid in the storage tank | DEF Tank Temperature | °C, °F, K |
| 3515 | Aftertreatment 1 Diesel Exhaust Fluid Temperature 2 | 64923 | Temperature of the diesel exhaust fluid at the device measuring diesel exhaust fluid quality | DEF Temperature 2 | °С, °F, К |
| 3516 | Aftertreatment 1 Diesel Exhaust Fluid Concentration | 64923 | A measure of the concentration of urea in water. Zero percent means that the tank contains no urea. A 32.5% value indicates that the diesel exhaust fluid is of the proper concentration. The 32.5% value indicates that the concentration is highest quality. | DEF Concentration | 0-100%, Engineering Units |
| 3517 | Aftertreatment 1 Diesel Exhaust Fluid Tank Level 2 | 65110 | The measure of the diesel exhaust fluid level in the diesel exhaust fluid tank | DEF Tank Level 2 | millimeter, centimeter, meter, inch, feet, yard |
| 3521 | Aftertreatment 1 Diesel Exhaust Fluid Property | 64923 | This parameter indicates the property of the fluid compound in the tank. A value of 0011 indicates uncontaminated Diesel Exhaust Fluid. | DEF Propery | numberic code |
| | | | | | |

SPECIFICATIONS



Specifications subject to change. See MadgeTech's Terms and Conditions at madgetech.com

| GENERAL | | | |
|----------------------------|--|--|--|
| | | | |
| Dimensions | 6.65 in x 4.40 in x 1.41 in (168.9 mm x 111.8 mm x 35.8 mm) <i>Data logger only</i> | | |
| Touch Screen Dimensions | 5 inches | | |
| Number of Channels | 24: 23 can be configured for CAN data. Channel 1 cannot be CAN, and channels 2-8 can be used for direct measurements. If 1-8 are configured for direct measurements, 9-24 can still be CAN channels. | | |
| Weight | 1.3 l | bs (20.8 oz) | |
| IP Rating | IP20 |) | |
| Start Modes | Imn | nediate Start & Delay Start | |
| Memory | | 1.8 GB, with session size of 1,000,000 or 5,000,000 readings | |
| Battery Type | Rec | hargeable 3.7 V Lithium Ion Battery Pack | |
| Battery Life | Continuous on-screen sampling: 7–9 hours depending on display setting and reading rate Stand-by mode: 100 hours | | |
| Data Format | Exported .csv file format, .mtb or both | | |
| Time Accuracy | ±1 minute/month | | |
| Operating Environment | 0 °C to +50 °C (32 °F to +122 °F) 0 %RH to 95 %RH non-condensing | | |
| Enclosure Material | Polycarbonate, TPE Protective Boot | | |
| Calibration | Factory calibration is recommended annually | | |
| Alarm Output | 50 mA @ 100V, Solid State Relay Output | | |
| SAE | J1939 (55 available SPN's) | | |
| Range | SPN Dependent | | |
| Resolution | SPN Dependent | | |
| Message Priority | SPN | Dependent | |
| 0 - 24 mA | | | |
| Range | | -5 mA to 50 mA | |
| Resolution | | 0.0001 mA | |
| Accuracy | | ±0.024 mA (0 to 24 mA) | |
| Input Impedance | | 30 Ω | |

| 0 - 100 mVRange-100 mV to 2450 mVResolution0.001 mVAccuracy±0.1 mV (0 to 100 mV)Input Impedance1 GQMaximum Voltage3.0 V0 - 10 V | n.com. | | | | |
|--|-------------------|---|--|--|--|
| No Proceeding Resolution 0.001 mV Accuracy ±0.1 mV (0 to 100 mV) Input Impedance 1 GΩ Maximum Voltage 3.0 V 0 - 10 V -0.5 V to 12.0 V Resolution 0.001 V Accuracy ± 0.01 V (-0.5 V to 12.0 V) Input Impedance 1 GΩ Maximum Voltage 25 V FREQUENCY / PUL - Maximum Voltage 25 V FREQUENCY / PUL - Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-UO (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-U (2252) Range Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe | 0 - 100 mV | | | | |
| Accuracy ±0.1 mV (0 to 100 mV) Input Impedance 1 GΩ Maximum Voltage 3.0 V 0 - 10 V Range -0.5 V to 12.0 V Resolution 0.001 V Accuracy ± 0.01 V (-0.5 V to 12.0 V) Input Impedance 1 GΩ Maximum Voltage 25 V FREQUENCY / PUL> Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT- VO (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-T (2252) Range Range -25 °C to +150 °C (Probe Dependent) ±0.034 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) (29,380 Ω to 41.9 Ω) Range -25 °C to +150 °C (Pro | Range | -100 mV to 2450 mV | | | |
| Input Impedance I GΩ Maximum Voltage 3.0 V O - 10 V O Range -0.5 V to 12.0 V Resolution 0.001 V Accuracy ± 0.01 V (-0.5 V to 12.0 V) Input Impedance I GΩ Maximum Voltage 25 V FREQUENCY / PUL V Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Signal 0 V to 12 V Input Signal 0.00 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Range -200 °C to +450 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) (18.5 Ω to 390.5 Ω) Range -25 °C to +150 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.01 °C (-200 °C to +400 °C) (Probe Dependent) (29,380 Ω to 41.9 Ω) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) (102,900 Ω to 238 Ω) | Resolution | 0.001 mV | | | |
| Maximum Voltage 3.0 V O - 10 V Pange -0.5 V to 12.0 V Range -0.5 V to 12.0 V Resolution 0.001 V Accuracy ± 0.01 V (-0.5 V to 12.0 V) Input Impedance 1 GΩ Maximum Voltage 25 V FREQUENCY / PUL PUL Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-1 (2252) Range Range -25 °C to +150 °C (Probe Dependent) ±0.034 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) (29,380 Ω to 41.9 Ω) ±0.50% FSR (Probe Dependent) (29,380 Ω to 238 Ω) ±0.50% Ω to 238 Ω) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) <td>Accuracy</td> <td>±0.1 mV (0 to 100 mV)</td> | Accuracy | ±0.1 mV (0 to 100 mV) | | | |
| Number of High International Stress 0 - 10 V Range -0.5 V to 12.0 V Resolution 0.001 V Accuracy ± 0.01 V (-0.5 V to 12.0 V) Input Impedance 1 GΩ Maximum Voltage 25 V FREQUENCY / PUL> Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-1 (2252) Range Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NT-2 (10K) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C | Input Impedance | 1 GΩ | | | |
| Range -0.5 V to 12.0 V Resolution 0.001 V Accuracy ± 0.01 V (-0.5 V to 12.0 V) Input Impedance 1 GΩ Maximum Voltage 25 V FREQUENCY / PULS Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-UO (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-I (2252) Range Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) ±0.39 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) (29,380 Ω to 41.9 Ω) 25° °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) 25° °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) 25° °C to +150 °C (Probe Dependent) | Maximum Voltage | 3.0 V | | | |
| Resolution 0.001 V Accuracy ± 0.01 V (-0.5 V to 12.0 V) Input Impedance 1 GΩ Maximum Voltage 25 V FREQUENCY / PULSE Maximum Count Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NTC-1 (2252) Range Range -25 °C to +150 °C (Probe Dependent) ±0.03% Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NTC-2 (10K) TEMPERATURE NTC-2 (10K) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) -25 °C to 238 Ω) | 0 - 10 V | | | | |
| Accuracy ± 0.01 V (-0.5 V to 12.0 V) Input Impedance 1 GΩ Maximum Voltage 25 V FREQUENCY / PUL Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-1 (2252) Range Range -25 °C to +150 °C (Probe Dependent) ±0.30% Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) Range -25 °C to +150 °C (Probe Depende | Range | -0.5 V to 12.0 V | | | |
| Input Impedance 1 GΩ Maximum Voltage 25 V FREQUENCY / PUL> Maximum Count 4,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT- 100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-1 (2252) Range -25 °C to +150 °C (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution Range -25 °C to +150 °C (Probe Dependent) (25 °C to +150 °C (Probe Dependent) Range -25 °C to +150 °C (Probe Dependent) (25 °C to +150 °C (Probe Dependent) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C (25 °C to +150 °C (Probe Dependent) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω t | Resolution | 0.001 V | | | |
| Maximum Voltage 25 V FREQUENCY / PULSE Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-UO (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-T (2252) Range Range -25 °C to +150 °C (Probe Dependent) ±0.034 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NT-2 (10K) TEMPERATURE NT-2 (10K) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C | Accuracy | ± 0.01 V (-0.5 V to 12.0 V) | | | |
| FREQUENCY / PULSE Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NTC-1 (2252) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) (29,380 Ω to 41.9 Ω) Extension Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Extension Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) (102,900 Ω to 238 Ω) Extension Resolution 0.01 °C | Input Impedance | 1 GΩ | | | |
| Maximum Count 4,000,000,000 Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NT-1 (2252) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C 4ccuracy ±0.50% FSR (Probe Dependent) 29,380 Ω to 41.9 Ω) Resolution 0.01 °C 25 °C to +150 °C (Probe Dependent) 29,380 Ω to 41.9 Ω) 25 °C to +150 °C (Probe Dependent) 29,380 Ω to 41.9 Ω) Resolution 0.01 °C 40.50% FSR (Probe Dependent) 20,290 Ω to 238 Ω) 25 °C to +150 °C (Probe Dependent) 20,290 Ω to 238 Ω) 25 °C to +150 °C (Probe Dependent) 20,290 Ω to 238 Ω) 25 °C to +150 °C (Probe Dependent) 20,290 Ω to 238 Ω) 25 °C to +150 °C (Probe Dependent) 20,290 Ω to 238 Ω) 25 °C to +150 °C (Probe Dependent) 20,290 Ω to 238 Ω) 25 °C to +150 °C (Probe Dependent) 20,290 Ω to 238 Ω) 25 °C to +150 °C (Probe Dep | Maximum Voltage | 25 V | | | |
| Maximum Frequency 25 KHz Input Signal 0 V to 12 V Input Impedance 58 KΩ TEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NTC-1 (2252) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NTC-2 (10K) TEMPERATURE NTC-2 (10K) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C | FREQUENCY / PUL | SE | | | |
| Input Signal0 V to 12 VInput Impedance58 KΩTEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE)Range-200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω)Resolution0.01 °CAccuracy±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω)TEMPERATURE NTC-1 (2252)Range-25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω)Resolution0.01 °CAccuracy±0.50% FSR (Probe Dependent) (29,380 Ω to 41.9 Ω)Resolution0.01 °CAccuracy±0.50% FSR (Probe Dependent) (102,900 Ω to 238 Ω)Resolution0.01 °C | Maximum Count | 4,000,000,000 | | | |
| Input Impedance 58 KΩ TEMPERATURE PT-JOO (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NTC-1 (2252) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NTC-2 (10K) TEMPERATURE NTC-2 (10K) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C | Maximum Frequency | 25 KHz | | | |
| TEMPERATURE PT-100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) Range -200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NTC-1 (2252) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NTC-2 (10K) TEMPERATURE NTC-2 (10K) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C | Input Signal | 0 V to 12 V | | | |
| Range-200 °C to +850 °C (Probe Dependent) (18.5 Ω to 390.5 Ω)Resolution0.01 °CAccuracy±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω)TEMPERATURE NTC-1 (2252)Range-25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω)Resolution0.01 °CAccuracy±0.50% FSR (Probe Dependent)TEMPERATURE NTC-2 (10K)Range-25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω)Resolution0.01 °C | Input Impedance | 58 ΚΩ | | | |
| (18.5 Ω to 390.5 Ω) Resolution 0.01 °C Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NTC-1 (2252) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NTC-2 (10K) Range -25 °C to +150 °C (Probe Dependent) 0.25 °C to +150 °C (Probe Dependent) 0.20 °C to +350 °C (Probe Dependent) 0.01 °C | TEMPERATURE PT | -100 (2, 3, 4-WIRE RTD) (0.00385 CURVE) | | | |
| Accuracy ±0.1 °C (-200 °C to +400 °C) (Probe Dependent) ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NTC-1 (2252) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NTC-2 (10K) -25 °C to +150 °C (Probe Dependent) Range -0.01 °C | Range | | | | |
| ±0.034 Ω (18.5 Ω to 247.1 Ω) TEMPERATURE NTC-1 (2252) Range -25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω) Resolution 0.01 °C Accuracy ±0.50% FSR (Probe Dependent) TEMPERATURE NTC-2 (10K) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C | Resolution | 0.01 °C | | | |
| Range-25 °C to +150 °C (Probe Dependent) (29,380 Ω to 41.9 Ω)Resolution0.01 °CAccuracy±0.50% FSR (Probe Dependent)TEMPERATURE NTC-2 (10K)Range-25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω)Resolution0.01 °C | Accuracy | | | | |
| (29,380 Ω to 41.9 Ω)Resolution0.01 °CAccuracy±0.50% FSR (Probe Dependent)TEMPERATURE NTC-2 (10K)Range-25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω)Resolution0.01 °C | TEMPERATURE NT | C-1 (2252) | | | |
| Accuracy±0.50% FSR (Probe Dependent)TEMPERATURE NTC-2 (10K)Range-25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω)Resolution0.01 °C | Range | | | | |
| TEMPERATURE NTC-2 (10K) Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C | Resolution | 0.01 °C | | | |
| Range -25 °C to +150 °C (Probe Dependent) (102,900 Ω to 238 Ω) Resolution 0.01 °C | Accuracy | ±0.50% FSR (Probe Dependent) | | | |
| (102,900 Ω to 238 Ω) Resolution 0.01 °C | TEMPERATURE NT | C-2 (10K) | | | |
| | Range | | | | |
| Accuracy ±0.50% FSR (Probe Dependent) | Resolution | 0.01 °C | | | |
| | Accuracy | ±0.50% FSR (Probe Dependent) | | | |

RTD Note (All RTD Configurations)

Temperature Specifications based on ideal 100 Ω PT RTD Complaint with IEC 751(1983) and ITS-90. Accuracy based on 4-wire configuration.

BATTERY WARNING: Battery may explode or catch fire if mistreated. Do not disassemble or dispose of in fire. Do not charge except specified with charging condition. Do not heat above 212 °F, or short circuit. Do not crush or modify.

SPECIFICATIONS



Sensor Types & Measurement Ranges

Each of the 8 input channels can be individually configured for the following types and sensor ranges.

| PARAMETER | INPUT TYPE | RANGE |
|-------------------------------|-------------------------|---------------------------|
| Current | Current input | -5 mA to 50 mA |
| Frequency (port 1 only) | Frequency input | 0 to 25,000 Hz |
| Pulse / Counter (port 1 only) | Pulse input | 0 to 4,000,000,000 Pulses |
| Voltage | Volt input | -0.5 V to 12.0 V |
| Voltage | Millivolt input | -100 mV to 2450 mV |
| Temperature | Thermistor NTC-1 (2252) | -25 °C to +150 °C |
| Temperature | Thermistor NTC-2 (10K) | -25 °C to +150 °C |
| Temperature | PT100 RTD 2-Wire | -200 °C to +850 °C |
| Temperature | PT100 RTD 3-Wire | -200 °C to +850 °C |
| Temperature | PT100 RTD 4-Wire | -200 °C to +850 °C |
| Temperature | Thermocouple J | -210 °C to +760 °C |
| Temperature | Thermocouple K | -270 °C to +1370 °C |
| Temperature | Thermocouple T | -270 °C to +400 °C |
| Temperature | Thermocouple E | -270 °C to +980 °C |
| Temperature | Thermocouple R | -50 °C to +1760 °C |
| Temperature | Thermocouple S | -50 °C to +1760 °C |
| Temperature | Thermocouple N | -270 °C to +1300 °C |
| Temperature | Thermocouple B | +50 °C to +1820 °C |

Measurement Accuracy

- At room temperature (25 °C ±10 °C) after 60 minute warm-up period.
- Temperature calibrated accuracy is thermocouple dependent.
- Accuracy does not include Cold Junction Compensation (CJC). CJC error: ± 1.5 °C

| THERMOCOUPLE TYPE | RANGE | RESOLUTION | ACCURACY |
|----------------------|---------------------|------------|----------|
| J | -200 °C to +760 °C | 0.1 °C | ±0.5 °C |
| К | -270 °C to +1370 °C | 0.1 °C | ±0.5 °C |
| Т | -270 °C to +400 °C | 0.1 °C | ±0.5 °C |
| E | -270 °C to +980 °C | 0.1 °C | ±0.5 °C |
| R | -50 °C to +1760 °C | 0.5 °C | ±2.0 °C |
| S | -50 °C to +1760 °C | 0.5 °C | ±2.0 °C |
| Ν | -270 °C to +1300 °C | 0.1 °C | ±0.5 °C |
| В | 50 °C to 1820 °C | 0.5 °C | ±2.0 °C |

SPECIFICATIONS



Reading Rate Information

All channels will use the same reading rate.

Reading rates will be capped at 4 Hz when a temperature channel is selected.

- 4 KHz (Supports single channel of voltage or current measurement only)
- 2 KHz (Supports single channel of voltage or current measurement only)
- 1 KHz (Supports single channel of voltage or current measurement only)
- 500 Hz (Supports single channel of voltage or current measurement only)
- 250 Hz (Supports single channel of voltage or current measurement only)
- 100 Hz (Supports single channel of voltage or current measurement only)
- 50 Hz (Supports single channel of voltage or current measurement only)
- 25 Hz (Supports single channel of voltage or current measurement only)
- 10 Hz (Supports multiple channels of voltage or current measurement only)
- 4 Hz
- 1 Second
- 2 Seconds
- 5 Seconds
- 10 Seconds
- 15 Seconds
- 30 Seconds
- 1 Minute
- 2 Minutes
- 5 Minutes
- 10 Minutes
- 15 Minutes
- 30 Minutes
- 1 Hour
- 2 Hours
- 5 Hours
- 10 Hours
- 12 Hours
- 24 Hours

INDEX



| Product Overview | 2 |
|---|---|
| Device Overview | 2 |
| External Features | 2 |
| Device Orientation | 3 |
| Device Ports | 3 |
| Powering, Charging and Downloading Data | 1 |
| CAN to Vehicle Connection | 1 |

| User interface5 |
|----------------------------------|
| Top Menu Bar5 |
| Home Screen5 |
| First Time Use6 |
| Channel Configuration7 |
| Channel Setup7 |
| Measurement Setup8 |
| Measurement Units8 |
| Engineering Units9 |
| Setting Up Engineering Units10 |
| Keyboard Function11 |
| Alarms11 |
| Factory Calibration12 |
| Channel Configuration Overview12 |
| Save Configuration Settings13 |
| Wiring Diagram13 |
| Load Configuration Settings13 |

| Logging Data | 14 |
|--|----|
| Start Logging | 14 |
| Delayed Start | 14 |
| Automatic Stop | 15 |
| Reading Rate | 15 |
| Review Session Details and Start Logging | 16 |
| Device Memory Warning | 16 |
| Stop Logging | 16 |
| | |

| Viewing Data | 17 |
|---|----|
| Real-Time Data | 17 |
| Current Session — Graph View | 17 |
| Current Session — Tabular View | |
| Managing Data | 19 |
| Data Storage | 19 |
| Storage Space | 19 |
| Saved Session Options | 20 |
| Copy Stored Sessions | 20 |
| View Data Sessions | 21 |
| View/Edit Note and Session Name | 21 |
| Delete Stored Session | 22 |
| Delete All | 22 |
| No Stored Sessions | 23 |
| FFT User Capabilities | 23 |
| Device Settings | 24 |
| System | 24 |
| File Format | 24 |
| Date & Time | 24 |
| Display | 25 |
| Alarms | 25 |
| Network | 25 |
| Help | 26 |
| Power | 26 |
| SAE Parameters | 27 |
| Specifications | 29 |
| Sensor Types & Measurement Ranges | |
| Measurement Accuracy | |
| Reading Rate Information | 31 |
| Need Help? | 30 |
| Device Maintenance | |
| Product Support & Troubleshooting Contact | |

NEED HELP?





Device Maintenance:

- To provide optimum performance and accuracy, MadgeTech recommends an annual factory calibration for the Titan S8-CAN.
- To send a device back to MadgeTech for calibration or repair, please visit the MadgeTech website at **madgetech.com**.



Product Support & Troubleshooting:

- Visit our Knowledge Base online at madgetech.com.
- Contact our friendly Customer Support Team at (603) 456-2011 or support@madgetech.com.



6 Warner Road, Warner, NH 03278 (603) 456-2011 info@madgetech.com madgetech.com

DOC-1411036-00 | REV 1 2020.08.25